

---

---

## Rubber process fumes components — Quantitative test methods

*Constituant des fumées de procédé du caoutchouc — Méthodes d'essai  
quantitatives*

STANDARDSISO.COM : Click to view the full PDF of ISO/TS 21522:2017



STANDARDSISO.COM : Click to view the full PDF of ISO/TS 21522:2017



**COPYRIGHT PROTECTED DOCUMENT**

© ISO 2017, Published in Switzerland

All rights reserved. Unless otherwise specified, no part of this publication may be reproduced or utilized otherwise in any form or by any means, electronic or mechanical, including photocopying, or posting on the internet or an intranet, without prior written permission. Permission can be requested from either ISO at the address below or ISO's member body in the country of the requester.

ISO copyright office  
Ch. de Blandonnet 8 • CP 401  
CH-1214 Vernier, Geneva, Switzerland  
Tel. +41 22 749 01 11  
Fax +41 22 749 09 47  
copyright@iso.org  
www.iso.org

# Contents

	Page
Foreword.....	iv
Introduction.....	v
1 Scope.....	1
2 Normative references.....	1
3 Terms and definitions.....	1
4 General.....	1
5 Test methods for the quantification of selected hazardous substances in rubber fumes.....	2
Bibliography.....	4

STANDARDSISO.COM : Click to view the full PDF of ISO/TS 21522:2017

## Foreword

ISO (the International Organization for Standardization) is a worldwide federation of national standards bodies (ISO member bodies). The work of preparing International Standards is normally carried out through ISO technical committees. Each member body interested in a subject for which a technical committee has been established has the right to be represented on that committee. International organizations, governmental and non-governmental, in liaison with ISO, also take part in the work. ISO collaborates closely with the International Electrotechnical Commission (IEC) on all matters of electrotechnical standardization.

The procedures used to develop this document and those intended for its further maintenance are described in the ISO/IEC Directives, Part 1. In particular the different approval criteria needed for the different types of ISO documents should be noted. This document was drafted in accordance with the editorial rules of the ISO/IEC Directives, Part 2 (see [www.iso.org/directives](http://www.iso.org/directives)).

Attention is drawn to the possibility that some of the elements of this document may be the subject of patent rights. ISO shall not be held responsible for identifying any or all such patent rights. Details of any patent rights identified during the development of the document will be in the Introduction and/or on the ISO list of patent declarations received (see [www.iso.org/patents](http://www.iso.org/patents)).

Any trade name used in this document is information given for the convenience of users and does not constitute an endorsement.

For an explanation on the voluntary nature of standards, the meaning of ISO specific terms and expressions related to conformity assessment, as well as information about ISO's adherence to the World Trade Organization (WTO) principles in the Technical Barriers to Trade (TBT) see the following URL: [www.iso.org/iso/foreword.html](http://www.iso.org/iso/foreword.html).

This document was prepared by Technical Committee ISO/TC 45, *Rubber and rubber products*.

## Introduction

Rubber process fumes are emitted during the rubber manufacturing process. These rubber fumes have been the topic of many studies, for example ISO/TR 21275. ISO/TR 21275 gives a bibliographic study of 95 publications describing the compositions of fumes that could be emitted during the processing of rubber. The study also confirms that rubber fumes are a complex and variable mix of chemicals which have a wide range of possible sources and origins, including chemicals generated from the chemical reactions occurring in the rubber compounds during processing and curing. Some of these chemical substances can be hazardous. ISO/TR 21275 demonstrates the need for standardization of test methods to identify and quantify the hazardous chemicals to which the operators of the factories producing rubber articles may be exposed, allowing the identification and mitigation of potential health risks.

ISO/TS 17796 specifies a qualitative method (by thermodesorption – gas chromatography – mass spectrometry) for the identification of volatile components in rubber fumes, and is applicable to the screening of emissions from the processing of rubber compounds in the ambient workplace and storage environment. The document is an efficient tool for identifying hazardous substances contained in rubber process fumes.

If a hazardous component is identified in rubber fumes, then the most efficient way to eliminate risk for the operators is to substitute the substance or the process which generates the hazardous component.

In cases where there is no substitute, then the risk can be reduced by controlling the exposure of the operators to the hazardous component. Test methods are therefore necessary to quantify each hazardous substance.

[Table 1](#) provides an overview of the diverse range of rubber components made from general manufacturing processes and dipped latex technology. The list of components is by no means exhaustive but helps to highlight the diverse areas and products in which rubber is used.

**Table 1 — Range of rubber components**

Types of products	Examples
Tyres	Passenger cars, trucks, racing vehicles, cycles, off-road tyres, inner tubes, curing bladders
Conveyor /transmission belting	Steel cord conveyor belting, repair material for conveyor belting, scrapers, mining conveyors, V-belts, flat belts, synchronous belts
Industrial hoses	Water hoses, high pressure hoses, welding hoses, hydraulic hoses, spiral hoses, offshore hoses, oil hoses, chemical hoses
Automotive products	Coolant hoses, fuel hoses, seals and gaskets, anti-vibration mounts, hydraulic hoses, fuel injectors, timing belts, window and door channelling, transmission and engine components, wiper blades, exhaust hangers
General mouldings/sheeting	Moulded seals and gaskets, anti-vibration products, floor coverings, sheeting, tube rings, roofing layers, subsoil water sheeting, roller coverings, protection linings, moulded micro-cellular products, composite profiles, rubberized fabric, micro-cellular rubbers/profiles, wire and cable jackets and insulations, glass sealants, pump impellers, roof membranes, pond liners, rail mounts, bridge bearings, military vehicle track pads
Medical/pharmaceutical products	Surgical gloves, medical tubing, MDI valve gaskets, catheters, dialysis products, surgical implants, prostheses, contraceptives, soothers, baby feeding teats and breast caps, blood transfusion tubing and valves, medical and antistatic sheeting and membranes, masks and respirators
Clothing	Boots/footwear, protective suits, household gloves, industrial gloves, footwear/ boot heels and soling, cellular rubber soles, wet suits, diving suits, coated fabrics, sports footwear and clothing

**Table 1** (continued)

Types of products	Examples
Food contact products	Food transportation (e.g. conveyer belts, hoses and tubing), food handling (gloves), pipe and machinery components (seals, gaskets, flexible connectors and diaphragm/butterfly valves), pumping system components (e.g. progressive cavity pumps stators, diaphragm pumps), plate heat exchanger gaskets, seals/gaskets for cans, bottles and closures
Potable water products	Pipe seals and gaskets, hoses, linings of pumps and valves, tap washers, membranes in pipes and filters, coatings on process plant, tank linings
Miscellaneous products	Adhesives, rubberised asphalt, high vacuum and radiation components, carpet backing, latex thread, sealants and caulking, toys

The rubber material used to make any particular product is not a single entity but is a complex compounded material referred to as a “compound” or “formulation”, which can contain a large number of essential chemical ingredients. These ingredients include the base rubber polymer(s), reinforcing and non-reinforcing particulate fillers, process oils, vulcanizing agents, protective agents, process aids, etc. (all of which are available in many types and grades from many suppliers and can be included at different levels). The company or individual that designs a rubber formulation for a specific product has a vast number of ingredients to choose from and many formulations are therefore possible for a specific rubber product.

The processing route by which the majority of rubber components are manufactured includes mixing the ingredients together in a controlled manner to produce a rubber “compound” or “mix”, shaping of the mixed compound to give the desired shape or form, then “vulcanizing” (also known as “cross-linking” and “curing”) the compound to convert it to a condition where it has permanent properties and shape.

STANDARDSISO.COM : Click to view the full PDF of ISO/TS 21522:2017

# Rubber process fumes components — Quantitative test methods

## 1 Scope

This document gives guidance on the quantitative test methods to measure chemical components in fumes emitted during the manufacturing process of rubbers (including storage) and considered hazardous.

NOTE Quantification of the level of exposure allows selection of the correct type of protection for the operators and, after implementation of the protection, verification that the risk was eliminated by implementation of the selected protection.

## 2 Normative references

There are no normative references in this document.

## 3 Terms and definitions

For the purposes of this document, the following terms and definitions apply.

ISO and IEC maintain terminological databases for use in standardization at the following addresses:

- IEC Electropedia: available at <http://www.electropedia.org/>
- ISO Online browsing platform: available at <http://www.iso.org/obp>

### 3.1

#### rubber process fumes

variety of volatile substances emitted from rubber compounds into a workplace atmosphere as a result of industrial processing, the composition of which depends on the formulation of the compounds concerned, the process technology in use and the associated process parameters

## 4 General

The list of the hazardous substances which can exist in rubber fumes is established by using the results obtained by ISO/TS 17796 and also by the work done by rubber industries and others, regarding chemical reactions appearing during the process of the rubber. ISO/TR 21275 gives many examples.

NOTE 1 The study given in ISO/TR 21275 compiles and reviews published data with respect to rubber fumes emissions in the workplace. ISO/TS 17796 gives a method for the identification of volatile components in rubber fumes, and is applicable for a screening of emissions from the processing of rubber compounds in the ambient workplace and storage environment.

Many producers of rubber articles use their own techniques to determine the amount of hazardous substances in rubber fumes. Generally, those methods are based on individual internal development and/or on studies published by external laboratories. A standardized technique (including sampling) for the determination of the amount of hazardous substances in various rubber fumes is becoming increasingly important and is the logical complement to ISO/TS 17796.

The process is described in three steps:

- a) identification of the hazardous substances which may be present in rubber process fumes;

- b) identification of the test methods available for each of the hazardous substances; and
- c) selection of the most suitable test method to quantify the identified substances.

[Clause 5](#) provides an overview of the test methods for the quantification of selected hazardous substances in rubber fumes resulting from this process. For more information, see Reference [12].

NOTE 2 Application of this process will not only allow rubber companies to globally improve protection of workshop operators, but will also help small companies which do not have the resources to perform a selection of test methods. It will also simplify the work of policy makers.

## 5 Test methods for the quantification of selected hazardous substances in rubber fumes

[Table 2](#) gives the list of hazardous substances that can be observed in rubber fumes and test methods to quantify their presence.

**Table 2 — List of hazardous substances in rubber fumes and their test methods**

Name of substance	Identified/evaluated test methods
Benzene	Recommended method: ISO 9487:1991 For information, other methods: <ul style="list-style-type: none"> <li>— BS EN 14662-3:2005</li> <li>— NIOSH 1501, Issue 3</li> <li>— IS 5182 (Part 11):2006</li> <li>— NIOSH 2549, Issue 1</li> <li>— NIOSH 3700, Issue 2</li> <li>— ISO 16000-29:2014</li> </ul>
Acrylonitrile	Recommended method: BGIA 6041
Formaldehyde	Recommended method: ISO 16000-3 For information, other methods: <ul style="list-style-type: none"> <li>— 3M 3721 Formaldehyde monitors</li> <li>— ASTM D5197 — 09e1</li> <li>— MTA/MA-018/A89</li> <li>— MDHS 78</li> <li>— NIOSH 2016</li> <li>— NIOSH 2541</li> <li>— NIOSH 3500</li> <li>— OSHA 52</li> </ul>

Table 2 (continued)

Name of substance	Identified/evaluated test methods
o-Toluidine	Recommended methods: no international standards are available, but only methods from national safety and health organizations (OSHA, NIOSH and MDHS): <ul style="list-style-type: none"> <li>— BGI 505-49E</li> <li>— OSHA 73</li> <li>— NIOSH 2017</li> <li>— PN-81/Z-04031/03</li> <li>— WHOMDHS 75</li> <li>— MDHS 75</li> <li>— MDHS 96</li> <li>— ISO 16200-1</li> </ul>
2-Chloro-1,3-butadiene (CHLOROPRENE)	Recommended methods: NIOSH 1002 or OSHA 112
1,3 Butadiene	Recommended methods: NIOSH 1024 or OSHA 56 Other available method: Metropol 177
Isoprene	Recommended method: OSHA 7
Dibenzo[a,h]anthracene	Recommended methods: NIOSH 5506 and Metropol 332
Chrysene	For information, other methods:
Benzo[k]fluoranthene	— NIOSH 5515
Benzo[j]fluoranthene	— MTA/MA039/A00
Benzo[e]pyrene	— OSHA 58
Benzo[b]fluoranthene	— NF-X-43-294
Benzo[a]pyrene	— BGIA 6272
Benzo[a]anthracene	— PN-Z-04240-4:1999
	— NF-X-43-329
	— ISO 12884:2000
	— ISO 11338-1 and ISO 11338-1
N-nitrosodiethanolamine (NDELA)	Recommended method: BGI 505.36 (previously named ZH 1/120.36)
	For information, other method: TRGS 552
High volatile nitrosamines	Recommended method: DGUV 213-523
	For information, other methods:
	<ul style="list-style-type: none"> <li>— TRGS 552</li> <li>— BGI 505-23 (previously named ZH 1/12023)</li> </ul>
Low volatile nitrosamines	Recommended method: BGI 505-62 (previously named ZH 1/120.62)
	For information, other method: TRGS 552

## Bibliography

- [1] ISO/TR 21275, *Rubber — Comprehensive review of the composition and nature of process fumes in the rubber industry*
- [2] ISO/TS 17796, *Rubber — Trapping and identification of volatile components of rubber fumes with active sampling on a poly(2,6-diphenylphenylene oxide) type sorbent, using thermodesorption and gas chromatographic method with mass spectrometric detection*
- [3] ISO 9487:1991, *Workplace air — Determination of vaporous aromatic hydrocarbons — Charcoal tube/solvent desorption/gas chromatographic method*
- [4] ISO 12884:2000, *Ambient air — Determination of total (gas and particle-phase) polycyclic aromatic hydrocarbons — Collection on sorbent-backed filters with gas chromatographic/mass spectrometric analyses*
- [5] ISO 11338-1, *Stationary source emissions — Determination of gas and particle-phase polycyclic aromatic hydrocarbons — Part 1: Sampling*
- [6] ISO 11338-2, *Stationary source emissions — Determination of gas and particle-phase polycyclic aromatic hydrocarbons — Part 2: Sample preparation, clean-up and determination*
- [7] ISO 16000-29:2014, *Indoor air — Part 29: Test methods for VOC detectors*
- [8] ISO 16000-3, *Indoor air — Part 3: Determination of formaldehyde and other carbonyl compounds in indoor air and test chamber air — Active sampling method*
- [9] ISO 16200-1, *Workplace air quality — Sampling and analysis of volatile organic compounds by solvent desorption/gas chromatography — Part 1: Pumped sampling method*
- [10] IS 5182 (Part 11):2006, *Methods for measurement of air pollution, Part 11: Benzene, Toluene and Xylene (BTX)*
- [11] BS EN 14662-3:2005, *Ambient air quality. Standard method for measurement of benzene concentrations. Automated pumped sampling with in situ gas chromatography*
- [12] European Tyre and Rubber Manufacturers' Association, available at <http://www.etrma.org>
- [13] ASTM D5197 — 09e1, *Standard Test Method for Determination of Formaldehyde and Other Carbonyl Compounds in Air (Active Sampler Methodology)*
- [14] NF-X-43-294, *Air des lieux de travail - Échantillonnage et analyse des hydrocarbures aromatiques polycycliques [Working place air — Sampling and measurement of polycyclic aromatic hydrocarbon]*
- [15] NF-X-43-329, *Émissions de sources fixes - Prélèvement et mesurage d'hydrocarbures aromatiques polycycliques à l'émission [Emission from fixed sources - Sampling and measurement of polycyclic aromatic hydrocarbons at the level of emission]*
- [16] NIOSH Manual of Analytical Methods (NMAM). 4th edition, Hydrocarbons, Aromatic: Method 1501, Issue 3
- [17] NIOSH Manual of Analytical Methods (NMAM), 4th edition, Volatile organic compounds (Screening): Method 2549, Issue 1
- [18] NIOSH Manual of Analytical Methods (NMAM), 4th edition, BENZENE by portable GC: Method 3700, Issue 2
- [19] NIOSH 1002, b-CHLOROPRENE 1002

- [20] NIOSH 1024, 1,3-BUTADIENE 1024
- [21] NIOSH 2016, FORMALDEHYDE 2016
- [22] NIOSH 2541, FORMALDEHYDE by GC 2541
- [23] NIOSH 3500, FORMALDEHYDE by VIS3500
- [24] NIOSH 2017, ANILINE, o-TOLUIDINE, AND NITROBENZENE 2017
- [25] NIOSH 5515, POLYNUCLEAR AROMATIC HYDROCARBONS by GC 5515
- [26] NIOSH 5506, POLYNUCLEAR AROMATIC HYDROCARBONS by HPLC 5506
- [27] 3M 3721 Formaldehyde monitors
- [28] MTA/MA-018/A89, Determinación de formaldehído en aire — método de captación en sílica gel impregnada con 2,4-dinitrofenilhidracina / cromatografía líquida de alta resolución [Determination of formaldehyde in air - use of trapping in silica gel impregnated with 2,4-dinitrophenyl hydrazine and high performance liquid chromatography]
- [29] MTA/MA039/A00, Determinación de hidrocarburos policíclicos en aire. Método de captación en filtro y tubo adsorbente y detección fluorimétrica / Cromatografía líquida de alta resolución
- [30] MDHS 78, Formaldehyde in air — Laboratory method using a diffusive sampler, solvent desorption and high performance liquid chromatography
- [31] MDHS 96, Volatile Organic compounds in air - laboratory method using pumped solid sorbent tubes, solvent desorption and gas chromatography
- [32] Metropol 177 (M-177: 1-3 Butadiène)
- [33] Metropol 332 (M-332: HAP)
- [34] OSHA 7, *Sampling and Analytical Methods Organic Vapors*
- [35] OSHA 52, *Sampling and Analytical Methods — Acrolein and/or Formaldehyde*
- [36] OSHA 56, *Sampling and Analytical Methods 1.3 — Butadiene*
- [37] OSHA 58, *Sampling and Analytical Methods — Coal Tar Pitch Volatiles (CTPV), Coke Oven Emissions (COE), Selected Polynuclear Aromatic Hydrocarbons (PAHs)*
- [38] OSHA 73, *Sampling and Analytical Methods — o-Toluidine, m-Toluidine, p-Toluidine*
- [39] OSHA 112, *Sampling and Analytical Methods b-Chloroprene*
- [40] BGI 505-23, (bisher ZH 1/120.23), Verfahren zur Bestimmung von N-Nitrosaminen Hauptverband der gewerblichen Berufsgenossenschaften Fachausschuß "Chemie" September 1992 (BGI 505.23 (previously named ZH 1/120.23) [Methods for the determination of N-nitrosamines - Professional trade associations Technical Committee "Chemie" September 1992]
- [41] BGI 505.36 (bisher ZH 1/120.36), Verfahren zur Bestimmung von N-Nitrosodiethanolamin Hauptverband der gewerblichen Berufsgenossenschaften Fachausschuß "Chemie" September 1992 (BGI 505.36 previously named ZH 1/120.36) [Methods for the determination of N-nitrosamines - Professional trade associations Technical Committee "Chemie" September 1992]
- [42] BGI 505-49E, Method for the determination of o-toluidine
- [43] BGI 505.62 (bisher ZH 1/120.62), Verfahren zur Bestimmung von NNitrosomethylphenylamin und NNitrosoethylphenylamin Hauptverband der gewerblichen Berufsgenossenschaften Fachausschuß "Chemie" Dezember 1996. (BGI 505.62 (previously named ZH 1/120.62) [Methods