



ISO/IEC 29341-6-13

Edition 1.0 2008-11

# INTERNATIONAL STANDARD

Information technology – UPnP Device Architecture –  
Part 6-13: Heating, Ventilation and Air Conditioning Device Control Protocol –  
House Status Service

IECNORM.COM : Click to view the full PDF of ISO/IEC 29341-6-13:2008



**THIS PUBLICATION IS COPYRIGHT PROTECTED**  
**Copyright © 2008 ISO/IEC, Geneva, Switzerland**

All rights reserved. Unless otherwise specified, no part of this publication may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without permission in writing from either IEC or IEC's member National Committee in the country of the requester.

If you have any questions about ISO/IEC copyright or have an enquiry about obtaining additional rights to this publication, please contact the address below or your local IEC member National Committee for further information.

IEC Central Office  
3, rue de Varembe  
CH-1211 Geneva 20  
Switzerland  
Email: [inmail@iec.ch](mailto:inmail@iec.ch)  
Web: [www.iec.ch](http://www.iec.ch)

### **About the IEC**

The International Electrotechnical Commission (IEC) is the leading global organization that prepares and publishes International Standards for all electrical, electronic and related technologies.

### **About IEC publications**

The technical content of IEC publications is kept under constant review by the IEC. Please make sure that you have the latest edition, a corrigenda or an amendment might have been published.

- Catalogue of IEC publications: [www.iec.ch/searchpub](http://www.iec.ch/searchpub)

The IEC on-line Catalogue enables you to search by a variety of criteria (reference number, text, technical committee,...). It also gives information on projects, withdrawn and replaced publications.

- IEC Just Published: [www.iec.ch/online\\_news/justpub](http://www.iec.ch/online_news/justpub)

Stay up to date on all new IEC publications. Just Published details twice a month all new publications released. Available on-line and also by email.

- Electropedia: [www.electropedia.org](http://www.electropedia.org)

The world's leading online dictionary of electronic and electrical terms containing more than 20 000 terms and definitions in English and French, with equivalent terms in additional languages. Also known as the International Electrotechnical Vocabulary online.

- Customer Service Centre: [www.iec.ch/webstore/custserv](http://www.iec.ch/webstore/custserv)

If you wish to give us your feedback on this publication or need further assistance, please visit the Customer Service Centre FAQ or contact us:

Email: [csc@iec.ch](mailto:csc@iec.ch)  
Tel.: +41 22 919 02 11  
Fax: +41 22 919 03 00

IECNORM.COM : Click to view the full PDF of ISO/IEC 29341-6-13:2008



ISO/IEC 29341-6-13

Edition 1.0 2008-11

# INTERNATIONAL STANDARD

---

**Information technology – UPnP Device Architecture –  
Part 6-13: Heating, Ventilation and Air Conditioning Device Control Protocol –  
House Status Service**

IECNORM.COM : Click to view the full PDF of ISO/IEC 29341-6-13:2008

INTERNATIONAL  
ELECTROTECHNICAL  
COMMISSION

PRICE CODE

**G**

---

ICS 35.200

ISBN 2-8318-1007-9

## CONTENTS

FOREWORD .....	4
ORIGINAL UPNP DOCUMENTS (informative) .....	6
<b>1. Overview and Scope</b> .....	<b>8</b>
<b>2. Service Modeling Definitions</b> .....	<b>9</b>
2.1. Service Type .....	9
2.2. State Variables .....	9
2.2.1. OccupancyState .....	9
2.2.2. ActivityLevel .....	9
2.2.3. DormancyLevel .....	10
2.2.4. Relationships Between State Variables .....	10
2.3. Eventing and Moderation .....	11
2.3.1. Event Model .....	11
2.4. Actions.....	12
2.4.1. GetOccupancyState .....	12
2.4.2. GetActivityLevel .....	12
2.4.3. GetDormancyLevel .....	13
2.4.4. SetOccupancyState .....	13
2.4.5. SetActivityLevel .....	14
2.4.6. SetDormancyLevel.....	14
2.4.7. Non-Standard Actions Implemented by a UPnP Vendor .....	15
2.4.8. Common Error Codes.....	15
2.5. Theory of Operation .....	16
2.6. Synchronization of Multiple Instances .....	16
<b>3. XML Service Description</b> .....	<b>18</b>
<b>4. Test</b> .....	<b>20</b>

IECNORM.COM : Click to view the full PDF of ISO/IEC 29341-6-13:2008

LIST OF TABLES

Table 1: State Variables .....9

Table 2: AllowedValueList for ActivityLevel .....10

Table 3: DefaultValue for ActivityLevel .....10

Table 4: AllowedValueList for DormancyLevel .....10

Table 5: DefaultValue for DormancyLevel .....10

Table 6: Event Moderation.....11

Table 7: Actions .....12

Table 8: Arguments for GetOccupancyState .....12

Table 9: Arguments for GetActivityLevel .....12

Table 10: Arguments for GetDormancyLevel .....13

Table 11: Arguments for SetOccupancyState .....13

Table 12: Arguments for SetActivityLevel .....14

Table 13: Arguments for SetDormancyLevel .....14

Table 14: Common Error Codes .....15

IECNORM.COM : Click to view the full PDF of ISO/IEC 29341-6-13:2008

## INFORMATION TECHNOLOGY – UPNP DEVICE ARCHITECTURE –

### Part 6-13: Heating, Ventilation and Air Conditioning Device Control Protocol – House Status Service

#### FOREWORD

- 1) ISO (International Organization for Standardization) and IEC (International Electrotechnical Commission) form the specialized system for worldwide standardization. National bodies that are members of ISO or IEC participate in the development of International Standards. Their preparation is entrusted to technical committees; any ISO and IEC member body interested in the subject dealt with may participate in this preparatory work. International governmental and non-governmental organizations liaising with ISO and IEC also participate in this preparation.
- 2) In the field of information technology, ISO and IEC have established a joint technical committee, ISO/IEC JTC 1. Draft International Standards adopted by the joint technical committee are circulated to national bodies for voting. Publication as an International Standard requires approval by at least 75 % of the national bodies casting a vote.
- 3) The formal decisions or agreements of IEC and ISO on technical matters express, as nearly as possible, an international consensus of opinion on the relevant subjects since each technical committee has representation from all interested IEC and ISO member bodies.
- 4) IEC, ISO and ISO/IEC publications have the form of recommendations for international use and are accepted by IEC and ISO member bodies in that sense. While all reasonable efforts are made to ensure that the technical content of IEC, ISO and ISO/IEC publications is accurate, IEC or ISO cannot be held responsible for the way in which they are used or for any misinterpretation by any end user.
- 5) In order to promote international uniformity, IEC and ISO member bodies undertake to apply IEC, ISO and ISO/IEC publications transparently to the maximum extent possible in their national and regional publications. Any divergence between any ISO/IEC publication and the corresponding national or regional publication should be clearly indicated in the latter.
- 6) ISO and IEC provide no marking procedure to indicate their approval and cannot be rendered responsible for any equipment declared to be in conformity with an ISO/IEC publication.
- 7) All users should ensure that they have the latest edition of this publication.
- 8) No liability shall attach to IEC or ISO or its directors, employees, servants or agents including individual experts and members of their technical committees and IEC or ISO member bodies for any personal injury, property damage or other damage of any nature whatsoever, whether direct or indirect, or for costs (including legal fees) and expenses arising out of the publication of, use of, or reliance upon, this ISO/IEC publication or any other IEC, ISO or ISO/IEC publications.
- 9) Attention is drawn to the normative references cited in this publication. Use of the referenced publications is indispensable for the correct application of this publication.

IEC and ISO draw attention to the fact that it is claimed that compliance with this document may involve the use of patents as indicated below.

ISO and IEC take no position concerning the evidence, validity and scope of the putative patent rights. The holders of the putative patent rights have assured IEC and ISO that they are willing to negotiate free licences or licences under reasonable and non-discriminatory terms and conditions with applicants throughout the world. In this respect, the statements of the holders of the putative patent rights are registered with IEC and ISO.

Intel Corporation has informed IEC and ISO that it has patent applications or granted patents.

Information may be obtained from:

Intel Corporation  
Standards Licensing Department  
5200 NE Elam Young Parkway  
MS: JFS-98  
USA – Hillsboro, Oregon 97124

Microsoft Corporation has informed IEC and ISO that it has patent applications or granted patents as listed below:

6101499 / US; 6687755 / US; 6910068 / US; 7130895 / US; 6725281 / US; 7089307 / US; 7069312 / US;  
10/783 524 / US

Information may be obtained from:

Microsoft Corporation  
One Microsoft Way  
USA – Redmond WA 98052

Philips International B.V. has informed IEC and ISO that it has patent applications or granted patents.

Information may be obtained from:

Philips International B.V. – IP&S  
High Tech campus, building 44 3A21  
NL – 5656 Eindhoven

NXP B.V. (NL) has informed IEC and ISO that it has patent applications or granted patents.

Information may be obtained from:

NXP B.V. (NL)  
High Tech campus 60  
NL – 5656 AG Eindhoven

Matsushita Electric Industrial Co. Ltd. has informed IEC and ISO that it has patent applications or granted patents.

Information may be obtained from:

Matsushita Electric Industrial Co. Ltd.  
1-3-7 Shiromi, Chuoh-ku  
JP – Osaka 540-6139

Hewlett Packard Company has informed IEC and ISO that it has patent applications or granted patents as listed below:

5 956 487 / US; 6 170 007 / US; 6 139 177 / US; 6 529 936 / US; 6 470 339 / US; 6 571 388 / US; 6 205  
466 / US

Information may be obtained from:

Hewlett Packard Company  
1501 Page Mill Road  
USA – Palo Alto, CA 94304

Samsung Electronics Co. Ltd. has informed IEC and ISO that it has patent applications or granted patents.

Information may be obtained from:

Digital Media Business, Samsung Electronics Co. Ltd.  
416 Maetan-3 Dong, Yeongtang-Gu,  
KR – Suwon City 443-742

Attention is drawn to the possibility that some of the elements of this document may be the subject of patent rights other than those identified above. IEC and ISO shall not be held responsible for identifying any or all such patent rights.

ISO/IEC 29341-6-13 was prepared by UPnP Implementers Corporation and adopted, under the PAS procedure, by joint technical committee ISO/IEC JTC 1, *Information technology*, in parallel with its approval by national bodies of ISO and IEC.

The list of all currently available parts of the ISO/IEC 29341 series, under the general title *Universal plug and play (UPnP) architecture*, can be found on the IEC web site.

This International Standard has been approved by vote of the member bodies, and the voting results may be obtained from the address given on the second title page.

## ORIGINAL UPnP DOCUMENTS (informative)

Reference may be made in this document to original UPnP documents. These references are retained in order to maintain consistency between the specifications as published by ISO/IEC and by UPnP Implementers Corporation. The following table indicates the original UPnP document titles and the corresponding part of ISO/IEC 29341:

UPnP Document Title	ISO/IEC 29341 Part
UPnP Device Architecture 1.0	ISO/IEC 29341-1
UPnP Basic:1 Device	ISO/IEC 29341-2
UPnP AV Architecture:1	ISO/IEC 29341-3-1
UPnP MediaRenderer:1 Device	ISO/IEC 29341-3-2
UPnP MediaServer:1 Device	ISO/IEC 29341-3-3
UPnP AVTransport:1 Service	ISO/IEC 29341-3-10
UPnP ConnectionManager:1 Service	ISO/IEC 29341-3-11
UPnP ContentDirectory:1 Service	ISO/IEC 29341-3-12
UPnP RenderingControl:1 Service	ISO/IEC 29341-3-13
UPnP MediaRenderer:2 Device	ISO/IEC 29341-4-2
UPnP MediaServer:2 Device	ISO/IEC 29341-4-3
UPnP AV Datastructure Template:1	ISO/IEC 29341-4-4
UPnP AVTransport:2 Service	ISO/IEC 29341-4-10
UPnP ConnectionManager:2 Service	ISO/IEC 29341-4-11
UPnP ContentDirectory:2 Service	ISO/IEC 29341-4-12
UPnP RenderingControl:2 Service	ISO/IEC 29341-4-13
UPnP ScheduledRecording:1	ISO/IEC 29341-4-14
UPnP DigitalSecurityCamera:1 Device	ISO/IEC 29341-5-1
UPnP DigitalSecurityCameraMotionImage:1 Service	ISO/IEC 29341-5-10
UPnP DigitalSecurityCameraSettings:1 Service	ISO/IEC 29341-5-11
UPnP DigitalSecurityCameraStillImage:1 Service	ISO/IEC 29341-5-12
UPnP HVAC_System:1 Device	ISO/IEC 29341-6-1
UPnP HVAC_ZoneThermostat:1 Device	ISO/IEC 29341-6-2
UPnP ControlValve:1 Service	ISO/IEC 29341-6-10
UPnP HVAC_FanOperatingMode:1 Service	ISO/IEC 29341-6-11
UPnP FanSpeed:1 Service	ISO/IEC 29341-6-12
UPnP HouseStatus:1 Service	ISO/IEC 29341-6-13
UPnP HVAC_SetpointSchedule:1 Service	ISO/IEC 29341-6-14
UPnP TemperatureSensor:1 Service	ISO/IEC 29341-6-15
UPnP TemperatureSetpoint:1 Service	ISO/IEC 29341-6-16
UPnP HVAC_UserOperatingMode:1 Service	ISO/IEC 29341-6-17
UPnP BinaryLight:1 Device	ISO/IEC 29341-7-1
UPnP DimmableLight:1 Device	ISO/IEC 29341-7-2
UPnP Dimming:1 Service	ISO/IEC 29341-7-10
UPnP SwitchPower:1 Service	ISO/IEC 29341-7-11
UPnP InternetGatewayDevice:1 Device	ISO/IEC 29341-8-1
UPnP LANDevice:1 Device	ISO/IEC 29341-8-2
UPnP WANDevice:1 Device	ISO/IEC 29341-8-3
UPnP WANConnectionDevice:1 Device	ISO/IEC 29341-8-4
UPnP WLANAccessPointDevice:1 Device	ISO/IEC 29341-8-5
UPnP LANHostConfigManagement:1 Service	ISO/IEC 29341-8-10
UPnP Layer3Forwarding:1 Service	ISO/IEC 29341-8-11
UPnP LinkAuthentication:1 Service	ISO/IEC 29341-8-12
UPnP RadiusClient:1 Service	ISO/IEC 29341-8-13
UPnP WANCableLinkConfig:1 Service	ISO/IEC 29341-8-14
UPnP WANCommonInterfaceConfig:1 Service	ISO/IEC 29341-8-15
UPnP WANDSLLinkConfig:1 Service	ISO/IEC 29341-8-16
UPnP WANEthernetLinkConfig:1 Service	ISO/IEC 29341-8-17
UPnP WANIPConnection:1 Service	ISO/IEC 29341-8-18
UPnP WANPOTSLinkConfig:1 Service	ISO/IEC 29341-8-19
UPnP WANPPPoEConnection:1 Service	ISO/IEC 29341-8-20
UPnP WLANConfiguration:1 Service	ISO/IEC 29341-8-21
UPnP Printer:1 Device	ISO/IEC 29341-9-1
UPnP Scanner:1.0 Device	ISO/IEC 29341-9-2
UPnP ExternalActivity:1 Service	ISO/IEC 29341-9-10
UPnP Feeder:1.0 Service	ISO/IEC 29341-9-11
UPnP PrintBasic:1 Service	ISO/IEC 29341-9-12
UPnP Scan:1 Service	ISO/IEC 29341-9-13
UPnP QoS Architecture:1.0	ISO/IEC 29341-10-1
UPnP QoSDevice:1 Service	ISO/IEC 29341-10-10
UPnP QoSManager:1 Service	ISO/IEC 29341-10-11
UPnP QoSPolicyHolder:1 Service	ISO/IEC 29341-10-12
UPnP QoS Architecture:2	ISO/IEC 29341-11-1
UPnP QOS v2 Schema Files	ISO/IEC 29341-11-2

<b>UPnP Document Title</b>	<b>ISO/IEC 29341 Part</b>
UPnP QosDevice:2 Service	ISO/IEC 29341-11-10
UPnP QosManager:2 Service	ISO/IEC 29341-11-11
UPnP QosPolicyHolder:2 Service	ISO/IEC 29341-11-12
UPnP RemoteUIClientDevice:1 Device	ISO/IEC 29341-12-1
UPnP RemoteUIServerDevice:1 Device	ISO/IEC 29341-12-2
UPnP RemoteUIClient:1 Service	ISO/IEC 29341-12-10
UPnP RemoteUIServer:1 Service	ISO/IEC 29341-12-11
UPnP DeviceSecurity:1 Service	ISO/IEC 29341-13-10
UPnP SecurityConsole:1 Service	ISO/IEC 29341-13-11

IECNORM.COM : Click to view the full PDF of ISO/IEC 29341-6-13:2008

# 1. Overview and Scope

This service definition is compliant with the UPnP Device Architecture version 1.0.

This service-type provides an indication about house occupancy status and operational mode. It is commonly used as a mechanism for influencing the state of Devices and/or Control Points depending upon whether people are in the house. Typical applications are: e.g. switching on or off lights, air-conditioning etc.

Occupancy status can be derived i) directly from an occupant via a user interface, or ii) indirectly by algorithms such as a calendar program, or iii) indirectly by heuristics that determine the status from subsystem or device activity. That is to say: this service type would be implemented in two types of occupancy "detector" devices:

- A physical switch (e.g. a home/away push button on a device).
- A "virtual" switch that uses some kind of algorithm or heuristics to work out if the house is occupied (e.g. a calendar or a predictive algorithm).

In case a) the physical detection device would incorporate this occupancy service, but in case b) the MMI of the device that contains the algorithm would incorporate this occupancy service.

This service is a "source" of UPnP event messages. Control Points that are interested to be updated about the occupancy state of the house should subscribe to receive events from this service type. (However, Control Points are also permitted to "poll" the service from time to time in order to enquire about the current occupancy state).

This service template does not address:

- Presence detection for security alarm purposes.
- Actual number of persons in the building (or building part) e.g. for demand controlled ventilation in (say) a conference room.

IECNORM.COM : Click to view the full PDF of ISO/IEC 29341-6-13:2008

## 2. Service Modeling Definitions

### 2.1. Service Type

The following service type identifies a service that is compliant with this template:

**urn:schemas-upnp-org:service:HouseStatus:1**

### 2.2. State Variables

**Table 1: State Variables**

Variable Name	Req. or Opt. <sup>1</sup>	Data Type	Allowed Value <sup>2</sup>	Default Value <sup>2</sup>	Eng. Units
OccupancyState	R	string	Occupied, Unoccupied, Indeterminate	Occupied	none
ActivityLevel	O	string	See table 2	See table 3	none
DormancyLevel	O	string	See table 4	See table 5	none
<i>Non-standard state variables implemented by an UPnP vendor go here.</i>	<i>X</i>	<i>TBD</i>	<i>TBD</i>	<i>TBD</i>	<i>TBD</i>

<sup>1</sup> R = Required, O = Optional, X = Non-standard.

<sup>2</sup> Values listed in this column are required. To specify standard optional values or to delegate assignment of values to the vendor, you must reference a specific instance of an appropriate table below.

#### 2.2.1. OccupancyState

This is a read only variable that represents the occupancy status of the house, whereby:

- **Occupied** = People in the house
- **Unoccupied** = No people in the house
- **Indeterminate** = The service is unable to determine if the house is occupied or not.

#### 2.2.2. ActivityLevel

This is an optional read only variable that acts as a qualifier to provide an extra level of detail concerning the occupancy status of the house. It indicates the level of activity of the occupants. Whereby:

- **Regular** = Indicates that the house is in a neutral/normal state of occupancy. Note: ActivityLevel is optional, so in case of a service where ActivityLevel is NOT implemented, a Control Point should assume that the activity level is regular.
- **Asleep** = Means that although the house is occupied, the occupants are asleep – meaning that the degree of activity is lower than “Regular”. (example: this could be used to adjust the temperature or switch off lights).
- **HighActivity** = Means that the house is occupied with a degree of activity that is higher than “Regular” – e.g. for a party. (example: this could be used to increase the speed of a ventilation fan).

**Table 2: AllowedValueList for ActivityLevel**

Value	Req. or Opt.
Regular	R
Asleep	R
HighActivity	R
<i>Vendor-defined</i>	O

<sup>1</sup> R = Required, O = Optional

**Table 3: DefaultValue for ActivityLevel**

Value	Req. or Opt.
Regular	R

<sup>1</sup> R = Required, O = Optional

### 2.2.3. DormancyLevel

This is an optional read only variable that acts as a qualifier to provide an extra level of detail concerning the un-occupied status of the house. It indicates the expected duration of the absence. Whereby:

- **Vacation** = Means that the duration of the unoccupied period is expected to be, (but not guaranteed to be), longer than 1 day.
- **Regular** = Indicates that the house is in a neutral/normal state of un-occupancy. Note: DormancyLevel is optional, so in case of a service where DormancyLevel is NOT implemented, a Control Point should assume that the level is regular.
- **PetsAtHome** = The house is not occupied by humans, but there may be pets moving around inside the house. (i.e. the security motion detectors inside the house should not be armed).

**Table 4: AllowedValueList for DormancyLevel**

Value	Req. or Opt.
Vacation	R
Regular	R
PetsAtHome	R
<i>Vendor-defined</i>	O

<sup>1</sup> R = Required, O = Optional

**Table 5: DefaultValue for DormancyLevel**

Value	Req. or Opt.
Regular	R

<sup>1</sup> R = Required, O = Optional

### 2.2.4. Relationships Between State Variables

None.

## 2.3. Eventing and Moderation

For the HouseStatus service, an example event subscription would be as follows:

- A thermostat (say) implements the HouseStatus service in the physical form of a home / away button on the front.
- The Lights, Answering machine, Oven, Lawn Sprinkler (or whatever) do an M-SEARCH for an HouseStatus service, and when they find one, they subscribe to receive events from that service using SUBSCRIBE. (In principle, the thermostat could also use a subscription to its own HouseStatus service too, but in practice since it is in the same device, it would probably use an internal signal instead).
- When the homeowner presses the home / away button on the thermostat, the service publishes (sources) the corresponding OccupancyState change event NOTIFY message.
- The Lights, Answering machine, Oven, Lawn Sprinkler (or whatever) and thermostat all receive (sink) this notification and switch over into their "Occupied" respectively "Unoccupied" mode accordingly.

**Table 6: Event Moderation**

Variable Name	Evented	Moderated Event?	Max Event Rate <sup>1</sup>	Logical Combination	Min Delta per Event <sup>2</sup>
OccupancyState	Yes	Yes	30	no	See note 3
ActivityLevel	Yes	Yes	30	no	See note 3
DormancyLevel	Yes	Yes	30	no	See note 3
<i>Non-standard state variables implemented by an UPnP vendor go here.</i>	<i>TBD</i>	<i>TBD</i>	<i>TBD</i>	<i>TBD</i>	<i>TBD</i>

<sup>1</sup> Determined by N, where Rate = (Event)/(N secs).

<sup>2</sup> (N) \* (allowedValueRange Step)

Note 3: Never send events if the value of the state variable has not changed! This is important for avoiding race conditions. See section 2.6

### 2.3.1. Event Model

#### 2.3.1.1. Delayed Response

Depending on the physical implementation of the containing device, a state change of HouseStatus may be triggered in a number of ways: e.g. "going out" button on the front of a security panel, "standby" button on a room thermostat etc. Especially, in the case of human operated buttons, etc. it is obvious that the person will still remain in the building for a certain period even AFTER the button has been set to Unoccupied mode. Therefore any Control Point that subscribes to HouseStatus events must make allowances for this.

Example: After receiving an OccupancyState=Unoccupied event, a lighting circuit should perhaps wait for a certain period of time before turning off the lights. However, in the case of receiving an OccupancyState=Occupied event, it should probably turn on the lights immediately.

## 2.4. Actions

**Table 7: Actions**

Name	Req. or Opt. <sup>1</sup>
GetOccupancyState	R
GetActivityLevel	O
GetDormancyLevel	O
SetOccupancyState	R
SetActivityLevel	O
SetDormancyLevel	O
<i>Non-standard actions implemented by an UPnP vendor go here.</i>	X

<sup>1</sup> R = Required, O = Optional, X = Non-standard.

### 2.4.1. GetOccupancyState

Reads the current value of OccupancyState

#### 2.4.1.1. Arguments

**Table 8: Arguments for GetOccupancyState**

Argument	Direction	relatedStateVariable
CurrentOccupancyState	OUT <sup>R</sup>	OccupancyState

<sup>R</sup> = Return Value (RETVAL)

#### 2.4.1.2. Effect on State

None.

#### 2.4.1.3. Errors

errorCode	errorDescription	Description
402	Invalid Args	See UPnP Device Architecture section on Control.
501	Action Failed	See UPnP Device Architecture section on Control.
<i>800-899</i>	<i>TBD</i>	<i>(Specified by UPnP vendor.)</i>

### 2.4.2. GetActivityLevel

Reads the current value of ActivityLevel

#### 2.4.2.1. Arguments

**Table 9: Arguments for GetActivityLevel**

Argument	Direction	relatedStateVariable
CurrentActivityLevel	OUT <sup>R</sup>	ActivityLevel

<sup>R</sup> = Return Value (RETVAL)

#### 2.4.2.2. Effect on State

None.

### 2.4.2.3. Errors

errorCode	errorDescription	Description
402	Invalid Args	See UPnP Device Architecture section on Control.
501	Action Failed	See UPnP Device Architecture section on Control.
800-899	TBD	(Specified by UPnP vendor.)

## 2.4.3. GetDormancyLevel

Reads the current value of DormancyLevel

### 2.4.3.1. Arguments

Table 10: Arguments for GetDormancyLevel

Argument	Direction	relatedStateVariable
CurrentDormancyLevel	OUT <sup>R</sup>	DormancyLevel

<sup>R</sup> = Return Value (RETVAL)

### 2.4.3.2. Effect on State

None.

### 2.4.3.3. Errors

errorCode	errorDescription	Description
402	Invalid Args	See UPnP Device Architecture section on Control.
501	Action Failed	See UPnP Device Architecture section on Control.
800-899	TBD	(Specified by UPnP vendor.)

## 2.4.4. SetOccupancyState

Changes the value of OccupancyState.

### 2.4.4.1. Arguments

Table 11: Arguments for SetOccupancyState

Argument	Direction	relatedStateVariable
NewOccupancyState	IN	OccupancyState

<sup>R</sup> = Return Value (RETVAL)

### 2.4.4.2. Effect on State

Changes the value of OccupancyState.

**2.4.4.3. Errors**

errorCode	errorDescription	Description
402	Invalid Args	See UPnP Device Architecture section on Control.
501	Action Failed	See UPnP Device Architecture section on Control.
800-899	TBD	(Specified by UPnP vendor.)

**2.4.5. SetActivityLevel**

Changes the value of ActivityLevel

**2.4.5.1. Arguments**

**Table 12: Arguments for SetActivityLevel**

Argument	Direction	relatedStateVariable
NewActivityLevel	IN	ActivityLevel

<sup>R</sup> = Return Value (RETVAl)

**2.4.5.2. Effect on State**

Changes the value of ActivityLevel

**2.4.5.3. Errors**

errorCode	errorDescription	Description
402	Invalid Args	See UPnP Device Architecture section on Control.
501	Action Failed	See UPnP Device Architecture section on Control.
800-899	TBD	(Specified by UPnP vendor.)

**2.4.6. SetDormancyLevel**

Changes the value of DormancyLevel.

**2.4.6.1. Arguments**

**Table 13: Arguments for SetDormancyLevel**

Argument	Direction	relatedStateVariable
NewDormancyLevel	IN	DormancyLevel

<sup>R</sup> = Return Value (RETVAl)

**2.4.6.2. Effect on State**

Changes the value of DormancyLevel.

### 2.4.6.3. Errors

errorCode	errorDescription	Description
402	Invalid Args	See UPnP Device Architecture section on Control.
501	Action Failed	See UPnP Device Architecture section on Control.
800-899	TBD	(Specified by UPnP vendor.)

### 2.4.7. Non-Standard Actions Implemented by a UPnP Vendor

To facilitate certification, non-standard actions implemented by UPnP vendors should be included in this service template. The UPnP Device Architecture lists naming requirements for non-standard actions (see the section on Description).

### 2.4.8. Common Error Codes

The following table lists error codes common to actions for this service type. If an action results in multiple errors, the most specific error should be returned.

**Table 14: Common Error Codes**

ErrorCode	errorDescription	Description
401	Invalid Action	See UPnP Device Architecture section on Control.
402	Invalid Args	See UPnP Device Architecture section on Control.
404	Invalid Var	See UPnP Device Architecture section on Control.
501	Action Failed	See UPnP Device Architecture section on Control.
600-699	TBD	Common action errors. Defined by UPnP Forum Technical Committee.
701-799		Common action errors defined by the UPnP Forum working committees.
800-899	TBD	(Specified by UPnP vendor.)

## 2.5. Theory of Operation

This service-type provides an indication about house occupancy status and operational mode. It is commonly used as a mechanism for influencing the state of Control Points depending upon whether people are in the house. For example, when the house is unoccupied, the environmental system may use a different heating or cooling goal, or the lighting system may turn unneeded lights off.

Typically such a Control Point may SUBSCRIBE to receive occupied / unoccupied events from the OccupancyState variable; whenever it receives the respective event notifications, it will adjust it's state accordingly. Alternatively a Control Point may poll this service using the GetOccupancyState function.

It is the responsibility of each device vendor to select a behavior --a strategy-- that is appropriate for best supporting the user's desire for a given state reported by the HouseStatus service. This mechanism should provide a simple, coordinated way for users to operate their homes.

Occupancy State	Activity Level	Dormancy Level	Remarks
Occupied	Regular		There are people in the house. There is a "normal" (i.e. regular) amount of occupant activity.
	Asleep		There are people in the house. There is a <b>below</b> "normal" amount of occupant activity – e.g. the occupants are sleeping.
	HighActivity		There are people in the house. There is an <b>above</b> "normal" amount of occupant activity – e.g. the occupants are partying.
Unoccupied		Regular	There are no people in the house (i.e. the house is "dormant"). The level of dormancy is "normal" – e.g. the occupants are out at work, and they are expected to return in the evening.
		Vacation	There are no people in the house. The level of dormancy is <b>above</b> "normal" – e.g. the occupants are away on vacation (say > 48 hours absence).
		PetsAtHome	There are no people in the house. The level of dormancy is <b>below</b> "normal" – e.g. the occupants are out at work, but they left their pet animal(s) at home; the pet(s) may be moving about the home.
Indeterminate			The service is currently unable to ascertain the state of the house,

## 2.6. Synchronization of Multiple Instances

It is conceivable that a home might contain more than one instance of the HouseStatus service (e.g. a home / away button on the thermostat, and another one on the security panel). This could lead to potentially confusing situations where one device might indicate an occupied status and another might indicate an unoccupied status. In order to resolve this issue, vendors MUST to do the following:

- i) Each device that implements the HouseStatus service, MUST also implement a Control Point.
- ii) On initialization, (and from time to time thereafter), this Control Point must search for all other instances of HouseStatus.

- iii) This Control Point must subscribe to receive event notifications from all such other instances of HouseStatus that it finds.
- iv) Whenever this Control Point receives an occupancy state change notification from another instance of the HouseStatus service, the service must update the value of its OccupancyState, ActivityLevel or DormancyLevel variables to the same value(s) as that received in the notification message.
- v) If (and only if) the value of its own OccupancyState, ActivityLevel or DormancyLevel variables change, the service shall in turn notify all other Control points that have subscribed to it. NB the HouseStatus service should NEVER send state change notifications if the value of its OccupancyState, ActivityLevel or DormancyLevel variables have not changed – since otherwise race conditions could develop with two or more instances of the HouseStatus service notifying each other in a circular fashion.

IECNORM.COM : Click to view the full PDF of ISO/IEC 29341-6-13:2008