



**International
Standard**

ISO 4266-5

**Petroleum and liquid petroleum
products — Measurement of level
and temperature in storage tanks by
automatic methods —**

**Part 5:
Measurement of temperature in
marine vessels**

*Pétrole et produits pétroliers liquides — Mesurage du niveau et
de la température dans les réservoirs de stockage par méthodes
automatiques —*

Partie 5: Mesurage de la température dans les citernes de navire

**Second edition
2024-09**

STANDARDSISO.COM : Click to view the full PDF of ISO 4266-5:2024



COPYRIGHT PROTECTED DOCUMENT

© ISO 2024

All rights reserved. Unless otherwise specified, or required in the context of its implementation, no part of this publication may be reproduced or utilized otherwise in any form or by any means, electronic or mechanical, including photocopying, or posting on the internet or an intranet, without prior written permission. Permission can be requested from either ISO at the address below or ISO's member body in the country of the requester.

ISO copyright office
CP 401 • Ch. de Blandonnet 8
CH-1214 Vernier, Geneva
Phone: +41 22 749 01 11
Email: copyright@iso.org
Website: www.iso.org

Published in Switzerland

Contents

	Page
Foreword	iv
1 Scope	1
2 Normative reference	1
3 Terms and definitions	1
4 Precautions	2
4.1 Safety precautions.....	2
4.2 Equipment precautions.....	2
4.3 General precautions.....	2
5 Accuracy	3
5.1 General.....	3
5.2 Intrinsic error of ATTs.....	3
5.3 Calibration prior to installation.....	3
5.3.1 General.....	3
5.3.2 ATT calibrated as a system.....	4
5.3.3 ATT calibrated by components.....	4
5.3.4 Multiple-point ATTs.....	4
5.3.5 Uncertainty of the reference.....	4
5.4 Error caused by installation and operating conditions.....	4
5.5 Overall accuracy.....	4
5.5.1 General.....	4
5.5.2 Use of ATT for fiscal/custody transfer purposes.....	5
6 Selection of ATTs	5
6.1 General.....	5
6.2 ATTs for fiscal/custody transfer purpose.....	5
7 Description of ATT equipment — Electrical temperature elements	6
7.1 General.....	6
8 Installation of marine ATTs	6
8.1 General.....	6
8.2 Location of temperature sensing element(s).....	6
8.3 Location of manual (temperature) gauge hatch.....	6
8.4 Temperature measurement of inerted tanks.....	6
9 Calibration and on-board verification of marine ATTs	7
9.1 General.....	7
9.2 Calibration of single-point temperature element ATTs for fiscal/custody transfer purposes.....	7
9.2.1 Calibration prior to installation.....	7
9.2.2 Initial verification at shipyard or during sea trials.....	7
9.3 Calibration of multiple-point ATTs for fiscal/custody transfer purposes.....	8
9.3.1 Calibration prior to installation.....	8
9.3.2 Initial on-board verification at shipyard or during sea trials.....	8
9.4 Subsequent verification of ATTs.....	9
9.4.1 General.....	9
9.4.2 Frequency of subsequent verification.....	9
9.4.3 Record keeping.....	9
10 Data communication and receiving	10
Annex A (informative) Accuracy limitations of tank-temperature measurements on board marine vessels	11
Bibliography	12

Foreword

ISO (the International Organization for Standardization) is a worldwide federation of national standards bodies (ISO member bodies). The work of preparing International Standards is normally carried out through ISO technical committees. Each member body interested in a subject for which a technical committee has been established has the right to be represented on that committee. International organizations, governmental and non-governmental, in liaison with ISO, also take part in the work. ISO collaborates closely with the International Electrotechnical Commission (IEC) on all matters of electrotechnical standardization.

The procedures used to develop this document and those intended for its further maintenance are described in the ISO/IEC Directives, Part 1. In particular, the different approval criteria needed for the different types of ISO document should be noted. This document was drafted in accordance with the editorial rules of the ISO/IEC Directives, Part 2 (see www.iso.org/directives).

ISO draws attention to the possibility that the implementation of this document may involve the use of (a) patent(s). ISO takes no position concerning the evidence, validity or applicability of any claimed patent rights in respect thereof. As of the date of publication of this document, ISO had not received notice of (a) patent(s) which may be required to implement this document. However, implementers are cautioned that this may not represent the latest information, which may be obtained from the patent database available at www.iso.org/patents. ISO shall not be held responsible for identifying any or all such patent rights.

Any trade name used in this document is information given for the convenience of users and does not constitute an endorsement.

For an explanation of the voluntary nature of standards, the meaning of ISO specific terms and expressions related to conformity assessment, as well as information about ISO's adherence to the World Trade Organization (WTO) principles in the Technical Barriers to Trade (TBT), see www.iso.org/iso/foreword.html.

This document was prepared by Technical Committee ISO/TC 28, *Petroleum and related products, fuels and lubricants from natural or synthetic sources*, Subcommittee SC 2, *Measurement of petroleum and related products*.

This second edition cancels and replaces the first edition (ISO 4266-5:2002), which has been technically revised.

The main changes are as follows:

- slightly modified the scope;
- updated normative references;
- expanded safety precautions;
- clarified the expectations for calibrated equipment throughout the document;
- added references to the bibliography.

A list of all parts in the ISO 4266 series can be found on the ISO website.

Any feedback or questions on this document should be directed to the user's national standards body. A complete listing of these bodies can be found at www.iso.org/members.html.

Petroleum and liquid petroleum products — Measurement of level and temperature in storage tanks by automatic methods —

Part 5: Measurement of temperature in marine vessels

1 Scope

This document provides requirements and guidance on the selection, accuracy, installation, commissioning, calibration and verification of automatic tank thermometers (ATTs) in fiscal/custody transfer applications.

The ATT is used for measuring the temperature of petroleum and liquid petroleum products having a Reid vapour pressure less than 100 kPa, stored in cargo tanks on board marine vessels (i.e. tankers and barges).

This document is not applicable to the measurement of temperature in refrigerated storage tanks, or pressurized cargo tanks on board marine vessels, which is covered in ISO 8310.

2 Normative reference

The following documents are referred to in the text in such a way that some or all of their content constitutes requirements of this document. For dated references, only the edition cited applies. For undated references, the latest edition of the referenced document (including any amendments) applies.

ISO 1998 (all parts), *Petroleum industry — Terminology*

3 Terms and definitions

For the purposes of this document, the terms and definitions given in ISO 1998 (all parts) and the following apply.

ISO and IEC maintain terminology databases for use in standardization at the following addresses:

- ISO Online browsing platform: available at <https://www.iso.org/obp>
- IEC Electropedia: available at <https://www.electropedia.org/>

3.1

automatic tank thermometer

ATT

instrument that continuously measures temperature in storage (or cargo) tanks

Note 1 to entry: A marine ATT, which can also be known as an automatic tank temperature system, typically includes precision temperature sensors, deck-mounted transmitters for electronic signal transmission, and receiving/readout device(s).

3.2

resistance temperature detector

RTD

electrical temperature-sensing element commonly used to measure the temperature of the contents of a storage tank

3.3

single-point automatic tank thermometer

spot automatic tank thermometer

automatic tank thermometer (3.1) that measures the temperature at a particular point in a tank by the spot temperature element

3.4

multiple-point automatic tank thermometer

automatic tank thermometer (3.1) consisting of multiple (usually three or more) spot temperature elements to measure the temperature(s) at selected liquid level(s)

Note 1 to entry: The readout equipment should average the readings from the submerged temperature elements to compute the average temperature of the liquid in the tank and may also display the temperature profile in the tank.

3.5

temperature transmitter

instrument that typically provides electrical power to the temperature element(s), converts the temperature measured by the element(s) to an electrical or electronic signal, and transmits the signal to a remote readout

Note 1 to entry: A local readout may be provided. Often, the function of the temperature transmitter is provided by the level transmitter of the automatic level gauge

4 Precautions

4.1 Safety precautions

Relevant international standards, classification society rules and the International Safety Guide for Oil Tankers and Terminals (ISGOTT)^[4] containing regulations on safety and material-compatibility precautions should be followed when using marine ATT equipment. In addition, the manufacturer's recommendations on the use and installation of the equipment should be followed. All requirements covering entry into hazardous areas are expected to be observed.

4.2 Equipment precautions

4.2.1 All marine ATTs should be capable of withstanding the pressure, temperature and other environmental conditions likely to be encountered in marine service. When an ATT is installed in a corrosive service, any parts exposed to the liquid or vapour should be of durable, corrosion-resistant construction to avoid both product contamination and ATT corrosion. All ATTs should be sealed to withstand the vapour pressure of liquid in the tank. ATTs mounted on vessels with an inert gas system (IGS) should be designed to withstand the operating pressure of the IGS.

4.2.2 All marine ATTs should be specified and installed according to appropriate marine electrical safety standards, including those developed by the IMO, IEC, CENELEC, ISGOTT and ISO. ATTs should be certified for use in the hazardous-area classification appropriate to their installation.

4.2.3 All external metal parts of ATTs mounted on tanks should be firmly connected to an electrical earth, i.e. the ship's hull.

4.2.4 All ATT equipment should be maintained in safe operating condition and the manufacturer's maintenance instructions should be complied with.

4.3 General precautions

4.3.1 The general precautions given in 4.3.2 to 4.3.6 apply to all types of ATTs and should be observed where they are applicable.

4.3.2 Tank levels should be measured and recorded simultaneously, or as close as practical, as the tank temperature is measured. For more details on level measurement, refer to ISO 4266-2.

4.3.3 Temperatures measured for bulk transfer should be recorded when they are taken, unless the remote readout equipment of the ATT automatically records the temperatures periodically.

4.3.4 In the case of multiple port loading and/or discharge, the same general procedures should be used to measure a tank temperature before product transfer (opening gauge) and after product transfer (closing gauge).

4.3.5 ATTs should provide security to prevent unauthorized adjustment or tampering. ATTs used in fiscal/custody transfer applications should provide facilities to allow sealing to prevent unauthorized calibration adjustment.

This protection can require mounting the ATT sensor(s) in a thermowell.

ATT sensors can be an integral part of the ALG level sensor assembly (e.g. float and tape, pole). Some design (e.g. float and tape) can require the level/temperature sensor assembly to be raised to a “store” position when it is not being used. Such ATTs shall not be used during tank washing.

4.3.6 The design and installation of ATTs can be subject to the approval of the national measurement organization, who will normally have issued a type or pattern approval (“Type Approval”) for the design of the ATT for the particular service for which it is to be employed. Type approval is normally issued after an ATT has been subjected to a specific series of tests and is subject to the ATT being installed in an approved manner. Type approval tests may include the following: visual inspection, performance, vibration, humidity, dry heat, inclination, fluctuations in power supplies, insulation, resistance, electromagnetic compatibility and high voltage.

5 Accuracy

5.1 General

The accuracy of petroleum temperatures taken by the ATTs should be consistent with the accuracy of the levels taken by the automatic level gauging system so that the overall accuracy of the standard volume measurement is not seriously degraded. Observance of the accuracy requirements for level and temperature gauging systems given in ISO 4266-2 and in this document are expected to ensure overall accuracy of the standard volume measurement.

5.2 Intrinsic error of ATTs

The intrinsic error of the ATT, i.e. the accuracy of the ATTs when tested under controlled conditions as specified by the manufacturers, can be a major component of the uncertainty of the temperature measurement of the ATT as installed. It is presupposed that the calibration reference device used to calibrate the ATT is traceable to appropriate national standards.

NOTE The temperature elements and onboard transmitters used for fixed, automatic tank temperature measurement are calibrated prior to installation. The transmitters normally do not provide on-board calibration adjustments.

5.3 Calibration prior to installation

5.3.1 General

The ATT can be calibrated or verified either as a system or by components.

5.3.2 ATT calibrated as a system

If verified as a system, the temperature reading of the ATT readout should agree with the temperature reading of the thermostatically controlled reference bath or oven temperature within 0,25 °C at a minimum of three test temperatures spanning the anticipated working range of the ATT.

5.3.3 ATT calibrated by components

If the ATT is verified by components:

- a) the temperature equivalent of the measured resistance should agree with the bath temperature within 0,20 °C at each temperature;
- b) the temperature transmitter/converter and the ATT readout should be checked using precision resistors or a recently calibrated thermal calibrator. The ATT readout should agree with the temperature equivalent of the resistors or calibrator within 0,15 °C at each temperature.

5.3.4 Multiple-point ATTs

The required accuracy for each spot temperature sensor should be as given in [5.3.2](#) or [5.3.3](#), depending on the method used.

5.3.5 Uncertainty of the reference

The uncertainty of the reference should not exceed $\pm 0,05$ °C.

5.4 Error caused by installation and operating conditions

The total error of the ATT for custody transfer service can be affected by the installation and by variations in the operating conditions.

NOTE 1 The accuracy of an ATT depends on the following:

- the number of temperature-sensing elements;
- the location of the temperature-sensing elements.

NOTE 2 The tank content's temperature can be subject to stratification which varies with:

- cargo-heating method and/or location of heating coils;
- multiple sources of supply;
- viscosity of the liquid in the tanks;
- tank insulation;
- adjacent tank temperatures, and
- sea water temperature for tanks in contact with the ship's hull and bottom.

NOTE 3 Temperatures in large tanks (i.e. 750 m³ or larger) are often vertically stratified unless the contents are thoroughly mixed. Larger stratification can be expected in high-viscosity petroleum liquids. Temperatures in wing tanks can also be horizontally stratified due to the effect of the sea temperature.

5.5 Overall accuracy

5.5.1 General

The overall accuracy of temperature measurement by the ATT, as installed, is limited by the intrinsic error of the ATT equipment (temperature-sensing element, transmitter and readout), the effect of installation methods, and the effect of the operating conditions.

5.5.2 Use of ATT for fiscal/custody transfer purposes

In tanks with vertical temperature stratification, the temperature gradient is rarely linear. An average temperature should be used for fiscal/custody transfer services. It is possible that the mid-level temperature of the tank contents does not give an accurate average temperature.

An ATT system should be considered suitable for fiscal/custody transfer services if the ATT system meets the following on-board verification tolerances specified in [9.2.2](#) and [9.3.2](#).

The ATT should meet the calibration tolerances prior to installation (see [5.3](#)).

Including the effects of installation methods and changes in operating conditions, the ATT should meet the on-board verification tolerance specified in [9.2.2](#) and [9.3.2](#).

The remote readout, if used, should meet the recommendations of [Clause 10](#).

6 Selection of ATTs

6.1 General

Copper or platinum temperature element bulbs, i.e. resistance temperature detectors (RTDs), are normally used for this application. The following types of ATT elements are widely used:

- single-point (or spot) ATT;
- multiple-point ATT.

Other types of ATT elements, which provide comparable performance, may be used.

The selection of a suitable ATT should be made based on the following criteria:

- a) the accuracy required;
- b) the operating conditions which may affect the accuracy (e.g. expected product temperature stratification);
- c) the minimum level in the tank at which temperature measurement is required;
- d) environmental conditions;
- e) number, type and size of the tanks;
- f) requirement for local and remote readout, signal transmission, and cabling.

6.2 ATTs for fiscal/custody transfer purpose

Tanks using an automatic method to determine temperature in fiscal/custody transfer should preferably be fitted with a multiple-point ATT, except when:

- the cargo tanks have a capacity less than 159 m³ (1 000 barrels), or the level is less than 3 m;
- the maximum vertical temperature variation is less than 1 °C, and the manual average temperature measurement has been used to verify temperature stratification.

NOTE Single-point or spot tank temperature measurement can be used when the temperature of the liquid in the cargo tank is considered to be uniform, or when any temperature stratification in the tank has been shown to be small and acceptable (see ISO 4268).

7 Description of ATT equipment — Electrical temperature elements

7.1 General

Copper or platinum electrical-resistance detectors (RTDs) are normally used for temperature measurement for fiscal/custody transfers because of their high accuracy and stability. Other types of temperature elements (e.g. thermocouples, thermistors, semiconductors, fibre optics) are available. Unless calibrated and meeting the verification tolerance given in [Clause 5](#), their accuracy is not considered suitable for fiscal/custody transfer services.

8 Installation of marine ATTs

8.1 General

Marine ATTs should be installed in accordance with the ATT and ALG manufacturer's instructions.

8.2 Location of temperature-sensing element(s)

The single-point (spot) and/or multiple-point temperature-sensing elements should be installed close to a vapour lock valve, gauging hatch, or other suitable gauging access point. The following methods of installation are commonly used.

- a) The elements are installed in a metal thermowell through the deck (tank roof). This vertical thermowell should allow for one or more (usually three) temperature-sensing elements to be mounted from the deck, suspended by their individual metal cabling, down to various depths in the tank. When three temperature-sensing elements are used, they should be located respectively in the upper third (approximately 70 % to 80 % of the tank height), in the middle (approximately 40 % to 50 % of the tank height) and in the lower third (approximately 15 % to 20 % of the tank height).
- b) The elements are installed as an integral part of ALGs with level-sensing element(s) in contact with the liquid. The height of each temperature element can depend on the ALG mounting.

For both of the above methods a) and b), the ullage corresponding to the depth of each individual temperature-sensing element for each tank should be readily available for the operator, together with other ALG/ATT system data.

8.3 Location of manual (temperature) gauge hatch

To permit accurate comparison between manual and automatic temperature measurement, the ATT deck penetration should be close (e.g. preferably within 1 m) to a location where manual gauging can be performed.

8.4 Temperature measurement of inerted tanks

On cargo tanks connected to the vessel's inert gas system (IGS), the ATT should be designed and installed so that it can be maintained and calibrated without depressurizing the IGS.

9 Calibration and on-board verification of marine ATTs

9.1 General

The ATT, including the temperature element(s), the transmitter and the readout, selected for temperature measurement for fiscal/custody transfers, should meet the calibration tolerances given in [Clause 5](#). It is expected that the calibration reference for an ATT is traceable to appropriate national standards.

NOTE 1 The precision electronic temperature elements and on-board transmitters/converter used for fixed, automatic tank temperature measurement are calibrated prior to installation. The transmitters normally do not provide on-board calibration adjustments.

NOTE 2 The purpose of the following procedures is to verify the adequacy of the calibration and the accuracy of the ATT (including the temperature elements, the transmitter, and the local/remote readout) as installed.

When an ATT is checked or calibrated by manual temperature measurement, the manual temperature measurement should be performed according to ISO 4268. The uncertainty of the field calibration reference should not exceed 0,1 °C (with any necessary calibration corrections applied).

The ATT can be calibrated/verified either as a system or by components.

9.2 Calibration of single-point temperature element ATTs for fiscal/custody transfer purposes

9.2.1 Calibration prior to installation

Prior to installation, single-point ATTs should be calibrated, under controlled conditions (i.e. in the factory or in a testing laboratory), in one of the two ways described below. It is expected that the calibration reference for an ATT should be traceable to appropriate national standards.

- a) The ATT (including the temperature sensors, the temperature transmitter/converter, and the readout) as a whole may be calibrated with constant temperature baths, at three or more temperatures covering the operating range. The bath temperatures should be measured by reference thermometer(s) (see [5.3.2](#) for the required accuracy).
- b) Alternatively, the components of the ATT may be separately calibrated. The resistance of the temperature element should be measured in the bath. Separately, precision resistors, or a thermal calibrator, should be used to simulate temperature input to the temperature transmitter/converter and readout of the ATT (see [5.3.3](#) for the required accuracy). It is expected that the thermal calibrator is recently calibrated against a reference traceable to a national standard.

9.2.2 Initial verification at shipyard or during sea trials

9.2.2.1 General

Initial verification and adjustment procedures at the shipyard or during sea trials should be performed according to the ATT manufacturer's instructions. In addition, one of the procedures given in [9.2.2.2](#) or [9.2.2.3](#) should be used, if practical.

9.2.2.2 Verification by components

9.2.2.2.1 Temperature element

Use a recently calibrated, portable electronic thermometer (PET) to verify the measurement by the temperature element. With the cargo tank filled, lower the thermometer to the depth at which the element is located and move the PET up and down (over a range of approximately 300 mm) until the temperature

is stable. The temperature measured by the RTD temperature sensor should agree with the temperature measured by the calibrated, portable electronic thermometer within 0,75 °C.

NOTE The tolerance is larger than that for shore-tank-based ATT systems because the location where manual temperature measurements are taken with a portable electronic thermometer (through a vapour lock valve or other suitable gauging access point) is often not close to the location of the ATT temperature elements, and there are other additional factors which can result in marine cargo temperature measurement being less precise (see [Annex A](#)).

9.2.2.2.2 Temperature transmitter

The ATT, excluding the temperature element, can be verified by using a temperature calibrator (e.g. precision resistors or a thermal calibrator) to simulate temperature input at three or more temperatures covering the expected tank operating temperatures. The readout for each temperature element of a multiple-point ATT should agree with the temperature equivalent of the resistors within 0,25 °C at each temperature.

9.2.2.3 Verification as a system

As an alternative to separate calibration checks of the temperature element and the transmitter, a portable electronic thermometer (PET), calibrated immediately prior to verification, may be used to verify the entire ATT, preferably with the cargo tanks nearly full and all temperature elements submerged. Since there is a possibility that the PET cannot be placed close to the temperature element, and because slight horizontal temperature stratification can exist, it is possible that the measurement by the thermometer does not agree completely.

The temperature read by the ATT system (temperature sensor, temperature transmitter/converter, and readout) should agree with the temperature measured by a recently calibrated, portable electronic thermometer within 1 °C.

It is expected that the PET is calibrated against a reference traceable to a national standard.

NOTE The tolerance is larger than that for shore-tank-based ATT systems because the location where manual temperature measurements are taken with the PET (through a vapour lock valve or other suitable gauging access point) is often not close to the location of the ATT temperature elements, and there are other additional factors which can result in marine cargo temperature measurement being less precise (see [Annex A](#)).

9.3 Calibration of multiple-point ATTs for fiscal/custody transfer purposes

9.3.1 Calibration prior to installation

Each point (i.e. temperature sensing element) of the ATT should be checked following the calibration procedure described in [9.2.1](#) for single-point ATTs (see [5.3.4](#) for the required accuracy).

9.3.2 Initial on-board verification at shipyard or during sea trials

9.3.2.1 General

Initial verification and adjustment procedures at the shipyard or during sea trials should be according to the ATT manufacturer's instructions. In addition, one of the two procedures described in [9.3.2.2](#) or [9.3.2.3](#) should be followed, if practical.

9.3.2.2 Verification by components

9.3.2.2.1 Temperature element

It is recommended to use a recently calibrated portable electronic thermometer to verify the measurement by the temperature element. With the cargo tank almost full, the thermometer should be lowered to the depths at which the RTDs are located and the thermometer moved up and down (over a range of approximately

300 mm) until the temperature is stable. Each temperature sensor (of a multiple-point ATT) should agree with the temperature measured by the calibrated portable electronic thermometer within 0,75 °C.

NOTE The tolerance is larger than that for shore-tank-based ATT systems because the location where manual temperature measurements are taken with a portable electronic thermometer (through a vapour lock valve or other suitable gauging access point) is often not close to the location of the ATT temperature elements, and there are other additional factors which can result in marine cargo temperature measurement being less precise (see [Annex A](#)).

9.3.2.2.2 Temperature transmitter

The ATT, excluding the temperature element, can be verified by using a temperature calibrator (e.g. precision resistors or a thermal calibrator) to simulate temperature input at three or more temperatures covering the expected tank operating temperatures. The ATT readout should agree with the temperature equivalent of the resistors within 0,25 °C at each temperature.

9.3.2.3 Verification as a system

As an alternative to separate calibration checks of the temperature element and the transmitter, a portable electronic thermometer (PET), calibrated immediately prior to the verification, can be used to verify the entire ATT. The tank should preferably be nearly full with all temperature elements submerged. However, an “upper-middle-lower” ATT, which automatically adjusts according to the liquid level, does not require the tank to be full. It is recommended to take temperature measurements at the depths of the temperature elements. At each measurement location, the PET should be moved up and down (over a range of approximately 300 mm) until the temperature is stable. The manual average temperature read by the PET is the average of the readings. The average temperature read by the ATT is the average temperature of all temperature elements submerged in the liquid.

The average temperature read by the ATT system should agree with the average of the temperatures read by the calibrated PET within 1 °C.

It is expected that the PET is calibrated against a reference traceable to a national standard.

NOTE The tolerance is larger than that for shore-tank-based ATT systems because the location where manual temperature measurements are taken with the PET (through a vapour lock valve or other suitable gauging access point) is often not close to the location of the ATT temperature elements, and there are other additional factors which can result in marine cargo temperature measurement being less precise (see [Annex A](#)).

9.4 Subsequent verification of ATTs

9.4.1 General

A regular verification programme should be established for ATTs used in fiscal/custody transfer. All essential components of the ATT installation should be checked as recommended by the manufacturer's instructions. Each ATT should be inspected and its calibration verified using the procedure described in [9.2.2](#) or [9.3.2](#) (initial field verification).

9.4.2 Frequency of subsequent verification

The ATT should initially be inspected and its calibration verified at least once per quarter. If operating experience confirms stable performance within the verification tolerance, the verification schedule can be extended to once per year.

ATTs used for fiscal/custody transfer measurement should be verified on a monthly basis.

9.4.3 Record keeping

Full records should be kept of the initial calibration and the periodic verifications of each ATT used for fiscal/custody transfer. The records should be kept for a minimum of one year or 20 voyages.

10 Data communication and receiving

This clause gives recommendations for the specification of the communication between temperature transmitter(s) and receiver(s) or vice versa.

The remote readout of an acceptable ATT may be used for custody transfer provided that the whole system, including the remote readout, meets the calibration tolerances given in [Clause 5](#) of this document.

NOTE 1 Some readout equipment can be programmed to alarm at high at low temperatures.

NOTE 2 Some ATTs do not provide temperature readout locally at the tank.

The ATT should be designed and installed such that data transmission and receiving should:

- not compromise the accuracy of the measurement, i.e. the difference between the temperatures displayed by the remote receiving unit and displayed (or measured) by the temperature transmitter at the tank should not exceed 0,1 °C,
- not compromise the resolution of the measurement output signal,
- provide proper security and protection of the measured data to ensure its integrity,
- provide adequate speed to meet the update time required for the receiving unit, and
- be electromagnetically immune.

STANDARDSISO.COM : Click to view the full PDF of ISO 4266-5:2024