

INTERNATIONAL  
STANDARD

**ISO**  
**9088**

First edition  
1997-03-01

---

---

**Carbonaceous materials used for the  
production of aluminium — Cathode blocks  
and prebacked anodes — Determination of  
the density in xylene by a pycnometric  
method**

*Produits carbonés utilisés pour la production de l'aluminium — Blocs  
cathodiques et anodes précuites — Détermination par pycnométrie de la  
masse volumique en xylène*



Reference number  
ISO 9088:1997(E)

## Foreword

ISO (the International Organization for Standardization) is a worldwide federation of national standards bodies (ISO member bodies). The work of preparing International Standards is normally carried out through ISO technical committees. Each member body interested in a subject for which a technical committee has been established has the right to be represented on that committee. International organizations, governmental and non-governmental, in liaison with ISO, also take part in the work. ISO collaborates closely with the International Electrotechnical Commission (IEC) on all matters of electrotechnical standardization.

Draft International Standards adopted by the technical committees are circulated to the member bodies for voting. Publication as an International Standard requires approval by at least 75 % of the member bodies casting a vote.

International Standard ISO 9088 was prepared by Technical Committee ISO/TC 47, *Chemistry*, Subcommittee SC 7, *Aluminium oxide, cryolite, aluminium fluoride, sodium fluoride, carbonaceous products for the aluminium industry*.

STANDARDSISO.COM : Click to view the full PDF of ISO 9088:1997

© ISO 1997

All rights reserved. Unless otherwise specified, no part of this publication may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without permission in writing from the publisher.

International Organization for Standardization  
Case postale 56 • CH-1211 Genève 20 • Switzerland  
Internet: central@iso.ch  
X.400: c=ch; a=400net; p=iso; o=isocs; s=central

Printed in Switzerland

# Carbonaceous materials used for the production of aluminium — Cathode blocks and prebaked anodes — Determination of the density in xylene by pycnometric method

## 1 Scope

This International Standard specifies a pycnometric method for the determination of the true density in xylene of cathode blocks and prebaked anodes used for the production of aluminium.

## 2 Normative references

The following standards contain provisions which, through reference in this text, constitute provisions of this International Standard. At the time of publication, the editions indicated were valid. All standards are subject to revision, and parties to agreements based on this International Standard are encouraged to investigate the possibility of applying the most recent editions of the standards indicated below. Members of IEC and ISO maintain registers of currently valid International Standards.

ISO 3507:1976, *Pycnometers*.

ISO 8007:1985, *Carbonaceous materials used in the production of aluminium — Sampling from cathodic blocks and prebaked anodes — General*.

## 3 Principle

The true density of cathode blocks and prebaked anodes is measured in xylene in a pycnometer after degassing under a vacuum.

## 4 Reagents and materials

During the determination, unless otherwise stated, use only reagents of recognized analytical grade and only distilled water, or water of equivalent purity, degassed by boiling for 1 h.

**4.1 Ethanol**, 95 % (V/V).

**4.2 Acetone**.

**4.3 Sulfuric acid**, density approx. 1,84 g/ml, about 98 % (m/m) solution.

**4.4 Xylene**, commercial grade, density about 0,86 g/ml.

**WARNING** — Xylene burns the skin and can also be absorbed into the system through the skin. In addition, inhalation of the vapour from hot material is to be avoided.

## 5 Apparatus

**5.1 Pyknometer**, type 3 as defined in ISO 3507 (Gay-Lussac), capacity 25 ml.

**5.2 Degassing apparatus** (see figure 1), comprising the following items:

**5.2.1 Container (1) for the pyknometer**, consisting of a glass beaker (2) with removable lid (3) and O-ring (4), capable of containing the pyknometer without its stopper. The container outlet (5) is connected to a pump (not shown).

**5.2.2 Filling device (6)**, fitted to the container by a ground-glass joint (7). A tube (8) extends down into the pyknometer. A reservoir (9) with a ground-glass stopper (10) contains the pyknometer liquid which is allowed to flow into the pyknometer through a teflon valve (11).

**5.2.3 Stand (12)**, to support the beaker when no vacuum is applied to the degassing apparatus. A rod (13) with a spring (14) allows the beaker (2), with the pyknometer in it, to be shaken to facilitate the evolution of a gas bubbles during degassing.

The apparatus is made of glass. A rotary pump is connected to the outlet of the apparatus via an oil trap (15). A manometer (16) is connected to the vacuum system between the pump and the oil trap. The vacuum is adjusted so that the manometer, which is about 600 mm from the joint (7) between the container and the filling device, registers  $1,3 \text{ kPa} \pm 0,3 \text{ kPa}$ . A valve (17) is fitted to allow air back into the apparatus. This has to be done slowly and with due care.

NOTE — At a pressure of  $1,3 \text{ kPa} \pm 0,3 \text{ kPa}$  and an ambient temperature of  $25 \text{ }^\circ\text{C}$ , slight vapourization of xylene may occur until equilibrium is reached, but this is of no consequence.

The apparatus described above is only an example; other apparatus with the same characteristics may be used.

**5.3 Drying oven**, capable of being maintained at  $120 \text{ }^\circ\text{C} \pm 2 \text{ }^\circ\text{C}$ .

**5.4 Thermostatically controlled bath**, capable of being maintained at  $25 \text{ }^\circ\text{C} \pm 0,05 \text{ }^\circ\text{C}$ .

**5.5 Grinder**, capable of grinding the sample to a particle size of less than  $63 \text{ }\mu\text{m}$ . The parts which come into contact with the sample shall be made of hardmetal to avoid contamination.

**5.6 Filter paper**.

**5.7 Jaw-type crusher**.

## 6 Sampling

Sample in accordance with ISO 8007.



## 7 Procedure

### 7.1 General

Carry out all weighings to an accuracy of 0,1 mg. When the pycnometer contains a liquid, stabilize its temperature in the thermostatically controlled bath (5.4) at  $25\text{ °C} \pm 0,05\text{ °C}$  before weighing.

### 7.2 Preparation of the sample

Drill a cylinder or cut a piece out of the carbon block and crush it into small pieces using the jaw-type crusher (5.7).

Grind the sample to a particle size of  $< 63\text{ }\mu\text{m}$  using the grinder (5.5). Store the ground material in an airtight container until required for the determination. Before the determination, dry the sample in the drying oven (5.3) at  $120\text{ °C} \pm 2\text{ °C}$  for 8 h. Then cool in a desiccator containing silica gel.

NOTE — In order to avoid the need to verify the particle size of each sample, it is advisable to determine the grinding conditions which will enable the required particle size to be obtained with each sample type (carbon blocks, cathode blocks, prebaked anodes), using the grinder available. This can be done with any apparatus capable of determining the size of such particles.

### 7.3 Calibration of the pycnometer

Commercial pycnometers are usually calibrated at  $20\text{ °C}$ , whereas the present determination is carried out at  $25\text{ °C}$ . It is therefore necessary to calibrate the pycnometer at this temperature.

#### 7.3.1 Determination of pycnometer mass

Wash the pycnometer (5.1) with warm concentrated sulfuric acid solution (4.3), taking all necessary precautions. Rinse carefully, first with running tap water, then with distilled water, then with ethanol (4.1), and finally with acetone (4.2). Weigh the perfectly dry pycnometer to the nearest 0,1 mg (mass  $m_0$ ).

#### 7.3.2 Determination of pycnometer volume

Fill the pycnometer with distilled water degassed at  $23\text{ °C}$  to  $24\text{ °C}$ , with the ground-glass stopper firmly inserted and the pycnometer cleaned of excess water with filter paper (5.6).

Place the filled pycnometer in the thermostatically controlled bath and heat to  $25\text{ °C} \pm 0,05\text{ °C}$ . During heating, remove the liquid which emerges from the capillary carefully with filter paper. When no more water runs out, the pycnometer has reached the temperature of the bath. Remove it from the bath and dry it carefully. To avoid the pycnometer overflowing due to the absorption of heat from the hand, it may be briefly chilled in cooler water or with acetone (4.2) before drying it. Weigh the pycnometer, which shall be completely dry on the outside, to the nearest 0,1 mg (mass  $m_1$ ).

The volume  $V$ , in millilitres, of the pycnometer is given by the equation

$$V = \frac{m_1 - m_0}{0,997\,05}$$

where

$m_0$  is the mass, in grams, of the clean, dry, empty pycnometer;

$m_1$  is the mass, in grams, of the pycnometer filled with distilled and degassed water;

0,997 05 is the density of water, in grams per millilitre, at  $25\text{ °C}$ .

Determine the pycnometer volume several times on different days to eliminate the effect of external influences, as well as any small differences in the temperature of the bath. The result shall be taken as the mean of 8 to 10 determinations. Individual values shall not deviate from the mean value by more than  $\pm 0,0015$  ml.

Round the result to the nearest 0,001 ml.

### 7.3.3 Frequency of calibration

Repeat the calibration at least every 3 months. The mass  $m_0$  shall remain constant to  $\pm 1$  mg.

NOTE — Since no two pycnometers have exactly the same volume, each pycnometer has to be calibrated individually. It is not necessary to check the volume every time the pycnometer is used for a series of density determinations, for instance, although it is usual to check the mass each time.

## 7.4 Determination of the density of the xylene (4.4)

Follow the procedure described in 7.3.2. The density of the xylene,  $\rho_x$ , expressed in grams per millilitre, is given by the equation

$$\rho_x = \frac{m_2 - m_0}{V}$$

where

$m_0$  and  $V$  are as defined in 7.3.2;

$m_2$  is the mass, in grams, of the pycnometer filled with xylene (4.4).

The result shall be taken as the mean of 10 determinations made over a number of days to eliminate the effect of external influences.

## 7.5 Determination of the density of the sample

### 7.5.1 Test portion

Weigh, to the nearest 0,1 mg,  $5 \text{ g} \pm 0,1 \text{ g}$  of the sample (see 7.2) (mass  $m_3$ ) into the clean, dry, empty pycnometer, prepared in accordance with 7.3.1.

### 7.5.2 Determination

The determination shall not be carried out if the ambient temperature exceeds 30 °C.

Place the pycnometer, containing the test portion but without its stopper, in the container of the degassing apparatus (5.2). Before adding xylene, evacuate for 15 min to a residual pressure of  $1,3 \text{ kPa} \pm 0,3 \text{ kPa}$  with the xylene feed closed. This pressure is necessary for a repeatability of  $\pm 0,004 \text{ g/ml}$  (see 8.2). If a precision of only  $\pm 0,01 \text{ g/ml}$  is required, a pressure of  $2,6 \text{ kPa} \pm 0,3 \text{ kPa}$  is sufficient.

Add xylene drop by drop to the pycnometer. When the test portion is covered with 20 mm of xylene at the most, interrupt the addition of xylene. Continue the evacuation of air, occasionally shaking the pycnometer and the support, until the evolution of air bubbles has stopped. In general, this takes up to 60 min.

Slowly allow air to enter the degassing apparatus. Remove the pycnometer and fill with xylene to the lower edge of the ground.

Allow the test portion to settle for at least 30 min, completely fill the pycnometer with xylene and insert the stopper. Remove from the outside of the pycnometer any xylene which overflows.

Repeat the procedure given in the second paragraph of 7.3.2 ("Place the filled pyknometer..."). Weigh the pyknometer containing the test portion and xylene to the nearest 0,1 mg (mass  $m_4$ ).

## 7.6 Checking the determination

The apparatus can be checked for systematic errors by carrying out determinations on standard samples from time to time.

## 8 Expression of results

### 8.1 Method of calculation

The density  $\rho$  of the sample, expressed in grams per millilitre, is given by the equation

$$\rho = \frac{m_3}{V - \left[ \frac{m_4 - (m_0 + m_3)}{\rho_x} \right]}$$

where

$V$  and  $m_0$  are as defined in 7.3.2;

$\rho_x$  is as defined in 7.4;

$m_3$  is the mass, in grams, of the test portion (see 7.5.1);

$m_4$  is the mass, in grams, of the pyknometer containing the test portion and xylene.

Round the result to the third decimal place.

### 8.2 Precision

#### 8.2.1 General

The precision data for this method were obtained in accordance with ISO 5725:1986, *Precision of test methods — Determination of repeatability and reproducibility for a standard test method by inter-laboratory tests* (now withdrawn).

#### 8.2.2 Repeatability, $r$

The results of two determinations carried out on the same sample under repeatability conditions (same operator, same apparatus, short time interval between the determinations) may be considered to be acceptable if they do not differ by more than 0,004 g/ml.

#### 8.2.3 Reproducibility, $R$

The results of two determinations carried out on the same sample under reproducibility conditions (different operators, different apparatus, different times) may be considered to be acceptable if they do not differ by more than 0,006 g/ml.

## 9 Test report

The test report shall include the following particulars:

- a) all details necessary for identification of the sample;
- b) a reference to this International Standard;
- c) the result of the determination, and the units in which it has been expressed;
- d) details of any unusual features noted during the determination;
- e) details of any operation not included in this International Standard or in the International Standards to which reference is made, as well as any operation regarded as optional.

STANDARDSISO.COM : Click to view the full PDF of ISO 9088:1997