

Submitted for recognition as an American National Standard

(R) Air-to-Air Charge Air Cooler (CAC) Internal Cleanliness

1. **Scope**—This SAE Standard outlines the acceptance criteria and procedure for determining the internal cleanliness of CAC assemblies ready for installation in the engine air intake loop in vehicular or stationary applications.
2. **References**
 - 2.1 **Related Publication**—The following publication is provided for information purposes only and is not a required part of this document.
 - 2.1.1 SAE PUBLICATION—Available from SAE, 400 Commonwealth Drive, Warrendale, PA 15096-0001.

SAE J1148—Engine Charge Air Cooler Nomenclature
3. **Acceptance Criteria**¹—Completed CAC assemblies shall meet the following internal cleanliness criteria:
 - a. Maximum Weight of Debris = 25.0 mg (8.82×10^{-4} oz)
 - b. Maximum Debris Particle Size = 3.175 mm (0.125 in)
 - c. Maximum Debris Particle Area = 2.58 mm² (0.004 in²)

Particles for dimensional analysis include sand, scale, cleaning shot, machining chips, weld spatter, slag, or particles not easily broken with a probe.

1. Confirm applicability of this criteria with your specific engine manufacturer.

SAE Technical Standards Board Rules provide that: "This report is published by SAE to advance the state of technical and engineering sciences. The use of this report is entirely voluntary, and its applicability and suitability for any particular use, including any patent infringement arising therefrom, is the sole responsibility of the user."

SAE reviews each technical report at least every five years at which time it may be reaffirmed, revised, or cancelled. SAE invites your written comments and suggestions.

TO PLACE A DOCUMENT ORDER: (724) 776-4970 FAX: (724) 776-0790
SAE WEB ADDRESS <http://www.sae.org>

4. **Test Method**—The apparatus and procedure for determining CAC internal cleanliness is described as follows:

4.1 Apparatus

5.0 μ Qualitative Grade Filter Paper
0.5 μ Membrane Filter Paper
Filtering Assembly
Vacuum Filtering Flask
Beakers
Reagent Grade Solvent, i.e.: Methanol²
Analytical Balance Sensitive to 0.1 mg
Drying Oven
Desiccator
Tweezers
Magnification Device with Scale

4.2 Procedure

- a. All glassware and the test area used for determining CAC compliance with this document must be clean and free from debris.
- b. Filter the selected test solvent through a 0.5 μ membrane filter paper.
- c. Place a 5.0 μ qualitative grade filter paper in the drying oven at 100 °C (212 °F) for 15 min. Remove filter paper from drying oven and place in a desiccator to cool to 20 °C (68 °F). Remove filter paper from the desiccator and weigh it to the nearest 0.1 mg (3.5×10^{-6} oz) with an analytical balance. Record tare weight of filter paper as W_{t0} .
- d. Lay the CAC horizontal on one of its faces. Pour a volume of filtered solvent equal to 40% of the total internal volume of the CAC into the CAC air inlet, and cap the air inlet and outlet portals.
- e. Tip the CAC back and forth in such a manner that the inlet and outlet tanks are alternatively filled with solvent. Repeat the back and forth tipping for 10 cycles to insure that the solvent flushes all the internal surfaces. Tipping the CAC back and forth so that the solvent flows from one tank to the other and then back to the first tank is equal to 1 cycle.
- f. Drain the solvent from the air outlet portal of the CAC into a beaker. Filter the solvent through the previously prepared and weighed 5.0 μ filter paper, which has been set up in the vacuum filtering assembly.
- g. The spent filtrate can be used for future CAC testing after it has been filtered through a 0.5 μ filter paper.
- h. Remove the filter paper from the filtering assembly and place it in the drying oven at 100 °C (212 °F) for 15 min. Remove the filter paper from the drying oven and place it in a desiccator to cool to 20 °C (68 °F). Remove the filter paper from the desiccator and weigh it to the nearest 0.1 mg (3.5×10^{-6} oz) with an analytical balance as W_{te} .
- i. The dry weight of the filter paper with the debris residue (W_{te}) minus the tare weight of the filter paper (W_{t0}) equals the debris weight (W_{td}). Compare the measured debris weight (W_{td}) to the debris weight limit to determine if this requirement has been met.
- j. With the magnification device and its included optical scale, measure the maximum and minimum linear dimensions of the debris particles on the filter paper. Calculate the area of the debris particles. Compare the measured debris particle sizes to the debris size limit and compare the calculated debris particle areas to the debris particle area limit to determine if these requirements have been met.

2. This is highly volatile and flammable solvent and should be handled accordingly. Methanol is compatible with most metallic and non-metallic CAC component parts. If possible, CAC component part compatibility with methanol should be confirmed prior to testing.

k. The report should include the following:

1. Customer Part Number
2. Manufacturer's Part Number
3. Date of Manufacture
4. Debris Weight and Particle Size Results

5. Notes

5.1 Marginal Indicia—The change bar (I) located in the left margin is for the convenience of the user in locating areas where technical revisions have been made to the previous issue of the report. An (R) symbol to the left of the document title indicates a complete revision of the report.

PREPARED BY THE SAE COOLING SYSTEMS STANDARDS COMMITTEE

SAENORM.COM : Click to view the full PDF of J1726_200011