



<b>SURFACE VEHICLE RECOMMENDED PRACTICE</b>	<b>J2517™</b>	<b>OCT2022</b>
	Issued 2000-06 Reaffirmed 2016-08 Revised 2022-10	Superseding J2517 AUG2016
Hybrid III Family Chest Potentiometer Calibration Procedure		

RATIONALE

SAE J2517 has been revised to replace references to Engineering Aids 25 and 26 with references to SAE J2860 and SAE J2862 where applicable. Also added references to SAE J2858.

TABLE OF CONTENTS

1.	SCOPE AND PURPOSE .....	2
2.	REFERENCES .....	2
2.1	Applicable Documents .....	2
2.1.1	SAE Publications .....	2
2.2	Related Publication .....	3
2.2.1	Federal Publication .....	3
3.	CALIBRATION PROCEDURE .....	3
3.1	Chest Potentiometer Assembly .....	3
3.2	Calibration Fixture .....	3
3.3	Calibration Procedure .....	5
3.4	Use of the Calibration Coefficients .....	6
4.	NOTES .....	6
4.1	Revision Indicator .....	6
APPENDIX A	SAMPLE HIII-5F CHEST POTENTIOMETER CALIBRATION VALUES .....	7
Figure 1	Calibration fixture side view .....	4
Figure 2	Calibration fixture front view .....	4

SAENORM.COM Click to view the full PDF of J2517\_202210

SAE Technical Standards Board Rules provide that: "This report is published by SAE to advance the state of technical and engineering sciences. The use of this report is entirely voluntary, and its applicability and suitability for any particular use, including any patent infringement arising therefrom, is the sole responsibility of the user."

SAE reviews each technical report at least every five years at which time it may be revised, reaffirmed, stabilized, or cancelled. SAE invites your written comments and suggestions.

Copyright © 2022 SAE International

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or transmitted, in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of SAE.

**TO PLACE A DOCUMENT ORDER:** Tel: 877-606-7323 (inside USA and Canada)  
 Tel: +1 724-776-4970 (outside USA)  
 Fax: 724-776-0790  
 Email: CustomerService@sae.org  
 http://www.sae.org

SAE WEB ADDRESS:

For more information on this standard, visit  
[https://www.sae.org/standards/content/J2517\\_202210/](https://www.sae.org/standards/content/J2517_202210/)

## 1. SCOPE AND PURPOSE

This procedure establishes a recommended practice for establishing the sensitivity of the chest displacement potentiometer assembly used in the Hybrid III family of Anthropomorphic Test Devices (ATDs, or crash dummies). This potentiometer assembly is used in the Hybrid III family to measure the linear displacement of the sternum relative to the spine (referred to as chest compression). An inherent nonlinearity exists in this measurement because a rotary potentiometer is being used to measure a generally linear displacement. As the chest cavity is compressed the potentiometer rotates, however the relationship between the compression and the potentiometer rotation (and voltage output) is nonlinear.

Crash testing facilities have in the past used a variety of techniques to calibrate the chest potentiometer, that is to establish a sensitivity value (mm/(volt/volt) or mm/(mvolt/volt)). These sensitivity values are used to convert recorded voltage measurements to engineering units, in this case chest compression in mm. Some of these techniques intended to correct for the nonlinearity and others did not. Of those that did correct for the nonlinearity, there was a variation in techniques used. This variation in calibration procedures was in part identified by the SAE Dummy Testing Equipment Committee (DTEC) and led to overall variability in chest compression measurements between laboratories.

The intent of this recommended practice is to minimize the variations in chest deflection measurements between crash testing laboratories. Before this procedure was written, a round robin showed variations for the Small Female of 10% among eight labs for the chest pot sensitivity value. A follow-up round robin of this procedure showed a worst case variation of 2.7% among 10 labs, with a standard deviation of 0.9%. The initial version of SAE J2517 released in May 2000 attempted to fix this problem by recommending a two-point calibration which was not intended to correct for the nonlinearity (which, for example, is as large as 3% for the Small Female but is small near the peak). It also did not require the measurement of a starting position of the potentiometer before each crash test, thus it did not correct for the difference in starting chest geometry between a subject dummy and its design intent. It was intended to be a simple and reproducible calibration procedure which crash test facilities could easily adopt with little or no modifications to their facilities. In practice, most laboratories did not adopt the procedure since it did not correct for the nonlinearities.

Recent attempts to reduce dummy-to-dummy and lab-to-lab variations at lower deflection levels (around 25 mm) have renewed interest in adopting a calibration procedure to correct for the nonlinearity of the measurement system. This current revision of this procedure uses a multipoint calibration with a third order regression to correct for the nonlinearities of the system with a standardized method. It requires changes in the calibration method of the transducer, the data collection procedures when used in a dummy, and the processing procedures after test data is collected. Following this standardized methodology will minimize linearity errors as well as lab-to-lab variations.

## 2. REFERENCES

### 2.1 Applicable Documents

The following publications form a part of this specification to the extent specified herein. Unless otherwise indicated, the latest issue of SAE publications shall apply.

#### 2.1.1 SAE Publications

Available from SAE International, 400 Commonwealth Drive, Warrendale, PA 15096-0001, Tel: 877-606-7323 (inside USA and Canada) or +1 724-776-4970 (outside USA), [www.sae.org](http://www.sae.org).

SAE J211-1	Instrumentation for Impact Test - Part 1 - Electronic Instrumentation
SAE J2570	Performance Specifications for Anthropomorphic Test Device Transducers
SAE J2706	Hybrid III Six-Year-Old Child Dummy User's Manual
SAE J2856	User's Manual for the 50 <sup>th</sup> Percentile Male Hybrid III Test Dummy
SAE J2857	Hybrid III 3-Year-Old Child Dummy User's Manual

- SAE J2858 Hybrid III Ten-Year-Old Child Dummy User's Manual
- SAE J2860 User's Manual for the Large Male Hybrid III Test Dummy
- SAE J2862 User's Manual for the Small Adult Female Hybrid III Test Dummy

## 2.2 Related Publication

The following publication is provided for information purposes only and are not a required part of this SAE Technical Report.

### 2.2.1 Federal Publication

Available from the Superintendent of Documents, U.S. Government Printing Office, Mail Stop: SSOP, Washington, DC 20402-9320.

Federal Safety Standards, Motor Vehicle Regulation No. 572, Test Dummies Specifications - Anthropomorphic Test Dummy for Applicable Test Procedures


## 3. CALIBRATION PROCEDURE

### 3.1 Chest Potentiometer Assembly


The chest potentiometer assembly consists of the potentiometer, potentiometer bracket, arm connector, and arm. These components will be treated as an assembly during the calibration process. The assembly should be removed from the dummy as described in SAE J2856, J2706, J2857, J2858, J2860, and J2862. Next it should be placed in a fixture as described in 3.2, calibrated as described in 3.3, and replaced in the dummy. There should be no mechanical adjustments or disassembly of the potentiometer assembly once the calibration is completed. Any adjustments to the assembly would require re-calibration.

### 3.2 Calibration Fixture

The potentiometer assembly is placed in a calibration fixture that duplicates the nominal design position of arm, which is referenced as  $X_0$  in Figure 1. (This starting position represents the design position of the uncompressed chest.) The fixture should also be capable of stroking the arm relative to the potentiometer a distance of  $X_c$  as listed in Table 2. (This represents a position of the sternum when the chest is compressed.) The fixture does not need to be of a specific design, it simply needs to duplicate the position of the potentiometer at the points referenced in Table 2. As shown in Figure 2, the rotational position of the arm assembly about the longitudinal (fore-aft in dummy) axis is not critical. The potentiometer can either be installed in the fixture with the arm parallel to the slider track, or at a slight angle as installed in the dummy. (This angle between the slider track and arm should be less than 10 degrees, however.)



**Figure 1 - Calibration fixture side view**



**Figure 2 - Calibration fixture front view**

NOTE: The dimensions given are to the center of the ball. If a fixture is used that goes to the edge of the ball, the ball radius  $R_b$  must be added to  $X_A$  to get the starting position.

**Table 1 - Calibration setup dimensions**

Dummy Type	Initial Position $X_o$ , (mm)	Reference Dimension $X_a$ (mm)	Reference Dimension $X_b$ (mm)	Reference Dimension $X_r$ (mm)	Ball Radius $R_b$ (mm)
3 year old Hybrid III	40	50	15	10	3.2
6 year old Hybrid III	44	54	12	10	3.2
10 year old Hybrid III	62	72	26	10	3.2
Small female Hybrid III	67	81	27	14	4.8
50 <sup>th</sup> percentile male Hybrid III	70	84	16	14	4.8
Large adult male Hybrid III	94	108	37	14	4.8

**Table 2 - Calibration points**

Dummy Type	Calibration Points, $X_c$ (mm)
3 year old Hybrid III	-6, -3, 0, 3, 6, 9, 12, 15, 18, 21, 24, 27, 30, 33, 36, 39
6 year old Hybrid III	-8, -4, 0, 4, 8, 12, 16, 20, 24, 28, 32, 36, 40, 44, 48
10 year old Hybrid III	-8, -4, 0, 4, 8, 12, 16, 20, 24, 28, 32, 36, 40, 42, 46, 50
Small Female Hybrid III	-10, -5, 0, 5, 10, 15, 20, 25, 30, 35, 40, 45, 50, 55, 60
50 <sup>th</sup> percentile male Hybrid III	-10, -5, 0, 5, 10, 15, 20, 25, 30, 35, 40, 45, 50, 55, 60, 65, 70, 75
Large adult male Hybrid III	-10, -5, 0, 5, 10, 15, 20, 25, 30, 35, 40, 45, 50, 55, 60, 65, 70, 75, 80

### 3.3 Calibration Procedure

At the initial position,  $X_o$ , loosen the set screw locking the pot shaft to the arm coupling and adjust the pot so that the output reading is 0.0 V ( $\pm 2.5$  mV/V). Tighten the set screw to lock the pot shaft to the coupling and recheck the  $V_o$  output level.

Set the fixture to each of the calibration points,  $X_c$ , shown in Table 2 within  $\pm 0.25$  mm. Take a sensor output reading (S) at each of the Displacements (D) for the  $X_c$  calibration points listed in Table 2. Record the actual displacement values (D) in mm and the sensor output readings (S) in mV/V.

Complete a third order regression through the calibration data to relate the sensor output readings S (mV/V) to the displacement values D (mm) according to the following equation:

$$D = A*S^3 + B*S^2 + C*S + M \quad (\text{Eq. 1})$$

where:

D = actual displacement in mm

S = sensor output reading in mV/V

A, B, C, and M = calibration coefficients

From the regression analyses determine values for A, B, C, and M. These are the calibration coefficients that will be stored for the sensor and used to convert test data to engineering units. A sample of a calibration dataset is located in Appendix A of this procedure.