

---

# INTERNATIONAL STANDARD



# 2058

---

INTERNATIONAL ORGANIZATION FOR STANDARDIZATION • МЕЖДУНАРОДНАЯ ОРГАНИЗАЦИЯ ПО СТАНДАРТИЗАЦИИ • ORGANISATION INTERNATIONALE DE NORMALISATION

---

## Raw styrene butadiene rubber (SBR) — Determination of volatile matter

First edition — 1973-09-15

STANDARDSISO.COM : Click to view the full PDF of ISO 2058:1973

---

UDC 678.76 : 543.81

Ref. No. ISO 2058-1973 (E)

**Descriptors :** elastomers, synthetic elastomers, styrene butadiene resins, determination of content, volatility, moisture content.

Price based on 2 pages

## FOREWORD

ISO (the International Organization for Standardization) is a worldwide federation of national standards institutes (ISO Member Bodies). The work of developing International Standards is carried out through ISO Technical Committees. Every Member Body interested in a subject for which a Technical Committee has been set up has the right to be represented on that Committee. International organizations, governmental and non-governmental, in liaison with ISO, also take part in the work.

Draft International Standards adopted by the Technical Committees are circulated to the Member Bodies for approval before their acceptance as International Standards by the ISO Council.

International Standard ISO 2058 was drawn up by Technical Committee ISO/TC 45, *Rubber and rubber products*, and circulated to the Member Bodies in June 1970.

It has been approved by the Member Bodies of the following countries :

Australia	Hungary	Spain
Austria	India	Sweden
Canada	Israel	Switzerland
Czechoslovakia	Italy	Thailand
Egypt. Arab Rep. of	Netherlands	United Kingdom
France	New Zealand	U.S.A.
Greece	South Africa, Rep. of	U.S.S.R.

The Member Body of the following country expressed disapproval of the document on technical grounds :

Germany

# Raw styrene butadiene rubber (SBR) – Determination of volatile matter

## 1 SCOPE AND FIELD OF APPLICATION

This International Standard specifies two methods for the determination in raw solid styrene butadiene rubber of substances, including moisture, which are volatile under the conditions of the determination.

## 2 REFERENCE

ISO 1796, *Raw rubber – Sample preparation*.

## 3 PRINCIPLE

### 3.1 Method A (Hot-mill method)

A test portion is sheeted out on a heated mill until all volatile matter is driven off. The percentage of volatile matter is calculated from the difference in mass before and after milling.

A limitation of the method may arise if the polymer is too tacky to handle on a hot mill without loss of material. If such is the case, Method B should be used.

### 3.2 Method B (Mill-oven method)

A test portion is sheeted out on a laboratory mill or cut into small pieces and placed in an oven and dried to constant mass. The difference in mass before and after drying is calculated as volatile matter.

NOTE – It is necessary to state which of the two methods is employed because they do not give identical results in all cases.

## 4 APPARATUS

### 4.1 Laboratory mill.

### 4.2 Balance.

### 4.3 Oven, capable of being controlled at $100 \pm 5$ °C (for method B).

## 5 PROCEDURE

### 5.1 Method A

Weigh, to the nearest 0,1 g, about 450 g of sample prepared according to ISO 1796.

Pass the weighed test portion repeatedly through a laboratory mill, with the rolls of the mill maintained at  $100 \pm 5$  °C and the distance between the rolls being  $0,25 \pm 0,05$  mm.

Do not allow the test portion to band, and take care to prevent any loss of sample. At the end of 4 min, weigh the test portion to the nearest 0,1 g. Pass it through the mill for an additional 2 min and reweigh it. If the masses at the end of the 4 min and 6 min periods are within 0,1 g, calculate the volatile matter; if not, continue passing the test portion through the mill for 2 min periods until the mass remains constant within 0,1 g. Before each weighing, allow the sample to cool to room temperature in a desiccator.

### 5.2 Method B

Take a sample of rubber (at least 250 g) prepared according to ISO 1796 and sheet it out on a laboratory mill by passing it, not more than twice, between the cold rolls set  $0,25 \pm 0,05$  mm apart.

If this sheeting procedure is impracticable, cut the sample into pieces not larger than 2 mm x 2 mm x 2 mm. If cutting is impossible (for example with crumb rubber) weigh as such.

Weigh, to the nearest 1 mg, two pieces of the sheeted rubber each about 10 g, or 20 g of the cut rubber, on a weighed watch glass. Place in an oven at  $100 \pm 5$  °C for at least 1 h and thereafter until the loss in mass on successive weighings at half-hourly intervals is less than 1 mg. Before each weighing, allow the test portion to cool to room temperature in a desiccator.