

---

---

**Methods of testing cement — Report of a  
test programme — Chemical analysis by  
x-ray fluorescence**

*Méthodes d'essai des ciments — Rapport d'un programme d'essais —  
Analyse chimique par fluorescence X*

STANDARDSISO.COM : Click to view the full PDF of ISO/TR 12389:2009



**PDF disclaimer**

This PDF file may contain embedded typefaces. In accordance with Adobe's licensing policy, this file may be printed or viewed but shall not be edited unless the typefaces which are embedded are licensed to and installed on the computer performing the editing. In downloading this file, parties accept therein the responsibility of not infringing Adobe's licensing policy. The ISO Central Secretariat accepts no liability in this area.

Adobe is a trademark of Adobe Systems Incorporated.

Details of the software products used to create this PDF file can be found in the General Info relative to the file; the PDF-creation parameters were optimized for printing. Every care has been taken to ensure that the file is suitable for use by ISO member bodies. In the unlikely event that a problem relating to it is found, please inform the Central Secretariat at the address given below.

STANDARDSISO.COM : Click to view the full PDF of ISO/TR 12389:2009



**COPYRIGHT PROTECTED DOCUMENT**

© ISO 2009

All rights reserved. Unless otherwise specified, no part of this publication may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without permission in writing from either ISO at the address below or ISO's member body in the country of the requester.

ISO copyright office  
Case postale 56 • CH-1211 Geneva 20  
Tel. + 41 22 749 01 11  
Fax + 41 22 749 09 47  
E-mail [copyright@iso.org](mailto:copyright@iso.org)  
Web [www.iso.org](http://www.iso.org)

Published in Switzerland

**Contents**

Page

|  |           |
|--|-----------|
| <b>Foreword</b> .....  | <b>iv</b> |
| <b>Introduction</b> .....  | <b>v</b>  |
| <b>1 Scope</b> .....   | <b>1</b>  |
| <b>2 Test methods</b> .....  | <b>1</b>  |
| <b>2.1 General arrangements</b> .....  | <b>1</b>  |
| <b>2.2 Test method and constituents to be determined</b> .....   | <b>2</b>  |
| <b>3 Samples</b> .....   | <b>2</b>  |
| <b>3.1 Test samples</b> .....  | <b>2</b>  |
| <b>3.2 Calibration standards</b> .....   | <b>2</b>  |
| <b>3.3 Validation materials</b> .....  | <b>2</b>  |
| <b>3.4 Participating laboratories</b> .....  | <b>3</b>  |
| <b>4 Method for analysis of results</b> .....  | <b>3</b>  |
| <b>4.1 Statistics</b> .....  | <b>3</b>  |
| <b>4.2 Definition of Q-laboratories</b> .....  | <b>4</b>  |
| <b>5 Results and considerations</b> .....  | <b>5</b>  |
| <b>5.1 Laboratory number</b> .....   | <b>5</b>  |
| <b>5.2 Validation results for all laboratories</b> .....   | <b>5</b>  |
| <b>5.3 Test results of Q-laboratories</b> .....  | <b>12</b> |
| <b>6 Conclusions</b> .....   | <b>26</b> |
| <b>6.1 Result of test sample analyses</b> .....  | <b>26</b> |
| <b>6.2 Factors affecting conformity with the validation criteria</b> .....                             | <b>27</b> |
| <b>6.3 Application to other international inter-laboratory testing</b> .....                           | <b>27</b> |
| <b>Annex A (informative) List of participating laboratories</b> .....                                  | <b>28</b> |
| <b>Annex B (informative) Individual results of all laboratories</b> .....                              | <b>30</b> |
| <b>Annex C (informative) Questionnaire results</b> .....   | <b>46</b> |
| <b>Annex D (informative) Other international inter-laboratory round-robin analyses of cement</b> ..... | <b>48</b> |
| <b>Annex E (informative) Acknowledgements</b> .....  | <b>51</b> |
| <b>Bibliography</b> .....  | <b>52</b> |

## Foreword

ISO (the International Organization for Standardization) is a worldwide federation of national standards bodies (ISO member bodies). The work of preparing International Standards is normally carried out through ISO technical committees. Each member body interested in a subject for which a technical committee has been established has the right to be represented on that committee. International organizations, governmental and non-governmental, in liaison with ISO, also take part in the work. ISO collaborates closely with the International Electrotechnical Commission (IEC) on all matters of electrotechnical standardization.

International Standards are drafted in accordance with the rules given in the ISO/IEC Directives, Part 2.

The main task of technical committees is to prepare International Standards. Draft International Standards adopted by the technical committees are circulated to the member bodies for voting. Publication as an International Standard requires approval by at least 75 % of the member bodies casting a vote.

In exceptional circumstances, when a technical committee has collected data of a different kind from that which is normally published as an International Standard ("state of the art", for example), it may decide by a simple majority vote of its participating members to publish a Technical Report. A Technical Report is entirely informative in nature and does not have to be reviewed until the data it provides are considered to be no longer valid or useful.

Attention is drawn to the possibility that some of the elements of this document may be the subject of patent rights. ISO shall not be held responsible for identifying any or all such patent rights.

ISO/TR 12389 was prepared by Technical Committee ISO/TC 74, *Cement and lime*.

## Introduction

This Technical Report summarizes the results of inter-laboratory testing of the chemical analysis of cement by x-ray fluorescence undertaken by laboratories in Japan, in Asian countries and in Europe. This testing programme was planned and conducted by the Committee on Cement Chemistry, Japan Cement Association and extended to the members of ISO in Asia and members of CEN/TC 51/WG 15 (Revision of methods of testing cement) in Europe. A total of 42 laboratories participated.

The wet method is a longstanding technique used for chemical analysis of cement. However, since this manner of analysis is extremely time-consuming, more rapid methods have been investigated, leading to the development of chemical analysis of cement by x-ray fluorescence (XRF method). As a result, Japanese Industrial Standard JIS R 5204 was established in July 2002.

JIS R 5204 established a scheme to confirm the validity of calibration equations when the concentrations of a pair of validation beads made from certified reference materials satisfy the criteria for both the repeatability limits and accuracy limits specified in JIS R 5204. Use of this validation system improves the repeatability and accuracy of results obtained by the JIS R 5204 method.

Since an International Standard for this analysis method had not yet been established, the Japanese National Committee for ISO/TC 74 (J/TC 74) proposed the "Development of chemical analysis of cement by x-ray fluorescence" to ISO/TC 74 in June 2004. The English version of JIS R 5204 was included as the first working draft at that time.

In order to introduce JIS R 5204 to Asian members of ISO/TC 74 and to promote technical exchange among them, an inter-laboratory testing programme was organized. This inter-laboratory testing was carried out with the participation of 16 laboratories in Japan and 14 outside Japan, mostly Asian members of ISO/TC 74.

As this first part of the round-robin testing was taking place, work was in progress within CEN committee TC 51/WG 15 to produce a standard method for the chemical analysis of cement by x-ray fluorescence. The Japanese Industrial Standard JIS R 5204 was accepted by this committee and, working jointly with the Japanese co-opted member, was incorporated into the draft for ISO 29581-2. At the invitation of the Japanese Cement Association, members of CEN/TC 51/WG 15 were invited to join in the Japanese/Asian round robin and in 2005 twelve European laboratories participated. The results of their testing are included in this report.

Those laboratories that obtained analyses of JCA-CRM-1 and/or JCA-CRM-2 satisfying the criteria for both the repeatability limits and accuracy limits for all components were defined as "Q-laboratories". A comparison of the results for "Q-laboratories" with those obtained from other inter-laboratory testing for all constituents other than CaO indicates that the variation was equal to or smaller than that of wet analysis. The variation in results for CaO in "Q-laboratories" was slightly larger than that by wet analysis. Therefore, this inter-laboratory testing demonstrates that the accuracy of results obtained by the JIS R 5204/ISO 29581-2 method is generally the same as that for the wet method.

[STANDARDSISO.COM](http://STANDARDSISO.COM) : Click to view the full PDF of ISO/TR 12389:2009

# Methods of testing cement — Report of a test programme — Chemical analysis by x-ray fluorescence

## 1 Scope

This Technical Report describes the results of the inter-laboratory testing of the chemical analysis of cement by x-ray fluorescence. In the first instance, the inter-laboratory testing was carried out in Japan and in Asian countries in accordance with JIS R 5204:2002. A total of 30 laboratories, 16 in Japan and 14 outside Japan, participated in the original testing programme. A further 12 European laboratories participated in tests with the same materials in 2005 in accordance with EN 196-2, a development by CEN/TC 51/WG 15/TG 1 of JIS R 5204. The latest version, developed as ISO 29581-2, is, as of the date of publication of this Technical Report, in the process of being circulated for technical enquiry.

The test samples used were Portland cement conforming to CEM I of EN 197-1 and a mixture of Portland cement and blast furnace slag. The mixture corresponded to the composition of Portland blast furnace slag cement, class B, specified in JIS R 5211 and CEM III/A of EN 197-1. Cement reference materials for x-ray fluorescence analysis (No. 601A) are used for the calibration standards, and certified reference materials JCA-CRM-1 and JCA-CRM-2 are used as the validation materials.

Constituents analysed include  $\text{SiO}_2$ ,  $\text{Al}_2\text{O}_3$ ,  $\text{Fe}_2\text{O}_3$ ,  $\text{CaO}$ ,  $\text{MgO}$ ,  $\text{SO}_3$ ,  $\text{Na}_2\text{O}$ ,  $\text{K}_2\text{O}$ ,  $\text{TiO}_2$ ,  $\text{P}_2\text{O}_5$ ,  $\text{MnO}$  and  $\text{SrO}$ . The loss on ignition is also determined.

The ISO round robin is a method-performance study conducted under close to optimum conditions with clear calibration and measurement guidelines. This is conducive to producing “best practice” values representative of the ideal situation. However, ISO 29581-2 is intended for use under everyday conditions in laboratories that operate to “good practice”. Annex D sets out the results of some international round robins carried out by a large number of laboratories demonstrating the suitability of ISO 29581-2 as a means for comparing the everyday performance of laboratories.

## 2 Test methods

### 2.1 General arrangements

The outline of the inter-laboratory testing is shown in Table 1.

Table 1 — Outline of the inter-laboratory testing

|                         |   |
|-------------------------|---|
| Test method             | First part – JIS R 5204:2002<br>Second part – ISO 29581-1   |
| Test samples            | JCA #1 Portland cement<br>JCA #2 Cement made by mixing Portland cement with blast furnace slag (composition corresponding to Portland blast furnace slag cement Class B specified in JIS R 5211 and CEM III/A of EN 197-1)                |
| Calibration standards   | Cement reference materials for x-ray fluorescence analysis, JCA No. 601A  |
| Validation materials    | JCA-CRM-1 Ordinary Portland cement<br>JCA-CRM-2 Portland blast furnace slag cement  |
| Constituents determined | SiO <sub>2</sub> , Al <sub>2</sub> O <sub>3</sub> , Fe <sub>2</sub> O <sub>3</sub> , CaO, MgO, SO <sub>3</sub> , Na <sub>2</sub> O, K <sub>2</sub> O, TiO <sub>2</sub> , P <sub>2</sub> O <sub>5</sub> , MnO, SrO, loss on ignition (LOI) |

## 2.2 Test method and constituents to be determined

The first phase of this inter-laboratory testing was based on JIS R 5204. The second phase of this inter-laboratory testing was based on ISO 29581-2. There were no substantial differences between the two methods. For the remainder of this report they will be referred to as “the XRF method”.

Twelve constituents: SiO<sub>2</sub>, Al<sub>2</sub>O<sub>3</sub>, Fe<sub>2</sub>O<sub>3</sub>, CaO, MgO, SO<sub>3</sub>, Na<sub>2</sub>O, K<sub>2</sub>O, TiO<sub>2</sub>, P<sub>2</sub>O<sub>5</sub>, MnO, and SrO, determined by XRF method using glass beads, and loss on ignition were to be evaluated. Although SO<sub>3</sub> for Portland blast furnace slag cement was outside the scope of JIS R 5204, it was an option for Sample #2 in this testing.

## 3 Samples

### 3.1 Test samples

Two test samples were used: Portland cement (Sample #1) conforming to EN 197-1 CEM I, and a cement mixture of Portland cement and blast furnace slag (Sample #2). Sample #2 corresponded to the B-type Portland blast furnace slag cement specified in JIS R 5211 and CEM III/A of EN 197-1. Approximately 30 g of each sample was distributed.

### 3.2 Calibration standards

Cement reference materials for x-ray fluorescence analysis (see NOTE), provided by the Japan Cement Association, were used for the calibration standards.

Approximately 12 g of each standard of JCA No. 601A was distributed to the foreign laboratories. The only requirement was that seven or more calibration standards be used when making calibration equations in accordance with the XRF method.

NOTE JCA No. 601A is a set of 15 cement reference materials consisting of nine Portland cements and six Portland blast furnace slag cements.

### 3.3 Validation materials

Validation of calibration equations was specified in the XRF method. Certified reference materials JCA-CRM-1 and JCA-CRM-2, provided by the Japan Cement Association, were used as the validation materials.

Approximately 30 g of each CRM was distributed to the laboratories.

### 3.4 Participating laboratories

#### 3.4.1 Japan

An announcement of the inter-laboratory testing was sent out to members of the Japan Cement Association. In response to the announcement, 16 laboratories registered as participants in this testing programme. A list of participating laboratories is shown in Annex A.

#### 3.4.2 Asia

An announcement of the inter-laboratory testing was sent out to Asian members registered as P-members or O-members in ISO/TC 74 (See NOTE). Sixteen laboratories responded to the announcement and expressed their desire to participate, and 14 laboratories registered for the programme. A list of participating laboratories is shown in the Annex A.

NOTE The announcement was sent out to member bodies registered in ISO/TC74, and to Cement Associations of the members; see Reference [10].

#### 3.4.3 Europe

Invitations were issued to the members of European Standards Organization Technical Committee TC 51, *Cement and building limes*, Working Group 15, *Methods of testing cement*, Task Group 1, *Analysis by x-ray fluorescence*, to nominate participating laboratories. Twelve laboratories undertook to participate. A list of participating laboratories is shown in Annex A.

## 4 Method for analysis of results

### 4.1 Statistics

Symbols and definitions of statistical terms used in this report are shown in Table 2.

Table 2 — Definitions of the statistical terms

| Statistical term   | Abbreviation/symbol | Definition of the statistical term <sup>a</sup>                       |
|--|---------------------|---|
| Average  | Av./ $\bar{x}$      | $\bar{x} = \frac{\sum_{i=1}^{i=n} x_i}{n}$                            |
| Maximum value  | Max.                | Maximum value in the data   |
| Minimum value  | Min.                | Minimum value in the data   |
| Range  | —                   | Range is equal to max. minus min.                                     |
| Standard deviation   | S.D./ $\sigma$      | $\sigma = \sqrt{\frac{\sum_{i=1}^n (x_i - \bar{x})^2}{n-1}}$          |
| Coefficient of variation   | C.V./ $C_V$         | $C_V = \frac{\sigma \times 100}{\bar{x}}$ , expressed as a percentage |
| <sup>a</sup> $n$ is the number of laboratories; $\bar{x}$ is the mean value of a pair of results from each laboratory. |                     |   |

**4.2 Definition of Q-laboratories**

**4.2.1 General**

In this inter-laboratory testing, a Q-laboratory is one where the concentration of a pair of validation beads made from certified reference materials satisfies the criteria for both the repeatability limits and accuracy limits set out in the XRF method.

**4.2.2 Validation procedure**

**4.2.2.1** Determination of the concentration of a pair of validation beads made from at least one certified reference material for all analysis constituents.

**4.2.2.2** Check that the difference in the concentration, rounded off to three decimal places, of a pair of validation beads is within the repeatability limits obtained from Equation (1):

$$\log(y) = 0,48 \log(x) - 1,499 \tag{1}$$

where

*y* is the repeatability limit, as a percentage;

*x* is the mean value of the concentration of a pair of validation beads, as a percentage.

When *x* is less than 0,5 %, a limit for *y* of 0,020 % is applied to all values.

NOTE Equation (1) is specified in JIS R 5204.

**4.2.2.3** Check that the difference between the mean values, rounded off to two decimal places, of the concentration of a pair of validation beads and the “certified values” of the certified reference materials are within the accuracy limits specified according to the level of concentration in Table 3 for each analysed constituent.

Both JCA-CRM-1 and JCA-CRM-2 are used for the validation materials in this inter-laboratory testing. However, in the XRF method, the use of just one certified reference material is permitted. Therefore, for the purpose of this inter-laboratory test, the validations are considered as satisfied if the analysis of either JCA-CRM-1 or JCA-CRM-2 meets the validation criteria. Laboratories that obtained concentrations of JCA-CRM-1 and/or JCA-CRM-2 satisfying the criteria for both the repeatability limits and accuracy limits for all constituents, were defined as “Q-laboratories” in this inter-laboratory testing. In ISO 29581-2, these are referred to as “expert” laboratories.

**Table 3 — Accuracy limits for analysis validation**

| Level of the certified value<br>(% absolute) | Accuracy limits for analysis validation<br>(% absolute) |
|--|---|
| 0,00 to 0,49                                 | 0,02  |
| 0,50 to 0,99                                 | 0,03  |
| 1,00 to 6,99                                 | 0,08  |
| 7,00 to 14,99                                | 0,12  |
| 15,00 to 29,99                               | 0,15  |
| 30,00 to 49,99                               | 0,20  |
| 50,00 to 79,99                               | 0,25  |
| 80,00 to 100,00                              | 0,30  |

## 5 Results and considerations

### 5.1 Laboratory number

Validation results for all laboratories and results of determination for Q-laboratories are shown in Tables B.1 to B.8. Laboratories No. 1 to No. 16 represent laboratories in Japan; Laboratories No. 101 to No. 113 represent ISO member laboratories outside Japan. Although there were 14 participating laboratories outside Japan, the report submitted by Laboratory No. 114 is mentioned only in Tables B.2, B.4, B.6 and B.8, because the laboratory carried out XRF analysis by the pellet method. Laboratories No. E1 to E12 represent laboratories participating in the European stage.

### 5.2 Validation results for all laboratories

The difference in concentration for each pair of JCA-CRM-1 is shown in Table 4, and that for JCA-CRM-2 is shown in Table 5. The difference between the mean values of concentration for each pair of JCA-CRM-1 and the certified values is shown in Table 6, and that for JCA-CRM-2 is shown in Table 7.

Data in the shaded cells of Table 4 and Table 5 denote results that did not satisfy the required criteria for repeatability. Data in the shaded cells of Table 6 and Table 7 represent results that did not satisfy the required criteria for accuracy limits. “-” in each table indicates that there is no report from the laboratory for that constituent.

The presence of data in the shaded cells indicates that some validation results did not satisfy the required criteria for repeatability or accuracy limits. Therefore, in determining the Q-laboratories according to the definition described in 4.2, 27 laboratories were judged as Q-laboratories.

**Table 4 — Difference in concentrations for each pair of validation beads**  
(All laboratories — Validation material: JCA-CRM-1)

| Laboratory ref.           | SiO <sub>2</sub> % | Al <sub>2</sub> O <sub>3</sub> % | Fe <sub>2</sub> O <sub>3</sub> % | CaO %  | MgO % | SO <sub>3</sub> % | Na <sub>2</sub> O % | K <sub>2</sub> O % | TiO <sub>2</sub> % | P <sub>2</sub> O <sub>5</sub> % | MnO % | SrO % |
|---------------------------|--------------------|----------------------------------|----------------------------------|--------|-------|-------------------|---------------------|--------------------|--------------------|---------------------------------|-------|-------|
| 1                         | 0,039              | 0,028                            | 0,009                            | 0,180  | 0,006 | 0,010             | 0,015               | 0,007              | 0,000              | 0,001                           | 0,000 | -     |
| 2                         | 0,034              | 0,004                            | 0,001                            | 0,072  | 0,005 | 0,032             | 0,001               | 0,003              | 0,007              | 0,001                           | 0,001 | 0,000 |
| 3                         | 0,012              | 0,005                            | 0,017                            | 0,018  | 0,012 | 0,028             | 0,013               | 0,002              | 0,003              | 0,001                           | 0,000 | -     |
| 4                         | 0,080              | 0,010                            | 0,013                            | 0,020  | 0,001 | 0,009             | 0,002               | 0,004              | 0,004              | 0,002                           | 0,000 | 0,000 |
| 5                         | 0,032              | 0,012                            | 0,003                            | 0,004  | 0,003 | 0,009             | 0,001               | 0,003              | 0,002              | 0,001                           | 0,000 | 0,000 |
| 6                         | 0,024              | 0,027                            | 0,002                            | 0,083  | 0,039 | 0,012             | 0,011               | 0,007              | 0,008              | 0,002                           | 0,002 | 0,000 |
| 7                         | 0,014              | 0,013                            | 0,003                            | 0,046  | 0,005 | 0,006             | 0,002               | 0,002              | 0,005              | 0,000                           | 0,001 | 0,000 |
| 8                         | 0,040              | 0,006                            | 0,004                            | 0,115  | 0,010 | 0,008             | 0,007               | 0,001              | 0,008              | 0,001                           | 0,000 | 0,000 |
| 9                         | 0,011              | 0,017                            | 0,004                            | 0,041  | 0,003 | 0,006             | 0,001               | 0,001              | 0,002              | 0,001                           | 0,000 | 0,000 |
| 10                        | 0,028              | 0,035                            | 0,003                            | 0,012  | 0,017 | 0,017             | 0,007               | 0,001              | 0,003              | 0,000                           | 0,000 | -     |
| 11                        | 0,012              | 0,006                            | 0,008                            | 0,061  | 0,014 | 0,018             | 0,012               | 0,010              | 0,004              | 0,005                           | 0,001 | -     |
| 12                        | 0,011              | 0,006                            | 0,006                            | 0,073  | 0,005 | 0,024             | 0,007               | 0,002              | 0,011              | 0,000                           | 0,003 | 0,001 |
| 13                        | 0,018              | 0,004                            | 0,003                            | 0,042  | 0,009 | 0,005             | 0,002               | 0,000              | 0,004              | 0,000                           | 0,001 | 0,000 |
| 14                        | 0,080              | 0,029                            | 0,006                            | 0,112  | 0,006 | 0,001             | 0,002               | 0,018              | 0,013              | 0,010                           | 0,001 | 0,000 |
| 15                        | 0,090              | 0,008                            | 0,004                            | 0,038  | 0,003 | 0,015             | 0,002               | 0,001              | 0,006              | 0,000                           | 0,001 | 0,001 |
| 16                        | 0,007              | 0,011                            | 0,004                            | 0,014  | 0,003 | 0,008             | 0,008               | 0,001              | 0,005              | 0,002                           | 0,000 | 0,000 |
| 101                       | 0,005              | 0,005                            | 0,007                            | 0,006  | 0,012 | 0,130             | 0,006               | 0,004              | 0,003              | 0,003                           | -     | -     |
| 102                       | 0,017              | 0,058                            | 0,004                            | 0,005  | 0,007 | 0,001             | -                   | 0,000              | -                  | -                               | -     | -     |
| 103                       | 0,020              | 0,020                            | 0,010                            | 0,060  | 0,170 | 0,020             | 0,010               | 0,010              | -                  | -                               | -     | -     |
| 104                       | 0,016              | 0,020                            | 0,009                            | 0,193  | 0,011 | 0,035             | 0,010               | 0,016              | 0,002              | 0,004                           | 0,001 | 0,000 |
| 105                       | 0,084              | 0,052                            | 0,008                            | 0,024  | 0,001 | 0,006             | 0,003               | 0,001              | 0,011              | 0,003                           | 0,000 | 0,001 |
| 106                       | 0,118              | 0,014                            | 0,002                            | 0,090  | 0,002 | 0,014             | 0,017               | 0,003              | -                  | -                               | -     | -     |
| 107                       | 0,006              | 0,211                            | 0,008                            | 0,045  | 0,033 | 0,032             | 0,005               | 0,006              | -                  | 0,011                           | 0,001 | -     |
| 108                       | 0,010              | 0,010                            | 0,010                            | 0,020  | 0,010 | 0,010             | 0,030               | 0,000              | -                  | 0,000                           | -     | -     |
| 109                       | 0,032              | 0,009                            | 0,014                            | 0,116  | 0,003 | 0,015             | -                   | 0,002              | -                  | -                               | -     | -     |
| 110                       | 0,122              | 0,099                            | 0,059                            | 0,041  | 0,261 | 0,136             | 0,082               | 0,161              | -                  | 0,022                           | -     | -     |
| 111                       | 0,040              | 0,030                            | 0,010                            | 0,010  | 0,020 | 0,000             | 0,010               | 0,000              | 0,010              | 0,010                           | 0,000 | 0,000 |
| 112                       | 0,110              | 0,010                            | 0,000                            | 0,020  | 0,090 | 0,010             | 0,000               | 0,000              | -                  | -                               | -     | -     |
| 113                       | 0,030              | 0,030                            | 0,010                            | 0,150  | 0,090 | 0,030             | 0,010               | 0,000              | 0,000              | 0,010                           | 0,000 | 0,000 |
| E1                        | 0,112              | 0,045                            | 0,013                            | 0,039  | 0,007 | 0,025             | 0,009               | 0,002              | 0,006              | 0,000                           | 0,000 | 0,000 |
| E2                        | 0,001              | 0,053                            | 0,008                            | 0,016  | 0,019 | 0,021             | 0,002               | 0,005              | 0,002              | 0,003                           | 0,000 | -     |
| E3                        | 0,020              | 0,050                            | 0,040                            | 0,030  | 0,000 | 0,060             | 0,000               | 0,000              | 0,000              | 0,010                           | 0,000 | 0,000 |
| E4                        | 0,034              | 0,012                            | 0,009                            | 0,038  | 0,008 | 0,003             | 0,005               | 0,002              | 0,000              | 0,003                           | 0,001 | 0,000 |
| E5                        | 0,020              | 0,010                            | 0,020                            | 0,050  | 0,010 | 0,010             | 0,010               | 0,010              | 0,010              | 0,030                           | 0,000 | 0,000 |
| E6                        | 0,036              | 0,039                            | 0,003                            | 0,093  | 0,003 | 0,042             | 0,004               | 0,004              | 0,001              | 0,010                           | 0,001 | -     |
| E7                        | 0,208              | 0,051                            | 0,003                            | 0,204  | 0,051 | 0,006             | 0,008               | 0,006              | 0,010              | 0,005                           | 0,001 | 0,001 |
| E8                        | 0,085              | 0,036                            | 0,002                            | 0,014  | 0,004 | 0,007             | 0,011               | 0,001              | 0,004              | 0,000                           | 0,001 | 0,000 |
| E9                        | 0,038              | 0,039                            | 0,008                            | 0,169  | 0,028 | -                 | 0,009               | 0,001              | 0,011              | -                               | -     | -     |
| E10                       | 0,010              | 0,010                            | 0,020                            | 0,050  | 0,020 | 0,000             | 0,000               | 0,000              | -                  | -                               | -     | -     |
| E11                       | 0,003              | 0,005                            | 0,007                            | 0,010  | 0,021 | 0,002             | 0,000               | 0,002              | 0,001              | 0,000                           | 0,001 | 0,000 |
| E12                       | 0,240              | 0,014                            | 0,022                            | 0,700  | 0,001 | 0,017             | 0,020               | 0,011              | 0,007              | 0,007                           | 0,001 | 0,000 |
| <b>Average</b>            | 0,048              | 0,028                            | 0,010                            | 0,076  | 0,025 | 0,021             | 0,009               | 0,008              | 0,005              | 0,005                           | 0,001 | 0,000 |
| <b>Max.</b>               | 0,240              | 0,211                            | 0,059                            | 0,700  | 0,261 | 0,136             | 0,082               | 0,161              | 0,013              | 0,030                           | 0,003 | 0,001 |
| <b>Min.</b>               | 0,001              | 0,004                            | 0,000                            | 0,004  | 0,000 | 0,000             | 0,000               | 0,000              | 0,000              | 0,000                           | 0,000 | 0,000 |
| <b>Range</b>              | 0,239              | 0,207                            | 0,059                            | 0,696  | 0,261 | 0,136             | 0,082               | 0,161              | 0,013              | 0,030                           | 0,003 | 0,001 |
| <b>Certified analysis</b> | 20,99              | 5,260                            | 2,670                            | 65,210 | 2,130 | 2,050             | 0,260               | 0,560              | 0,350              | 0,280                           | 0,060 | 0,050 |
| <b>Limit value</b>        | 0,150              | 0,080                            | 0,080                            | 0,250  | 0,080 | 0,080             | 0,020               | 0,030              | 0,020              | 0,020                           | 0,020 | 0,020 |

NOTE Data in shaded cells represent results that did not satisfy the required criteria for repeatability specified for "expert" laboratories for the XRF method.

**Table 5 — Difference in concentrations for each pair of validation beads**  
(All laboratories — Validation material: JCA-CRM-2)

| Laboratory ref.                       | SiO <sub>2</sub><br>% | Al <sub>2</sub> O <sub>3</sub><br>% | Fe <sub>2</sub> O <sub>3</sub><br>% | CaO<br>% | MgO<br>% | SO <sub>3</sub> <sup>a</sup><br>% | Na <sub>2</sub> O<br>% | K <sub>2</sub> O<br>% | TiO <sub>2</sub><br>% | P <sub>2</sub> O <sub>5</sub><br>% | MnO<br>% | SrO<br>% |
|---------------------------------------|-----------------------|-------------------------------------|-------------------------------------|----------|----------|-----------------------------------|------------------------|-----------------------|-----------------------|------------------------------------|----------|----------|
| 1                                     | 0,001                 | 0,001                               | 0,003                               | 0,002    | 0,002    | 0,00                              | 0,005                  | 0,006                 | 0,001                 | 0,000                              | 0,000    | -        |
| 2                                     | 0,051                 | 0,010                               | 0,001                               | 0,020    | 0,018    | 0,03                              | 0,003                  | 0,002                 | 0,014                 | 0,002                              | 0,000    | 0,000    |
| 3                                     | 0,032                 | 0,010                               | 0,013                               | 0,013    | 0,009    | -                                 | 0,009                  | 0,001                 | 0,000                 | 0,000                              | 0,001    | -        |
| 4                                     | 0,008                 | 0,016                               | 0,006                               | 0,047    | 0,010    | 0,02                              | 0,003                  | 0,003                 | 0,000                 | 0,001                              | 0,003    | 0,000    |
| 5                                     | 0,038                 | 0,019                               | 0,001                               | 0,012    | 0,009    | 0,02                              | 0,001                  | 0,001                 | 0,002                 | 0,000                              | 0,000    | 0,000    |
| 6                                     | 0,113                 | 0,044                               | 0,018                               | 0,105    | 0,025    | 0,03                              | 0,012                  | 0,007                 | 0,007                 | 0,002                              | 0,000    | 0,000    |
| 7                                     | 0,009                 | 0,003                               | 0,001                               | 0,038    | 0,026    | 0,00                              | 0,000                  | 0,001                 | 0,002                 | 0,001                              | 0,000    | 0,000    |
| 8                                     | 0,005                 | 0,016                               | 0,003                               | 0,040    | 0,003    | 0,00                              | 0,000                  | 0,000                 | 0,007                 | 0,001                              | 0,001    | 0,000    |
| 9                                     | 0,094                 | 0,016                               | 0,001                               | 0,101    | 0,012    | -                                 | 0,002                  | 0,002                 | 0,004                 | 0,000                              | 0,001    | 0,000    |
| 10                                    | 0,035                 | 0,091                               | 0,015                               | 0,183    | 0,040    | -                                 | 0,011                  | 0,002                 | 0,003                 | 0,000                              | 0,001    | -        |
| 11                                    | 0,020                 | 0,030                               | 0,002                               | 0,100    | 0,047    | 0,00                              | 0,016                  | 0,000                 | 0,014                 | 0,001                              | 0,001    | -        |
| 12                                    | 0,006                 | 0,052                               | 0,020                               | 0,022    | 0,004    | -                                 | 0,014                  | 0,004                 | 0,006                 | 0,000                              | 0,001    | 0,001    |
| 13                                    | 0,010                 | 0,008                               | 0,003                               | 0,058    | 0,008    | 0,01                              | 0,002                  | 0,000                 | 0,005                 | 0,000                              | 0,000    | 0,000    |
| 14                                    | 0,071                 | 0,052                               | 0,006                               | 0,156    | 0,009    | 0,01                              | 0,008                  | 0,004                 | 0,014                 | 0,015                              | 0,003    | 0,001    |
| 15                                    | 0,052                 | 0,006                               | 0,005                               | 0,021    | 0,001    | 0,01                              | 0,006                  | 0,002                 | 0,003                 | 0,001                              | 0,000    | 0,000    |
| 16                                    | 0,054                 | 0,046                               | 0,006                               | 0,019    | 0,011    | 0,03                              | 0,005                  | 0,002                 | 0,003                 | 0,000                              | 0,001    | 0,001    |
| 101                                   | 0,005                 | 0,039                               | 0,011                               | 0,060    | 0,013    | -                                 | 0,017                  | 0,001                 | 0,001                 | 0,000                              | -        | -        |
| 102                                   | 0,022                 | 0,011                               | 0,004                               | 0,029    | 0,008    | 0,00                              | -                      | 0,001                 | -                     | -                                  | -        | -        |
| 103                                   | 0,020                 | 0,070                               | 0,010                               | 0,000    | 0,140    | 0,03                              | 0,010                  | 0,000                 | -                     | -                                  | -        | -        |
| 104                                   | 0,034                 | 0,039                               | 0,010                               | 0,188    | 0,009    | 0,02                              | 0,007                  | 0,017                 | 0,003                 | 0,001                              | 0,003    | 0,000    |
| 105                                   | 0,043                 | 0,019                               | 0,002                               | 0,010    | 0,020    | 0,00                              | 0,004                  | 0,004                 | 0,010                 | 0,005                              | 0,006    | 0,000    |
| 106                                   | 0,057                 | 0,045                               | 0,043                               | 0,107    | 0,015    | -                                 | 0,002                  | 0,001                 | -                     | -                                  | -        | -        |
| 107                                   | 0,121                 | 0,014                               | 0,048                               | 0,012    | 0,015    | -                                 | 0,009                  | 0,005                 | -                     | 0,002                              | 0,003    | -        |
| 108                                   | 0,250                 | 0,060                               | 0,000                               | 0,250    | 0,020    | 0,03                              | 0,070                  | 0,000                 | -                     | 0,010                              | -        | -        |
| 109                                   | 0,054                 | 0,023                               | 0,013                               | 0,057    | 0,002    | 0,02                              | -                      | 0,010                 | -                     | -                                  | -        | -        |
| 110                                   | 0,022                 | 0,119                               | 0,018                               | 0,138    | 0,037    | 0,02                              | 0,021                  | 0,019                 | -                     | 0,008                              | -        | -        |
| 111                                   | 0,060                 | 0,050                               | 0,010                               | 0,070    | 0,030    | 0,02                              | 0,000                  | 0,000                 | 0,010                 | 0,020                              | 0,000    | 0,000    |
| 112                                   | -                     | -                                   | -                                   | -        | -        | -                                 | -                      | -                     | -                     | -                                  | -        | -        |
| 113                                   | 0,050                 | 0,050                               | 0,020                               | 0,050    | 0,030    | -                                 | 0,010                  | 0,010                 | 0,010                 | 0,000                              | 0,000    | 0,000    |
| E1                                    | 0,045                 | 0,063                               | 0,025                               | 0,121    | 0,002    | 0,179                             | 0,008                  | 0,005                 | 0,007                 | 0,007                              | 0,001    | 0,001    |
| E2                                    | 0,003                 | 0,003                               | 0,008                               | 0,017    | 0,002    | 0,025                             | 0,005                  | 0,005                 | 0,001                 | 0,006                              | 0,002    | -        |
| E3                                    | 0,010                 | 0,010                               | 0,010                               | 0,030    | 0,030    | 0,020                             | 0,000                  | 0,000                 | 0,000                 | 0,010                              | 0,000    | 0,000    |
| E4                                    | 0,062                 | 0,054                               | 0,001                               | 0,111    | 0,026    | 0,047                             | 0,013                  | 0,001                 | 0,001                 | 0,002                              | 0,004    | 0,002    |
| E5                                    | 0,040                 | 0,030                               | 0,010                               | 0,120    | 0,100    | 0,030                             | 0,015                  | 0,000                 | 0,003                 | 0,010                              | 0,001    | 0,002    |
| E6                                    | 0,002                 | 0,019                               | 0,008                               | 0,041    | 0,033    | -                                 | 0,000                  | 0,003                 | 0,000                 | 0,007                              | 0,002    | -        |
| E7                                    | 0,118                 | 0,052                               | 0,001                               | 0,179    | 0,008    | 0,013                             | 0,003                  | 0,002                 | 0,003                 | 0,005                              | 0,001    | 0,001    |
| E8                                    | 0,049                 | 0,003                               | 0,014                               | 0,070    | 0,038    | 0,005                             | 0,008                  | 0,002                 | 0,000                 | 0,004                              | 0,000    | 0,000    |
| E9                                    | 0,063                 | 0,025                               | 0,006                               | 0,082    | 0,008    | -                                 | -                      | 0,001                 | 0,016                 | -                                  | -        | -        |
| E10                                   | 0,010                 | 0,010                               | 0,010                               | 0,040    | 0,000    | 0,000                             | 0,000                  | 0,000                 | -                     | -                                  | -        | -        |
| E11                                   | 0,086                 | 0,030                               | 0,006                               | 0,052    | 0,009    | 0,003                             | 0,008                  | 0,001                 | 0,000                 | 0,001                              | 0,000    | 0,001    |
| E12                                   | 0,260                 | 0,193                               | 0,023                               | 0,430    | 0,005    | -                                 | 0,016                  | 0,003                 | 0,003                 | 0,009                              | 0,000    | -        |
| <b>Average</b>                        | 0,052                 | 0,036                               | 0,010                               | 0,080    | 0,021    | 0,022                             | 0,009                  | 0,003                 | 0,005                 | 0,004                              | 0,001    | 0,000    |
| <b>Max.</b>                           | 0,260                 | 0,193                               | 0,048                               | 0,430    | 0,140    | 0,179                             | 0,070                  | 0,019                 | 0,016                 | 0,020                              | 0,006    | 0,002    |
| <b>Min.</b>                           | 0,001                 | 0,001                               | 0,000                               | 0,000    | 0,000    | 0,000                             | 0,000                  | 0,000                 | 0,000                 | 0,000                              | 0,000    | 0,000    |
| <b>Range</b>                          | 0,259                 | 0,192                               | 0,048                               | 0,430    | 0,140    | 0,179                             | 0,070                  | 0,019                 | 0,016                 | 0,020                              | 0,006    | 0,002    |
| <b>Certified analysis Limit value</b> | 25,66                 | 8,940                               | 2,080                               | 56,330   | 3,050    | -                                 | 0,240                  | 0,310                 | 0,500                 | 0,070                              | 0,150    | 0,070    |
| <b>Limit value</b>                    | 0,150                 | 0,120                               | 0,080                               | 0,250    | 0,080    | -                                 | 0,020                  | 0,020                 | 0,030                 | 0,020                              | 0,020    | 0,020    |

NOTE Data in shaded cells represent results that did not satisfy the required criteria for repeatability specified for "expert" laboratories for the XRF method.

<sup>a</sup> SO<sub>3</sub> for JCA-CRM-2 is outside the scope of JIS R 5204.

**Table 6 — Differences between the mean value of the concentrations of a pair of validation beads and the certified value**  
(All laboratories — Validation material: JCA-CRM-1)

| Laboratory ref.        | SiO <sub>2</sub> %      |         | Al <sub>2</sub> O <sub>3</sub> % |         | Fe <sub>2</sub> O <sub>3</sub> % |         | CaO %                   |         | MgO %                   |         | SO <sub>3</sub> %       |         |
|------------------------|-------------------------|---------|----------------------------------|---------|----------------------------------|---------|-------------------------|---------|-------------------------|---------|-------------------------|---------|
|                        | Mean value <sup>a</sup> | Diff. b | Mean value <sup>a</sup>          | Diff. b | Mean value <sup>a</sup>          | Diff. b | Mean value <sup>a</sup> | Diff. b | Mean value <sup>a</sup> | Diff. b | Mean value <sup>a</sup> | Diff. b |
| 1                      | 20,96                   | -0,03   | 5,27                             | 0,01    | 2,61                             | -0,06   | 65,29                   | 0,08    | 2,11                    | -0,02   | 2,08                    | 0,03    |
| 2                      | 20,92                   | -0,07   | 5,26                             | 0,00    | 2,65                             | -0,02   | 65,33                   | 0,12    | 2,13                    | 0,00    | 2,02                    | -0,03   |
| 3                      | 20,94                   | -0,05   | 5,25                             | -0,01   | 2,68                             | 0,01    | 65,11                   | -0,10   | 2,14                    | 0,01    | 2,08                    | 0,03    |
| 4                      | 20,97                   | -0,02   | 5,26                             | 0,00    | 2,68                             | 0,01    | 65,20                   | -0,01   | 2,14                    | 0,01    | 2,08                    | 0,03    |
| 5                      | 20,93                   | -0,06   | 5,26                             | 0,00    | 2,67                             | 0,00    | 65,24                   | 0,03    | 2,13                    | 0,00    | 2,09                    | 0,04    |
| 6                      | 20,93                   | -0,06   | 5,24                             | -0,02   | 2,61                             | -0,06   | 65,17                   | -0,04   | 2,12                    | -0,01   | 2,07                    | 0,02    |
| 7                      | 21,00                   | 0,01    | 5,27                             | 0,01    | 2,66                             | -0,01   | 65,20                   | -0,01   | 2,17                    | 0,04    | 2,06                    | 0,01    |
| 8                      | 20,92                   | -0,07   | 5,27                             | 0,01    | 2,68                             | 0,01    | 65,05                   | -0,16   | 2,16                    | 0,03    | 2,06                    | 0,01    |
| 9                      | 20,91                   | -0,08   | 5,26                             | 0,00    | 2,61                             | -0,06   | 65,21                   | 0,00    | 2,12                    | -0,01   | 2,07                    | 0,02    |
| 10                     | 20,96                   | -0,03   | 5,24                             | -0,02   | 2,63                             | -0,04   | 65,32                   | 0,11    | 2,11                    | -0,02   | 2,08                    | 0,03    |
| 11                     | 21,02                   | 0,03    | 5,28                             | 0,02    | 2,67                             | 0,00    | 65,21                   | 0,00    | 2,12                    | -0,01   | 2,07                    | 0,02    |
| 12                     | 20,98                   | -0,01   | 5,27                             | 0,01    | 2,68                             | 0,01    | 65,27                   | 0,06    | 2,14                    | 0,01    | 2,09                    | 0,04    |
| 13                     | 21,03                   | 0,04    | 5,27                             | 0,01    | 2,68                             | 0,01    | 64,98                   | -0,23   | 2,14                    | 0,01    | 2,05                    | 0,00    |
| 14                     | 21,00                   | 0,01    | 5,28                             | 0,02    | 2,72                             | 0,05    | 65,40                   | 0,19    | 2,15                    | 0,02    | 2,07                    | 0,02    |
| 15                     | 21,04                   | 0,05    | 5,26                             | 0,00    | 2,67                             | 0,00    | 65,21                   | 0,00    | 2,11                    | -0,02   | 1,98                    | -0,07   |
| 16                     | 21,01                   | 0,02    | 5,29                             | 0,03    | 2,67                             | 0,00    | 65,18                   | -0,03   | 2,15                    | 0,02    | 2,09                    | 0,04    |
| 101                    | 21,05                   | 0,06    | 5,29                             | 0,03    | 2,62                             | -0,05   | 65,34                   | 0,13    | 2,12                    | -0,01   | 2,03                    | -0,02   |
| 102                    | 21,17                   | 0,18    | 5,21                             | -0,05   | 2,64                             | -0,03   | 66,29                   | 1,08    | 2,13                    | 0,00    | 2,43                    | 0,38    |
| 103                    | 20,98                   | -0,01   | 5,21                             | -0,05   | 2,64                             | -0,03   | 65,25                   | 0,04    | 2,14                    | 0,01    | 2,08                    | 0,03    |
| 104                    | 20,98                   | -0,01   | 5,24                             | -0,02   | 2,63                             | -0,04   | 64,96                   | -0,25   | 2,10                    | -0,03   | 2,08                    | 0,03    |
| 105                    | 21,02                   | 0,03    | 5,27                             | 0,01    | 2,64                             | -0,03   | 65,38                   | 0,17    | 2,18                    | 0,05    | 2,06                    | 0,01    |
| 106                    | 20,95                   | -0,04   | 5,26                             | 0,00    | 2,67                             | 0,00    | 65,13                   | -0,08   | 2,12                    | -0,01   | 2,06                    | 0,01    |
| 107                    | 21,06                   | 0,07    | 5,42                             | 0,16    | 2,69                             | 0,02    | 64,47                   | -0,74   | 2,15                    | 0,02    | 2,04                    | -0,01   |
| 108                    | 20,90                   | -0,09   | 5,26                             | 0,00    | 2,62                             | -0,05   | 65,17                   | -0,04   | 2,10                    | -0,03   | 2,06                    | 0,01    |
| 109                    | 20,98                   | -0,01   | 5,26                             | 0,00    | 2,63                             | -0,04   | 65,50                   | 0,29    | 2,11                    | -0,02   | 1,95                    | -0,10   |
| 110                    | 20,91                   | -0,08   | 5,25                             | -0,01   | 2,61                             | -0,06   | 65,13                   | -0,08   | 2,17                    | 0,04    | 1,99                    | -0,06   |
| 111                    | 20,92                   | -0,07   | 4,98                             | -0,28   | 2,62                             | -0,05   | 64,68                   | -0,53   | 2,38                    | 0,25    | 2,00                    | -0,05   |
| 112                    | 21,00                   | 0,01    | 5,86                             | 0,60    | 2,58                             | -0,09   | 64,77                   | -0,44   | 2,06                    | -0,07   | 1,80                    | -0,25   |
| 113                    | 22,98                   | 1,99    | 5,24                             | -0,02   | 2,64                             | -0,03   | 65,28                   | 0,07    | 2,02                    | -0,11   | 2,06                    | 0,01    |
| E1                     | 20,91                   | -0,08   | 5,26                             | 0,00    | 2,66                             | -0,01   | 65,16                   | -0,05   | 2,14                    | 0,01    | 2,20                    | 0,15    |
| E2                     | 20,80                   | -0,19   | 5,30                             | 0,04    | 2,61                             | -0,06   | 65,00                   | -0,21   | 2,11                    | -0,02   | 2,07                    | 0,02    |
| E3                     | 20,79                   | -0,20   | 5,17                             | -0,09   | 2,71                             | 0,04    | 65,17                   | -0,04   | 2,27                    | 0,14    | 1,98                    | -0,07   |
| E4                     | 20,93                   | -0,06   | 5,28                             | 0,02    | 2,65                             | -0,02   | 65,01                   | -0,20   | 2,17                    | 0,04    | 2,04                    | -0,01   |
| E5                     | 21,01                   | 0,02    | 5,25                             | -0,01   | 2,65                             | -0,02   | 65,33                   | 0,12    | 2,14                    | 0,01    | 2,07                    | 0,02    |
| E6                     | 20,95                   | -0,04   | 5,23                             | -0,03   | 2,68                             | 0,01    | 65,16                   | -0,05   | 2,15                    | 0,02    | 2,13                    | 0,08    |
| E7                     | 21,00                   | 0,01    | 5,27                             | 0,01    | 2,69                             | 0,02    | 65,34                   | 0,13    | 2,15                    | 0,02    | 2,07                    | 0,02    |
| E8                     | 20,89                   | -0,10   | 5,27                             | 0,01    | 2,58                             | -0,09   | 65,13                   | -0,08   | 2,14                    | 0,01    | 2,07                    | 0,02    |
| E9                     | 20,99                   | 0,00    | 5,22                             | -0,04   | 2,68                             | 0,01    | 65,21                   | 0,00    | 2,15                    | 0,02    | -                       | -       |
| E10                    | 21,09                   | 0,10    | 5,16                             | -0,10   | 2,61                             | -0,06   | 65,14                   | -0,07   | 2,11                    | -0,02   | 2,01                    | -0,04   |
| E11                    | 20,75                   | -0,24   | 5,27                             | 0,01    | 2,67                             | 0,00    | 65,52                   | 0,31    | 2,17                    | 0,04    | 1,99                    | -0,06   |
| E12                    | 20,88                   | -0,11   | 5,29                             | 0,03    | 2,67                             | 0,00    | 64,91                   | -0,30   | 2,15                    | 0,02    | 2,05                    | 0,00    |
| <b>Average</b>         | 21,01                   |         | 5,27                             |         | 2,65                             |         | 65,19                   |         | 2,14                    |         | 2,06                    |         |
| <b>Max.</b>            | 22,98                   |         | 5,86                             |         | 2,72                             |         | 66,29                   |         | 2,38                    |         | 2,43                    |         |
| <b>Min.</b>            | 20,75                   |         | 4,98                             |         | 2,58                             |         | 64,47                   |         | 2,02                    |         | 1,80                    |         |
| <b>Range</b>           | 2,23                    |         | 0,88                             |         | 0,14                             |         | 1,82                    |         | 0,36                    |         | 0,63                    |         |
| <b>S.D.</b>            | 0,325                   |         | 0,111                            |         | 0,033                            |         | 0,268                   |         | 0,053                   |         | 0,085                   |         |
| <b>C.V.</b>            | 1,5                     |         | 2,1                              |         | 1,3                              |         | 0,4                     |         | 2,5                     |         | 4,1                     |         |
| <b>Certified value</b> | 20,99                   |         | 5,26                             |         | 2,67                             |         | 65,21                   |         | 2,13                    |         | 2,05                    |         |

Table 6 (continued)

| Laboratory<br>ref.         | Na <sub>2</sub> O<br>%     |                    | K <sub>2</sub> O<br>%      |                    | TiO <sub>2</sub><br>%      |                    | P <sub>2</sub> O <sub>5</sub><br>% |                    | MnO<br>%                   |                    | SrO<br>%                   |                    |
|----------------------------|----------------------------|--------------------|----------------------------|--------------------|----------------------------|--------------------|------------------------------------|--------------------|----------------------------|--------------------|----------------------------|--------------------|
|                            | Mean<br>value <sup>a</sup> | Diff. <sup>b</sup> | Mean<br>value <sup>a</sup> | Diff. <sup>b</sup> | Mean<br>value <sup>a</sup> | Diff. <sup>b</sup> | Mean<br>value <sup>a</sup>         | Diff. <sup>b</sup> | Mean<br>value <sup>a</sup> | Diff. <sup>b</sup> | Mean<br>value <sup>a</sup> | Diff. <sup>b</sup> |
| 1                          | 0,26                       | 0,00               | 0,54                       | -0,02              | 0,34                       | -0,01              | 0,29                               | 0,01               | 0,07                       | 0,01               | -                          | -                  |
| 2                          | 0,26                       | 0,00               | 0,53                       | -0,03              | 0,35                       | 0,00               | 0,28                               | 0,00               | 0,07                       | 0,01               | 0,04                       | -0,01              |
| 3                          | 0,26                       | 0,00               | 0,57                       | 0,01               | 0,36                       | 0,01               | 0,28                               | 0,00               | 0,06                       | 0,00               | -                          | -                  |
| 4                          | 0,26                       | 0,00               | 0,56                       | 0,00               | 0,36                       | 0,01               | 0,29                               | 0,01               | 0,06                       | 0,00               | 0,04                       | -0,01              |
| 5                          | 0,26                       | 0,00               | 0,56                       | 0,00               | 0,36                       | 0,01               | 0,28                               | 0,00               | 0,06                       | 0,00               | 0,04                       | -0,01              |
| 6                          | 0,27                       | 0,01               | 0,58                       | 0,02               | 0,34                       | -0,01              | 0,29                               | 0,01               | 0,06                       | 0,00               | 0,04                       | -0,01              |
| 7                          | 0,25                       | -0,01              | 0,56                       | 0,00               | 0,36                       | 0,01               | 0,28                               | 0,00               | 0,06                       | 0,00               | 0,04                       | -0,01              |
| 8                          | 0,25                       | -0,01              | 0,56                       | 0,00               | 0,35                       | 0,00               | 0,28                               | 0,00               | 0,06                       | 0,00               | 0,04                       | -0,01              |
| 9                          | 0,26                       | 0,00               | 0,57                       | 0,01               | 0,35                       | 0,00               | 0,29                               | 0,01               | 0,07                       | 0,01               | 0,04                       | -0,01              |
| 10                         | 0,24                       | -0,02              | 0,57                       | 0,01               | 0,35                       | 0,00               | 0,28                               | 0,00               | 0,07                       | 0,01               | -                          | -                  |
| 11                         | 0,25                       | -0,01              | 0,53                       | -0,03              | 0,36                       | 0,01               | 0,29                               | 0,01               | 0,06                       | 0,00               | -                          | -                  |
| 12                         | 0,27                       | 0,01               | 0,57                       | 0,01               | 0,35                       | 0,00               | 0,28                               | 0,00               | 0,06                       | 0,00               | 0,04                       | -0,01              |
| 13                         | 0,26                       | 0,00               | 0,56                       | 0,00               | 0,36                       | 0,01               | 0,29                               | 0,01               | 0,06                       | 0,00               | 0,04                       | -0,01              |
| 14                         | 0,27                       | 0,01               | 0,58                       | 0,02               | 0,33                       | -0,02              | 0,30                               | 0,02               | 0,06                       | 0,00               | 0,04                       | -0,01              |
| 15                         | 0,27                       | 0,01               | 0,56                       | 0,00               | 0,35                       | 0,00               | 0,29                               | 0,01               | 0,06                       | 0,00               | 0,04                       | -0,01              |
| 16                         | 0,26                       | 0,00               | 0,58                       | 0,02               | 0,35                       | 0,00               | 0,28                               | 0,00               | 0,06                       | 0,00               | 0,04                       | -0,01              |
| 101                        | 0,23                       | -0,03              | 0,57                       | 0,01               | 0,35                       | 0,00               | 0,29                               | 0,01               | -                          | -                  | -                          | -                  |
| 102                        | -                          | -                  | 0,60                       | 0,04               | -                          | -                  | -                                  | -                  | -                          | -                  | -                          | -                  |
| 103                        | 0,28                       | 0,02               | 0,58                       | 0,02               | -                          | -                  | -                                  | -                  | -                          | -                  | -                          | -                  |
| 104                        | 0,24                       | -0,02              | 0,56                       | 0,00               | 0,34                       | -0,01              | 0,27                               | -0,01              | 0,07                       | 0,01               | 0,04                       | -0,01              |
| 105                        | 0,25                       | -0,01              | 0,60                       | 0,04               | 0,35                       | 0,00               | 0,29                               | 0,01               | 0,07                       | 0,01               | 0,04                       | -0,01              |
| 106                        | 0,27                       | 0,01               | 0,57                       | 0,01               | -                          | -                  | -                                  | -                  | -                          | -                  | -                          | -                  |
| 107                        | 0,25                       | -0,01              | 0,56                       | 0,00               | -                          | -                  | 0,28                               | 0,00               | 0,06                       | 0,00               | -                          | -                  |
| 108                        | 0,26                       | 0,00               | 0,59                       | 0,03               | -                          | -                  | 0,28                               | 0,00               | -                          | -                  | -                          | -                  |
| 109                        | -                          | -                  | 0,57                       | 0,01               | -                          | -                  | -                                  | -                  | -                          | -                  | -                          | -                  |
| 110                        | 0,28                       | 0,02               | 0,58                       | 0,02               | -                          | -                  | 0,29                               | 0,01               | -                          | -                  | -                          | -                  |
| 111                        | 0,28                       | 0,02               | 0,57                       | 0,01               | 0,38                       | 0,03               | 0,36                               | 0,08               | 0,07                       | 0,01               | 0,04                       | -0,01              |
| 112                        | 0,19                       | -0,07              | 0,58                       | 0,02               | -                          | -                  | -                                  | -                  | -                          | -                  | -                          | -                  |
| 113                        | 0,26                       | 0,00               | 0,58                       | 0,02               | 0,35                       | 0,00               | 0,28                               | 0,00               | 0,07                       | 0,01               | 0,04                       | -0,01              |
| E1                         | 0,26                       | 0,00               | 0,56                       | 0,00               | 0,35                       | 0,00               | 0,29                               | 0,01               | 0,06                       | 0,00               | 0,04                       | -0,01              |
| E2                         | 0,27                       | 0,01               | 0,57                       | 0,01               | 0,34                       | -0,01              | 0,29                               | 0,01               | 0,07                       | 0,01               | -                          | -                  |
| E3                         | 0,26                       | 0,00               | 0,55                       | -0,01              | 0,35                       | 0,00               | 0,30                               | 0,02               | 0,07                       | 0,01               | 0,05                       | 0,00               |
| E4                         | 0,27                       | 0,01               | 0,57                       | 0,01               | 0,34                       | -0,01              | 0,29                               | 0,01               | 0,07                       | 0,01               | 0,04                       | -0,01              |
| E5                         | 0,27                       | 0,01               | 0,58                       | 0,02               | 0,35                       | 0,00               | 0,28                               | 0,00               | 0,07                       | 0,01               | 0,04                       | -0,01              |
| E6                         | 0,13                       | -0,13              | 0,56                       | 0,00               | 0,35                       | 0,00               | 0,31                               | 0,03               | 0,06                       | 0,00               | -                          | -                  |
| E7                         | 0,27                       | 0,01               | 0,56                       | 0,00               | 0,36                       | 0,01               | 0,28                               | 0,00               | 0,06                       | 0,00               | 0,05                       | 0,00               |
| E8                         | 0,27                       | 0,01               | 0,57                       | 0,01               | 0,34                       | -0,01              | 0,28                               | 0,00               | 0,07                       | 0,01               | 0,04                       | -0,01              |
| E9                         | 0,26                       | 0,00               | 0,56                       | 0,00               | 0,34                       | -0,01              | -                                  | -                  | -                          | -                  | -                          | -                  |
| E10                        | 0,29                       | 0,03               | 0,57                       | 0,01               | -                          | -                  | -                                  | -                  | -                          | -                  | -                          | -                  |
| E11                        | 0,25                       | -0,01              | 0,57                       | 0,01               | 0,34                       | -0,01              | 0,28                               | 0,00               | 0,06                       | 0,00               | 0,05                       | 0,00               |
| E12                        | 0,25                       | -0,01              | 0,57                       | 0,01               | 0,35                       | 0,00               | 0,29                               | 0,01               | 0,07                       | 0,01               | -                          | -                  |
| <b>Average</b>             | 0,26                       |                    | 0,57                       |                    | 0,35                       |                    | 0,29                               |                    | 0,06                       |                    | 0,04                       |                    |
| <b>Max.</b>                | 0,29                       |                    | 0,60                       |                    | 0,38                       |                    | 0,36                               |                    | 0,07                       |                    | 0,05                       |                    |
| <b>Min.</b>                | 0,13                       |                    | 0,53                       |                    | 0,33                       |                    | 0,27                               |                    | 0,06                       |                    | 0,04                       |                    |
| <b>Range</b>               | 0,16                       |                    | 0,07                       |                    | 0,05                       |                    | 0,09                               |                    | 0,01                       |                    | 0,01                       |                    |
| <b>S.D.</b>                | 0,027                      |                    | 0,015                      |                    | 0,010                      |                    | 0,015                              |                    | 0,005                      |                    | 0,003                      |                    |
| <b>C.V.</b>                | 10,2                       |                    | 2,6                        |                    | 2,7                        |                    | 5,3                                |                    | 8,4                        |                    | 6,9                        |                    |
| <b>Certified<br/>value</b> | 0,26                       |                    | 0,56                       |                    | 0,35                       |                    | 0,28                               |                    | 0,06                       |                    | 0,05                       |                    |

NOTE Data in shaded cells represent concentrations that did not satisfy the required criteria for accuracy limits for "expert" laboratories specified for the XRF method.

a "Mean value" is the mean value of the concentrations of a pair of validated beads.

b "Diff." is the difference between the mean value of the concentrations of a pair of validated beads and the certified value for the validation material.

**Table 7 — Differences between the mean value of the concentrations of a pair of validation beads and the certified value**  
(All laboratories — Validation material: JCA-CRM-2)

| Laboratory ref.        | SiO <sub>2</sub> %      |         | Al <sub>2</sub> O <sub>3</sub> % |         | Fe <sub>2</sub> O <sub>3</sub> % |         | CaO %                   |         | MgO %                   |         | SO <sub>3</sub> <sup>a</sup> % |         |
|------------------------|-------------------------|---------|----------------------------------|---------|----------------------------------|---------|-------------------------|---------|-------------------------|---------|--------------------------------|---------|
|                        | Mean value <sup>b</sup> | Diff. c | Mean Value <sup>b</sup>          | Diff. c | Mean value <sup>b</sup>          | Diff. c | Mean value <sup>b</sup> | Diff. c | Mean value <sup>b</sup> | Diff. c | Mean value <sup>b</sup>        | Diff. c |
| 1                      | 25,65                   | -0,01   | 8,94                             | 0,00    | 2,14                             | 0,06    | 56,49                   | 0,16    | 3,05                    | 0,00    | 2,56                           | -       |
| 2                      | 25,55                   | -0,11   | 8,92                             | -0,02   | 2,09                             | 0,01    | 56,47                   | 0,14    | 3,03                    | 0,02    | 2,57                           | -       |
| 3                      | 25,52                   | -0,14   | 8,94                             | 0,00    | 2,10                             | 0,02    | 56,53                   | 0,20    | 2,97                    | -0,08   | -                              | -       |
| 4                      | 25,64                   | -0,02   | 8,93                             | -0,01   | 2,10                             | 0,02    | 56,38                   | 0,05    | 3,04                    | -0,01   | 2,58                           | -       |
| 5                      | 25,61                   | -0,05   | 8,93                             | -0,01   | 2,08                             | 0,00    | 56,43                   | 0,10    | 3,03                    | -0,02   | 2,57                           | -       |
| 6                      | 25,59                   | -0,07   | 9,00                             | 0,06    | 2,14                             | 0,06    | 56,56                   | 0,23    | 3,06                    | 0,01    | 2,53                           | -       |
| 7                      | 25,69                   | 0,03    | 8,95                             | 0,01    | 2,07                             | -0,01   | 56,48                   | 0,15    | 3,08                    | 0,03    | 2,60                           | -       |
| 8                      | 25,57                   | -0,09   | 8,90                             | -0,04   | 2,04                             | -0,04   | 56,15                   | -0,18   | 3,06                    | 0,01    | 2,37                           | -       |
| 9                      | 25,58                   | -0,08   | 8,93                             | -0,01   | 2,14                             | 0,06    | 56,49                   | 0,16    | 3,06                    | 0,01    | -                              | -       |
| 10                     | 25,59                   | -0,07   | 8,90                             | -0,04   | 2,13                             | 0,05    | 56,53                   | 0,20    | 2,98                    | -0,07   | -                              | -       |
| 11                     | 25,69                   | 0,03    | 8,88                             | -0,06   | 2,08                             | 0,00    | 56,41                   | 0,08    | 3,02                    | -0,03   | 2,61                           | -       |
| 12                     | 25,68                   | 0,02    | 8,94                             | 0,00    | 2,08                             | 0,00    | 56,43                   | 0,10    | 3,04                    | -0,01   | -                              | -       |
| 13                     | 25,73                   | 0,07    | 8,92                             | -0,02   | 2,08                             | 0,00    | 56,24                   | -0,09   | 3,06                    | 0,01    | 2,63                           | -       |
| 14                     | 25,75                   | 0,09    | 8,94                             | 0,00    | 2,12                             | 0,04    | 56,51                   | 0,18    | 3,06                    | 0,01    | 2,64                           | -       |
| 15                     | 25,58                   | -0,08   | 8,96                             | 0,02    | 2,09                             | 0,01    | 56,32                   | -0,01   | 3,02                    | -0,03   | 2,60                           | -       |
| 16                     | 25,68                   | 0,02    | 8,96                             | 0,02    | 2,08                             | 0,00    | 56,52                   | 0,19    | 3,04                    | -0,01   | 2,59                           | -       |
| 101                    | 25,63                   | -0,03   | 8,92                             | -0,02   | 2,12                             | 0,04    | 56,56                   | 0,23    | 3,02                    | -0,03   | -                              | -       |
| 102                    | 25,60                   | -0,06   | 8,92                             | -0,02   | 2,13                             | 0,05    | 56,66                   | 0,33    | 3,07                    | 0,02    | 1,32                           | -       |
| 103                    | 25,66                   | 0,00    | 8,96                             | 0,02    | 2,16                             | 0,08    | 56,53                   | 0,20    | 2,99                    | -0,06   | 2,56                           | -       |
| 104                    | 25,53                   | -0,13   | 8,87                             | -0,07   | 2,12                             | 0,04    | 56,32                   | -0,01   | 3,03                    | -0,02   | 1,89                           | -       |
| 105                    | 25,63                   | -0,03   | 8,92                             | -0,02   | 2,12                             | 0,04    | 56,55                   | 0,22    | 3,08                    | 0,03    | 2,57                           | -       |
| 106                    | 25,52                   | -0,14   | 8,94                             | 0,00    | 2,07                             | -0,01   | 56,56                   | 0,23    | 3,02                    | -0,03   | -                              | -       |
| 107                    | 25,57                   | -0,09   | 8,94                             | 0,00    | 2,06                             | -0,02   | 56,48                   | 0,13    | 2,88                    | -0,17   | -                              | -       |
| 108                    | 25,74                   | 0,08    | 8,95                             | 0,01    | 2,13                             | 0,05    | 56,64                   | 0,31    | 3,04                    | -0,01   | 2,56                           | -       |
| 109                    | 25,72                   | 0,06    | 8,98                             | 0,04    | 2,15                             | 0,07    | 56,51                   | 0,18    | 3,08                    | 0,03    | 2,44                           | -       |
| 110                    | 25,65                   | -0,01   | 8,88                             | -0,06   | 2,07                             | -0,01   | 56,55                   | 0,22    | 3,07                    | 0,02    | 1,92                           | -       |
| 111                    | 25,31                   | -0,35   | 8,62                             | -0,32   | 2,10                             | 0,02    | 56,30                   | -0,03   | 3,24                    | 0,19    | 1,27                           | -       |
| 112                    | -                       | -       | -                                | -       | -                                | -       | -                       | -       | -                       | -       | -                              | -       |
| 113                    | 25,72                   | 0,06    | 8,94                             | 0,00    | 2,13                             | 0,05    | 56,82                   | 0,49    | 3,12                    | 0,07    | -                              | -       |
| E1                     | 25,65                   | -0,01   | 8,92                             | -0,02   | 2,08                             | 0,00    | 56,43                   | 0,10    | 3,04                    | -0,01   | 2,38                           | -       |
| E2                     | 25,58                   | -0,10   | 8,92                             | -0,02   | 2,12                             | 0,04    | 56,52                   | 0,19    | 3,03                    | -0,02   | 2,58                           | -       |
| E3                     | 25,35                   | -0,31   | 8,72                             | -0,22   | 2,12                             | 0,04    | 56,35                   | 0,02    | 3,21                    | 0,16    | 2,52                           | -       |
| E4                     | 25,59                   | -0,07   | 8,87                             | -0,07   | 2,12                             | 0,04    | 56,10                   | -0,23   | 2,99                    | -0,06   | -                              | -       |
| E5                     | 25,65                   | -0,01   | 8,93                             | -0,01   | 2,10                             | 0,02    | 56,23                   | -0,10   | 3,03                    | -0,02   | -                              | -       |
| E6                     | 25,57                   | -0,09   | 8,87                             | -0,07   | 2,10                             | 0,02    | 56,42                   | 0,09    | 3,05                    | 0,00    | -                              | -       |
| E7                     | 25,79                   | 0,13    | 8,91                             | -0,03   | 2,09                             | 0,01    | 56,45                   | 0,12    | 3,04                    | -0,01   | 2,62                           | -       |
| E8                     | 25,61                   | -0,05   | 8,93                             | -0,01   | 2,15                             | 0,07    | 56,40                   | 0,07    | 3,04                    | -0,01   | 2,71                           | -       |
| E9                     | 25,68                   | 0,02    | 8,89                             | -0,05   | 2,10                             | 0,02    | 56,54                   | 0,21    | 3,06                    | 0,01    | -                              | -       |
| E10                    | 25,50                   | -0,16   | 8,64                             | -0,30   | 2,13                             | 0,05    | 57,10                   | 0,77    | 2,97                    | -0,08   | 2,16                           | -       |
| E11                    | 25,50                   | -0,16   | 8,99                             | 0,05    | 2,14                             | 0,06    | 57,04                   | 0,71    | 3,11                    | 0,06    | 2,50                           | -       |
| E12                    | 25,65                   | -0,01   | 8,96                             | 0,02    | 2,09                             | 0,01    | 56,46                   | 0,13    | 3,09                    | 0,04    | -                              | -       |
| <b>Average</b>         | 25,61                   |         | 8,91                             |         | 2,11                             |         | 56,49                   |         | 3,05                    |         | 2,40                           |         |
| <b>Max.</b>            | 25,79                   |         | 9,00                             |         | 2,16                             |         | 57,10                   |         | 3,24                    |         | 2,71                           |         |
| <b>Min.</b>            | 25,31                   |         | 8,62                             |         | 2,04                             |         | 56,10                   |         | 2,88                    |         | 1,27                           |         |
| <b>Range</b>           | 0,48                    |         | 0,38                             |         | 0,12                             |         | 1,00                    |         | 0,36                    |         | 1,44                           |         |
| <b>S.D.</b>            | 0,097                   |         | 0,079                            |         | 0,028                            |         | 0,191                   |         | 0,059                   |         | 0,376                          |         |
| <b>C.V.</b>            | 0,4                     |         | 0,9                              |         | 1,4                              |         | 0,3                     |         | 1,9                     |         | -                              |         |
| <b>Certified value</b> | 25,66                   |         | 8,94                             |         | 2,08                             |         | 56,33                   |         | 3,05                    |         | -                              |         |

Table 7 (continued)

| Laboratory<br>ref.         | Na <sub>2</sub> O<br>%     |                    | K <sub>2</sub> O<br>%      |                    | TiO <sub>2</sub><br>%      |                    | P <sub>2</sub> O <sub>5</sub><br>% |                    | MnO<br>%                   |                    | SrO<br>%                   |                    |
|----------------------------|----------------------------|--------------------|----------------------------|--------------------|----------------------------|--------------------|------------------------------------|--------------------|----------------------------|--------------------|----------------------------|--------------------|
|                            | Mean<br>value <sup>b</sup> | Diff. <sup>c</sup> | Mean<br>value <sup>b</sup> | Diff. <sup>c</sup> | Mean<br>value <sup>b</sup> | Diff. <sup>c</sup> | Mean<br>value <sup>b</sup>         | Diff. <sup>c</sup> | Mean<br>value <sup>b</sup> | Diff. <sup>c</sup> | Mean<br>value <sup>b</sup> | Diff. <sup>c</sup> |
| 1                          | 0,27                       | 0,03               | 0,31                       | 0,00               | 0,50                       | 0,00               | 0,07                               | 0,00               | 0,16                       | 0,01               | -                          | -                  |
| 2                          | 0,24                       | 0,00               | 0,32                       | 0,01               | 0,51                       | 0,01               | 0,07                               | 0,00               | 0,16                       | 0,01               | 0,07                       | 0,00               |
| 3                          | 0,22                       | -0,02              | 0,32                       | 0,01               | 0,51                       | 0,01               | 0,08                               | 0,01               | 0,16                       | 0,01               | -                          | -                  |
| 4                          | 0,24                       | 0,00               | 0,32                       | 0,01               | 0,51                       | 0,01               | 0,08                               | 0,01               | 0,15                       | 0,00               | 0,06                       | -0,01              |
| 5                          | 0,24                       | 0,00               | 0,32                       | 0,01               | 0,50                       | 0,00               | 0,08                               | 0,01               | 0,15                       | 0,01               | 0,07                       | 0,00               |
| 6                          | 0,24                       | 0,00               | 0,32                       | 0,01               | 0,51                       | 0,01               | 0,07                               | 0,00               | 0,16                       | 0,01               | 0,07                       | 0,00               |
| 7                          | 0,23                       | -0,01              | 0,32                       | 0,01               | 0,50                       | 0,00               | 0,07                               | 0,00               | 0,15                       | 0,00               | 0,07                       | 0,00               |
| 8                          | 0,23                       | -0,01              | 0,32                       | 0,01               | 0,50                       | 0,00               | 0,08                               | 0,01               | 0,16                       | 0,01               | 0,06                       | -0,01              |
| 9                          | 0,25                       | 0,01               | 0,31                       | 0,00               | 0,50                       | 0,00               | 0,07                               | 0,00               | 0,16                       | 0,01               | 0,06                       | -0,01              |
| 10                         | 0,23                       | -0,01              | 0,32                       | 0,01               | 0,51                       | 0,01               | 0,07                               | 0,00               | 0,16                       | 0,01               | -                          | -                  |
| 11                         | 0,25                       | 0,01               | 0,32                       | 0,01               | 0,50                       | 0,00               | 0,08                               | 0,01               | 0,16                       | 0,01               | -                          | -                  |
| 12                         | 0,24                       | 0,00               | 0,33                       | 0,02               | 0,51                       | 0,01               | 0,08                               | 0,01               | 0,16                       | 0,01               | 0,06                       | -0,01              |
| 13                         | 0,24                       | 0,00               | 0,32                       | 0,01               | 0,51                       | 0,01               | 0,08                               | 0,01               | 0,15                       | 0,00               | 0,07                       | 0,00               |
| 14                         | 0,25                       | 0,01               | 0,33                       | 0,02               | 0,48                       | -0,02              | 0,09                               | 0,02               | 0,15                       | 0,00               | 0,07                       | 0,00               |
| 15                         | 0,25                       | 0,01               | 0,32                       | 0,01               | 0,52                       | 0,02               | 0,08                               | 0,01               | 0,16                       | 0,01               | 0,06                       | -0,01              |
| 16                         | 0,24                       | 0,00               | 0,31                       | 0,00               | 0,50                       | 0,00               | 0,08                               | 0,01               | 0,15                       | 0,00               | 0,07                       | 0,00               |
| 101                        | 0,21                       | -0,03              | 0,32                       | 0,01               | 0,51                       | 0,01               | 0,07                               | 0,00               | -                          | -                  | -                          | -                  |
| 102                        | -                          | -                  | 0,31                       | 0,00               | -                          | -                  | -                                  | -                  | -                          | -                  | -                          | -                  |
| 103                        | 0,24                       | 0,00               | 0,31                       | 0,00               | -                          | -                  | -                                  | -                  | -                          | -                  | -                          | -                  |
| 104                        | 0,26                       | 0,02               | 0,32                       | 0,01               | 0,50                       | 0,00               | 0,07                               | 0,00               | 0,16                       | 0,01               | 0,07                       | 0,00               |
| 105                        | 0,23                       | -0,01              | 0,34                       | 0,03               | 0,51                       | 0,01               | 0,08                               | 0,01               | 0,16                       | 0,01               | 0,06                       | -0,01              |
| 106                        | 0,25                       | 0,01               | 0,33                       | 0,02               | -                          | -                  | -                                  | -                  | -                          | -                  | -                          | -                  |
| 107                        | 0,26                       | 0,02               | 0,33                       | 0,02               | -                          | -                  | 0,07                               | 0,00               | 0,16                       | 0,01               | -                          | -                  |
| 108                        | 0,24                       | 0,00               | 0,32                       | 0,01               | -                          | -                  | 0,08                               | 0,01               | -                          | -                  | -                          | -                  |
| 109                        | -                          | -                  | 0,31                       | 0,00               | -                          | -                  | -                                  | -                  | -                          | -                  | -                          | -                  |
| 110                        | 0,23                       | -0,01              | 0,32                       | 0,01               | -                          | -                  | 0,08                               | 0,01               | -                          | -                  | -                          | -                  |
| 111                        | 0,27                       | 0,03               | 0,33                       | 0,02               | 0,52                       | 0,02               | 0,02                               | -0,05              | 0,16                       | 0,01               | 0,06                       | -0,01              |
| 112                        | -                          | -                  | -                          | -                  | -                          | -                  | -                                  | -                  | -                          | -                  | -                          | -                  |
| 113                        | 0,24                       | 0,00               | 0,32                       | 0,01               | 0,50                       | 0,00               | 0,08                               | 0,01               | 0,16                       | 0,01               | 0,06                       | -0,01              |
| E1                         | 0,25                       | 0,01               | 0,32                       | 0,01               | 0,50                       | 0,00               | 0,08                               | 0,01               | 0,16                       | 0,01               | 0,07                       | 0,00               |
| E2                         | 0,28                       | 0,04               | 0,32                       | 0,01               | 0,50                       | 0,00               | 0,08                               | 0,01               | 0,16                       | 0,01               | -                          | -                  |
| E3                         | 0,24                       | 0,00               | 0,31                       | 0,00               | 0,49                       | -0,01              | 0,08                               | 0,01               | 0,18                       | 0,03               | 0,08                       | 0,01               |
| E4                         | 0,24                       | 0,00               | 0,32                       | 0,01               | 0,50                       | 0,00               | 0,07                               | 0,00               | 0,16                       | 0,01               | 0,06                       | -0,01              |
| E5                         | 0,23                       | -0,01              | 0,32                       | 0,01               | 0,51                       | 0,01               | 0,07                               | 0,00               | 0,16                       | 0,01               | 0,08                       | 0,01               |
| E6                         | 0,12                       | -0,12              | 0,32                       | 0,01               | 0,50                       | 0,00               | 0,11                               | 0,04               | 0,15                       | 0,00               | -                          | -                  |
| E7                         | 0,25                       | 0,01               | 0,32                       | 0,01               | 0,50                       | 0,00               | 0,08                               | 0,01               | 0,16                       | 0,01               | 0,08                       | 0,01               |
| E8                         | 0,26                       | 0,02               | 0,32                       | 0,01               | 0,51                       | 0,01               | 0,07                               | 0,00               | 0,16                       | 0,01               | 0,06                       | -0,01              |
| E9                         | -                          | -                  | 0,33                       | 0,02               | 0,53                       | 0,03               | -                                  | -                  | -                          | -                  | -                          | -                  |
| E10                        | 0,26                       | 0,02               | 0,34                       | 0,03               | -                          | -                  | -                                  | -                  | -                          | -                  | -                          | -                  |
| E11                        | 0,23                       | -0,01              | 0,33                       | 0,02               | 0,50                       | 0,01               | 0,08                               | 0,01               | 0,16                       | 0,01               | 0,08                       | 0,01               |
| E12                        | 0,25                       | 0,01               | 0,32                       | 0,01               | 0,50                       | 0,01               | 0,08                               | 0,01               | 0,18                       | 0,03               | -                          | -                  |
| <b>Average</b>             | 0,24                       |                    | 0,32                       |                    | 0,50                       |                    | 0,08                               |                    | 0,16                       |                    | 0,07                       |                    |
| <b>Max.</b>                | 0,28                       |                    | 0,34                       |                    | 0,53                       |                    | 0,11                               |                    | 0,18                       |                    | 0,08                       |                    |
| <b>Min.</b>                | 0,12                       |                    | 0,31                       |                    | 0,48                       |                    | 0,02                               |                    | 0,15                       |                    | 0,06                       |                    |
| <b>Range</b>               | 0,16                       |                    | 0,03                       |                    | 0,05                       |                    | 0,09                               |                    | 0,03                       |                    | 0,02                       |                    |
| <b>S.D.</b>                | 0,025                      |                    | 0,007                      |                    | 0,009                      |                    | 0,013                              |                    | 0,007                      |                    | 0,008                      |                    |
| <b>C.V.</b>                | 10,3                       |                    | 2,4                        |                    | 1,8                        |                    | 18,0                               |                    | 4,5                        |                    | 10,7                       |                    |
| <b>Certified<br/>value</b> | 0,24                       |                    | 0,31                       |                    | 0,50                       |                    | 0,07                               |                    | 0,15                       |                    | 0,07                       |                    |

NOTE Data in shaded cells represent concentrations that did not satisfy the required criteria for accuracy limits for "expert" laboratories specified for the XRF method.

<sup>a</sup> SO<sub>3</sub> determination for JCA-CRM-2 is outside the scope of JIS R 5204.

<sup>b</sup> "Mean value" is the mean value of the concentrations of a pair of validated beads.

<sup>c</sup> "Diff." is the difference between the mean value of the concentrations of a pair of validated beads and the certified value for the validation material.

5.3 Test results of Q-laboratories

5.3.1 Differences in concentration for each pair of test samples

The differences in concentration for each pair of Sample JCA #1 and Sample JCA #2 is shown in Table 8 and Table 9.

**Table 8 — Differences in concentrations for each pair of test sample**  
(Q-laboratories —Test sample: Sample JCA #1)

| Laboratory ref.      | SiO <sub>2</sub> % | Al <sub>2</sub> O <sub>3</sub> % | Fe <sub>2</sub> O <sub>3</sub> % | CaO % | MgO % | SO <sub>3</sub> % | Na <sub>2</sub> O % | K <sub>2</sub> O % | TiO <sub>2</sub> % | P <sub>2</sub> O <sub>5</sub> % | MnO % | SrO %          |
|----------------------|--------------------|----------------------------------|----------------------------------|-------|-------|-------------------|---------------------|--------------------|--------------------|---------------------------------|-------|----------------|
| 1                    | 0,066              | 0,021                            | 0,008                            | 0,128 | 0,002 | 0,002             | 0,012               | 0,019              | 0,002              | 0,001                           | 0,000 | - <sup>a</sup> |
| 2                    | 0,015              | 0,008                            | 0,003                            | 0,066 | 0,005 | 0,030             | 0,003               | 0,001              | 0,002              | 0,004                           | 0,002 | 0,000          |
| 3                    | 0,082              | 0,021                            | 0,023                            | 0,139 | 0,027 | 0,020             | 0,003               | 0,001              | 0,005              | 0,001                           | 0,000 | -              |
| 4                    | 0,098              | 0,008                            | 0,007                            | 0,015 | 0,016 | 0,001             | 0,008               | 0,008              | 0,006              | 0,003                           | 0,001 | 0,001          |
| 5                    | 0,008              | 0,006                            | 0,002                            | 0,027 | 0,006 | 0,014             | 0,001               | 0,001              | 0,000              | 0,001                           | 0,000 | 0,000          |
| 6                    | 0,085              | 0,030                            | 0,005                            | 0,175 | 0,006 | 0,019             | 0,018               | 0,011              | 0,006              | 0,001                           | 0,000 | 0,000          |
| 7                    | 0,016              | 0,004                            | 0,003                            | 0,062 | 0,013 | 0,001             | 0,005               | 0,000              | 0,000              | 0,001                           | 0,001 | 0,000          |
| 8                    | 0,064              | 0,001                            | 0,002                            | 0,007 | 0,005 | 0,007             | 0,000               | 0,002              | 0,003              | 0,001                           | 0,003 | 0,000          |
| 9                    | 0,010              | 0,001                            | 0,003                            | 0,062 | 0,000 | 0,007             | 0,000               | 0,001              | 0,003              | 0,003                           | 0,000 | 0,000          |
| 10                   | 0,050              | 0,024                            | 0,001                            | 0,120 | 0,031 | 0,010             | 0,014               | 0,001              | 0,002              | 0,010                           | 0,000 | -              |
| 11                   | 0,005              | 0,046                            | 0,017                            | 0,224 | 0,006 | 0,040             | 0,001               | 0,007              | 0,005              | 0,003                           | 0,002 | -              |
| 12                   | 0,022              | 0,006                            | 0,004                            | 0,079 | 0,010 | 0,020             | 0,003               | 0,002              | 0,006              | 0,000                           | 0,000 | 0,001          |
| 13                   | 0,028              | 0,010                            | 0,001                            | 0,083 | 0,006 | 0,007             | 0,002               | 0,001              | 0,001              | 0,001                           | 0,001 | 0,000          |
| 14                   | 0,058              | 0,003                            | 0,003                            | 0,026 | 0,004 | 0,014             | 0,000               | 0,001              | 0,009              | 0,001                           | 0,000 | 0,000          |
| 15                   | 0,056              | 0,035                            | 0,018                            | 0,199 | 0,022 | 0,030             | 0,011               | 0,003              | 0,003              | 0,002                           | 0,002 | 0,000          |
| 16                   | 0,022              | 0,014                            | 0,002                            | 0,108 | 0,008 | 0,003             | 0,006               | 0,003              | 0,001              | 0,004                           | 0,001 | 0,000          |
| 104                  | 0,102              | 0,035                            | 0,040                            | 0,135 | 0,010 | 0,029             | 0,005               | 0,019              | 0,007              | 0,004                           | 0,001 | 0,000          |
| 106                  | 0,083              | 0,007                            | 0,011                            | 0,128 | 0,001 | 0,025             | 0,004               | 0,002              | -                  | -                               | -     | -              |
| 108                  | 0,020              | 0,000                            | 0,000                            | 0,060 | 0,010 | 0,010             | 0,000               | 0,000              | -                  | 0,000                           | -     | -              |
| 109                  | 0,034              | 0,000                            | 0,003                            | 0,053 | 0,008 | 0,012             | -                   | 0,007              | -                  | -                               | -     | -              |
| E1                   | 0,023              | 0,060                            | 0,022                            | 0,077 | 0,015 | 0,013             | 0,011               | 0,003              | 0,013              | 0,007                           | 0,001 | 0,001          |
| E4                   | 0,079              | 0,020                            | 0,003                            | 0,066 | 0,007 | 0,026             | 0,006               | 0,004              | 0,002              | 0,000                           | 0,000 | 0,004          |
| E5                   | 0,020              | 0,060                            | 0,010                            | 0,120 | 0,050 | 0,000             | 0,000               | 0,010              | 0,012              | 0,012                           | 0,004 | 0,001          |
| E6                   | 0,024              | 0,017                            | 0,011                            | 0,189 | 0,004 | 0,015             | 0,004               | 0,000              | 0,001              | 0,004                           | 0,001 | -              |
| E7                   | 0,120              | 0,032                            | 0,019                            | 0,070 | 0,034 | 0,020             | 0,003               | 0,004              | 0,001              | 0,011                           | 0,001 | 0,002          |
| E8                   | 0,019              | 0,021                            | 0,017                            | 0,091 | 0,021 | 0,002             | 0,011               | 0,001              | 0,004              | 0,002                           | 0,000 | 0,000          |
| E9                   | 0,088              | 0,050                            | 0,009                            | 0,138 | 0,006 | -                 | 0,013               | 0,010              | 0,012              | -                               | -     | -              |
| <b>Average</b>       | 0,049              | 0,033                            | 0,011                            | 0,101 | 0,018 | 0,012             | 0,006               | 0,004              | 0,006              | 0,005                           | 0,001 | 0,002          |
| <b>Max.</b>          | 0,120              | 0,060                            | 0,022                            | 0,189 | 0,050 | 0,026             | 0,013               | 0,019              | 0,013              | 0,012                           | 0,004 | 0,004          |
| <b>Min.</b>          | 0,019              | 0,000                            | 0,000                            | 0,060 | 0,004 | 0,000             | 0,000               | 0,000              | 0,000              | 0,000                           | 0,000 | 0,000          |
| <b>Range</b>         | 0,101              | 0,060                            | 0,022                            | 0,129 | 0,046 | 0,026             | 0,013               | 0,019              | 0,013              | 0,012                           | 0,004 | 0,004          |
| <b>Mean analysis</b> | 20,91              | 5,09                             | 3,03                             | 65,95 | 1,37  | 2,21              | 0,21                | 0,50               | 0,31               | 0,24                            | 0,10  | 0,05           |
| <b>Limit value</b>   | 0,150              | 0,080                            | 0,080                            | 0,250 | 0,080 | 0,080             | 0,020               | 0,030              | 0,030              | 0,020                           | 0,020 | 0,020          |

<sup>a</sup> “-” indicates that there was no result reported by the laboratory.

**Table 9 — Differences in concentrations for each pair of test sample**  
(Q-laboratories — Test sample: Sample JCA #2)

| Laboratory ref.      | SiO <sub>2</sub> % | Al <sub>2</sub> O <sub>3</sub> % | Fe <sub>2</sub> O <sub>3</sub> % | CaO % | MgO % | SO <sub>3</sub> <sup>a</sup> % | Na <sub>2</sub> O % | K <sub>2</sub> O % | TiO <sub>2</sub> % | P <sub>2</sub> O <sub>5</sub> % | MnO % | SrO %          |
|----------------------|--------------------|----------------------------------|----------------------------------|-------|-------|--------------------------------|---------------------|--------------------|--------------------|---------------------------------|-------|----------------|
| 1                    | 0,014              | 0,011                            | 0,002                            | 0,077 | 0,002 | 0,006                          | 0,000               | 0,003              | 0,001              | 0,000                           | 0,000 | - <sup>b</sup> |
| 2                    | 0,027              | 0,006                            | 0,006                            | 0,022 | 0,018 | 0,004                          | 0,002               | 0,001              | 0,006              | 0,001                           | 0,000 | 0,001          |
| 3                    | 0,015              | 0,000                            | 0,005                            | 0,013 | 0,006 | -                              | 0,003               | 0,000              | 0,002              | 0,000                           | 0,000 | -              |
| 4                    | 0,015              | 0,005                            | 0,005                            | 0,017 | 0,005 | 0,008                          | 0,000               | 0,000              | 0,003              | 0,002                           | 0,001 | 0,000          |
| 5                    | 0,019              | 0,008                            | 0,003                            | 0,083 | 0,004 | 0,018                          | 0,001               | 0,002              | 0,001              | 0,002                           | 0,000 | 0,001          |
| 6                    | 0,066              | 0,003                            | 0,022                            | 0,050 | 0,011 | 0,052                          | 0,004               | 0,001              | 0,004              | 0,006                           | 0,000 | 0,000          |
| 7                    | 0,015              | 0,006                            | 0,000                            | 0,002 | 0,014 | 0,002                          | 0,002               | 0,001              | 0,004              | 0,001                           | 0,001 | 0,000          |
| 8                    | 0,061              | 0,001                            | 0,001                            | 0,014 | 0,002 | 0,003                          | 0,006               | 0,001              | 0,002              | 0,001                           | 0,000 | 0,000          |
| 9                    | 0,012              | 0,013                            | 0,002                            | 0,010 | 0,004 | -                              | 0,000               | 0,000              | 0,003              | 0,001                           | 0,001 | 0,000          |
| 10                   | 0,081              | 0,016                            | 0,002                            | 0,204 | 0,011 | -                              | 0,007               | 0,000              | 0,000              | 0,001                           | 0,001 | -              |
| 11                   | 0,067              | 0,065                            | 0,015                            | 0,120 | 0,017 | 0,038                          | 0,008               | 0,002              | 0,005              | 0,001                           | 0,001 | -              |
| 12                   | 0,039              | 0,045                            | 0,028                            | 0,115 | 0,027 | -                              | 0,004               | 0,005              | 0,006              | 0,001                           | 0,001 | 0,001          |
| 13                   | 0,011              | 0,064                            | 0,007                            | 0,109 | 0,007 | 0,013                          | 0,001               | 0,003              | 0,012              | 0,003                           | 0,000 | 0,000          |
| 14                   | 0,094              | 0,040                            | 0,006                            | 0,061 | 0,001 | 0,013                          | 0,002               | 0,000              | 0,001              | 0,001                           | 0,000 | 0,000          |
| 15                   | 0,003              | 0,024                            | 0,004                            | 0,047 | 0,040 | 0,039                          | 0,008               | 0,003              | 0,002              | 0,000                           | 0,000 | 0,000          |
| 16                   | 0,013              | 0,018                            | 0,001                            | 0,050 | 0,015 | 0,024                          | 0,008               | 0,002              | 0,007              | 0,002                           | 0,001 | 0,000          |
| 104                  | 0,038              | 0,022                            | 0,011                            | 0,045 | 0,006 | 0,036                          | 0,010               | 0,016              | 0,003              | 0,007                           | 0,001 | 0,001          |
| 106                  | 0,082              | 0,077                            | 0,013                            | 0,187 | 0,011 | -                              | 0,004               | 0,001              | -                  | -                               | -     | -              |
| 108                  | 0,020              | 0,010                            | 0,000                            | 0,100 | 0,050 | 0,030                          | 0,020               | 0,000              | -                  | 0,000                           | -     | -              |
| 109                  | 0,041              | 0,019                            | 0,052                            | 0,142 | 0,012 | 0,090                          | -                   | 0,004              | -                  | -                               | -     | -              |
| E1                   | 0,045              | 0,063                            | 0,025                            | 0,121 | 0,002 | 0,179                          | 0,008               | 0,005              | 0,007              | 0,007                           | 0,001 | 0,001          |
| E4                   | 0,062              | 0,054                            | 0,001                            | 0,111 | 0,026 | 0,047                          | 0,013               | 0,001              | 0,001              | 0,002                           | 0,004 | 0,002          |
| E5                   | 0,040              | 0,030                            | 0,010                            | 0,120 | 0,100 | 0,030                          | 0,015               | 0,000              | 0,003              | 0,010                           | 0,001 | 0,002          |
| E6                   | 0,002              | 0,019                            | 0,008                            | 0,041 | 0,033 | 0,000                          | 0,000               | 0,003              | 0,000              | 0,007                           | 0,002 | -              |
| E7                   | 0,118              | 0,052                            | 0,001                            | 0,179 | 0,008 | 0,013                          | 0,003               | 0,002              | 0,003              | 0,005                           | 0,001 | 0,001          |
| E8                   | 0,049              | 0,003                            | 0,014                            | 0,070 | 0,038 | 0,005                          | 0,008               | 0,002              | 0,000              | 0,004                           | 0,000 | 0,000          |
| E9                   | 0,063              | 0,025                            | 0,006                            | 0,082 | 0,008 | -                              | -                   | 0,001              | 0,016              | -                               | -     | -              |
| <b>Average</b>       | 0,041              | 0,026                            | 0,009                            | 0,081 | 0,018 | 0,033                          | 0,005               | 0,002              | 0,004              | 0,003                           | 0,001 | 0,001          |
| <b>Max.</b>          | 0,118              | 0,077                            | 0,052                            | 0,204 | 0,100 | 0,179                          | 0,020               | 0,016              | 0,016              | 0,010                           | 0,004 | 0,002          |
| <b>Min.</b>          | 0,002              | 0,000                            | 0,000                            | 0,002 | 0,001 | 0,002                          | 0,000               | 0,000              | 0,000              | 0,000                           | 0,000 | 0,000          |
| <b>Range</b>         | 0,116              | 0,077                            | 0,052                            | 0,202 | 0,099 | 0,177                          | 0,020               | 0,016              | 0,016              | 0,010                           | 0,004 | 0,002          |
| <b>Mean analysis</b> | 26,00              | 8,81                             | 1,62                             | 56,12 | 3,35  | 2,82                           | 0,21                | 0,42               | 0,39               | 0,24                            | 0,09  | 0,05           |
| <b>Limit value</b>   | 0,150              | 0,120                            | 0,080                            | 0,250 | 0,080 | -                              | 0,020               | 0,020              | 0,020              | 0,020                           | 0,020 | 0,020          |

NOTE Data in shaded cells represent results that did not satisfy the required criteria for repeatability specified for "expert" laboratories for the XRF method.

<sup>a</sup> SO<sub>3</sub> determination for sample JCA #2 is outside the scope of JIS R 5204.

<sup>b</sup> "-" indicates that there was no result reported by the laboratory.

### 5.3.2 Distribution of concentrations for test samples

Each concentration obtained by Q-laboratories for Sample JCA #1 and Sample JCA #2 is shown in Table 10 and Table 11. "Mean value" represents the average of two concentrations, and "Diff." represents the difference between the "Mean value" and the average, respectively. Data in parentheses are "outliers" by the Grubbs test, which was excluded from statistic calculation of the results.

The Grubbs test specified in 7.3.4 of ISO 5725-2:1994 was carried out when analysing results. "Outlier" means 5% "outlier" by the Grubbs test and "Outliers in Q-laboratory" are shown in the histograms. However, although both the minimum of K<sub>2</sub>O and the maximum of SrO for Sample JCA #2 were judged as "outliers", it was concluded that they were not "extreme results" and therefore, they were not excluded.

With regard to judgment of validation for results obtained by XRF analysis using validated calibration, it would be unlikely that the analytical accuracy of the results varies significantly in the same kind of sample without a failure in one of the processes of XRF analysis. For example, both JCA-CRM-1 and Sample JCA #1 are Portland cement, and both JCA-CRM-2 and Sample JCA #2 are Portland blast furnace slag cement.

It is normal practice that when there is a statistical “outlier” it is necessary to conduct an investigation to determine the cause.

The histograms of concentrations of test samples for all constituents are shown in Figure 1 to Figure 23. The data group shown by the shaded bars indicates the data of Q-laboratories, and the white bars indicate the data of the other laboratories (non-Q-laboratories). The average and two times the standard deviation ( $2\sigma$ ) shown in the histograms were calculated after excluding “outliers”.

The concentrations obtained by Q-laboratories were generally distributed between the average  $\pm 2\sigma$  for all constituents. On the other hand, the distribution of concentrations of non-Q-laboratories was wider than that of Q-laboratories, and there were some concentrations that were far from the average. As reported above, it is important for accurate analysis to use calibration equations validated in accordance with this XRF method.

**Table 10 — Concentrations for sample JCA #1 — Q-laboratories**

| Laboratory ref. | SiO <sub>2</sub> %      |         | Al <sub>2</sub> O <sub>3</sub> % |         | Fe <sub>2</sub> O <sub>3</sub> % |         | CaO %                   |         | MgO %                   |         | SO <sub>3</sub> %       |         |
|-----------------|-------------------------|---------|----------------------------------|---------|----------------------------------|---------|-------------------------|---------|-------------------------|---------|-------------------------|---------|
|                 | Mean value <sup>a</sup> | Diff. b | Mean value <sup>a</sup>          | Diff. b | Mean value <sup>a</sup>          | Diff. b | Mean value <sup>a</sup> | Diff. b | Mean value <sup>a</sup> | Diff. b | Mean value <sup>a</sup> | Diff. b |
| 1               | 20,93                   | -0,03   | 5,11                             | 0,01    | 2,99                             | -0,04   | 65,97                   | 0,08    | 1,36                    | 0,00    | 2,23                    | 0,02    |
| 2               | 20,85                   | -0,11   | 5,10                             | 0,00    | 3,02                             | -0,01   | 65,95                   | 0,06    | 1,36                    | 0,00    | 2,19                    | -0,02   |
| 3               | 20,96                   | 0,00    | 5,11                             | 0,01    | 3,03                             | 0,00    | 65,86                   | -0,03   | 1,34                    | -0,02   | 2,19                    | -0,02   |
| 4               | 20,88                   | -0,08   | 5,10                             | 0,00    | 3,04                             | 0,01    | 65,87                   | -0,02   | 1,36                    | 0,00    | 2,25                    | 0,04    |
| 5               | 20,90                   | -0,06   | 5,12                             | 0,02    | 3,04                             | 0,01    | 65,94                   | 0,05    | 1,36                    | 0,00    | 2,22                    | 0,01    |
| 6               | 21,04                   | 0,08    | 5,12                             | 0,02    | 2,99                             | -0,04   | 65,91                   | 0,02    | 1,34                    | -0,02   | 2,23                    | 0,02    |
| 7               | 20,92                   | -0,04   | 5,10                             | 0,00    | 3,03                             | 0,00    | 65,76                   | -0,13   | 1,36                    | 0,00    | 2,21                    | 0,00    |
| 8               | 20,96                   | 0,00    | 5,13                             | 0,03    | 3,03                             | 0,00    | 65,80                   | -0,09   | 1,38                    | 0,02    | 2,21                    | 0,00    |
| 9               | 20,83                   | -0,13   | 5,10                             | 0,00    | 2,98                             | -0,05   | 65,89                   | 0,00    | 1,36                    | 0,00    | 2,23                    | 0,02    |
| 10              | 20,98                   | 0,02    | 5,08                             | -0,02   | 3,01                             | -0,02   | 66,10                   | 0,21    | 1,36                    | 0,00    | 2,22                    | 0,01    |
| 11              | 21,01                   | 0,05    | 5,12                             | 0,02    | 3,05                             | 0,02    | 65,89                   | 0,00    | 1,36                    | 0,00    | (1,99) <sup>c</sup>     | -       |
| 12              | 20,96                   | 0,00    | 5,11                             | 0,01    | 3,05                             | 0,02    | 65,84                   | -0,05   | 1,34                    | -0,02   | 2,17                    | -0,04   |
| 13              | 21,08                   | 0,12    | 5,12                             | 0,02    | 3,06                             | 0,03    | 65,68                   | -0,21   | 1,37                    | 0,01    | 2,21                    | 0,00    |
| 14              | 20,96                   | 0,00    | 5,13                             | 0,03    | 3,10                             | 0,07    | 66,15                   | 0,26    | 1,37                    | 0,01    | 2,20                    | -0,01   |
| 15              | 21,07                   | 0,11    | 5,12                             | 0,02    | 3,05                             | 0,02    | 65,86                   | -0,03   | 1,33                    | -0,03   | 2,16                    | -0,05   |
| 16              | 20,96                   | 0,00    | 5,12                             | 0,02    | 3,04                             | 0,01    | 65,77                   | -0,12   | 1,38                    | 0,02    | 2,21                    | 0,00    |
| 104             | 20,95                   | -0,01   | 5,09                             | -0,01   | 3,00                             | -0,03   | 65,51                   | -0,38   | 1,37                    | 0,01    | 2,15                    | -0,06   |
| 106             | (20,47) <sup>c</sup>    | -       | 5,05                             | -0,05   | 2,97                             | -0,06   | (64,61) <sup>c</sup>    | -       | 1,33                    | -0,03   | 2,17                    | -0,04   |
| 108             | 21,01                   | 0,05    | 5,12                             | 0,02    | 3,00                             | -0,03   | 65,88                   | -0,01   | 1,36                    | 0,00    | 2,22                    | 0,01    |
| 109             | 20,80                   | -0,16   | 5,06                             | -0,04   | 3,00                             | -0,03   | 65,88                   | -0,01   | 1,35                    | -0,01   | 2,11                    | -0,10   |
| E1              | 20,89                   | -0,06   | 5,12                             | 0,01    | 3,04                             | 0,01    | 65,86                   | -0,03   | 1,36                    | 0,00    | 2,30                    | 0,09    |
| E4              | 20,94                   | -0,01   | 5,10                             | -0,01   | 2,99                             | -0,03   | 65,71                   | -0,18   | 1,30                    | -0,06   | 2,21                    | 0,00    |
| E5              | 21,06                   | 0,10    | 5,07                             | -0,03   | 3,02                             | -0,01   | 66,00                   | 0,11    | 1,39                    | 0,03    | 2,22                    | 0,01    |
| E6              | 21,10                   | 0,14    | 5,10                             | -0,01   | 3,08                             | 0,06    | 66,37                   | 0,48    | 1,37                    | 0,02    | 2,24                    | 0,03    |
| E7              | 20,86                   | -0,10   | 5,09                             | -0,01   | 3,08                             | 0,05    | 65,83                   | -0,06   | 1,37                    | 0,01    | 2,22                    | 0,01    |
| E8              | 20,92                   | -0,04   | 5,10                             | 0,00    | 2,98                             | -0,04   | 65,91                   | 0,02    | 1,37                    | 0,01    | 2,22                    | 0,01    |
| E9              | 21,01                   | 0,05    | 5,13                             | 0,02    | 3,04                             | 0,01    | 65,91                   | 0,02    | 1,35                    | -0,01   | -                       | -       |
| <b>Average</b>  | 20,96                   |         | 5,10                             |         | 3,03                             |         | 65,89                   |         | 1,36                    |         | 2,21                    |         |
| <b>Max.</b>     | 21,10                   |         | 5,13                             |         | 3,10                             |         | 66,37                   |         | 1,39                    |         | 2,30                    |         |
| <b>Min.</b>     | 20,80                   |         | 5,05                             |         | 2,97                             |         | 65,51                   |         | 1,30                    |         | 2,11                    |         |
| <b>Range</b>    | 0,30                    |         | 0,08                             |         | 0,13                             |         | 0,86                    |         | 0,09                    |         | 0,19                    |         |
| <b>S.D.</b>     | 0,078                   |         | 0,021                            |         | 0,033                            |         | 0,160                   |         | 0,018                   |         | 0,037                   |         |
| <b>C.V.</b>     | 0,4                     |         | 0,4                              |         | 1,1                              |         | 0,2                     |         | 1,4                     |         | 1,7                     |         |

Table 10 (continued)

| Laboratory<br>ref. | Na <sub>2</sub> O<br>%     |                    | K <sub>2</sub> O<br>%      |                    | TiO <sub>2</sub><br>%      |                    | P <sub>2</sub> O <sub>5</sub><br>% |                    | MnO<br>%                   |                    | SrO<br>%                   |                    |
|--------------------|----------------------------|--------------------|----------------------------|--------------------|----------------------------|--------------------|------------------------------------|--------------------|----------------------------|--------------------|----------------------------|--------------------|
|                    | Mean<br>value <sup>a</sup> | Diff. <sup>b</sup> | Mean<br>Value <sup>a</sup> | Diff. <sup>b</sup> | Mean<br>value <sup>a</sup> | Diff. <sup>b</sup> | Mean<br>value <sup>a</sup>         | Diff. <sup>b</sup> | Mean<br>value <sup>a</sup> | Diff. <sup>b</sup> | Mean<br>value <sup>a</sup> | Diff. <sup>b</sup> |
| 1                  | 0,21                       | 0,00               | (0,45) <sup>c</sup>        | -                  | 0,31                       | 0,00               | 0,24                               | 0,00               | 0,10                       | 0,00               | -                          | -                  |
| 2                  | 0,21                       | 0,00               | 0,50                       | 0,00               | 0,32                       | 0,01               | 0,24                               | 0,00               | 0,10                       | 0,00               | 0,05                       | 0,00               |
| 3                  | 0,19                       | -0,02              | 0,50                       | 0,00               | 0,32                       | 0,01               | 0,23                               | -0,01              | 0,09                       | -0,01              | -                          | -                  |
| 4                  | 0,21                       | 0,00               | 0,50                       | 0,00               | 0,32                       | 0,01               | 0,24                               | 0,00               | 0,10                       | 0,00               | 0,05                       | 0,00               |
| 5                  | 0,21                       | 0,00               | 0,49                       | -0,01              | 0,32                       | 0,01               | 0,24                               | 0,00               | 0,10                       | 0,00               | 0,05                       | 0,00               |
| 6                  | 0,23                       | 0,02               | 0,52                       | 0,02               | 0,31                       | 0,00               | 0,24                               | 0,00               | 0,09                       | -0,01              | 0,04                       | -0,01              |
| 7                  | 0,20                       | -0,01              | 0,49                       | -0,01              | 0,32                       | 0,01               | 0,24                               | 0,00               | 0,10                       | 0,00               | 0,05                       | 0,00               |
| 8                  | 0,19                       | -0,02              | 0,49                       | -0,01              | 0,32                       | 0,01               | 0,24                               | 0,00               | 0,09                       | -0,01              | 0,05                       | 0,00               |
| 9                  | 0,21                       | 0,00               | 0,50                       | 0,00               | 0,31                       | 0,00               | 0,24                               | 0,00               | 0,10                       | 0,00               | 0,04                       | -0,01              |
| 10                 | 0,18                       | -0,03              | 0,50                       | 0,00               | 0,32                       | 0,01               | 0,24                               | 0,00               | 0,10                       | 0,00               | -                          | -                  |
| 11                 | 0,19                       | -0,02              | 0,52                       | 0,02               | 0,32                       | 0,01               | 0,24                               | 0,00               | 0,10                       | 0,00               | -                          | -                  |
| 12                 | 0,21                       | 0,00               | 0,48                       | -0,02              | 0,32                       | 0,01               | 0,24                               | 0,00               | 0,09                       | -0,01              | 0,05                       | 0,00               |
| 13                 | 0,21                       | 0,00               | 0,49                       | -0,01              | 0,31                       | 0,00               | 0,25                               | 0,01               | 0,09                       | -0,01              | 0,05                       | 0,00               |
| 14                 | 0,21                       | 0,00               | 0,49                       | -0,01              | 0,30                       | -0,01              | 0,25                               | 0,01               | 0,10                       | 0,00               | 0,05                       | 0,00               |
| 15                 | 0,18                       | -0,03              | 0,49                       | -0,01              | 0,31                       | 0,00               | 0,24                               | 0,00               | 0,10                       | 0,00               | 0,05                       | 0,00               |
| 16                 | 0,21                       | 0,00               | 0,50                       | 0,00               | 0,32                       | 0,01               | 0,24                               | 0,00               | 0,09                       | -0,01              | 0,05                       | 0,00               |
| 104                | (0,13) <sup>c</sup>        | -                  | 0,49                       | -0,01              | 0,31                       | 0,00               | 0,23                               | -0,01              | 0,09                       | -0,01              | 0,04                       | -0,01              |
| 106                | 0,20                       | -0,01              | 0,49                       | -0,01              | -                          | -                  | -                                  | -                  | -                          | -                  | -                          | -                  |
| 108                | (0,13) <sup>c</sup>        | -                  | 0,49                       | -0,01              | -                          | -                  | 0,24                               | 0,00               | -                          | -                  | -                          | -                  |
| 109                | -                          | -                  | 0,50                       | 0,00               | -                          | -                  | -                                  | -                  | -                          | -                  | -                          | -                  |
| E1                 | 0,20                       | -0,01              | 0,49                       | 0,00               | 0,32                       | 0,01               | 0,24                               | 0,00               | 0,10                       | 0,00               | 0,05                       | 0,00               |
| E4                 | 0,23                       | 0,02               | 0,49                       | -0,01              | 0,31                       | 0,00               | 0,24                               | 0,00               | 0,09                       | 0,00               | 0,05                       | 0,01               |
| E5                 | 0,23                       | 0,03               | 0,51                       | 0,01               | 0,31                       | 0,00               | 0,23                               | -0,01              | 0,10                       | 0,00               | 0,05                       | 0,00               |
| E6                 | (0,10) <sup>c</sup>        | -                  | 0,50                       | 0,00               | 0,31                       | 0,00               | 0,27                               | 0,03               | 0,09                       | -0,01              | -                          | -                  |
| E7                 | 0,21                       | 0,00               | 0,50                       | 0,00               | 0,32                       | 0,01               | 0,24                               | 0,00               | 0,10                       | 0,00               | 0,06                       | 0,01               |
| E8                 | 0,21                       | 0,00               | 0,50                       | 0,00               | 0,31                       | 0,00               | 0,24                               | 0,00               | 0,10                       | 0,00               | 0,05                       | 0,00               |
| E9                 | 0,26                       | 0,05               | 0,51                       | 0,01               | 0,30                       | -0,01              | -                                  | -                  | -                          | -                  | -                          | -                  |
| <b>Average</b>     | 0,21                       |                    | 0,50                       |                    | 0,31                       |                    | 0,24                               |                    | 0,10                       |                    | 0,05                       |                    |
| <b>Max.</b>        | 0,26                       |                    | 0,52                       |                    | 0,32                       |                    | 0,27                               |                    | 0,10                       |                    | 0,06                       |                    |
| <b>Min.</b>        | 0,18                       |                    | 0,48                       |                    | 0,30                       |                    | 0,23                               |                    | 0,09                       |                    | 0,04                       |                    |
| <b>Range</b>       | 0,08                       |                    | 0,04                       |                    | 0,02                       |                    | 0,04                               |                    | 0,01                       |                    | 0,02                       |                    |
| <b>S.D.</b>        | 0,019                      |                    | 0,009                      |                    | 0,007                      |                    | 0,008                              |                    | 0,005                      |                    | 0,005                      |                    |
| <b>C.V.</b>        | 8,9                        |                    | 1,8                        |                    | 2,1                        |                    | 3,4                                |                    | 4,9                        |                    | 10,8                       |                    |

<sup>a</sup> "Mean value" is the mean value of the concentrations of a pair of analysis beads.

<sup>b</sup> "Diff." is the difference between the mean value of the concentrations of a pair of analysis beads and the average for all Q-laboratories.

<sup>c</sup> Concentrations in parentheses are the "outliers" by the Grubbs test.

Table 11 — Concentrations for Sample JCA #2 — Q-laboratories

| Laboratory ref. | SiO <sub>2</sub> %      |         | Al <sub>2</sub> O <sub>3</sub> % |         | Fe <sub>2</sub> O <sub>3</sub> % |         | CaO %                   |         | MgO %                   |         | SO <sub>3</sub> <sup>a</sup> % |         |
|-----------------|-------------------------|---------|----------------------------------|---------|----------------------------------|---------|-------------------------|---------|-------------------------|---------|--------------------------------|---------|
|                 | Mean value <sup>b</sup> | Diff. c | Mean value <sup>b</sup>          | Diff. c | Mean value <sup>b</sup>          | Diff. c | Mean value <sup>b</sup> | Diff. c | Mean value <sup>b</sup> | Diff. c | Mean value <sup>b</sup>        | Diff. c |
| 1               | 26,02                   | 0,01    | 8,83                             | 0,03    | 1,62                             | 0,00    | 56,03                   | -0,06   | 3,34                    | 0,02    | 2,90                           | 0,04    |
| 2               | 25,83                   | -0,18   | 8,76                             | -0,04   | 1,63                             | 0,01    | 56,14                   | 0,05    | 3,31                    | -0,01   | 2,90                           | 0,04    |
| 3               | 25,99                   | -0,02   | 8,82                             | 0,02    | 1,56                             | -0,06   | 56,25                   | 0,16    | 3,29                    | -0,03   | -                              | -       |
| 4               | 26,00                   | -0,01   | 8,78                             | -0,02   | 1,65                             | 0,03    | 55,90                   | -0,19   | 3,32                    | 0,00    | 2,92                           | 0,06    |
| 5               | 25,95                   | -0,06   | 8,80                             | 0,00    | 1,62                             | 0,00    | 56,16                   | 0,07    | 3,31                    | -0,01   | 2,89                           | 0,03    |
| 6               | 26,16                   | 0,15    | (8,98) <sup>d</sup>              | -       | 1,63                             | 0,01    | 56,20                   | 0,11    | 3,38                    | 0,06    | 2,83                           | -0,03   |
| 7               | 25,99                   | -0,02   | 8,82                             | 0,02    | 1,61                             | -0,01   | 56,06                   | -0,03   | 3,35                    | 0,03    | 2,95                           | 0,09    |
| 8               | 26,04                   | 0,03    | 8,77                             | -0,03   | (1,51) <sup>d</sup>              | -       | 55,63                   | -0,46   | 3,34                    | 0,02    | 2,68                           | -0,18   |
| 9               | 25,91                   | -0,10   | 8,77                             | -0,03   | 1,63                             | 0,01    | 56,01                   | -0,08   | 3,32                    | 0,00    | -                              | -       |
| 10              | 25,94                   | -0,07   | 8,77                             | -0,03   | 1,63                             | 0,01    | 56,09                   | 0,00    | 3,29                    | -0,03   | -                              | -       |
| 11              | 25,91                   | -0,10   | 8,72                             | -0,08   | 1,61                             | -0,01   | 56,08                   | -0,01   | 3,28                    | -0,04   | 2,72                           | -0,14   |
| 12              | 26,03                   | 0,02    | 8,79                             | -0,01   | 1,58                             | -0,04   | 55,95                   | -0,14   | 3,33                    | 0,01    | -                              | -       |
| 13              | 26,10                   | 0,09    | 8,83                             | 0,03    | 1,63                             | 0,01    | 55,90                   | -0,19   | 3,32                    | 0,00    | 2,96                           | 0,10    |
| 14              | 26,06                   | 0,05    | 8,81                             | 0,01    | 1,64                             | 0,02    | 56,11                   | 0,02    | 3,31                    | -0,01   | 2,97                           | 0,11    |
| 15              | 26,15                   | 0,14    | 8,87                             | 0,07    | 1,64                             | 0,02    | 55,82                   | -0,27   | 3,30                    | -0,02   | 2,93                           | 0,07    |
| 16              | 26,02                   | 0,01    | 8,80                             | 0,00    | 1,61                             | -0,01   | 56,21                   | 0,12    | 3,32                    | 0,00    | 2,93                           | 0,07    |
| 104             | 25,98                   | -0,03   | 8,78                             | -0,02   | 1,63                             | 0,01    | 56,08                   | -0,01   | 3,31                    | -0,01   | (1,80) <sup>d</sup>            | -       |
| 106             | 25,97                   | -0,04   | 8,80                             | 0,00    | 1,57                             | -0,05   | 55,98                   | -0,11   | 3,28                    | -0,04   | -                              | -       |
| 108             | 26,07                   | 0,06    | 8,76                             | -0,04   | 1,63                             | 0,01    | 56,22                   | 0,13    | 3,32                    | 0,00    | 2,88                           | 0,02    |
| 109             | 26,15                   | 0,14    | 8,85                             | 0,05    | 1,66                             | 0,04    | 56,50                   | 0,41    | 3,35                    | 0,03    | (1,66) <sup>d</sup>            | -       |
| E1              | 25,95                   | -0,06   | 8,84                             | 0,04    | 1,62                             | 0,00    | 56,10                   | 0,02    | 3,32                    | 0,00    | 2,52                           | -0,34   |
| E4              | 25,87                   | -0,14   | 8,80                             | 0,00    | 1,60                             | -0,02   | (55,31) <sup>d</sup>    | -       | (3,23) <sup>d</sup>     | -       | (3,75) <sup>d</sup>            | -       |
| E5              | 26,00                   | -0,01   | 8,75                             | -0,05   | 1,60                             | -0,02   | 56,11                   | 0,02    | 3,32                    | 0,00    | (2,09) <sup>d</sup>            | -       |
| E6              | 26,07                   | 0,06    | 8,79                             | -0,01   | 1,64                             | 0,02    | 56,53                   | 0,44    | 3,36                    | 0,04    | -                              | -       |
| E7              | 25,95                   | -0,06   | 8,76                             | -0,04   | 1,63                             | 0,01    | 55,93                   | -0,16   | 3,32                    | 0,00    | 2,94                           | 0,07    |
| E8              | 26,03                   | 0,02    | 8,81                             | 0,02    | 1,63                             | 0,01    | 55,94                   | -0,15   | 3,34                    | 0,02    | 2,88                           | 0,02    |
| E9              | 26,09                   | 0,08    | 8,87                             | 0,07    | 1,58                             | -0,04   | 56,29                   | 0,20    | 3,34                    | 0,01    | -                              | -       |
| <b>Average</b>  | 26,01                   |         | 8,80                             |         | 1,62                             |         | 56,09                   |         | 3,32                    |         | 2,86                           |         |
| <b>Max.</b>     | 26,16                   |         | 8,87                             |         | 1,66                             |         | 56,53                   |         | 3,38                    |         | 2,97                           |         |
| <b>Min.</b>     | 25,83                   |         | 8,72                             |         | 1,56                             |         | 55,63                   |         | 3,28                    |         | 2,52                           |         |
| <b>Range</b>    | 0,33                    |         | 0,15                             |         | 0,10                             |         | 0,90                    |         | 0,10                    |         | 0,45                           |         |
| <b>S.D.</b>     | 0,083                   |         | 0,037                            |         | 0,025                            |         | 0,192                   |         | 0,024                   |         | 0,121                          |         |
| <b>C.V.</b>     | 0,3                     |         | 0,4                              |         | 1,5                              |         | 0,3                     |         | 0,7                     |         | 4,2                            |         |

Table 11 (continued)

| Laboratory<br>ref. | Na <sub>2</sub> O<br>%     |                    | K <sub>2</sub> O<br>%      |                    | TiO <sub>2</sub><br>%      |                    | P <sub>2</sub> O <sub>5</sub><br>% |                    | MnO<br>%                   |                    | SrO<br>%                   |                    |
|--------------------|----------------------------|--------------------|----------------------------|--------------------|----------------------------|--------------------|------------------------------------|--------------------|----------------------------|--------------------|----------------------------|--------------------|
|                    | Mean<br>value <sup>b</sup> | Diff. <sup>c</sup> | Mean<br>value <sup>b</sup> | Diff. <sup>c</sup> | Mean<br>value <sup>b</sup> | Diff. <sup>c</sup> | Mean<br>value <sup>b</sup>         | Diff. <sup>c</sup> | Mean<br>value <sup>b</sup> | Diff. <sup>c</sup> | Mean<br>value <sup>b</sup> | Diff. <sup>c</sup> |
| 1                  | 0,25                       | 0,03               | 0,40                       | -0,02              | 0,40                       | 0,01               | 0,24                               | 0,00               | 0,10                       | 0,01               | -                          | -                  |
| 2                  | 0,23                       | 0,01               | 0,43                       | 0,01               | 0,39                       | 0,00               | 0,24                               | 0,00               | 0,09                       | 0,00               | 0,05                       | 0,00               |
| 3                  | 0,21                       | -0,01              | 0,43                       | 0,01               | 0,40                       | 0,01               | 0,24                               | 0,00               | 0,10                       | 0,01               | -                          | -                  |
| 4                  | 0,22                       | 0,00               | 0,42                       | 0,00               | 0,39                       | 0,00               | 0,24                               | 0,00               | 0,09                       | 0,00               | 0,05                       | 0,00               |
| 5                  | 0,22                       | 0,00               | 0,43                       | 0,01               | 0,39                       | 0,00               | 0,24                               | 0,00               | 0,09                       | 0,00               | 0,05                       | 0,00               |
| 6                  | 0,19                       | -0,03              | 0,42                       | 0,00               | 0,39                       | 0,00               | 0,23                               | -0,01              | 0,09                       | 0,00               | 0,05                       | 0,00               |
| 7                  | 0,21                       | -0,01              | 0,43                       | 0,01               | 0,39                       | 0,00               | 0,24                               | 0,00               | 0,09                       | 0,00               | 0,05                       | 0,00               |
| 8                  | 0,22                       | 0,00               | 0,43                       | 0,01               | 0,40                       | 0,01               | 0,24                               | 0,00               | 0,09                       | 0,00               | 0,05                       | 0,00               |
| 9                  | 0,23                       | 0,01               | 0,41                       | -0,01              | 0,40                       | 0,01               | 0,23                               | -0,01              | 0,10                       | 0,01               | 0,05                       | 0,00               |
| 10                 | 0,21                       | -0,01              | 0,43                       | 0,01               | 0,40                       | 0,01               | 0,23                               | -0,01              | 0,10                       | 0,01               | -                          | -                  |
| 11                 | 0,20                       | -0,02              | 0,42                       | 0,00               | 0,38                       | -0,01              | 0,24                               | 0,00               | 0,09                       | 0,00               | -                          | -                  |
| 12                 | 0,23                       | 0,01               | 0,42                       | 0,00               | 0,40                       | 0,01               | 0,23                               | -0,01              | 0,09                       | 0,00               | 0,06                       | 0,01               |
| 13                 | 0,22                       | 0,00               | 0,43                       | 0,01               | 0,40                       | 0,01               | 0,25                               | 0,01               | 0,08                       | -0,01              | 0,05                       | 0,00               |
| 14                 | 0,22                       | 0,00               | 0,43                       | 0,01               | 0,38                       | -0,01              | 0,25                               | 0,01               | 0,09                       | 0,00               | 0,05                       | 0,00               |
| 15                 | 0,20                       | -0,02              | 0,43                       | 0,01               | 0,38                       | -0,01              | 0,25                               | 0,01               | 0,09                       | 0,00               | 0,05                       | 0,00               |
| 16                 | 0,22                       | 0,00               | 0,42                       | 0,00               | 0,38                       | -0,01              | 0,24                               | 0,00               | 0,09                       | 0,00               | 0,05                       | 0,00               |
| 104                | 0,19                       | -0,03              | 0,42                       | 0,00               | 0,39                       | 0,00               | 0,23                               | -0,01              | 0,09                       | 0,00               | 0,05                       | 0,00               |
| 106                | 0,24                       | 0,02               | 0,43                       | 0,01               | -                          | -                  | -                                  | -                  | -                          | -                  | -                          | -                  |
| 108                | (0,15) <sup>d</sup>        | -                  | 0,43                       | 0,01               | -                          | -                  | 0,23                               | -0,01              | -                          | -                  | -                          | -                  |
| 109                | -                          | -                  | 0,43                       | 0,01               | -                          | -                  | -                                  | -                  | -                          | -                  | -                          | -                  |
| E1                 | 0,21                       | -0,01              | 0,43                       | 0,01               | 0,39                       | -0,01              | 0,25                               | 0,01               | 0,09                       | -0,01              | 0,05                       | 0,00               |
| E4                 | 0,23                       | 0,01               | 0,42                       | -0,01              | 0,39                       | 0,00               | 0,23                               | -0,01              | 0,10                       | 0,01               | 0,05                       | 0,00               |
| E5                 | 0,23                       | 0,01               | 0,43                       | 0,01               | 0,40                       | 0,01               | 0,23                               | -0,01              | 0,09                       | 0,00               | 0,05                       | 0,00               |
| E6                 | (0,10) <sup>d</sup>        | -                  | 0,43                       | 0,01               | 0,38                       | -0,01              | 0,27                               | 0,03               | 0,08                       | -0,01              | -                          | -                  |
| E7                 | 0,23                       | 0,01               | 0,43                       | 0,00               | 0,39                       | 0,00               | 0,24                               | 0,00               | 0,09                       | 0,00               | 0,06                       | 0,01               |
| E8                 | 0,22                       | 0,00               | 0,42                       | 0,00               | 0,40                       | 0,00               | 0,23                               | -0,01              | 0,10                       | 0,00               | 0,05                       | 0,00               |
| E9                 | -                          | -                  | 0,42                       | 0,00               | 0,43                       | 0,03               | -                                  | -                  | -                          | -                  | -                          | -                  |
| <b>Average</b>     | 0,22                       |                    | 0,42                       |                    | 0,39                       |                    | 0,24                               |                    | 0,09                       |                    | 0,05                       |                    |
| <b>Max.</b>        | 0,25                       |                    | 0,43                       |                    | 0,43                       |                    | 0,27                               |                    | 0,10                       |                    | 0,06                       |                    |
| <b>Min.</b>        | 0,19                       |                    | 0,40                       |                    | 0,38                       |                    | 0,23                               |                    | 0,08                       |                    | 0,05                       |                    |
| <b>Range</b>       | 0,06                       |                    | 0,03                       |                    | 0,05                       |                    | 0,04                               |                    | 0,02                       |                    | 0,01                       |                    |
| <b>S.D.</b>        | 0,014                      |                    | 0,008                      |                    | 0,010                      |                    | 0,009                              |                    | 0,006                      |                    | 0,003                      |                    |
| <b>C.V.</b>        | 6,6                        |                    | 1,8                        |                    | 2,6                        |                    | 3,9                                |                    | 6,4                        |                    | 5,8                        |                    |

<sup>a</sup> SO<sub>3</sub> for sample JCA #2 is outside the scope of JIS R 5204.

<sup>b</sup> "Mean value" is the mean value of the concentrations of a pair of analysis beads.

<sup>c</sup> "Diff." is the difference between the mean value of the concentrations of a pair of analysis beads and the average for all Q-laboratories

<sup>d</sup> Concentrations in parentheses are the "outliers" by the Grubbs test.




Figure 1 — The histogram of concentrations (Sample JCA #1, constituent SiO<sub>2</sub>)




Figure 2 — The histogram of concentrations (Sample JCA #1, constituent Al<sub>2</sub>O<sub>3</sub>)




Figure 3 — The histogram of concentrations (Sample JCA #1, constituent Fe<sub>2</sub>O<sub>3</sub>)




Figure 4 — The histogram of concentrations (Sample JCA #1, constituent CaO)




Figure 5 — The histogram of concentrations (Sample JCA #1, constituent MgO)




Figure 6 — The histogram of concentrations (Sample JCA #1, constituent SO<sub>3</sub>)




Figure 7 — The histogram of concentrations (Sample JCA #1, constituent Na<sub>2</sub>O)




Figure 8 — The histogram of concentrations (Sample JCA #1, constituent K<sub>2</sub>O)




Figure 9 — The histogram of concentrations (Sample JCA #1, constituent TiO<sub>2</sub>)




Figure 10 — The histogram of concentrations (Sample JCA #1, constituent P<sub>2</sub>O<sub>5</sub>)




Figure 11 — The histogram of concentrations (Sample JCA #1 – constituent MnO)




Figure 12 — The histogram of concentrations (Sample JCA #1, constituent SrO)




Figure 13 — The histogram of concentrations (Sample JCA #2, constituent SiO<sub>2</sub>)




Figure 14 — The histogram of concentrations (Sample JCA #2, constituent Al<sub>2</sub>O<sub>3</sub>)




Figure 15 — The histogram of concentrations (Sample JCA #2, constituent Fe<sub>2</sub>O<sub>3</sub>)




Figure 16 — The histogram of concentrations (Sample JCA #2, constituent CaO)




Figure 17 — The histogram of concentrations (Sample JCA #2, constituent MgO)




Figure 18 — The histogram of concentrations (Sample JCA #2, constituent Na<sub>2</sub>O)




Figure 19 — The histogram of concentrations (Sample JCA #2, constituent K<sub>2</sub>O)




Figure 20 — The histogram of concentrations (Sample JCA #2, constituent TiO<sub>2</sub>)




Figure 21 — The histogram of concentrations (Sample JCA #2, constituent P<sub>2</sub>O<sub>5</sub>)




Figure 22 — The histogram of concentrations (Sample JCA #2, constituent MnO)




Figure 23 — The histogram of concentrations (Sample JCA #2, constituent SrO)

## 6 Conclusions

### 6.1 Result of test sample analyses

The average and the standard deviations of reproducibility of test samples obtained from the inter-laboratory testing by x-ray fluorescence are shown in Table 12.

For comparison, standard deviations of reproducibility obtained from the wet-chemistry methods in Inter-laboratory testing, 2004-OC in accordance with JIS R 5202 are also shown in Table 12.

Inter-laboratory testing, 2004-OC was conducted by the Japan Cement Association and the standard deviation of the reproducibility was calculated using only data from the laboratories of cement companies in Japan. Most of these laboratories participated in the inter-laboratory testing by x-ray fluorescence.

NOTE An "Inter-laboratory testing, xxxx-OC" has been conducted by the Japan Cement Association since 1948. "xxxx" stands for the year in which the inter-laboratory testing was conducted.

**Table 12 — Comparison between standard deviation obtained by Q-laboratories in this testing and that obtained from data of the wet method in Inter-laboratory testing, 2004-OC**

| Constituent                    | Sample    | Q-laboratories this inter-laboratory testing |                        | Inter-laboratory testing 2004-OC |                        |
|--------------------------------|-----------|--|------------------------|----------------------------------|------------------------|
|                                |           | Average %                                    | Reproducibility S.D. % | Reproducibility S.D. %           | Number of laboratories |
| SiO <sub>2</sub>               | Sample #1 | 20,96  | 0,078                  | 0,129                            | 22                     |
|                                | Sample #2 | 26,01  | 0,083                  |                                  |                        |
| Al <sub>2</sub> O <sub>3</sub> | Sample #1 | 5,10   | 0,021                  | 0,068                            | 22                     |
|                                | Sample #2 | 8,80   | 0,037                  |                                  |                        |
| Fe <sub>2</sub> O <sub>3</sub> | Sample #1 | 3,03   | 0,033                  | 0,049                            | 21                     |
|                                | Sample #2 | 1,62   | 0,025                  |                                  |                        |
| CaO                            | Sample #1 | 65,89  | 0,160                  | 0,117                            | 22                     |
|                                | Sample #2 | 56,09  | 0,192                  |                                  |                        |
| MgO                            | Sample #1 | 1,36   | 0,018                  | 0,042                            | 22                     |
|                                | Sample #2 | 3,32   | 0,024                  |                                  |                        |
| SO <sub>3</sub>                | Sample #1 | 2,21   | 0,037                  | 0,039                            | 27                     |
|                                | Sample #2 | (2,86) <sup>a</sup>                          | (0,121) <sup>a</sup>   |                                  |                        |
| Na <sub>2</sub> O              | Sample #1 | 0,21   | 0,019                  | 0,014                            | 23                     |
|                                | Sample #2 | 0,22   | 0,014                  |                                  |                        |
| K <sub>2</sub> O               | Sample #1 | 0,50   | 0,009                  | 0,009                            | 23                     |
|                                | Sample #2 | 0,42   | 0,008                  |                                  |                        |
| TiO <sub>2</sub>               | Sample #1 | 0,31   | 0,007                  | 0,012                            | 22                     |
|                                | Sample #2 | 0,39   | 0,010                  |                                  |                        |
| P <sub>2</sub> O <sub>5</sub>  | Sample #1 | 0,24   | 0,008                  | 0,027                            | 22                     |
|                                | Sample #2 | 0,24   | 0,009                  |                                  |                        |
| MnO                            | Sample #1 | 0,10   | 0,005                  | 0,007                            | 22                     |
|                                | Sample #2 | 0,09   | 0,006                  |                                  |                        |
| SrO                            | Sample #1 | 0,05   | 0,005                  | -                                | -                      |
|                                | Sample #2 | 0,05   | 0,003                  |                                  |                        |

<sup>a</sup> Concentrations in parentheses are the "outliers" by the Grubbs test.

The standard deviations of Q-laboratories are almost equal to or less than those of Inter-laboratory testing, 2004-OC, except for CaO. Therefore, the accuracy of XRF analysis according to the XRF method is considered to be generally equal to that of wet analysis.

For CaO, a few laboratories obtained results that are not within the average  $\pm 2$  times the standard deviation, even if the results are not "outliers". Factors affecting the determination of CaO should be investigated further.

As reported in 5.3.2, there are some "outliers", even in the analyses by Q-laboratories. The principle of the method assumes that extreme results should not arise, provided that the calibration used for sample analysis satisfied the criteria for both repeatability limits and accuracy limits. The possibility of error factors in these analyses should be investigated.

## 6.2 Factors affecting conformity with the validation criteria

The XRF method requires that, when analysing a sample by XRF analysis, it is necessary to satisfy the criteria for repeatability limits and accuracy limits for certified reference materials. This validation is essential for accurate analysis.

Some laboratories were unable to satisfy the validation criteria in this inter-laboratory testing.

In these cases, it is recommended that those laboratories re-check general matters for chemical analysis, such as weighing of samples, performance of spectrometer and general facilities for accurate XRF analysis.

The following matters should also be checked:

- a) bead preparation conditions, such as fusion temperature, flux-to-sample ratio;
- b) repeatability of bead preparation;
- c) procedure for preparing ignited sample;
- d) agreed basis for calculating results, e.g., as-received or loss-free;
- e) procedure for establishing calibration equations, such as range of contents or application of correction for inter-element effect;
- f) measurement conditions for light elements, especially Na<sub>2</sub>O, MgO and Al<sub>2</sub>O<sub>3</sub>.

## 6.3 Application to other international inter-laboratory testing

ISO 29581-2 is intended for use under everyday conditions in laboratories that operate to "good practice". Annex D sets out the results of some international round robins carried out by a large number of laboratories demonstrating the suitability of ISO 29581-2 as a means for comparing the everyday performance of laboratories.

**Annex A**  
(informative)

**List of participating laboratories**

**A.1 Japanese laboratories:**

Ube-Mitsubishi Cement Research Institute Corporation, Ube Center

Ube-Mitsubishi Cement Research Institute Corporation, Kurosaki Center

Ube-Mitsubishi Cement Research Institute Corporation, Saitama Center

Ube-Mitsubishi Cement Research Institute Corporation, Sendai Concrete Center

Nippon Steel Blast-Furnace Slag Cement Co., Ltd., Production and Technical Dept., Quality Assurance Group

Sumitomo Osaka Cement Co., Ltd., Production and Technical Dept., Analytical Center

Sumitomo Osaka Cement Co., Ltd., Cement/Concrete Research Laboratory, Cement Chemistry Research Group

Sumitomo Osaka Cement Co., Ltd., Cement/Concrete Research Laboratory, Cement Technology Group

Taiheiyo Cement Corporation, Ofunato Plant, Production Dept., Quality Assurance Section

Taiheiyo Cement Corporation, Kamiiso Plant, Production Dept., Quality Assurance Section

Taiheiyo Cement Corporation, Oita Plant(Saiki), Production Dept., Quality Assurance Section

Taiheiyo Consultant Co., Ltd., Quality Assurance Dept., Chemical Analysis Group

Chuken Consultant Co., Ltd., Kanto Branch, Technical Dev., Material Analytical Section

Tokuyama Corporation, Cement Manufacturing Dept., Technical Section 1

Tosoh Corporation, Cement and Energy Manufacturing Dept., Cement Testing Div.

Japan Cement Association, R & D Laboratory, Basic Research on Cement/Environment Group

**A.2 ISO member laboratories – Outside Japan:**

China, People's Republic of – China Building Materials Academy

Asia Cement Co., Ltd.

Hanil Cement Co., Ltd.

Hyundai Cement Co., Ltd., Danyang Plant

Hyundai Cement Co., Ltd., Yongwol Plant

Lafarge Halla Cement Corporation

|                                  |  |
|----------------------------------|--|
|                                  | Ssangyong Cement Industrial Co., Ltd.  |
|                                  | Yongwol Plant  |
|                                  | Sungshin Cement Co., Ltd.  |
| Korea, Republic of –             | Tong Yang Cement Corporation, Samchok Plant  |
| Lithuania, Republic of –         | Prustitas Co., Ltd.  |
| Philippines, Republic of the –   | Cement Manufactures Association/APO Cement Corporation<br>Union Cement Corporation, Lugait Plant |
| Vietnam, Socialist Republic of – | Butson Cement Company<br>National Cement Association   |

### A.3 CEN member laboratories:

|                  |  |
|------------------|--|
| Italy –          | Italcementi Group, Bergamo   |
| France –         | Three laboratories co-ordinated by ATILH, Paris  |
| Germany –        | VDZ, Research Institute of the Cement Industry, Duesseldorf<br>HeidelbergCement Technology Center GmbH, Leimen |
| Belgium –        | CRIC, Brussels   |
| Turkey –         | Turkish Cement Manufacturing Association, Ankara   |
| United Kingdom – | Castle Cement Technical Centre, Clitheroe  |
| Netherlands –    | ENCI B.V. Vestiging, Maastricht  |
| Spain –          | IECA, Madrid   |
| Czech Republic – | Research Institute for Binding Materials, Brno   |
| Poland –         | IMMB, Krakow   |

NOTE One CEN member laboratory was unable to meet the validation criteria and withdrew. It was subsequently discovered that the x-ray tube was unstable.

**Annex B**  
(informative)

**Individual results of all laboratories**

Tables B.1 to B.8 list the results of all laboratories participating in the test programme: Chemical analysis of cement by x-ray fluorescence.

**Table B.1 — Individual results for all laboratories — JCA-CRM-1**

| Laboratory ref. | SiO <sub>2</sub> % |        | Al <sub>2</sub> O <sub>3</sub> % |       | Fe <sub>2</sub> O <sub>3</sub> % |       | CaO %            |        | MgO %          |       | SO <sub>3</sub> % |       |
|-----------------|--------------------|--------|----------------------------------|-------|----------------------------------|-------|------------------|--------|----------------|-------|-------------------|-------|
|                 | Results            | Mean   | Results                          | Mean  | Results                          | Mean  | Results          | Mean   | Results        | Mean  | Results           | Mean  |
| 1               | 20,982<br>20,943   | 20,962 | 5,287<br>5,259                   | 5,273 | 2,619<br>2,610                   | 2,614 | 65,197<br>65,377 | 65,287 | 2,117<br>2,111 | 2,114 | 2,083<br>2,073    | 2,078 |
| 2               | 20,902<br>20,936   | 20,919 | 5,257<br>5,253                   | 5,255 | 2,647<br>2,648                   | 2,648 | 65,370<br>65,298 | 65,334 | 2,134<br>2,129 | 2,132 | 2,005<br>2,037    | 2,021 |
| 3               | 20,933<br>20,945   | 20,939 | 5,244<br>5,249                   | 5,246 | 2,691<br>2,674                   | 2,682 | 65,115<br>65,097 | 65,106 | 2,143<br>2,131 | 2,137 | 2,089<br>2,061    | 2,075 |
| 4               | 21,006<br>20,926   | 20,966 | 5,260<br>5,250                   | 5,255 | 2,670<br>2,683                   | 2,676 | 65,188<br>65,208 | 65,198 | 2,135<br>2,137 | 2,136 | 2,074<br>2,083    | 2,078 |
| 5               | 20,914<br>20,946   | 20,930 | 5,254<br>5,266                   | 5,260 | 2,668<br>2,671                   | 2,670 | 65,243<br>65,247 | 65,245 | 2,136<br>2,133 | 2,134 | 2,085<br>2,094    | 2,090 |
| 6               | 20,945<br>20,921   | 20,933 | 5,250<br>5,223                   | 5,236 | 2,608<br>2,606                   | 2,607 | 65,126<br>65,209 | 65,168 | 2,142<br>2,103 | 2,122 | 2,061<br>2,073    | 2,067 |
| 7               | 20,996<br>21,010   | 21,003 | 5,273<br>5,260                   | 5,266 | 2,663<br>2,660                   | 2,662 | 65,177<br>65,223 | 65,200 | 2,163<br>2,168 | 2,166 | 2,063<br>2,057    | 2,060 |
| 8               | 20,945<br>20,905   | 20,925 | 5,272<br>5,266                   | 5,269 | 2,681<br>2,677                   | 2,679 | 65,103<br>64,988 | 65,046 | 2,161<br>2,151 | 2,156 | 2,054<br>2,062    | 2,058 |
| 9               | 20,912<br>20,901   | 20,906 | 5,266<br>5,249                   | 5,258 | 2,613<br>2,609                   | 2,611 | 65,227<br>65,186 | 65,206 | 2,117<br>2,120 | 2,118 | 2,076<br>2,070    | 2,073 |
| 10              | 20,942<br>20,970   | 20,956 | 5,219<br>5,254                   | 5,236 | 2,631<br>2,628                   | 2,630 | 65,331<br>65,319 | 65,325 | 2,122<br>2,105 | 2,114 | 2,067<br>2,084    | 2,076 |
| 11              | 21,027<br>21,015   | 21,021 | 5,280<br>5,274                   | 5,277 | 2,677<br>2,669                   | 2,673 | 65,241<br>65,180 | 65,210 | 2,127<br>2,113 | 2,120 | 2,083<br>2,065    | 2,074 |
| 12              | 20,978<br>20,989   | 20,984 | 5,264<br>5,270                   | 5,267 | 2,690<br>2,664                   | 2,677 | 65,310<br>65,237 | 65,274 | 2,147<br>2,142 | 2,144 | 2,098<br>2,074    | 2,086 |
| 13              | 21,042<br>21,024   | 21,033 | 5,265<br>5,269                   | 5,267 | 2,680<br>2,677                   | 2,678 | 64,999<br>64,957 | 64,978 | 2,137<br>2,146 | 2,142 | 2,056<br>2,051    | 2,054 |
| 14              | 21,040<br>20,960   | 21,000 | 5,296<br>5,267                   | 5,282 | 2,716<br>2,722                   | 2,719 | 65,341<br>65,453 | 65,397 | 2,154<br>2,148 | 2,151 | 2,067<br>2,068    | 2,068 |
| 15              | 21,086<br>20,996   | 21,041 | 5,260<br>5,252                   | 5,256 | 2,674<br>2,670                   | 2,672 | 65,192<br>65,230 | 65,211 | 2,109<br>2,106 | 2,108 | 1,976<br>1,991    | 1,984 |
| 16              | 21,004<br>21,011   | 21,008 | 5,297<br>5,286                   | 5,292 | 2,671<br>2,667                   | 2,669 | 65,190<br>65,176 | 65,183 | 2,153<br>2,156 | 2,154 | 2,088<br>2,096    | 2,092 |
| 101             | 21,050<br>21,055   | 21,052 | 5,288<br>5,293                   | 5,290 | 2,623<br>2,616                   | 2,620 | 65,348<br>65,342 | 65,345 | 2,122<br>2,110 | 2,116 | 1,962<br>2,092    | 2,027 |
| 102             | 21,162<br>21,179   | 21,170 | 5,183<br>5,241                   | 5,212 | 2,638<br>2,634                   | 2,636 | 66,288<br>66,283 | 66,286 | 2,127<br>2,134 | 2,130 | 2,429<br>2,430    | 2,430 |
| 103             | 20,990<br>20,970   | 20,980 | 5,200<br>5,220                   | 5,210 | 2,640<br>2,650                   | 2,645 | 65,280<br>65,220 | 65,250 | 2,230<br>2,060 | 2,145 | 2,070<br>2,090    | 2,080 |
| 104             | 20,989<br>20,973   | 20,981 | 5,248<br>5,228                   | 5,238 | 2,631<br>2,622                   | 2,626 | 65,060<br>64,867 | 64,964 | 2,093<br>2,104 | 2,098 | 2,051<br>2,096    | 2,074 |
| 105             | 20,978<br>21,062   | 21,020 | 5,242<br>5,294                   | 5,268 | 2,642<br>2,634                   | 2,638 | 65,396<br>65,372 | 65,384 | 2,176<br>2,175 | 2,176 | 2,064<br>2,058    | 2,061 |

Table B.1 (continued)

| Laboratory ref. | Na <sub>2</sub> O % |       | K <sub>2</sub> O % |       | TiO <sub>2</sub> % |       | P <sub>2</sub> O <sub>5</sub> % |       | MnO %          |       | SrO %          |       | Total   |
|-----------------|---------------------|-------|--------------------|-------|--------------------|-------|---------------------------------|-------|----------------|-------|----------------|-------|---------|
|                 | Results             | Mean  | Results            | Mean  | Results            | Mean  | Results                         | Mean  | Results        | Mean  | Results        | Mean  |         |
| 1               | 0,272<br>0,257      | 0,264 | 0,541<br>0,548     | 0,544 | 0,344<br>0,344     | 0,344 | 0,287<br>0,286                  | 0,286 | 0,069<br>0,069 | 0,069 | -<br>-         | -     | 99,835  |
| 2               | 0,264<br>0,263      | 0,264 | 0,533<br>0,536     | 0,534 | 0,356<br>0,349     | 0,352 | 0,283<br>0,284                  | 0,284 | 0,066<br>0,065 | 0,066 | 0,044<br>0,044 | 0,44  | 99,853  |
| 3               | 0,266<br>0,253      | 0,260 | 0,570<br>0,568     | 0,569 | 0,355<br>0,358     | 0,356 | 0,279<br>0,278                  | 0,278 | 0,063<br>0,063 | 0,063 | -<br>-         | -     | 99,711  |
| 4               | 0,260<br>0,258      | 0,259 | 0,560<br>0,564     | 0,562 | 0,358<br>0,354     | 0,356 | 0,288<br>0,286                  | 0,287 | 0,063<br>0,063 | 0,063 | 0,043<br>0,043 | 0,043 | 99,879  |
| 5               | 0,262<br>0,263      | 0,262 | 0,560<br>0,563     | 0,562 | 0,357<br>0,355     | 0,356 | 0,283<br>0,284                  | 0,284 | 0,064<br>0,064 | 0,064 | 0,044<br>0,044 | 0,044 | 99,901  |
| 6               | 0,265<br>0,276      | 0,270 | 0,581<br>0,588     | 0,584 | 0,341<br>0,349     | 0,345 | 0,287<br>0,285                  | 0,286 | 0,066<br>0,064 | 0,065 | 0,042<br>0,042 | 0,042 | 99,725  |
| 7               | 0,253<br>0,255      | 0,254 | 0,566<br>0,564     | 0,565 | 0,359<br>0,354     | 0,356 | 0,282<br>0,282                  | 0,282 | 0,065<br>0,064 | 0,064 | 0,044<br>0,044 | 0,044 | 99,922  |
| 8               | 0,244<br>0,251      | 0,248 | 0,562<br>0,561     | 0,562 | 0,352<br>0,344     | 0,348 | 0,283<br>0,282                  | 0,282 | 0,061<br>0,061 | 0,061 | 0,043<br>0,043 | 0,043 | 99,677  |
| 9               | 0,264<br>0,265      | 0,264 | 0,575<br>0,574     | 0,574 | 0,345<br>0,347     | 0,346 | 0,285<br>0,286                  | 0,286 | 0,069<br>0,069 | 0,069 | 0,041<br>0,041 | 0,041 | 99,752  |
| 10              | 0,232<br>0,239      | 0,236 | 0,568<br>0,567     | 0,568 | 0,347<br>0,350     | 0,348 | 0,281<br>0,281                  | 0,281 | 0,069<br>0,069 | 0,069 | -<br>-         | -     | 99,839  |
| 11              | 0,242<br>0,254      | 0,248 | 0,523<br>0,533     | 0,528 | 0,353<br>0,357     | 0,355 | 0,283<br>0,288                  | 0,286 | 0,063<br>0,062 | 0,062 | -<br>-         | -     | 99,854  |
| 12              | 0,264<br>0,271      | 0,268 | 0,572<br>0,570     | 0,571 | 0,346<br>0,357     | 0,352 | 0,285<br>0,285                  | 0,285 | 0,063<br>0,066 | 0,064 | 0,043<br>0,044 | 0,044 | 100,016 |
| 13              | 0,264<br>0,266      | 0,265 | 0,559<br>0,559     | 0,559 | 0,354<br>0,358     | 0,356 | 0,291<br>0,291                  | 0,291 | 0,064<br>0,063 | 0,064 | 0,044<br>0,044 | 0,044 | 99,731  |
| 14              | 0,267<br>0,269      | 0,268 | 0,586<br>0,568     | 0,577 | 0,341<br>0,328     | 0,334 | 0,302<br>0,292                  | 0,297 | 0,064<br>0,065 | 0,064 | 0,045<br>0,045 | 0,045 | 100,202 |
| 15              | 0,274<br>0,272      | 0,273 | 0,560<br>0,559     | 0,560 | 0,354<br>0,348     | 0,351 | 0,291<br>0,291                  | 0,291 | 0,064<br>0,065 | 0,064 | 0,043<br>0,042 | 0,042 | 99,853  |
| 16              | 0,263<br>0,255      | 0,259 | 0,577<br>0,576     | 0,576 | 0,351<br>0,356     | 0,354 | 0,284<br>0,282                  | 0,283 | 0,063<br>0,063 | 0,063 | 0,043<br>0,043 | 0,043 | 99,976  |
| 101             | 0,229<br>0,223      | 0,226 | 0,569<br>0,573     | 0,571 | 0,347<br>0,344     | 0,346 | 0,288<br>0,285                  | 0,286 | -<br>-         | -     | -<br>-         | -     | 99,879  |
| 102             | -<br>-              | -     | 0,596<br>0,596     | 0,596 | -<br>-             | -     | -<br>-                          | -     | -<br>-         | -     | -<br>-         | -     | 100,460 |
| 103             | 0,270<br>0,280      | 0,275 | 0,580<br>0,570     | 0,575 | -<br>-             | -     | -<br>-                          | -     | -<br>-         | -     | -<br>-         | -     | 99,160  |
| 104             | 0,239<br>0,249      | 0,244 | 0,556<br>0,572     | 0,564 | 0,343<br>0,341     | 0,342 | 0,276<br>0,272                  | 0,274 | 0,066<br>0,065 | 0,066 | 0,042<br>0,042 | 0,042 | 99,517  |
| 105             | 0,248<br>0,251      | 0,250 | 0,599<br>0,598     | 0,598 | 0,352<br>0,341     | 0,346 | 0,291<br>0,294                  | 0,292 | 0,067<br>0,067 | 0,067 | 0,042<br>0,041 | 0,042 | 100,142 |

Table B.2 — Individual results for all laboratories — JCA-CRM-1

| Laboratory ref. | SiO <sub>2</sub> % |        | Al <sub>2</sub> O <sub>3</sub> % |       | Fe <sub>2</sub> O <sub>3</sub> % |       | CaO %            |        | MgO %          |       | SO <sub>3</sub> % |       |
|-----------------|--------------------|--------|----------------------------------|-------|----------------------------------|-------|------------------|--------|----------------|-------|-------------------|-------|
|                 | Results            | Mean   | Results                          | Mean  | Results                          | Mean  | Results          | Mean   | Results        | Mean  | Results           | Mean  |
| 106             | 20,890<br>21,008   | 20,949 | 5,251<br>5,265                   | 5,258 | 2,673<br>2,675                   | 2,674 | 65,088<br>65,178 | 65,133 | 2,123<br>2,125 | 2,124 | 2,058<br>2,072    | 2,065 |
| 107             | 21,055<br>21,061   | 21,058 | 5,526<br>5,315                   | 5,420 | 2,687<br>2,695                   | 2,691 | 64,449<br>64,494 | 64,472 | 2,167<br>2,134 | 2,150 | 2,055<br>2,023    | 2,039 |
| 108             | 20,91<br>20,90     | 20,905 | 5,25<br>5,26                     | 5,255 | 2,62<br>2,61                     | 2,615 | 65,18<br>65,16   | 65,170 | 2,11<br>2,10   | 2,105 | 2,07<br>2,06      | 2,065 |
| 109             | 20,992<br>20,960   | 20,976 | 5,256<br>5,265                   | 5,260 | 2,636<br>2,622                   | 2,629 | 65,555<br>65,439 | 65,497 | 2,109<br>2,112 | 2,110 | 1,939<br>1,954    | 1,946 |
| 110             | 20,852<br>20,974   | 20,913 | 5,202<br>5,301                   | 5,252 | 2,581<br>2,640                   | 2,610 | 65,154<br>65,113 | 65,134 | 2,302<br>2,041 | 2,172 | 1,925<br>2,061    | 1,993 |
| 111             | 20,94<br>20,90     | 20,920 | 4,97<br>5,00                     | 4,985 | 2,62<br>2,63                     | 2,625 | 64,67<br>64,68   | 64,675 | 2,39<br>2,37   | 2,380 | 2,00<br>2,00      | 2,000 |
| 112             | 20,95<br>21,06     | 21,005 | 5,86<br>5,87                     | 5,865 | 2,58<br>2,58                     | 2,580 | 64,78<br>64,76   | 64,770 | 2,10<br>2,01   | 2,055 | 1,81<br>1,80      | 1,805 |
| 113             | 22,960<br>22,990   | 22,975 | 5,260<br>5,230                   | 5,245 | 2,650<br>2,640                   | 2,645 | 65,210<br>65,360 | 65,285 | 2,070<br>1,980 | 2,025 | 2,080<br>2,050    | 2,065 |
| 114             | 21,33<br>21,98     | 21,655 | 5,09<br>5,27                     | 5,180 | 2,94<br>2,84                     | 2,890 | 65,45<br>66,07   | 65,760 | 2,16<br>1,85   | 2,005 | 2,30<br>2,17      | 2,235 |
| E1              | 20,965<br>20,853   | 20,909 | 5,282<br>5,237                   | 5,260 | 2,669<br>2,656                   | 2,663 | 65,141<br>65,180 | 65,161 | 2,138<br>2,145 | 2,142 | 2,212<br>2,187    | 2,200 |
| E2              | 20,790<br>20,803   | 20,797 | 5,269<br>5,322                   | 5,296 | 2,601<br>2,609                   | 2,605 | 65,080<br>64,919 | 65,000 | 2,104<br>2,123 | 2,114 | 2,078<br>2,057    | 2,068 |
| E3              | 20,780<br>20,800   | 20,790 | 5,140<br>5,190                   | 5,165 | 2,730<br>2,690                   | 2,710 | 65,180<br>65,150 | 65,165 | 2,270<br>2,270 | 2,270 | 1,950<br>2,010    | 1,980 |
| E4              | 20,947<br>20,913   | 20,930 | 5,269<br>5,281                   | 5,275 | 2,658<br>2,649                   | 2,654 | 65,025<br>64,987 | 65,006 | 2,174<br>2,168 | 2,171 | 2,033<br>2,036    | 2,035 |
| E5              | 21,020<br>21,000   | 21,010 | 5,250<br>5,240                   | 5,245 | 2,640<br>2,660                   | 2,650 | 65,350<br>65,300 | 65,325 | 2,130<br>2,140 | 2,135 | 2,070<br>2,060    | 2,065 |
| E6              | 20,963<br>20,927   | 20,945 | 5,213<br>5,252                   | 5,233 | 2,680<br>2,683                   | 2,682 | 65,112<br>65,205 | 65,159 | 2,151<br>2,154 | 2,153 | 2,104<br>2,146    | 2,125 |
| E7              | 20,892<br>21,100   | 20,996 | 5,244<br>5,295                   | 5,270 | 2,689<br>2,686                   | 2,688 | 65,444<br>65,240 | 65,342 | 2,177<br>2,126 | 2,152 | 2,062<br>2,068    | 2,065 |
| E8              | 20,852<br>20,937   | 20,895 | 5,250<br>5,286                   | 5,268 | 2,576<br>2,578                   | 2,577 | 65,140<br>65,126 | 65,133 | 2,142<br>2,138 | 2,140 | 2,062<br>2,069    | 2,066 |
| E9              | 21,010<br>20,972   | 20,991 | 5,203<br>5,242                   | 5,223 | 2,681<br>2,673                   | 2,677 | 65,293<br>65,124 | 65,209 | 2,134<br>2,162 | 2,148 | -<br>-            | -     |
| E10             | 21,080<br>21,090   | 21,085 | 5,150<br>5,160                   | 5,155 | 2,600<br>2,620                   | 2,610 | 65,110<br>65,160 | 65,135 | 2,100<br>2,120 | 2,110 | 2,010<br>2,010    | 2,010 |
| E11             | 20,753<br>20,756   | 20,755 | 5,263<br>5,268                   | 5,266 | 2,670<br>2,663                   | 2,667 | 65,528<br>65,518 | 65,523 | 2,157<br>2,178 | 2,168 | 1,989<br>1,991    | 1,990 |
| E12             | 21,000<br>20,760   | 20,880 | 5,293<br>5,279                   | 5,286 | 2,678<br>2,656                   | 2,667 | 65,260<br>64,560 | 64,910 | 2,150<br>2,151 | 2,151 | 2,060<br>2,043    | 2,052 |

Table B.2 (continued)

| Laboratory ref. | Na <sub>2</sub> O % |       | K <sub>2</sub> O % |       | TiO <sub>2</sub> % |       | P <sub>2</sub> O <sub>5</sub> % |       | MnO %          |        | SrO %          |       | Total   |
|-----------------|---------------------|-------|--------------------|-------|--------------------|-------|---------------------------------|-------|----------------|--------|----------------|-------|---------|
|                 | Results             | Mean  | Results            | Mean  | Results            | Mean  | Results                         | Mean  | Results        | Mean   | Results        | Mean  |         |
| 106             | 0,282<br>0,265      | 0,274 | 0,569<br>0,566     | 0,568 | -<br>-             | -     | -<br>-                          | -     | -<br>-         | -<br>- | -<br>-         | -     | 99,045  |
| 107             | 0,247<br>0,252      | 0,250 | 0,563<br>0,557     | 0,560 | -<br>-             | -     | 0,273<br>0,284                  | 0,278 | 0,061<br>0,060 | 0,060  | -<br>-         | -     | 98,978  |
| 108             | 0,240<br>0,270      | 0,255 | 0,59<br>0,59       | 0,590 | -<br>-             | -     | 0,28<br>0,28                    | 0,280 | -<br>-         | -      | -<br>-         | -     | 99,240  |
| 109             | -<br>-              | -     | 0,569<br>0,571     | 0,570 | -<br>-             | -     | -<br>-                          | -     | -<br>-         | -      | -<br>-         | -     | 98,988  |
| 110             | 0,240<br>0,322      | 0,281 | 0,662<br>0,501     | 0,582 | -<br>-             | -     | 0,276<br>0,298                  | 0,287 | -<br>-         | -      | -<br>-         | -     | 99,224  |
| 111             | 0,280<br>0,290      | 0,285 | 0,57<br>0,57       | 0,570 | 0,38<br>0,39       | 0,385 | 0,35<br>0,36                    | 0,355 | 0,07<br>0,07   | 0,070  | 0,04<br>0,04   | 0,040 | 99,290  |
| 112             | 0,190<br>0,190      | 0,190 | 0,58<br>0,58       | 0,580 | -<br>-             | -     | -<br>-                          | -     | -<br>-         | -      | -<br>-         | -     | 98,850  |
| 113             | 0,260<br>0,250      | 0,255 | 0,580<br>0,580     | 0,580 | 0,350<br>0,350     | 0,350 | 0,280<br>0,290                  | 0,285 | 0,070<br>0,070 | 0,070  | 0,040<br>0,040 | 0,040 | 101,820 |
| 114             | 0,710<br>0,710      | 0,710 | 0,54<br>0,54       | 0,540 | -<br>-             | -     | -<br>-                          | -     | -<br>-         | -      | -<br>-         | -     | 100,975 |
| E1              | 0,253<br>0,262      | 0,258 | 0,565<br>0,563     | 0,564 | 0,351<br>0,357     | 0,354 | 0,292<br>0,292                  | 0,292 | 0,062<br>0,062 | 0,062  | 0,044<br>0,044 | 0,044 | 99,906  |
| E2              | 0,274<br>0,272      | 0,273 | 0,572<br>0,567     | 0,570 | 0,340<br>0,342     | 0,341 | 0,287<br>0,284                  | 0,286 | 0,068<br>0,068 | 0,068  | -<br>-         | -     | 99,415  |
| E3              | 0,260<br>0,260      | 0,260 | 0,550<br>0,550     | 0,550 | 0,350<br>0,350     | 0,350 | 0,300<br>0,290                  | 0,295 | 0,070<br>0,070 | 0,070  | 0,050<br>0,050 | 0,050 | 99,655  |
| E4              | 0,267<br>0,272      | 0,270 | 0,572<br>0,574     | 0,573 | 0,344<br>0,344     | 0,344 | 0,291<br>0,288                  | 0,290 | 0,067<br>0,066 | 0,067  | 0,041<br>0,041 | 0,041 | 99,654  |
| E5              | 0,270<br>0,260      | 0,265 | 0,570<br>0,580     | 0,575 | 0,340<br>0,350     | 0,345 | 0,260<br>0,290                  | 0,275 | 0,070<br>0,070 | 0,070  | 0,040<br>0,040 | 0,040 | 100,000 |
| E6              | 0,124<br>0,128      | 0,126 | 0,564<br>0,560     | 0,562 | 0,348<br>0,347     | 0,348 | 0,313<br>0,303                  | 0,308 | 0,059<br>0,060 | 0,060  | -<br>-         | -     | 99,698  |
| E7              | 0,270<br>0,278      | 0,274 | 0,561<br>0,567     | 0,564 | 0,361<br>0,351     | 0,356 | 0,281<br>0,286                  | 0,284 | 0,063<br>0,062 | 0,063  | 0,054<br>0,053 | 0,054 | 100,105 |
| E8              | 0,273<br>0,262      | 0,268 | 0,571<br>0,572     | 0,572 | 0,341<br>0,345     | 0,343 | 0,284<br>0,284                  | 0,284 | 0,067<br>0,068 | 0,068  | 0,042<br>0,042 | 0,042 | 99,654  |
| E9              | 0,251<br>0,260      | 0,256 | 0,562<br>0,563     | 0,563 | 0,332<br>0,343     | 0,338 | -<br>-                          | -     | -<br>-         | -      | -<br>-         | -     | 97,403  |
| E10             | 0,290<br>0,290      | 0,290 | 0,570<br>0,570     | 0,570 | -<br>-             | -     | -<br>-                          | -     | -<br>-         | -      | -<br>-         | -     | 98,965  |
| E11             | 0,249<br>0,249      | 0,249 | 0,571<br>0,569     | 0,570 | 0,340<br>0,341     | 0,341 | 0,280<br>0,280                  | 0,280 | 0,064<br>0,063 | 0,064  | 0,050<br>0,050 | 0,050 | 99,920  |
| E12             | 0,263<br>0,243      | 0,253 | 0,572<br>0,561     | 0,566 | 0,355<br>0,348     | 0,352 | 0,288<br>0,281                  | 0,285 | 0,071<br>0,070 | 0,071  | -<br>-         | -     | 99,471  |

Table B.3 — Individual results for all laboratories — JCA-CRM-2

| Laboratory ref. | SiO <sub>2</sub> % |        | Al <sub>2</sub> O <sub>3</sub> % |       | Fe <sub>2</sub> O <sub>3</sub> % |       | CaO %   |        | MgO %   |       | SO <sub>3</sub> % |       |
|-----------------|--------------------|--------|----------------------------------|-------|----------------------------------|-------|---------|--------|---------|-------|-------------------|-------|
|                 | Results            | Mean   | Results                          | Mean  | Results                          | Mean  | Results | Mean   | Results | Mean  | Results           | Mean  |
| 1               | 25,651             | 25,652 | 8,943                            | 8,944 | 2,137                            | 2,138 | 56,491  | 56,490 | 3,055   | 3,054 | 2,588             | 2,558 |
|                 | 25,652             |        | 8,944                            |       | 2,140                            |       | 56,489  |        | 3,053   |       | 2,557             |       |
| 2               | 25,573             | 25,548 | 8,915                            | 8,920 | 2,087                            | 2,088 | 56,482  | 56,472 | 3,022   | 3,031 | 2,553             | 2,570 |
|                 | 25,522             |        | 8,925                            |       | 2,088                            |       | 56,462  |        | 3,040   |       | 2,586             |       |
| 3               | 25,535             | 25,519 | 8,942                            | 8,937 | 2,107                            | 2,100 | 56,538  | 56,532 | 2,977   | 2,972 | -                 | -     |
|                 | 25,503             |        | 8,932                            |       | 2,094                            |       | 56,525  |        | 2,968   |       | -                 |       |
| 4               | 25,633             | 25,637 | 8,924                            | 8,932 | 2,104                            | 2,101 | 56,406  | 56,382 | 3,035   | 3,040 | 2,569             | 2,580 |
|                 | 25,641             |        | 8,940                            |       | 2,098                            |       | 56,359  |        | 3,045   |       | 2,590             |       |
| 5               | 25,595             | 25,614 | 8,921                            | 8,930 | 2,083                            | 2,082 | 56,424  | 56,430 | 3,026   | 3,030 | 2,579             | 2,569 |
|                 | 25,633             |        | 8,940                            |       | 2,082                            |       | 56,436  |        | 3,035   |       | 2,559             |       |
| 6               | 25,651             | 25,594 | 9,027                            | 9,005 | 2,152                            | 2,143 | 56,617  | 56,564 | 3,073   | 3,060 | 2,544             | 2,527 |
|                 | 25,538             |        | 8,983                            |       | 2,134                            |       | 56,512  |        | 3,048   |       | 2,510             |       |
| 7               | 25,695             | 25,690 | 8,948                            | 8,950 | 2,071                            | 2,072 | 56,462  | 56,481 | 3,097   | 3,084 | 2,602             | 2,602 |
|                 | 25,686             |        | 8,951                            |       | 2,072                            |       | 56,500  |        | 3,071   |       | 2,603             |       |
| 8               | 25,568             | 25,566 | 8,909                            | 8,901 | 2,040                            | 2,042 | 56,167  | 56,147 | 3,059   | 3,058 | 2,367             | 2,366 |
|                 | 25,563             |        | 8,893                            |       | 2,043                            |       | 56,127  |        | 3,056   |       | 2,366             |       |
| 9               | 25,537             | 25,584 | 8,923                            | 8,931 | 2,138                            | 2,138 | 56,444  | 56,494 | 3,049   | 3,055 | -                 | -     |
|                 | 25,631             |        | 8,939                            |       | 2,139                            |       | 56,545  |        | 3,061   |       | -                 |       |
| 10              | 25,568             | 25,586 | 8,947                            | 8,902 | 2,137                            | 2,130 | 56,437  | 56,528 | 2,956   | 2,976 | -                 | -     |
|                 | 25,603             |        | 8,856                            |       | 2,122                            |       | 56,620  |        | 2,996   |       | -                 |       |
| 11              | 25,697             | 25,687 | 8,892                            | 8,877 | 2,084                            | 2,083 | 56,457  | 56,407 | 3,044   | 3,020 | 2,603             | 2,606 |
|                 | 25,677             |        | 8,862                            |       | 2,082                            |       | 56,357  |        | 2,997   |       | 2,608             |       |
| 12              | 25,678             | 25,675 | 8,965                            | 8,939 | 2,070                            | 2,080 | 56,440  | 56,429 | 3,039   | 3,041 | -                 | -     |
|                 | 25,672             |        | 8,913                            |       | 2,090                            |       | 56,418  |        | 3,043   |       | -                 |       |
| 13              | 25,736             | 25,731 | 8,929                            | 8,925 | 2,083                            | 2,084 | 56,271  | 56,242 | 3,053   | 3,057 | 2,632             | 2,628 |
|                 | 25,726             |        | 8,921                            |       | 2,086                            |       | 56,213  |        | 3,061   |       | 2,624             |       |
| 14              | 25,787             | 25,752 | 8,965                            | 8,939 | 2,125                            | 2,122 | 56,428  | 56,506 | 3,062   | 3,058 | 2,641             | 2,638 |
|                 | 25,716             |        | 8,913                            |       | 2,119                            |       | 56,584  |        | 3,053   |       | 2,635             |       |
| 15              | 25,610             | 25,584 | 8,968                            | 8,965 | 2,087                            | 2,090 | 56,327  | 56,316 | 3,019   | 3,018 | 2,605             | 2,600 |
|                 | 25,558             |        | 8,962                            |       | 2,092                            |       | 56,306  |        | 3,018   |       | 2,596             |       |
| 16              | 25,712             | 25,685 | 8,937                            | 8,960 | 2,072                            | 2,075 | 56,533  | 56,524 | 3,046   | 3,040 | 2,604             | 2,590 |
|                 | 25,658             |        | 8,983                            |       | 2,078                            |       | 56,514  |        | 3,035   |       | 2,577             |       |
| 101             | 25,631             | 25,634 | 8,942                            | 8,922 | 2,124                            | 2,118 | 56,586  | 56,556 | 3,013   | 3,020 | -                 | -     |
|                 | 25,636             |        | 8,903                            |       | 2,113                            |       | 56,526  |        | 3,026   |       | -                 |       |
| 102             | 25,589             | 25,600 | 8,918                            | 8,924 | 2,131                            | 2,129 | 56,644  | 56,658 | 3,077   | 3,073 | 1,320             | 1,322 |
|                 | 25,611             |        | 8,929                            |       | 2,127                            |       | 56,673  |        | 3,069   |       | 1,323             |       |
| 103             | 25,650             | 25,660 | 8,930                            | 8,965 | 2,150                            | 2,155 | 56,530  | 56,530 | 3,060   | 2,990 | 2,540             | 2,555 |
|                 | 25,670             |        | 9,000                            |       | 2,160                            |       | 56,530  |        | 2,920   |       | 2,570             |       |
| 104             | 25,550             | 25,533 | 8,885                            | 8,866 | 2,123                            | 2,118 | 56,411  | 56,317 | 3,033   | 3,028 | 1,880             | 1,890 |
|                 | 25,516             |        | 8,846                            |       | 2,113                            |       | 56,223  |        | 3,024   |       | 1,900             |       |
| 105             | 25,653             | 25,632 | 8,911                            | 8,920 | 2,125                            | 2,124 | 56,557  | 56,552 | 3,073   | 3,083 | 2,568             | 2,570 |
|                 | 25,610             |        | 8,930                            |       | 2,123                            |       | 56,547  |        | 3,093   |       | 2,571             |       |

Table B.3 (continued)

| Laboratory ref. | Na <sub>2</sub> O % |       | K <sub>2</sub> O % |       | TiO <sub>2</sub> % |       | P <sub>2</sub> O <sub>5</sub> % |       | MnO %          |       | SrO %          |       | Total   |
|-----------------|---------------------|-------|--------------------|-------|--------------------|-------|---------------------------------|-------|----------------|-------|----------------|-------|---------|
|                 | Results             | Mean  | Results            | Mean  | Results            | Mean  | Results                         | Mean  | Results        | Mean  | Results        | Mean  |         |
| 1               | 0,273<br>0,268      | 0,270 | 0,309<br>0,315     | 0,312 | 0,505<br>0,504     | 0,504 | 0,074<br>0,074                  | 0,074 | 0,162<br>0,162 | 0,162 | -<br>-         | -     | 100,158 |
| 2               | 0,242<br>0,245      | 0,244 | 0,322<br>0,320     | 0,321 | 0,500<br>0,514     | 0,507 | 0,073<br>0,075                  | 0,074 | 0,155<br>0,155 | 0,155 | 0,069<br>0,068 | 0,68  | 99,998  |
| 3               | 0,223<br>0,214      | 0,218 | 0,323<br>0,324     | 0,324 | 0,506<br>0,506     | 0,506 | 0,075<br>0,075                  | 0,075 | 0,160<br>0,159 | 0,160 | -<br>-         | -     | 97,343  |
| 4               | 0,240<br>0,237      | 0,238 | 0,320<br>0,317     | 0,318 | 0,506<br>0,506     | 0,506 | 0,076<br>0,075                  | 0,076 | 0,151<br>0,154 | 0,152 | 0,065<br>0,065 | 0,065 | 100,027 |
| 5               | 0,241<br>0,240      | 0,240 | 0,320<br>0,321     | 0,320 | 0,504<br>0,502     | 0,503 | 0,075<br>0,075                  | 0,075 | 0,155<br>0,155 | 0,155 | 0,069<br>0,069 | 0,069 | 100,017 |
| 6               | 0,246<br>0,234      | 0,240 | 0,320<br>0,313     | 0,316 | 0,515<br>0,508     | 0,512 | 0,074<br>0,072                  | 0,073 | 0,155<br>0,155 | 0,155 | 0,066<br>0,066 | 0,066 | 100,255 |
| 7               | 0,231<br>0,231      | 0,231 | 0,322<br>0,323     | 0,322 | 0,502<br>0,504     | 0,503 | 0,074<br>0,073                  | 0,074 | 0,154<br>0,154 | 0,154 | 0,068<br>0,068 | 0,068 | 100,231 |
| 8               | 0,234<br>0,234      | 0,234 | 0,323<br>0,323     | 0,323 | 0,496<br>0,503     | 0,500 | 0,075<br>0,076                  | 0,076 | 0,157<br>0,158 | 0,158 | 0,063<br>0,063 | 0,063 | 99,434  |
| 9               | 0,252<br>0,254      | 0,253 | 0,310<br>0,312     | 0,311 | 0,504<br>0,500     | 0,502 | 0,074<br>0,074                  | 0,074 | 0,163<br>0,162 | 0,162 | 0,065<br>0,065 | 0,065 | 97,569  |
| 10              | 0,232<br>0,221      | 0,226 | 0,324<br>0,326     | 0,325 | 0,508<br>0,505     | 0,506 | 0,074<br>0,074                  | 0,074 | 0,158<br>0,159 | 0,158 | -<br>-         | -     | 97,411  |
| 11              | 0,257<br>0,241      | 0,249 | 0,319<br>0,319     | 0,319 | 0,512<br>0,498     | 0,505 | 0,076<br>0,077                  | 0,076 | 0,156<br>0,155 | 0,156 | -<br>-         | -     | 99,985  |
| 12              | 0,236<br>0,250      | 0,243 | 0,330<br>0,326     | 0,328 | 0,504<br>0,510     | 0,507 | 0,076<br>0,076                  | 0,076 | 0,157<br>0,156 | 0,156 | 0,063<br>0,064 | 0,064 | 97,538  |
| 13              | 0,241<br>0,243      | 0,242 | 0,320<br>0,320     | 0,320 | 0,503<br>0,508     | 0,506 | 0,080<br>0,080                  | 0,080 | 0,152<br>0,152 | 0,152 | 0,069<br>0,069 | 0,069 | 100,036 |
| 14              | 0,252<br>0,244      | 0,248 | 0,329<br>0,325     | 0,327 | 0,492<br>0,478     | 0,485 | 0,094<br>0,079                  | 0,086 | 0,153<br>0,156 | 0,154 | 0,070<br>0,071 | 0,070 | 100,385 |
| 15              | 0,253<br>0,247      | 0,250 | 0,320<br>0,322     | 0,321 | 0,521<br>0,518     | 0,520 | 0,081<br>0,082                  | 0,082 | 0,155<br>0,155 | 0,155 | 0,065<br>0,065 | 0,065 | 99,966  |
| 16              | 0,244<br>0,239      | 0,242 | 0,310<br>0,312     | 0,311 | 0,504<br>0,501     | 0,502 | 0,075<br>0,075                  | 0,075 | 0,155<br>0,154 | 0,154 | 0,066<br>0,067 | 0,066 | 100,224 |
| 101             | 0,217<br>0,200      | 0,208 | 0,323<br>0,324     | 0,324 | 0,506<br>0,505     | 0,506 | 0,074<br>0,074                  | 0,074 | -<br>-         | -     | -<br>-         | -     | 97,362  |
| 102             | -<br>-              | -     | 0,309<br>0,310     | 0,310 | -<br>-             | -     | -<br>-                          | -     | -<br>-         | -     | -<br>-         | -     | 98,016  |
| 103             | 0,240<br>0,250      | 0,245 | 0,310<br>0,310     | 0,310 | -<br>-             | -     | -<br>-                          | -     | -<br>-         | -     | -<br>-         | -     | 99,410  |
| 104             | 0,266<br>0,259      | 0,262 | 0,331<br>0,314     | 0,322 | 0,502<br>0,499     | 0,500 | 0,067<br>0,066                  | 0,066 | 0,158<br>0,155 | 0,156 | 0,066<br>0,066 | 0,066 | 99,124  |
| 105             | 0,226<br>0,230      | 0,228 | 0,345<br>0,341     | 0,343 | 0,518<br>0,508     | 0,513 | 0,086<br>0,081                  | 0,084 | 0,164<br>0,158 | 0,161 | 0,065<br>0,065 | 0,065 | 100,275 |

Table B.4 — Individual results for all laboratories — JCA-CRM-2

| Laboratory ref. | SiO <sub>2</sub> % |        | Al <sub>2</sub> O <sub>3</sub> % |       | Fe <sub>2</sub> O <sub>3</sub> % |       | CaO %            |        | MgO %          |       | SO <sub>3</sub> % |        |
|-----------------|--------------------|--------|----------------------------------|-------|----------------------------------|-------|------------------|--------|----------------|-------|-------------------|--------|
|                 | Results            | Mean   | Results                          | Mean  | Results                          | Mean  | Results          | Mean   | Results        | Mean  | Results           | Mean   |
| 106             | 25,547<br>25,490   | 25,518 | 8,962<br>8,917                   | 8,940 | 2,047<br>2,090                   | 2,068 | 56,510<br>56,617 | 56,564 | 3,009<br>3,024 | 3,016 | -<br>-            | -<br>- |
| 107             | 25,510<br>25,631   | 25,570 | 8,944<br>8,930                   | 8,937 | 2,033<br>2,081                   | 2,057 | 56,456<br>56,468 | 56,462 | 2,885<br>2,870 | 2,878 | -<br>-            | -<br>- |
| 108             | 25,870<br>25,620   | 25,745 | 8,980<br>8,920                   | 8,950 | 2,130<br>2,130                   | 2,130 | 56,770<br>56,520 | 56,645 | 3,050<br>3,030 | 3,040 | 2,570<br>2,540    | 2,555  |
| 109             | 25,752<br>25,698   | 25,725 | 8,996<br>8,973                   | 8,984 | 2,154<br>2,141                   | 2,148 | 56,542<br>56,485 | 56,514 | 3,076<br>3,074 | 3,075 | 2,454<br>2,430    | 2,442  |
| 110             | 25,663<br>25,641   | 25,652 | 8,940<br>8,821                   | 8,880 | 2,082<br>2,064                   | 2,073 | 56,482<br>56,620 | 56,551 | 3,054<br>3,091 | 3,072 | 1,910<br>1,932    | 1,921  |
| 111             | 25,280<br>25,340   | 25,310 | 8,650<br>8,600                   | 8,625 | 2,110<br>2,100                   | 2,105 | 56,340<br>56,270 | 56,305 | 3,230<br>3,260 | 3,245 | 1,260<br>1,280    | 1,270  |
| 112             | -<br>-             | -      | -<br>-                           | -     | -<br>-                           | -     | -<br>-           | -      | -<br>-         | -     | -<br>-            | -<br>- |
| 113             | 25,690<br>25,740   | 25,715 | 8,960<br>8,910                   | 8,935 | 2,140<br>2,120                   | 2,130 | 56,790<br>56,840 | 56,815 | 3,110<br>3,140 | 3,125 | -<br>-            | -<br>- |
| 114             | 25,460<br>25,310   | 25,385 | 6,540<br>6,600                   | 6,570 | 2,570<br>2,460                   | 2,515 | 56,570<br>56,740 | 56,655 | 2,160<br>3,140 | 2,650 | 2,310<br>2,160    | 2,235  |
| E1              | 25,667<br>25,635   | 25,651 | 8,914<br>8,919                   | 8,917 | 2,082<br>2,079                   | 2,081 | 56,470<br>56,398 | 56,434 | 3,030<br>3,040 | 3,035 | 2,385<br>2,384    | 2,385  |
| E2              | 25,515<br>25,595   | 25,555 | 8,915<br>8,921                   | 8,918 | 2,119<br>2,111                   | 2,115 | 56,440<br>56,593 | 56,517 | 3,032<br>3,035 | 3,034 | 2,592<br>2,569    | 2,581  |
| E3              | 25,330<br>25,370   | 25,350 | 8,700<br>8,730                   | 8,715 | 2,130<br>2,100                   | 2,115 | 56,330<br>56,370 | 56,350 | 3,210<br>3,200 | 3,205 | 2,540<br>2,500    | 2,520  |
| E4              | 25,538<br>25,636   | 25,587 | 8,861<br>8,872                   | 8,867 | 2,121<br>2,125                   | 2,123 | 56,073<br>56,121 | 56,097 | 2,984<br>2,997 | 2,991 | -<br>-            | -<br>- |
| E5              | 25,630<br>25,670   | 25,650 | 8,940<br>8,920                   | 8,930 | 2,100<br>2,100                   | 2,100 | 56,210<br>56,250 | 56,230 | 3,030<br>3,030 | 3,030 | -<br>-            | -<br>- |
| E6              | 25,532<br>25,598   | 25,565 | 8,870<br>8,879                   | 8,875 | 2,094<br>2,096                   | 2,095 | 56,360<br>56,480 | 56,420 | 3,043<br>3,061 | 3,052 | -<br>-            | -<br>- |
| E7              | 25,769<br>25,808   | 25,789 | 8,930<br>8,881                   | 8,906 | 2,094<br>2,095                   | 2,095 | 56,416<br>56,491 | 56,454 | 3,059<br>3,025 | 3,042 | 2,698<br>2,716    | 2,618  |
| E8              | 25,612<br>25,606   | 25,609 | 8,928<br>8,938                   | 8,933 | 2,154<br>2,141                   | 2,148 | 56,391<br>56,404 | 56,398 | 3,042<br>3,043 | 3,043 | 2,160<br>2,160    | 2,707  |
| E9              | 25,724<br>25,639   | 25,682 | 8,919<br>8,869                   | 8,894 | 2,091<br>2,116                   | 2,104 | 56,434<br>56,643 | 56,539 | 3,041<br>3,075 | 3,058 | -<br>-            | -<br>- |
| E10             | 25,470<br>25,530   | 25,500 | 8,620<br>8,650                   | 8,635 | 2,120<br>2,130                   | 2,125 | 57,080<br>57,110 | 57,095 | 2,970<br>2,960 | 2,965 | 2,619<br>2,617    | 2,160  |
| E11             | 25,519<br>25,472   | 25,496 | 8,989<br>8,996                   | 8,993 | 2,137<br>2,137                   | 2,137 | 57,040<br>57,038 | 57,039 | 3,125<br>3,089 | 3,107 | 2,503<br>2,504    | 2,504  |
| E12             | 25,620<br>25,680   | 25,650 | 9,002<br>8,919                   | 8,961 | 2,091<br>2,083                   | 2,087 | 56,250<br>56,660 | 56,455 | 3,077<br>3,099 | 3,088 | -<br>-            | -<br>- |

Table B.4 (continued)

| Laboratory ref. | Na <sub>2</sub> O % |       | K <sub>2</sub> O % |       | TiO <sub>2</sub> % |       | P <sub>2</sub> O <sub>5</sub> % |       | MnO %          |        | SrO %          |        | Total   |
|-----------------|---------------------|-------|--------------------|-------|--------------------|-------|---------------------------------|-------|----------------|--------|----------------|--------|---------|
|                 | Results             | Mean  | Results            | Mean  | Results            | Mean  | Results                         | Mean  | Results        | Mean   | Results        | Mean   |         |
| 106             | 0,253<br>0,251      | 0,252 | 0,328<br>0,329     | 0,328 | -<br>-             | -     | -<br>-                          | -     | -<br>-         | -<br>- | -<br>-         | -<br>- | 96,686  |
| 107             | 0,252<br>0,261      | 0,256 | 0,332<br>0,337     | 0,334 | -<br>-             | -     | 0,075<br>0,073                  | 0,074 | 0,159<br>0,162 | 0,160  | -<br>-         | -<br>- | 96,728  |
| 108             | 0,270<br>0,200      | 0,235 | 0,320<br>0,320     | 0,320 | -<br>-             | -     | 0,080<br>0,070                  | 0,075 | -<br>-         | -<br>- | -<br>-         | -<br>- | 99,695  |
| 109             | -<br>-              | -     | 0,307<br>0,317     | 0,312 | -<br>-             | -     | -<br>-                          | -     | -<br>-         | -<br>- | -<br>-         | -<br>- | 99,200  |
| 110             | 0,220<br>0,241      | 0,230 | 0,331<br>0,312     | 0,322 | -<br>-             | -     | 0,086<br>0,078                  | 0,082 | -<br>-         | -<br>- | -<br>-         | -<br>- | 98,783  |
| 111             | 0,270<br>0,270      | 0,270 | 0,330<br>0,330     | 0,330 | 0,530<br>0,520     | 0,525 | 0,010<br>0,030                  | 0,020 | 0,160<br>0,160 | 0,160  | 0,060<br>0,060 | 0,060  | 98,225  |
| 112             | -<br>-              | -     | -<br>-             | -     | -<br>-             | -     | -<br>-                          | -     | -<br>-         | -<br>- | -<br>-         | -<br>- | -       |
| 113             | 0,240<br>0,230      | 0,235 | 0,330<br>0,320     | 0,325 | 0,510<br>0,500     | 0,505 | 0,080<br>0,080                  | 0,080 | 0,160<br>0,160 | 0,160  | 0,060<br>0,060 | 0,060  | 98,085  |
| 114             | 0,660<br>0,660      | 0,660 | 0,280<br>0,270     | 0,275 | -<br>-             | -     | -<br>-                          | -     | -<br>-         | -<br>- | -<br>-         | -<br>- | 96,945  |
| E1              | 0,249<br>0,248      | 0,249 | 0,323<br>0,326     | 0,325 | 0,498<br>0,504     | 0,501 | 0,075<br>0,080                  | 0,078 | 0,156<br>0,156 | 0,156  | 0,068<br>0,068 | 0,068  | 99,877  |
| E2              | 0,303<br>0,265      | 0,284 | 0,320<br>0,317     | 0,319 | 0,503<br>0,503     | 0,503 | 0,076<br>0,077                  | 0,077 | 0,160<br>0,161 | 0,161  | -<br>-         | -<br>- | 100,061 |
| E3              | 0,240<br>0,240      | 0,240 | 0,310<br>0,310     | 0,310 | 0,490<br>0,490     | 0,490 | 0,080<br>0,080                  | 0,080 | 0,180<br>0,180 | 0,180  | 0,080<br>0,080 | 0,080  | 99,635  |
| E4              | 0,236<br>0,239      | 0,238 | 0,316<br>0,319     | 0,318 | 0,506<br>0,503     | 0,505 | 0,070<br>0,069                  | 0,070 | 0,164<br>0,160 | 0,162  | 0,058<br>0,059 | 0,059  | 97,014  |
| E5              | 0,220<br>0,240      | 0,230 | 0,310<br>0,320     | 0,315 | 0,500<br>0,510     | 0,505 | 0,070<br>0,070                  | 0,070 | 0,160<br>0,160 | 0,160  | 0,070<br>0,080 | 0,075  | 97,295  |
| E6              | 0,118<br>0,114      | 0,116 | 0,319<br>0,322     | 0,321 | 0,495<br>0,495     | 0,495 | 0,108<br>0,116                  | 0,112 | 0,145<br>0,145 | 0,145  | -<br>-         | -<br>- | 97,195  |
| E7              | 0,256<br>0,240      | 0,248 | 0,317<br>0,318     | 0,318 | 0,497<br>0,502     | 0,500 | 0,075<br>0,077                  | 0,076 | 0,156<br>0,156 | 0,156  | 0,082<br>0,080 | 0,081  | 100,280 |
| E8              | 0,271<br>0,257      | 0,264 | 0,315<br>0,316     | 0,316 | 0,509<br>0,505     | 0,507 | 0,075<br>0,074                  | 0,075 | 0,160<br>0,160 | 0,160  | 0,066<br>0,060 | 0,063  | 100,221 |
| E9              | -<br>-              | -     | 0,328<br>0,327     | 0,328 | 0,532<br>0,521     | 0,527 | -<br>-                          | -     | -<br>-         | -<br>- | -<br>-         | -<br>- | 97,130  |
| E10             | 0,260<br>0,260      | 0,260 | 0,340<br>0,340     | 0,340 | -<br>-             | -     | -<br>-                          | -     | -<br>-         | -<br>- | -<br>-         | -<br>- | 99,080  |
| E11             | 0,238<br>0,228      | 0,233 | 0,329<br>0,329     | 0,329 | 0,503<br>0,505     | 0,504 | 0,079<br>0,080                  | 0,080 | 0,157<br>0,157 | 0,157  | 0,075<br>0,075 | 0,075  | 100,652 |
| E12             | 0,262<br>0,240      | 0,251 | 0,324<br>0,324     | 0,324 | 0,502<br>0,505     | 0,504 | 0,071<br>0,085                  | 0,078 | 0,175<br>0,175 | 0,175  | -<br>-         | -<br>- | 97,572  |

Table B.5 — Individual results for all laboratories — Sample JCA #1

| Laboratory ref. | Loss on ignition | SiO <sub>2</sub> % |        | Al <sub>2</sub> O <sub>3</sub> % |       | Fe <sub>2</sub> O <sub>3</sub> % |       | CaO %            |        | MgO %          |       | SO <sub>3</sub> % |       |
|-----------------|------------------|--------------------|--------|----------------------------------|-------|----------------------------------|-------|------------------|--------|----------------|-------|-------------------|-------|
|                 |                  | Results            | Mean   | Results                          | Mean  | Results                          | Mean  | Results          | Mean   | Results        | Mean  | Results           | Mean  |
| 1               | 1,97             | 20,896<br>20,962   | 20,929 | 5,103<br>5,124                   | 5,114 | 2,984<br>2,992                   | 2,988 | 65,905<br>66,033 | 65,969 | 1,360<br>1,362 | 1,361 | 2,233<br>2,231    | 2,232 |
| 2               | 1,98             | 20,845<br>20,860   | 20,852 | 5,100<br>5,108                   | 5,104 | 3,022<br>3,019                   | 3,020 | 65,920<br>65,986 | 65,935 | 1,355<br>1,360 | 1,358 | 2,203<br>2,173    | 2,188 |
| 3               | 2,02             | 20,916<br>20,998   | 20,957 | 5,102<br>5,123                   | 5,112 | 3,020<br>3,043                   | 3,032 | 65,792<br>65,931 | 65,862 | 1,328<br>1,355 | 1,342 | 2,179<br>2,199    | 2,189 |
| 4               | 1,98             | 20,826<br>20,924   | 20,875 | 5,091<br>5,099                   | 5,095 | 3,047<br>3,040                   | 3,044 | 65,875<br>65,860 | 65,868 | 1,368<br>1,352 | 1,360 | 2,247<br>2,246    | 2,246 |
| 5               | 1,96             | 20,898<br>20,906   | 20,902 | 5,125<br>5,119                   | 5,122 | 3,040<br>3,038                   | 3,039 | 65,931<br>65,958 | 65,944 | 1,362<br>1,368 | 1,365 | 2,223<br>2,209    | 2,216 |
| 6               | 2,04             | 21,086<br>21,001   | 21,044 | 5,136<br>5,106                   | 5,121 | 2,994<br>2,989                   | 2,992 | 65,993<br>65,818 | 65,906 | 1,342<br>1,348 | 1,345 | 2,236<br>2,217    | 2,226 |
| 7               | 1,98             | 20,930<br>20,914   | 20,922 | 5,101<br>5,105                   | 5,103 | 3,032<br>3,035                   | 3,034 | 65,725<br>65,787 | 65,756 | 1,368<br>1,355 | 1,362 | 2,215<br>2,214    | 2,214 |
| 8               | 1,98             | 20,989<br>20,925   | 20,957 | 5,132<br>5,131                   | 5,132 | 3,032<br>3,030                   | 3,031 | 65,802<br>65,795 | 65,798 | 1,378<br>1,373 | 1,376 | 2,206<br>2,213    | 2,210 |
| 9               | 2,01             | 20,829<br>20,839   | 20,834 | 5,097<br>5,096                   | 5,096 | 2,981<br>2,978                   | 2,980 | 65,863<br>65,925 | 65,894 | 1,357<br>1,357 | 1,357 | 2,228<br>2,235    | 2,232 |
| 10              | 2,05             | 20,956<br>21,006   | 20,981 | 5,064<br>5,088                   | 5,076 | 3,011<br>3,010                   | 3,010 | 66,160<br>66,040 | 66,100 | 1,380<br>1,349 | 1,364 | 2,211<br>2,221    | 2,216 |
| 11              | 1,95             | 21,008<br>21,003   | 21,006 | 5,142<br>5,096                   | 5,119 | 3,056<br>3,039                   | 3,048 | 66,004<br>65,780 | 65,892 | 1,364<br>1,358 | 1,361 | 1,971<br>2,011    | 1,991 |
| 12              | 1,96             | 20,946<br>20,968   | 20,957 | 5,111<br>5,105                   | 5,108 | 3,046<br>3,050                   | 3,048 | 65,803<br>65,882 | 65,842 | 1,339<br>1,349 | 1,344 | 2,176<br>2,156    | 2,166 |
| 13              | 1,97             | 21,092<br>21,064   | 21,078 | 5,115<br>5,125                   | 5,120 | 3,064<br>3,063                   | 3,064 | 65,726<br>65,643 | 65,684 | 1,374<br>1,368 | 1,371 | 2,202<br>2,209    | 2,206 |
| 14              | 2,01             | 20,930<br>20,988   | 20,959 | 5,128<br>5,131                   | 5,130 | 3,097<br>3,094                   | 3,096 | 66,161<br>66,135 | 66,148 | 1,372<br>1,376 | 1,374 | 2,207<br>2,193    | 2,200 |
| 15              | 2,00             | 21,038<br>21,094   | 21,066 | 5,102<br>5,137                   | 5,120 | 3,037<br>3,055                   | 3,046 | 65,763<br>65,962 | 65,862 | 1,323<br>1,345 | 1,334 | 2,147<br>2,177    | 2,162 |
| 16              | 1,96             | 20,973<br>20,951   | 20,962 | 5,130<br>5,116                   | 5,123 | 3,039<br>3,037                   | 3,038 | 65,826<br>65,718 | 65,772 | 1,382<br>1,374 | 1,378 | 2,215<br>2,212    | 2,214 |
| 101             | -                | 21,009<br>20,924   | 20,966 | 5,104<br>5,095                   | 5,100 | 2,989<br>2,976                   | 2,982 | 66,017<br>65,836 | 65,926 | 1,355<br>1,338 | 1,346 | 2,458<br>2,476    | 2,467 |
| 102             | 2,00             | 21,306<br>21,338   | 21,322 | 5,147<br>5,145                   | 5,146 | 3,052<br>3,053                   | 3,052 | 67,380<br>67,387 | 67,384 | 1,382<br>1,386 | 1,384 | 2,514<br>2,520    | 2,517 |
| 103             | 2,04             | 20,990<br>21,000   | 20,995 | 5,050<br>5,050                   | 5,050 | 3,000<br>3,020                   | 3,010 | 66,020<br>65,990 | 66,005 | 1,440<br>1,500 | 1,470 | 2,240<br>2,240    | 2,240 |
| 104             | 1,74             | 21,001<br>20,899   | 20,950 | 5,107<br>5,072                   | 5,090 | 3,017<br>2,977                   | 2,997 | 65,574<br>65,439 | 65,506 | 1,371<br>1,361 | 1,366 | 2,169<br>2,140    | 2,154 |
| 105             | 2,00             | 20,777<br>20,694   | 20,736 | 5,107<br>5,062                   | 5,084 | 2,967<br>2,965                   | 2,966 | 65,120<br>65,061 | 65,090 | 1,389<br>1,389 | 1,389 | 2,200<br>2,185    | 2,192 |

Table B.5 (continued)

| Laboratory ref. | Na <sub>2</sub> O % |       | K <sub>2</sub> O % |       | TiO <sub>2</sub> % |       | P <sub>2</sub> O <sub>5</sub> % |       | MnO %          |       | SrO %          |       | Total   |
|-----------------|---------------------|-------|--------------------|-------|--------------------|-------|---------------------------------|-------|----------------|-------|----------------|-------|---------|
|                 | Results             | Mean  | Results            | Mean  | Results            | Mean  | Results                         | Mean  | Results        | Mean  | Results        | Mean  |         |
| 1               | 0,214<br>0,202      | 0,208 | 0,463<br>0,444     | 0,454 | 0,308<br>0,310     | 0,309 | 0,241<br>0,242                  | 0,242 | 0,097<br>0,097 | 0,097 | -<br>-         | -     | 99,903  |
| 2               | 0,211<br>0,208      | 0,210 | 0,500<br>0,499     | 0,500 | 0,314<br>0,316     | 0,315 | 0,241<br>0,237                  | 0,239 | 0,096<br>0,094 | 0,095 | 0,048<br>0,048 | 0,048 | 99,882  |
| 3               | 0,191<br>0,188      | 0,190 | 0,499<br>0,500     | 0,500 | 0,320<br>0,315     | 0,318 | 0,232<br>0,233                  | 0,232 | 0,094<br>0,094 | 0,094 | -<br>-         | -     | 99,828  |
| 4               | 0,213<br>0,205      | 0,209 | 0,496<br>0,504     | 0,500 | 0,320<br>0,326     | 0,323 | 0,239<br>0,242                  | 0,240 | 0,095<br>0,096 | 0,096 | 0,048<br>0,047 | 0,048 | 99,904  |
| 5               | 0,210<br>0,211      | 0,210 | 0,491<br>0,490     | 0,490 | 0,316<br>0,316     | 0,316 | 0,238<br>0,239                  | 0,238 | 0,096<br>0,096 | 0,096 | 0,049<br>0,049 | 0,049 | 99,987  |
| 6               | 0,236<br>0,218      | 0,227 | 0,521<br>0,510     | 0,516 | 0,317<br>0,311     | 0,314 | 0,244<br>0,243                  | 0,244 | 0,092<br>0,092 | 0,092 | 0,045<br>0,045 | 0,045 | 100,072 |
| 7               | 0,205<br>0,200      | 0,202 | 0,494<br>0,494     | 0,494 | 0,319<br>0,319     | 0,319 | 0,238<br>0,237                  | 0,238 | 0,096<br>0,097 | 0,096 | 0,048<br>0,048 | 0,048 | 99,788  |
| 8               | 0,193<br>0,193      | 0,193 | 0,495<br>0,493     | 0,494 | 0,318<br>0,315     | 0,316 | 0,237<br>0,238                  | 0,238 | 0,092<br>0,095 | 0,094 | 0,046<br>0,046 | 0,046 | 99,885  |
| 9               | 0,209<br>0,209      | 0,209 | 0,504<br>0,505     | 0,504 | 0,307<br>0,310     | 0,308 | 0,238<br>0,241                  | 0,240 | 0,097<br>0,097 | 0,097 | 0,044<br>0,044 | 0,044 | 99,795  |
| 10              | 0,170<br>0,170      | 0,170 | 0,499<br>0,499     | 0,500 | 0,317<br>0,317     | 0,316 | 0,247<br>0,237                  | 0,242 | 0,097<br>0,097 | 0,097 | -<br>-         | -     | 100,079 |
| 11              | 0,194<br>0,193      | 0,194 | 0,522<br>0,515     | 0,518 | 0,320<br>0,315     | 0,318 | 0,236<br>0,239                  | 0,238 | 0,097<br>0,095 | 0,096 | -<br>-         | -     | 99,781  |
| 12              | 0,205<br>0,208      | 0,206 | 0,484<br>0,486     | 0,485 | 0,317<br>0,323     | 0,320 | 0,235<br>0,235                  | 0,235 | 0,091<br>0,091 | 0,091 | 0,053<br>0,054 | 0,054 | 99,856  |
| 13              | 0,212<br>0,214      | 0,213 | 0,493<br>0,494     | 0,494 | 0,313<br>0,312     | 0,312 | 0,246<br>0,245                  | 0,246 | 0,094<br>0,095 | 0,094 | 0,049<br>0,049 | 0,049 | 99,931  |
| 14              | 0,213<br>0,213      | 0,213 | 0,493<br>0,492     | 0,492 | 0,300<br>0,309     | 0,304 | 0,246<br>0,247                  | 0,246 | 0,095<br>0,095 | 0,095 | 0,050<br>0,050 | 0,050 | 100,307 |
| 15              | 0,187<br>0,176      | 0,182 | 0,490<br>0,493     | 0,492 | 0,311<br>0,314     | 0,312 | 0,244<br>0,246                  | 0,245 | 0,097<br>0,095 | 0,096 | 0,047<br>0,047 | 0,047 | 99,964  |
| 16              | 0,205<br>0,211      | 0,208 | 0,503<br>0,506     | 0,504 | 0,319<br>0,318     | 0,318 | 0,240<br>0,236                  | 0,238 | 0,093<br>0,094 | 0,094 | 0,048<br>0,048 | 0,048 | 99,897  |
| 101             | 0,162<br>0,142      | 0,152 | 0,500<br>0,499     | 0,500 | 0,311<br>0,308     | 0,310 | 0,239<br>0,235                  | 0,237 | -<br>-         | -     | -<br>-         | -     | 99,986  |
| 102             | -<br>-              | -     | 0,517<br>0,515     | 0,516 | -<br>-             | -     | -<br>-                          | -     | -<br>-         | -     | -<br>-         | -     | 101,321 |
| 103             | 0,260<br>0,260      | 0,260 | 0,510<br>0,510     | 0,510 | -<br>-             | -     | -<br>-                          | -     | -<br>-         | -     | -<br>-         | -     | 99,540  |
| 104             | 0,135<br>0,130      | 0,132 | 0,503<br>0,484     | 0,494 | 0,313<br>0,306     | 0,310 | 0,234<br>0,230                  | 0,232 | 0,092<br>0,093 | 0,092 | 0,044<br>0,044 | 0,044 | 99,367  |
| 105             | 0,215<br>0,215      | 0,218 | 0,508<br>0,508     | 0,510 | 0,309<br>0,309     | 0,310 | 0,240<br>0,233                  | 0,237 | 0,096<br>0,094 | 0,095 | 0,043<br>0,043 | 0,043 | 99,870  |

Table B.6 — Individual results for all laboratories — Sample JCA #1

| Laboratory ref. | Loss on ignition | SiO <sub>2</sub> % |        | Al <sub>2</sub> O <sub>3</sub> % |       | Fe <sub>2</sub> O <sub>3</sub> % |       | CaO %            |        | MgO %          |       | SO <sub>3</sub> % |       |
|-----------------|------------------|--------------------|--------|----------------------------------|-------|----------------------------------|-------|------------------|--------|----------------|-------|-------------------|-------|
|                 |                  | Results            | Mean   | Results                          | Mean  | Results                          | Mean  | Results          | Mean   | Results        | Mean  | Results           | Mean  |
| 106             | 2,06             | 20,512<br>20,429   | 20,470 | 5,058<br>5,051                   | 5,054 | 2,979<br>2,968                   | 2,974 | 64,670<br>64,542 | 64,606 | 1,334<br>1,335 | 1,334 | 2,180<br>2,155    | 2,168 |
| 107             | 2,02             | 21,354<br>21,305   | 21,330 | 5,367<br>5,356                   | 5,362 | 3,173<br>3,142                   | 3,158 | 66,389<br>66,335 | 66,362 | 1,438<br>1,459 | 1,448 | 2,255<br>2,224    | 2,240 |
| 108             | 1,95             | 21,000<br>21,020   | 21,010 | 5,120<br>5,120                   | 5,120 | 3,000<br>3,000                   | 3,000 | 65,910<br>65,850 | 65,880 | 1,360<br>1,370 | 1,365 | 2,220<br>2,230    | 2,225 |
| 109             | 2,00             | 20,783<br>20,817   | 20,800 | 5,065<br>5,065                   | 5,065 | 2,998<br>2,995                   | 2,996 | 65,852<br>65,905 | 65,878 | 1,346<br>1,354 | 1,350 | 2,113<br>2,101    | 2,107 |
| 110             | -                | 20,590<br>20,631   | 20,610 | 4,781<br>4,941                   | 4,861 | 2,930<br>2,973                   | 2,952 | 65,161<br>65,083 | 65,122 | 1,292<br>1,351 | 1,322 | 2,211<br>2,170    | 2,190 |
| 111             | -                | 20,730<br>20,710   | 20,720 | 4,770<br>4,760                   | 4,765 | 2,980<br>2,970                   | 2,975 | 64,690<br>64,700 | 64,695 | 1,680<br>1,740 | 1,710 | 2,060<br>2,040    | 2,050 |
| 112             | -                | 20,860<br>20,900   | 20,880 | 5,650<br>5,710                   | 5,680 | 2,920<br>2,920                   | 2,920 | 64,820<br>65,000 | 64,910 | 1,300<br>1,280 | 1,290 | 1,990<br>1,850    | 1,920 |
| 113             | 2,03             | 20,780<br>20,850   | 20,815 | 5,160<br>5,110                   | 5,135 | 3,010<br>3,030                   | 3,020 | 65,400<br>65,540 | 65,470 | 1,440<br>1,420 | 1,430 | 2,230<br>2,160    | 2,195 |
| 114             | -                | 20,690<br>21,340   | 21,015 | 5,020<br>5,210                   | 5,115 | 3,220<br>3,450                   | 3,335 | 66,110<br>66,580 | 66,345 | 1,080<br>1,010 | 1,045 | 2,380<br>2,310    | 2,345 |
| E1              | -                | 20,882<br>20,905   | 20,894 | 5,147<br>5,087                   | 5,117 | 3,029<br>3,050                   | 3,040 | 65,821<br>65,898 | 65,860 | 1,353<br>1,368 | 1,361 | 2,308<br>2,295    | 2,302 |
| E2              | 2,00             | 20,814<br>20,886   | 20,850 | 5,111<br>5,103                   | 5,107 | 2,995<br>3,013                   | 3,004 | 65,725<br>65,924 | 65,825 | 1,361<br>1,361 | 1,361 | 2,230<br>2,214    | 2,222 |
| E3              | -                | 20,950<br>21,020   | 20,985 | 5,040<br>5,030                   | 5,035 | 3,120<br>3,130                   | 3,125 | 66,280<br>66,180 | 66,230 | 1,450<br>1,460 | 1,455 | 2,110<br>2,110    | 2,110 |
| E4              | -                | 20,903<br>20,982   | 20,943 | 5,085<br>5,105                   | 5,095 | 2,992<br>2,995                   | 2,994 | 65,675<br>65,741 | 65,708 | 1,303<br>1,296 | 1,300 | 2,193<br>2,219    | 2,206 |
| E5              | 1,96             | 21,070<br>21,050   | 21,060 | 5,100<br>5,040                   | 5,070 | 3,010<br>3,020                   | 3,015 | 65,940<br>66,060 | 66,000 | 1,410<br>1,360 | 1,385 | 2,220<br>2,220    | 2,220 |
| E6              | 2,12             | 21,087<br>21,111   | 21,099 | 5,105<br>5,088                   | 5,097 | 3,076<br>3,087                   | 3,082 | 66,274<br>66,463 | 66,369 | 1,376<br>1,372 | 1,374 | 2,235<br>2,250    | 2,243 |
| E7              | 2,02             | 20,918<br>20,798   | 20,858 | 5,076<br>5,108                   | 5,092 | 3,088<br>3,069                   | 3,079 | 65,865<br>65,793 | 65,828 | 1,385<br>1,351 | 1,368 | 2,228<br>2,208    | 2,218 |
| E8              | 2,07             | 20,929<br>20,910   | 20,920 | 5,113<br>5,092                   | 5,103 | 2,992<br>2,975                   | 2,984 | 65,865<br>65,956 | 65,911 | 1,380<br>1,359 | 1,370 | 2,217<br>2,215    | 2,216 |
| E9              | 1,94             | 21,054<br>20,966   | 21,010 | 5,152<br>5,102                   | 5,127 | 3,031<br>3,040                   | 3,036 | 65,981<br>65,843 | 65,912 | 1,344<br>1,350 | 1,347 | -<br>-            | -     |
| E10             | -                | 20,600<br>20,630   | 20,615 | 5,000<br>5,000                   | 5,000 | 2,960<br>2,970                   | 2,965 | 65,680<br>65,720 | 65,700 | 1,370<br>1,370 | 1,370 | 2,220<br>2,220    | 2,220 |
| E11             | 2,04             | 20,737<br>20,831   | 20,784 | 5,094<br>5,118                   | 5,106 | 3,019<br>3,019                   | 3,019 | 66,257<br>66,333 | 66,295 | 1,434<br>1,434 | 1,434 | 2,160<br>2,158    | 2,159 |
| E12             | 1,99             | 21,050<br>20,860   | 20,955 | 5,118<br>5,089                   | 5,104 | 3,037<br>3,029                   | 3,033 | 65,980<br>65,460 | 65,720 | 1,357<br>1,354 | 1,356 | 2,221<br>2,191    | 2,206 |

Table B.6 (continued)

| Laboratory ref. | Na <sub>2</sub> O % |       | K <sub>2</sub> O % |       | TiO <sub>2</sub> % |       | P <sub>2</sub> O <sub>5</sub> % |       | MnO %          |       | SrO %          |       | Total   |
|-----------------|---------------------|-------|--------------------|-------|--------------------|-------|---------------------------------|-------|----------------|-------|----------------|-------|---------|
|                 | Results             | Mean  | Results            | Mean  | Results            | Mean  | Results                         | Mean  | Results        | Mean  | Results        | Mean  |         |
| 106             | 0,201<br>0,205      | 0,203 | 0,491<br>0,489     | 0,490 | -                  | -     | -                               | -     | -              | -     | -              | -     | 97,299  |
| 107             | 0,265<br>0,275      | 0,270 | 0,510<br>0,510     | 0,510 | -                  | -     | 0,237<br>0,237                  | 0,237 | 0,081<br>0,091 | 0,086 | -              | -     | 101,003 |
| 108             | 0,130<br>0,130      | 0,130 | 0,490<br>0,490     | 0,490 | -                  | -     | 0,240<br>0,240                  | 0,240 | -              | -     | -              | -     | 99,460  |
| 109             | -                   | -     | 0,504<br>0,497     | 0,500 | -                  | -     | -                               | -     | -              | -     | -              | -     | 98,696  |
| 110             | 0,243<br>0,220      | 0,232 | 0,490<br>0,511     | 0,500 | -                  | -     | 0,230<br>0,238                  | 0,234 | -              | -     | -              | -     | 98,023  |
| 111             | 0,250<br>0,260      | 0,255 | 0,500<br>0,500     | 0,500 | 0,350<br>0,340     | 0,345 | 0,320<br>0,300                  | 0,310 | 0,100<br>0,100 | 0,100 | 0,040<br>0,040 | 0,040 | 98,465  |
| 112             | 0,230<br>0,230      | 0,230 | 0,510<br>0,510     | 0,510 | -                  | -     | -                               | -     | -              | -     | -              | -     | 98,340  |
| 113             | 0,210<br>0,200      | 0,205 | 0,510<br>0,510     | 0,510 | 0,340<br>0,340     | 0,340 | 0,240<br>0,240                  | 0,240 | 0,100<br>0,100 | 0,100 | 0,040<br>0,040 | 0,040 | 99,500  |
| 114             | 0,640<br>0,650      | 0,645 | 0,440<br>0,420     | 0,430 | -                  | -     | -                               | -     | -              | -     | -              | -     | 100,275 |
| E1              | 0,195<br>0,206      | 0,201 | 0,493<br>0,496     | 0,495 | 0,326<br>0,313     | 0,320 | 0,241<br>0,248                  | 0,245 | 0,095<br>0,096 | 0,096 | 0,048<br>0,049 | 0,049 | 99,975  |
| E2              | 0,208<br>0,207      | 0,208 | 0,498<br>0,499     | 0,499 | 0,312<br>0,311     | 0,312 | 0,240<br>0,236                  | 0,238 | 0,097<br>0,097 | 0,097 | -              | -     | 99,721  |
| E3              | 0,220<br>0,220      | 0,220 | 0,480<br>0,470     | 0,475 | 0,310<br>0,310     | 0,310 | 0,250<br>0,250                  | 0,250 | 0,110<br>0,110 | 0,110 | 0,060<br>0,060 | 0,060 | 100,365 |
| E4              | 0,234<br>0,228      | 0,231 | 0,490<br>0,494     | 0,492 | 0,305<br>0,307     | 0,306 | 0,238<br>0,238                  | 0,238 | 0,092<br>0,092 | 0,092 | 0,052<br>0,056 | 0,054 | 99,658  |
| E5              | 0,234<br>0,234      | 0,234 | 0,510<br>0,500     | 0,505 | 0,315<br>0,303     | 0,309 | 0,234<br>0,222                  | 0,228 | 0,102<br>0,098 | 0,100 | 0,046<br>0,047 | 0,047 | 100,173 |
| E6              | 0,105<br>0,101      | 0,103 | 0,496<br>0,497     | 0,496 | 0,313<br>0,315     | 0,314 | 0,273<br>0,269                  | 0,271 | 0,090<br>0,091 | 0,090 | -              | -     | 100,538 |
| E7              | 0,214<br>0,211      | 0,213 | 0,495<br>0,499     | 0,497 | 0,318<br>0,319     | 0,319 | 0,244<br>0,233                  | 0,239 | 0,099<br>0,100 | 0,100 | 0,061<br>0,063 | 0,062 | 99,871  |
| E8              | 0,204<br>0,215      | 0,210 | 0,501<br>0,502     | 0,502 | 0,309<br>0,305     | 0,307 | 0,240<br>0,238                  | 0,239 | 0,096<br>0,096 | 0,096 | 0,045<br>0,045 | 0,045 | 99,900  |
| E9              | 0,258<br>0,271      | 0,265 | 0,501<br>0,511     | 0,506 | 0,308<br>0,296     | 0,302 | -                               | -     | -              | -     | -              | -     | 97,504  |
| E10             | 0,220<br>0,210      | 0,215 | 0,510<br>0,510     | 0,510 | -                  | -     | -                               | -     | -              | -     | -              | -     | 98,595  |
| E11             | 0,202<br>0,201      | 0,202 | 0,496<br>0,497     | 0,497 | 0,302<br>0,303     | 0,303 | 0,237<br>0,235                  | 0,236 | 0,093<br>0,093 | 0,093 | 0,054<br>0,054 | 0,054 | 100,181 |
| E12             | 0,227<br>0,186      | 0,207 | 0,496<br>0,490     | 0,493 | 0,317<br>0,315     | 0,316 | 0,234<br>0,243                  | 0,239 | 0,107<br>0,104 | 0,106 | -              | -     | 99,732  |

Table B.7 — Individual results for all laboratories — Sample JCA #2

| Laboratory ref. | Loss on ignition | SiO <sub>2</sub> % |        | Al <sub>2</sub> O <sub>3</sub> % |       | Fe <sub>2</sub> O <sub>3</sub> % |       | CaO %   |        | MgO %   |       | SO <sub>3</sub> % |       |
|-----------------|------------------|--------------------|--------|----------------------------------|-------|----------------------------------|-------|---------|--------|---------|-------|-------------------|-------|
|                 |                  | Results            | Mean   | Results                          | Mean  | Results                          | Mean  | Results | Mean   | Results | Mean  | Results           | Mean  |
| 1               | 0,09             | 26,015             | 26,022 | 8,827                            | 8,832 | 1,623                            | 1,624 | 56,064  | 56,026 | 3,340   | 3,339 | 2,901             | 2,898 |
|                 |                  | 26,029             |        | 8,838                            |       | 1,625                            |       | 55,987  |        | 3,338   |       | 2,895             |       |
| 2               | 0,21             | 25,839             | 25,826 | 8,768                            | 8,765 | 1,629                            | 1,626 | 56,130  | 56,141 | 3,318   | 3,309 | 2,903             | 2,905 |
|                 |                  | 25,812             |        | 8,762                            |       | 1,623                            |       | 56,152  |        | 3,300   |       | 2,907             |       |
| 3               | 0,63             | 25,987             | 25,994 | 8,816                            | 8,816 | 1,556                            | 1,558 | 56,244  | 56,250 | 3,288   | 3,291 | -                 | -     |
|                 |                  | 26,002             |        | 8,816                            |       | 1,561                            |       | 56,257  |        | 3,294   |       | -                 |       |
| 4               | 0,18             | 25,990             | 25,998 | 8,781                            | 8,784 | 1,643                            | 1,646 | 55,904  | 55,896 | 3,325   | 3,322 | 2,920             | 2,916 |
|                 |                  | 26,005             |        | 8,786                            |       | 1,648                            |       | 55,887  |        | 3,320   |       | 2,912             |       |
| 5               | 0,19             | 25,955             | 25,946 | 8,805                            | 8,801 | 1,624                            | 1,622 | 56,205  | 56,164 | 3,310   | 3,312 | 2,879             | 2,888 |
|                 |                  | 25,936             |        | 8,797                            |       | 1,621                            |       | 56,122  |        | 3,314   |       | 2,897             |       |
| 6               | 0,12             | 26,196             | 26,163 | 8,986                            | 8,984 | 1,638                            | 1,627 | 56,229  | 56,204 | 3,382   | 3,376 | 2,857             | 2,831 |
|                 |                  | 26,130             |        | 8,983                            |       | 1,616                            |       | 56,179  |        | 3,371   |       | 2,805             |       |
| 7               | 0,11             | 25,999             | 25,992 | 8,820                            | 8,823 | 1,607                            | 1,607 | 56,058  | 56,059 | 3,359   | 3,352 | 2,949             | 2,948 |
|                 |                  | 25,984             |        | 8,826                            |       | 1,607                            |       | 56,060  |        | 3,345   |       | 2,947             |       |
| 8               | 0,14             | 26,014             | 26,044 | 8,774                            | 8,774 | 1,509                            | 1,510 | 55,662  | 55,629 | 3,345   | 3,344 | 2,682             | 2,684 |
|                 |                  | 26,075             |        | 8,775                            |       | 1,510                            |       | 55,636  |        | 3,343   |       | 2,685             |       |
| 9               | 0,16             | 25,913             | 25,907 | 8,773                            | 8,766 | 1,627                            | 1,628 | 56,014  | 56,009 | 3,320   | 3,322 | 2,890             | 2,888 |
|                 |                  | 25,901             |        | 8,760                            |       | 1,629                            |       | 56,004  |        | 3,324   |       | 2,887             |       |
| 10              | 0,30             | 25,979             | 25,938 | 8,766                            | 8,774 | 1,628                            | 1,627 | 56,191  | 56,089 | 3,286   | 3,292 | 2,898             | 2,903 |
|                 |                  | 25,898             |        | 8,782                            |       | 1,626                            |       | 55,987  |        | 3,297   |       | 2,908             |       |
| 11              | 0,14             | 25,942             | 25,908 | 8,683                            | 8,716 | 1,621                            | 1,614 | 56,137  | 56,077 | 3,272   | 3,280 | 2,704             | 2,723 |
|                 |                  | 25,875             |        | 8,748                            |       | 1,606                            |       | 56,017  |        | 3,289   |       | 2,742             |       |
| 12              | 0,12             | 26,048             | 26,028 | 8,771                            | 8,794 | 1,594                            | 1,580 | 56,012  | 55,954 | 3,343   | 3,330 | -                 | -     |
|                 |                  | 26,009             |        | 8,816                            |       | 1,566                            |       | 55,897  |        | 3,316   |       | -                 |       |
| 13              | 0,11             | 26,099             | 26,104 | 8,861                            | 8,829 | 1,625                            | 1,628 | 55,848  | 55,902 | 3,312   | 3,316 | 2,958             | 2,964 |
|                 |                  | 26,110             |        | 8,797                            |       | 1,632                            |       | 55,957  |        | 3,319   |       | 2,971             |       |
| 14              | 0,12             | 26,111             | 26,064 | 8,832                            | 8,812 | 1,637                            | 1,640 | 56,077  | 56,108 | 3,313   | 3,312 | 2,978             | 2,972 |
|                 |                  | 26,017             |        | 8,792                            |       | 1,643                            |       | 56,138  |        | 3,312   |       | 2,965             |       |
| 15              | 0,08             | 26,152             | 26,150 | 8,879                            | 8,867 | 1,634                            | 1,636 | 55,843  | 55,820 | 3,316   | 3,296 | 2,906             | 2,926 |
|                 |                  | 26,149             |        | 8,855                            |       | 1,638                            |       | 55,796  |        | 3,276   |       | 2,945             |       |
| 16              | 0,11             | 26,025             | 26,018 | 8,791                            | 8,800 | 1,611                            | 1,612 | 56,236  | 56,211 | 3,308   | 3,316 | 2,946             | 2,934 |
|                 |                  | 26,012             |        | 8,809                            |       | 1,612                            |       | 56,186  |        | 3,323   |       | 2,922             |       |
| 101             | -                | 26,035             | 26,024 | 8,786                            | 8,780 | 1,613                            | 1,610 | 56,202  | 56,188 | 3,306   | 3,300 | 2,515             | 2,454 |
|                 |                  | 26,012             |        | 8,773                            |       | 1,608                            |       | 56,175  |        | 3,295   |       | 2,392             |       |
| 102             | 0,08             | 25,904             | 25,922 | 8,750                            | 8,736 | 1,597                            | 1,596 | 56,245  | 56,258 | 3,339   | 3,344 | 1,619             | 1,618 |
|                 |                  | 25,941             |        | 8,721                            |       | 1,596                            |       | 56,270  |        | 3,348   |       | 1,617             |       |
| 103             | 0,13             | 26,010             | 25,990 | 8,790                            | 8,805 | 1,640                            | 1,645 | 56,020  | 56,020 | 3,430   | 3,405 | 2,890             | 2,895 |
|                 |                  | 25,970             |        | 8,820                            |       | 1,650                            |       | 56,020  |        | 3,380   |       | 2,900             |       |
| 104             | 0,00             | 25,998             | 25,979 | 8,766                            | 8,777 | 1,638                            | 1,632 | 56,102  | 56,080 | 3,310   | 3,307 | 1,814             | 1,796 |
|                 |                  | 25,960             |        | 8,788                            |       | 1,627                            |       | 56,057  |        | 3,304   |       | 1,778             |       |
| 105             | 0,11             | 26,149             | 26,162 | 8,796                            | 8,818 | 1,620                            | 1,624 | 56,355  | 56,368 | 3,363   | 3,372 | 2,911             | 2,904 |
|                 |                  | 26,174             |        | 8,841                            |       | 1,628                            |       | 56,380  |        | 3,380   |       | 2,897             |       |