

# Chemical Compositions of SAE Experimental Steels— SAE J1081 OCT80

SAE Information Report  
Last Revised October 1980

S.A.E.  
LIBRARY

THIS IS A PREPRINT WHICH IS  
SUBJECT TO REVISIONS AND  
CORRECTIONS. THE FINAL  
VERSION WILL APPEAR IN THE  
1982 EDITION OF THE SAE  
HANDBOOK.

**SAE** *The Engineering  
Resource For  
Advancing Mobility*

**PREPRINT**

SAENORM.COM : Click to view the full PDF of J1081-198010

SAENORM.COM : Click to view the full PDF of J1081\_198010

# CHEMICAL COMPOSITIONS OF SAE EXPERIMENTAL STEELS—SAE J1081 OCT80

## SAE Information Report

Report of the Iron and Steel Technical Committee, approved April 1974, second revision October 1980.

This SAE Information Report provides a uniform means of designating wrought steels during a period of usage prior to the time they meet the requirements for SAE standard steel designation. The numbers consist of the prefix *EX* followed by a sequential number starting with 1. A number once assigned is never assigned to any other composition.

An *EX* number may be obtained for an experimental steel composition by submitting a written request to SAE Staff, indicating the chemical composition and other pertinent characteristics of the material. If the request is

approved according to established procedures, SAE Staff will assign an *EX* number to the grade. This number will remain in effect until the experimental grade meets the requirements for an SAE standard steel or the grade is discontinued according to established procedures.

Table 1 is a listing of the chemical composition limits of experimental steels which were considered active on the date of the last survey prior to the date of this report. These ladle limits are subject to standard variations for check analysis as given in SAE J409.

TABLE 1—SAE EXPERIMENTAL STEEL COMPOSITIONS

Ladle Chemical Composition Limits, % by weight									
EX No.	C	Mn	P, max	S, max	Si	Ni	Cr	Mo	B
EX 10	0.19-0.24	0.95-1.25	0.035	0.040	0.15-0.35	0.20-0.40	0.25-0.40	0.05-0.10	—
EX 15	0.18-0.23	0.90-1.20	0.035	0.040	0.15-0.35	—	0.40-0.60	0.13-0.20	—
EX 16	0.20-0.25	0.90-1.20	0.035	0.040	0.15-0.35	—	0.40-0.60	0.13-0.20	—
EX 17	0.23-0.28	0.90-1.20	0.035	0.040	0.15-0.35	—	0.40-0.60	0.13-0.20	—
EX 18	0.25-0.30	0.90-1.20	0.035	0.040	0.15-0.35	—	0.40-0.60	0.13-0.20	—
EX 19	0.18-0.23	0.90-1.20	0.035	0.040	0.15-0.35	—	0.40-0.60	0.08-0.15	0.0005-0.003
EX 20	0.13-0.18	0.90-1.20	0.035	0.040	0.15-0.35	—	0.40-0.60	0.13-0.20	—
EX 21	0.15-0.20	0.90-1.20	0.035	0.040	0.15-0.35	—	0.40-0.60	0.13-0.20	—
EX 24	0.18-0.23	0.75-1.00	0.035	0.040	0.15-0.35	—	0.45-0.65	0.20-0.30	—
EX 30	0.13-0.18	0.70-0.90	0.035	0.040	0.15-0.35	0.70-1.00	0.45-0.65	0.45-0.60	—
EX 31	0.15-0.20	0.70-0.90	0.035	0.040	0.15-0.35	0.70-1.00	0.45-0.65	0.45-0.60	—
EX 32	0.18-0.23	0.70-0.90	0.035	0.040	0.15-0.35	0.70-1.00	0.45-0.65	0.45-0.60	—
EX 33	0.17-0.24	0.85-1.25	0.035	0.040	0.15-0.35	0.20 min	0.20 min	0.05 min	—
EX 34	0.28-0.33	0.90-1.20	0.035	0.040	0.15-0.35	—	0.40-0.60	0.13-0.20	—
EX 36	0.38-0.43	0.90-1.20	0.035	0.040	0.15-0.35	—	0.45-0.65	0.13-0.20	—
EX 38	0.43-0.48	0.90-1.20	0.035	0.040	0.15-0.35	—	0.45-0.65	0.13-0.20	—
EX 39	0.48-0.53	0.90-1.20	0.035	0.040	0.15-0.35	—	0.45-0.65	0.13-0.20	—
EX 40	0.51-0.59	0.90-1.20	0.035	0.040	0.15-0.35	—	0.45-0.65	0.13-0.20	—
EX 54	0.19-0.25	0.70-1.05	0.035	0.040	0.15-0.35	—	0.45-0.65	0.05 min	—
EX 55	0.15-0.20	0.70-1.00	0.035	0.040	0.15-0.35	1.65-2.00	0.45-0.65	0.65-0.80	—
EX 56	0.080-0.13	0.70-1.00	0.035	0.040	0.15-0.35	1.65-2.00	0.45-0.65	0.65-0.80	—
EX 57	0.08 max	1.25 max	0.040	0.15-0.35	1.00 max	—	17.00-19.00	1.75-2.25	—
EX 58	0.16-0.21	1.00-1.30	0.035	0.040	0.15-0.35	—	0.45-0.65	—	—
EX 59	0.18-0.23	1.00-1.30	0.035	0.040	0.15-0.35	—	0.70-0.90	—	—
EX 60	0.20-0.25	1.00-1.30	0.035	0.040	0.15-0.35	—	0.70-0.90	—	—
EX 61	0.23-0.28	1.00-1.30	0.035	0.040	0.15-0.35	—	0.70-0.90	—	—
EX 62	0.25-0.30	1.00-1.30	0.035	0.040	0.15-0.35	—	0.70-0.90	—	—
EX 63	0.31-0.38	0.75-1.10	0.035	0.040	0.15-0.35	—	0.45-0.65	—	0.0005-0.003
EX 64	0.16-0.21	1.00-1.30	0.035	0.040	0.15-0.35	—	0.70-0.90	—	—
EX 65	0.21-0.26	1.00-1.30	0.035	0.040	0.15-0.35	—	0.70-0.90	—	—

### APPENDIX A DESIGNATION AND NUMBERING OF EXPERIMENTAL COMPOSITIONS

**A. Scope**—This Appendix establishes a system for designating and numbering new or experimental compositions for steel products during a period of limited use in which technical and commercial desirability is evaluated.

**A.1 Designation and Numbering**—Such materials shall be designated by the prefix *EX* and numbered by assigning a sequential, non-significant number beginning with 1 in the order of approval for listing.

**A.1.1 Application for listing** may be made by any person, acting in his own behalf or for his company or association by written application to the SAE technical staff listing the range of chemical composition and other pertinent characteristics of the proposed material. This request shall be forwarded to the Chairman of the appropriate Division of ISTC for action.

**A.1.2 ASSIGNMENT OF NUMBER**—If the Division Chairman approves, he shall inform the appropriate member of the SAE Technical Staff who will assign the number, add the material to the list, and inform the applicant of the number assigned.

**A.2 Publication**—The current numbers, their range of chemical compo-

sition, and other pertinent characteristics, shall be published yearly in the SAE Handbook in SAE J1081. Publication of interim bulletins on newly listed numbers may be authorized by the ISTC Executive Committee.

**A.3 Discontinuance**—A material may be removed from the list by any of the following:

**A.3.1 Adoption of the material as an SAE standard steel and assignment of a permanent number.**

**A.3.2 Formal action to delist by the cognizant Division.**

**A.3.2.1** Every two years each Division shall determine the status of the steels within its jurisdiction and delete those which an ISTC ballot shows to be of insufficient interest to warrant further consideration.

**A.3.3** A request to delist by the applicant who originally requested listing, followed by action prescribed in A.3.2.

**A.4 Reassignment of a number once assigned may be done only if the material to which it was originally assigned is relisted.**

The  $\phi$  symbol is for the convenience of the user in locating areas where technical revisions have been made to the previous issue of the report. If the symbol is next to the report title, it indicates a complete revision of the report.