
**Information technology — Control
network protocol —**

**Part 1:
Protocol stack**

*Technologies de l'information — Protocole de réseau de contrôle —
Partie 1: Pile de protocole*

IECNORM.COM : Click to view the full PDF of ISO/IEC 14908-1:2012

IECNORM.COM : Click to view the full PDF of ISO/IEC 14908-1:2012



COPYRIGHT PROTECTED DOCUMENT

© ISO/IEC 2012

All rights reserved. Unless otherwise specified, no part of this publication may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without permission in writing from either ISO at the address below or ISO's member body in the country of the requester.

ISO copyright office
Case postale 56 • CH-1211 Geneva 20
Tel. + 41 22 749 01 11
Fax + 41 22 749 09 47
E-mail copyright@iso.org
Web www.iso.org

Published in Switzerland

Contents

page

| | |
|--|----|
| Foreword | 7 |
| Introduction..... | 8 |
| 1 Scope..... | 9 |
| 2 Normative references..... | 9 |
| 3 Terms and definitions | 9 |
| 4 Symbols and abbreviations..... | 11 |
| 4.1 Symbols and graphical representations..... | 11 |
| 4.2 Abbreviations..... | 12 |
| 5 Overview of protocol layering..... | 13 |
| 6 MAC sublayer..... | 15 |
| 6.1 Service provided..... | 15 |
| 6.2 Interface to the link layer | 15 |
| 6.3 Interface to the physical layer..... | 16 |
| 6.4 MPDU format..... | 17 |
| 6.5 Predictive p -persistent CSMA — overview description | 17 |
| 6.6 Idle channel detection..... | 18 |
| 6.7 Randomising..... | 19 |
| 6.8 Backlog estimation..... | 19 |
| 6.9 Optional priority..... | 20 |
| 6.10 Optional collision detection | 21 |
| 6.11 Beta1, Beta2 and Preamble Timings | 21 |
| 7 Link layer..... | 23 |
| 7.1 Assumptions..... | 23 |
| 7.2 Service provided..... | 24 |
| 7.3 CRC | 24 |
| 7.4 Transmit algorithm..... | 25 |
| 8 Network layer..... | 26 |
| 8.1 Assumptions..... | 26 |
| 8.2 Service provided..... | 27 |
| 8.3 Service interface..... | 27 |
| 8.4 Internal structuring of the network layer | 28 |
| 8.5 NPDU format | 28 |
| 8.6 Address recognition..... | 29 |
| 8.7 Routers | 29 |
| 8.8 Routing algorithm..... | 30 |
| 8.9 Learning algorithm — subnets | 30 |
| 9 Transaction control sublayer | 30 |
| 9.1 Assumptions..... | 30 |
| 9.2 Service provided..... | 31 |
| 9.3 Service interface..... | 31 |
| 9.4 State variables | 31 |
| 9.5 Transaction control algorithm | 32 |
| 10 Transport layer | 32 |
| 10.1 Assumptions..... | 32 |
| 10.2 Service provided..... | 32 |
| 10.3 Service interface..... | 33 |
| 10.4 TPDU types and formats..... | 33 |

| | | |
|--------|---|----|
| 10.5 | Protocol diagram | 35 |
| 10.6 | Transport protocol state variables | 35 |
| 10.7 | Send algorithm | 35 |
| 10.8 | Receive algorithm..... | 36 |
| 10.9 | Receive transaction record pool size and configuration engineering..... | 36 |
| 10.9.1 | General | 36 |
| 10.9.2 | Number of retries..... | 36 |
| 10.9.3 | Transport layer timers..... | 37 |
| 11 | Session layer | 38 |
| 11.1 | Assumptions..... | 38 |
| 11.2 | Service Provided | 38 |
| 11.3 | Service interface..... | 39 |
| 11.4 | Internal structure of the session layer | 40 |
| 11.5 | SPDU types and formats | 41 |
| 11.6 | Protocol timing diagrams | 42 |
| 11.7 | Request-response state variables | 44 |
| 11.8 | Request-response protocol — client part..... | 45 |
| 11.9 | Request-response protocol — server part | 45 |
| 11.10 | Request-response protocol timers..... | 45 |
| 11.11 | Authentication protocol..... | 46 |
| 11.12 | Encryption algorithm | 46 |
| 11.13 | Retries and the role of the checksum function | 46 |
| 11.14 | Random Number Generation | 47 |
| 11.15 | Using Authentication | 47 |
| 12 | Presentation/application layer | 47 |
| 12.1 | Assumptions..... | 47 |
| 12.2 | Service provided..... | 47 |
| 12.3 | Service interface..... | 48 |
| 12.4 | APDU types and formats | 49 |
| 12.5 | Protocol diagrams | 50 |
| 12.6 | Application protocol state variables | 51 |
| 12.7 | Request - response messaging in offline state..... | 51 |
| 12.8 | Network variables..... | 52 |
| 12.8.1 | General | 52 |
| 12.8.2 | Network variable processing | 52 |
| 12.9 | Error notification to the application program..... | 53 |
| 12.9.1 | General | 53 |
| 12.9.2 | Error notification for messages | 53 |
| 12.9.3 | Error notification for network variables | 53 |
| 13 | Network management & diagnostics | 53 |
| 13.1 | Assumptions..... | 53 |
| 13.2 | Services provided..... | 54 |
| 13.3 | Network management and diagnostics application structure..... | 54 |
| 13.4 | Node states | 54 |
| 13.5 | Using the network management services..... | 55 |
| 13.5.1 | General | 55 |
| 13.5.2 | Addressing considerations | 55 |
| 13.5.3 | Making network configuration changes..... | 56 |
| 13.5.4 | Downloading an Application Program | 56 |
| 13.5.5 | Error handling conditions (informative)..... | 56 |
| 13.6 | Using router network management commands | 59 |
| 13.7 | NMPDU formats and types | 60 |
| 13.7.1 | General | 60 |
| 13.7.2 | Query ID..... | 60 |
| 13.7.3 | Respond to query | 61 |
| 13.7.4 | Update domain..... | 61 |
| 13.7.5 | Leave domain..... | 61 |
| 13.7.6 | Update key | 61 |

| | | |
|---------|---|-----|
| 13.7.7 | Update address..... | 62 |
| 13.7.8 | Query address | 62 |
| 13.7.9 | Query network variable configuration..... | 62 |
| 13.7.10 | Update group address | 62 |
| 13.7.11 | Query domain | 62 |
| 13.7.12 | Update network variable configuration..... | 62 |
| 13.7.13 | Set node mode..... | 63 |
| 13.7.14 | Read memory..... | 63 |
| 13.7.15 | Write memory..... | 63 |
| 13.7.16 | Checksum recalculate..... | 63 |
| 13.7.17 | Install | 64 |
| 13.7.18 | Memory refresh..... | 78 |
| 13.7.19 | Query SI..... | 78 |
| 13.7.20 | Network variable value fetch..... | 79 |
| 13.7.21 | Manual service request message | 79 |
| 13.7.22 | Network management escape code | 79 |
| 13.7.23 | Router mode | 80 |
| 13.7.24 | Router clear group or subnet table | 80 |
| 13.7.25 | Router group or subnet table download..... | 80 |
| 13.7.26 | Router group forward..... | 80 |
| 13.7.27 | Router subnet forward..... | 80 |
| 13.7.28 | Router Do Not forward group..... | 80 |
| 13.7.29 | Router Do Not forward subnet..... | 80 |
| 13.7.30 | Router group or subnet table report | 80 |
| 13.7.31 | Router status | 81 |
| 13.7.32 | Router half escape code..... | 81 |
| 13.8 | DPDU types and formats | 81 |
| 13.8.1 | General | 81 |
| 13.8.2 | Query status..... | 81 |
| 13.8.3 | Proxy status | 85 |
| 13.8.4 | Clear status | 85 |
| 13.8.5 | Query transceiver status | 85 |
| Annex A | (normative) Reference implementation | 86 |
| A.1 | General | 86 |
| A.2 | Predictive CSMA algorithm | 86 |
| A.3 | LPDU transmit algorithm | 141 |
| A.4 | LPDU receive algorithm | 143 |
| A.5 | Routing algorithm..... | 144 |
| A.6 | Learning algorithm | 145 |
| A.7 | Transaction control algorithm | 145 |
| A.8 | Network layer algorithm..... | 152 |
| A.9 | TPDU and SPDU send algorithm with authentication | 168 |
| A.10 | Application Layer | 223 |
| A.11 | Network Management Commands..... | 278 |
| A.12 | Configuration data structures..... | 315 |
| A.13 | Include files for the reference implementation | 334 |
| A.14 | Application protocol state variables and address recognition Structures | 363 |
| A.15 | Query-id data structures..... | 366 |
| A.16 | Respond to query data structure..... | 366 |
| A.17 | Update somain data structures..... | 367 |
| A.18 | Leave domain data structures | 367 |
| A.19 | Update key data structures | 367 |
| A.20 | Update address data structures | 367 |
| A.21 | Query address data structures | 368 |
| A.22 | Query NV Cnfg data structures..... | 369 |
| A.23 | Update group address data structures | 369 |
| A.24 | Query domain data structures | 369 |
| A.25 | Update network variable configuration data structures..... | 370 |
| A.26 | Set node mode data structures..... | 370 |

| | | |
|---|---|------------|
| A.27 | Read memory data structures..... | 370 |
| A.28 | Write memory data structures | 371 |
| A.29 | Checksum recalculate data structures | 371 |
| A.30 | Install command data structures | 371 |
| A.31 | Memory refresh data structures | 380 |
| A.32 | Query SI data structures..... | 380 |
| A.33 | NV fetch data structures | 380 |
| A.34 | Manual service request message ddata structures..... | 380 |
| A.35 | Product query data structures | 381 |
| A.36 | Router mode data structures | 381 |
| A.37 | Router table clear group or subnet table data structures..... | 381 |
| A.38 | Router group or subnet download data structures | 381 |
| A.39 | Router group forward data structures | 382 |
| A.40 | Router subnet forward data structures..... | 382 |
| A.41 | Router group No-Forward data structures | 382 |
| A.42 | Router subnet No-Forward data structures | 382 |
| A.43 | Group / subnet table report data structures | 383 |
| A.44 | Router status data structures | 383 |
| A.45 | Query status data structures | 383 |
| A.46 | Proxy status data structures..... | 384 |
| A.47 | Clear status data structures..... | 384 |
| A.48 | Query transceiver status data structures | 384 |
| Annex B (normative) Additional Data Structures..... | | 385 |
| B.1 | General | 385 |
| B.1.1 | System image | 385 |
| B.1.2 | Application image..... | 385 |
| B.1.3 | Network image | 386 |
| B.2 | Read-only structures..... | 386 |
| B.2.1 | Fixed read-only data structures..... | 386 |
| B.2.2 | Read-only structure field descriptions..... | 387 |
| B.3 | Domain table..... | 390 |
| B.3.1 | Domain table field descriptions..... | 391 |
| B.4 | Address table..... | 391 |
| B.4.1 | Declaration of group address format | 392 |
| B.4.2 | Group address field descriptions | 392 |
| B.4.3 | Declaration of subnet/node address format..... | 392 |
| B.4.4 | Subnet/node address field descriptions | 393 |
| B.4.5 | Declaration of broadcast address format | 393 |
| B.4.6 | Broadcast address field descriptions | 393 |
| B.4.7 | Declaration of turnaround address format | 393 |
| B.4.8 | Turnaround address field descriptions..... | 394 |
| B.4.9 | Declaration of protocol processor's address format | 394 |
| B.4.10 | Protocol processor address field descriptions..... | 394 |
| B.4.11 | Timer field descriptions | 394 |
| B.5 | Network variable tables - informative..... | 395 |
| B.5.1 | Network variable configuration table field descriptions - informative | 396 |
| B.5.2 | Network variable alias table field descriptions - informative..... | 397 |
| B.5.3 | Network variable fixed table field descriptions - informative | 397 |
| B.6 | Self-Identification structures..... | 397 |
| B.6.1 | SI Structure field descriptions | 398 |
| B.6.2 | NV descriptor table field descriptions..... | 398 |
| B.6.3 | SNVT table extension records | 399 |
| B.6.4 | SNVT alias field descriptions | 400 |
| B.6.5 | Version 2 SI data..... | 400 |
| B.7 | Configuration structure | 403 |
| B.7.1 | General | 403 |
| B.7.2 | Configuration structure field descriptions | 404 |
| B.8 | Statistics relative structure | 405 |
| Annex C (informative) Behavioral characteristics | | 407 |

| | | |
|--|---|------------|
| C.1 | Channel capacity and throughput | 407 |
| C.2 | Network metrics | 408 |
| C.3 | Transaction metrics | 409 |
| C.4 | Boundary conditions — power-up | 410 |
| C.5 | Boundary conditions — high load | 410 |
| Annex D (normative) PDU summary | | 411 |
| Annex E (normative) Naming and addressing | | 413 |
| E.1 | Address types and formats | 413 |
| E.2 | Domains | 413 |
| E.3 | Subnets and nodes | 414 |
| E.4 | Groups | 414 |
| E.5 | Unique_Node_ID and node address assignment | 415 |
| E.6 | NPDU addressing | 416 |
| Annex F (normative) List of patents that pertain to this International Standard | | 418 |
| Bibliography | | 420 |

Figures

| | | |
|-----------|---|----|
| Figure 1 | — Network topology & symbols | 12 |
| Figure 2 | — Protocol terminology | 12 |
| Figure 3 | — Protocol layering | 14 |
| Figure 4 | — Interface between the MAC and the link layers | 16 |
| Figure 5 | — MPDU/LPDU format | 17 |
| Figure 6 | — Predictive p -persistent CSMA concepts and parameters | 18 |
| Figure 7 | — Allocation of priority slots within the Busy Channel Packet Cycle | 20 |
| Figure 8 | — CRC register state behaviour example | 25 |
| Figure 9 | — Single channel topologies | 26 |
| Figure 10 | — Typical tree-like domain topology | 27 |
| Figure 11 | — Network service interface | 28 |
| Figure 12 | — Network layer—internal structure | 28 |
| Figure 13 | — NPDU format | 28 |
| Figure 14 | — Transaction control service interface | 31 |
| Figure 15 | — Transport interface to upper layers | 33 |
| Figure 16 | — TPDU types and formats | 34 |
| Figure 17 | — Transport protocol diagram for multicast message with a loss of both the message and the ACK TPDU | 35 |
| Figure 18 | — Transport protocol—Send FSM | 36 |
| Figure 19 | — Transport protocol—Receive FSM | 36 |
| Figure 20 | — Probability of transaction completion in k Retries | 37 |

| | |
|--|-----|
| Figure 21 — Methodology for calculating timer values | 38 |
| Figure 22 — Session layer interface to application layer | 39 |
| Figure 23 — Session layer—internal structuring..... | 40 |
| Figure 24 — SPDU types and formats | 41 |
| Figure 25 — Non-Idempotent request with multiple SPDU losses..... | 43 |
| Figure 26 — Secure idempotent request with multiple SPDU losses | 44 |
| Figure 27 — Request-response protocol—client FSM..... | 45 |
| Figure 28 — Request-response protocol—simplified server FSM..... | 45 |
| Figure 29 — Application layer interface | 48 |
| Figure 30 — APDU format..... | 49 |
| Figure 31 — Application protocol diagram for multicast acknowledged transaction..... | 50 |
| Figure 32 — Application protocol diagram for multicast request/response transaction..... | 51 |
| Figure B.1 — SI data | 400 |
| Figure C.1 — Probability of successful delivery over k hops | 409 |
| Figure D.1 — Protocol PDU summary | 412 |
| Figure E.1 — Physical topology and logical addressing (single domain) | 415 |
| Figure E.2 — NPDU/TPDU/SPDU addressing—physical address formats..... | 416 |

Tables

| | |
|---|-----|
| Table 1 — Application layer primitives | 48 |
| Table 2 — Resource codes..... | 65 |
| Table 3 — Space of the property ID..... | 65 |
| Table B.1 — Buffer size encodings..... | 389 |
| Table B.2 — Buffer Count Encodings | 390 |
| Table B.3 — Encoding of timer field values | 395 |
| Table B.4 — Buffer timeout encoding | 405 |
| Table C.1 — Key throughput parameters..... | 408 |
| Table E.1 — NPDU/TPDU/SPDU addressing - logical address formats | 416 |
| Table F.1 — Patents in the US..... | 418 |
| Table F.2 — Patents in Europe and other countries..... | 419 |

Foreword

ISO (the International Organization for Standardization) and IEC (the International Electrotechnical Commission) form the specialized system for worldwide standardization. National bodies that are members of ISO or IEC participate in the development of International Standards through technical committees established by the respective organization to deal with particular fields of technical activity. ISO and IEC technical committees collaborate in fields of mutual interest. Other international organizations, governmental and non-governmental, in liaison with ISO and IEC, also take part in the work. In the field of information technology, ISO and IEC have established a joint technical committee, ISO/IEC JTC 1.

International Standards are drafted in accordance with the rules given in the ISO/IEC Directives, Part 2.

The main task of the joint technical committee is to prepare International Standards. Draft International Standards adopted by the joint technical committee are circulated to national bodies for voting. Publication as an International Standard requires approval by at least 75 % of the national bodies casting a vote.

ISO/IEC 14908-1 was prepared by CEN/TC 247 and was adopted, under a special “fast-track procedure”, by Joint Technical Committee ISO/IEC JTC 1, *Information technology*, in parallel with its approval by the national bodies of ISO and IEC.

ISO/IEC 14908 consists of the following parts, under the general title *Information technology — Control network protocol*:

- *Part 1: Protocol stack*
- *Part 2: Twisted pair communication*
- *Part 3: Power line channel specification*
- *Part 4: IP communication*

Introduction

This International Standard has been prepared to provide mechanisms through which various vendors of local area control networks may exchange information in a standardised way. It defines communication capabilities.

This International Standard is to be used by all involved in design, manufacture, engineering, installation and commissioning activities.

The International Organization for Standardization (ISO) and International Electrotechnical Commission (IEC) draw attention to the fact that it is claimed that compliance with this International Standard may involve the use of patents held by Echelon Corporation.

The ISO and IEC take no position concerning the evidence, validity and scope of this patent right. The holder of this putative patent right has assured the ISO and IEC that they are willing to negotiate free of charge licences under reasonable and non-discriminatory terms and conditions with applicants throughout the world. In this respect, the statement of the holder of the putative patent rights is registered with the ISO and IEC. Information may be obtained from:

Echelon Corporation, 4015 Meridian Avenue, San Jose, CA 94304, USA, phone +1-408-938-5234, fax: +1-408-790-3800 <http://www.echelon.com>.

Attention is drawn to the possibility that some of the elements of this International Standard may be the subject of patent rights other than those identified above. ISO and IEC shall not be held responsible for identifying any or all such patent rights.

IECNORM.COM : Click to view the full PDF of ISO/IEC 14908-1:2012

INFORMATION TECHNOLOGY – CONTROL NETWORK PROTOCOL –

Part 1: Protocol stack

1 Scope

This specification applies to a communication protocol for local area control networks. The protocol provides peer-to-peer communication for networked control and is suitable for implementing both peer-to-peer and master-slave control strategies. This specification describes services in layers 2 to 7. In the layer 2 (data link layer) specification, it also describes the MAC sub-layer interface to the physical layer. The physical layer provides a choice of transmission media. The interface described in this specification supports multiple transmission media at the physical layer. In the layer 7 specification, it includes a description of the types of messages used by applications to exchange application and network management data.

2 Normative references

None.

3 Terms and definitions

For the purposes of this International Standard, the following subclause introduces the basic terminology employed throughout this International Standard. Most of it is commonly used and the terms have the same meaning in both the general and the standard context. However, for some terms, there are subtle differences. For example, in general, bridges do selective forwarding based on the layer 2 destination address. There are no layer 2 addresses in this standard protocol, so bridges forward all packets, as long as the domain address in the packet matches a domain of which the bridge is a member. Routers, in general, perform network address modification so that two protocols with the same transport layer but different network layers can be connected to form a single logical network. Routers of this standard may perform network address modification, but typically they only examine the network address fields and selectively forward packets based on the network layer address fields.

3.1

channel

physical unit of bandwidth linking one or more communication nodes. Refer to Annex E for further explanation of the relationship between a channel and a subnet

3.2

physical repeater

device that reconditions the incoming physical layer signal on one channel and retransmits it on to the same or another channel

3.3

store-and-forward repeater

device that stores and then reproduces data packets on to a second channel

3.4

bridge

device that connects two channels (x and y); forwards all packets from x to y and vice versa, as long as the packets originate on one of the domain(s) that the bridge belongs to

3.5 configuration

non-volatile information used by the device to customise its operation. There is configuration data for the correct operation of the protocol in each device, and optionally, for application operation. The network configuration data stored in each device has a checksum associated with the data. Examples of network configuration data are node addresses, communication media parameters such as priority settings, etc. Application configuration information is application specific

3.6 domain

virtual network that is the network unit of management and administration. Group and subnet (see below) addresses are assigned by the administrator responsible for the domain, and they have meaning only in the context of that domain

3.7 flexible domain

used in conjunction with Unique_Node_ID and broadcast addressing. A node responds to a Unique_Node_ID-addressed message if the address matches, regardless of the domain on which the message was sent. To respond so that the sender receives it, the response must be sent on the domain in which it was received. Furthermore, this domain must be remembered for the duration of the transaction so that duplicate detection of any retries is possible. This transitory domain entry at a node is called the flexible domain. How many flexible domain entries a node supports is up to the implementation. However, a minimum of 1 is required

3.8 subnet

set of nodes accessible through the same link layer protocol; a routing abstraction for a channel; in this standard subnets are limited to a maximum of 127 nodes

3.9 node

abstraction for a physical node that represents the highest degree of address resolvability on a network. A node is identified (addressed) within a subnet by its (logical) node identifier. A physical node may belong to more than one subnet; when it does, it is assigned one (logical) node number for each subnet to which it belongs. A physical node may belong to at most two subnets; these subnets must be in different domains. A node may also be identified (absolutely) within a network by its Unique_Node_ID

3.10 group

uniquely identifiable set of nodes within a domain. Within this set, individual members are identified by their member number. Groups facilitate one-to-many communication and are intended to support functional addressing

3.11 router

device that routes data packets to their respective destinations by selectively forwarding from subnet to subnet; a router always connects two (sets of) subnets; routers may modify network layer address fields. Routers may be set to one of four modes: repeater mode, bridge mode, learning mode, and configured mode. In repeater mode, packets are forwarded if they are received with no errors. In bridge mode, packets are forwarded if they are received with no errors and match a domain that the router is a member of. Routers in learning mode learn the topology by examining packet traffic, while routers that are set to configured mode have the network topology stored in their memory and make their routing decisions solely upon the contents of their configured tables

3.12 (application) gateway

interconnects networks at their highest protocol layers (often two different protocols). Two domains can also be connected through an application gateway

3.13

Beta1

period immediately following the end of a packet cycle. A node attempting to transmit monitors the state of the channel, and if it detects no transmission during the Beta1 period, it determines the channel to be idle

3.14

Beta2

randomising slot. A node wishing to transmit generates a random delay T. This delay is an integer number of randomising slots of duration Beta2

3.15

network variable

variable in an application program whose value is automatically propagated over the network whenever a new value is assigned to it

3.16

Standard Network Variable Types (SNVTs)

variables with agreed-upon semantics. These variables are interpreted by all applications in the same way, and are the basis for interoperability. Definition of specific SNVTs is beyond the scope of this International Standard

3.17

manual service request message

network management message containing a node's Unique_Node_ID. Used by a network management device that receives this message to install and configure the node. May be generated by application or system code. May be triggered by external hardware event, e.g., driving a "manual service request" input low

3.18

transaction

sequence of messages that are correlated together. For example, a request and the responses to the request are all part of a single transaction. A transaction succeeds when all the expected messages from every node involved in the transaction are received at least once. A transaction fails in this International Standard if any of the expected messages within the transaction are not received. Retries of messages within a transaction are used to increase the probability of success of a transaction in the presence of transient errors

4 Symbols and abbreviations

4.1 Symbols and graphical representations

Figure 1 shows the basic topology of networks based on this protocol and the symbolic representations used in this International Standard.




Figure 1 — Network topology & symbols

The layering of this protocol is described using standard OSI terminology, as shown in Figure 2.




Figure 2 — Protocol terminology

4.2 Abbreviations

— CNP Control Network Protocol

The Protocol Data Unit (PDU) abbreviations used throughout this Standard are:

— PPDU Physical Protocol Data Unit, or frame

— MPDU MAC Protocol Data Unit, or frame

— LPDU Link Protocol Data Unit, or frame

— NPDU Network Protocol Data Unit, or packet

— TPDU Transport Protocol Data Unit, or a message/ack

— SPDU Session Protocol Data Unit, or request/response

- NMPDU Network Management Protocol Data Unit
- DPDU Diagnostic Protocol Data Unit
- APDU Application Protocol Data Unit
- FSM Finite State Machine (diagram)

Annex D (PDU Summary) contains the details of these PDUs.

5 Overview of protocol layering

The protocol specified by this Standard consists of the layers shown in Figure 3. Each layer is described below.

Multiple physical layer protocols and data encoding methods are allowed in systems based on this International Standard. Each encoding scheme is medium-dependent.

The MAC (Medium Access Control) sublayer employs a collision avoidance algorithm called Predictive p -persistent CSMA (Carrier Sense, Multiple Access). For a number of reasons, including simplicity and compatibility with the multicast protocol, the link *layer* supports a simple connectionless service. Its functions are limited to framing, frame encoding, and error detection, with no error recovery by re-transmission.

IECNORM.COM : Click to view the full PDF of ISO/IEC 14908-1:2012




Figure 3 — Protocol layering

The *Network* layer handles packet delivery within a single domain, with no provisions for inter-domain communication. The Network service is connection-less, unacknowledged, and supports neither segmentation nor re-assembly of messages. The routing algorithms employed by the network layer to learn the topology assumes a tree-like network topology; routers with configured tables may operate on topologies with physical loops, as long as the communication paths are logically tree-like. In this topology, a packet may never appear more than once at the router on the side on which the packet originated. The unicast routing algorithm uses learning for minimal over-head and no additional routing traffic. Use of configured routing tables is supported for both unicast and group addresses, although in many applications a simple flooding of group addressed messages is sufficient.

The heart of the protocol hierarchy is the *Transport* and *Session* layers. A common *Transaction Control Sublayer* handles transaction ordering and duplicate detection for both. The *Transport* layer is connection-less and provides reliable message delivery to both single and multiple destinations. Authentication of the message sender's identity is included as a transport layer service, for use when the security of sender authentication is required. The authentication server requires only the *Transaction Control Sublayer* to accomplish its function. Thus *Transport* and *Session* layer messages may be authenticated using all of the addressing modes other than broadcast.

The session layer provides a simple Request-Response mechanism for access to remote servers. This mechanism provides a platform upon which application specific remote procedure calls can be built. The network management protocol, for example, depends upon the Request-Response mechanism in the Session layer.

A transport layer acknowledged message expects indication of message delivery from remote destination(s). A session layer request message expects indication that application-specific remote task(s) have been completed. A given message uses only one or the other type of service, but not both.

This specification includes the *Presentation Layer* and the lowest level of the *Application Layer*. These layers provide services for sending and receiving application messages including network variables, and other types of messages such as network management and diagnostic messages and foreign frames (see clause 13). For a network variable update, the APDU header provides information on how to interpret the APDU. This application-independent interpretation of the data allows data to be shared among nodes without prior arrangement.

6 MAC sublayer

In this International Standard the following Media Access Control sublayer is defined. If there is a need for other MAC sublayers they are defined in additional parts of this International Standard.

6.1 Service provided

The Media Access Control (MAC) sublayer facilitates media access with optional priority and optional collision detection/collision resolution. It uses a protocol called Predictive *p*-persistent CSMA (Carrier Sense, Multiple Access), that has some resemblance to the *p*-persistent CSMA protocol family.

Predictive *p*-persistent CSMA is a *collision avoidance* technique that randomises channel access using knowledge of the expected channel load. A node wishing to transmit always accesses the channel with a random delay in the range (0..*w*). To avoid throughput degradation under high load, the size of the randomising window, *w*, is a function of estimated channel backlog BL:

$$w = (BL \times W_{\text{base}}) - 1, \tag{1}$$

where

W_{base} is the base window size. W_{base} is measured in time. Its duration, derived from Beta2 (see 6.7), equals 16 Beta2 slots.

6.2 Interface to the link layer

The MAC sublayer is closely coupled to the Link layer, described in clause 7. With the MAC sublayer being responsible for media access, the Link layer deals with all other layer 2 issues, including framing and error detection. For explanatory purposes, the interface between the two layers is described in the form shown in Figure 4.




Figure 4 — Interface between the MAC and the link layers

Although the service interface primitives are defined using a syntax similar to programming language procedure calls, no implementation technique is implied. Frame reception is handled entirely by the Link layer, that notifies the MAC sublayer about the backlog increment via the Frame_OK() primitive.

The following service interface primitives facilitate the interface between the Link and the MAC layers:

M_Data_Request (Priority, delta_BL, ALT_Path, LPDU)

This primitive is used by the Link layer to pass an outbound LPDU/MPDU to the MAC sublayer. Priority defines the priority with which the frame is to be transmitted; delta_BL is the backlog increment expected as a result of delivering this MPDU. ALT_Path is a binary flag indicating whether the LPDU is to be transmitted on the primary or alternate channel, baud rate, etc. See 6.4 for how ALT_Path is set.

Frame_OK (delta_BL)

On receiving a frame and verifying that its CRC is correct, the Link layer invokes this primitive to notify the MAC sublayer about the backlog increment associated with the frame just received.

M_Data_Indication()

The MAC sublayer provides this indication to the link layer once per incoming LPDU/MPDU.

6.3 Interface to the physical layer

The Physical layer handles the actual transmission and reception of binary data. Multiple physical layer protocols are supported by the control network protocol. The bit error rate presented to the link layer must be equal to or better than 1 in 10^4 . For compatibility with the higher layers, all physical protocols must support the defined service interface (see figure 4):

P_Data_Indication (Frame)

Physical layer provides this indication to the MAC sublayer and the link layer once per in-coming LPDU/MPDU.

P_Data_Request (Frame)

The MAC sublayer uses this primitive to pass the Frame, the encoded LPDU/MPDU, to the physical layer for immediate transmission. The bit transmission order is defined in Annex D.

P_Data_Confirm (Status)

The physical layer returns Status as to whether the frame was transmitted. Status has three possible values: success—indicating the frame was transmitted, request_denied—indicating that activity was detected on the line prior to transmission, and collision—indicating that transmission began, but a collision was detected. Whether or not the transmission is aborted depends on when the collision is detected (see 6.10).

P_Channel_Active ()

The physical layer uses this primitive to pass the status of the channel to the MAC sublayer. This is an indication of activity, not necessarily of valid data.

6.4 MPDU format

The combined MPDU/LPDU format is shown in Figure 5. (Annex D contains the details of the NPDU frame).




Figure 5 — MPDU/LPDU format

The MAC sublayer uses the L2Hdr field, that has the following syntax and semantics:

Pri 1-bit field specifying the priority of this MPDU: 0 = Normal, 1 = High.

Alt_Path 1-bit field specifying the channel to use. This is a provision for transceivers that have the ability to transmit on two different channels and receive on either one without the need to instruct the transceiver to explicitly receive on a specific channel. The transport layer sets this bit for the last two attempts (for acknowledged and request/response services), unless requested to specify the alternate path for every transmission. For any packet received that has the alt_path bit set and that requires an acknowledgement, response, challenge, or reply, the alt_path bit shall be set in the corresponding acknowledgement, response, challenge, or reply.

Delta_BL 6-bit unsigned field (≥ 0); specifies channel backlog increment to be generated as a result of delivering this MPDU.

6.5 Predictive p-persistent CSMA — overview description

Like CSMA, Predictive p-persistent CSMA senses the medium before transmitting. A node attempting to transmit monitors the state of the channel (see Figure 6), and determines the channel to be idle if it detects no transmission during the Beta1 period. Nodes without a packet to transmit during this Beta1 period shall remain in synchronisation for the duration of the priority slots (see 6.10), and at least W_{base} randomising slots. This maintenance of synchronisation allows a packet that arrives in the output

queue of the MAC sublayer after the end of the Beta1 time to be transmitted in a valid slot according to the other nodes with a packet to transmit.

Next, the node generates a random delay T (transmit) from the interval $(0..(BL \times W_{base})-1)$, where W_{base} is the number of randomising slots within the basic randomising window and BL is an estimate of the current channel backlog. T (transmit) is defined as an integer number of randomising slots of duration Beta2 (see 6.7 and 6.8). If the channel is idle when the delay expires, the node transmits; otherwise, the node receives the incoming packet, and then repeats the MAC algorithm. In Figure 6, D_{mean} is the average randomisation delay between packets, and, since the random delay T is uniformly distributed, D_{mean} is given as $(W_{base}-1)/2$ for small values of BL .




Figure 6 — Predictive p -persistent CSMA concepts and parameters

By adjusting the size of the randomising window as a function of the predicted load, the algorithm keeps the collision rate constant and independent of the load. Provided that the estimated backlog is greater than or equal to the real back-log, the following holds:

$$\text{Collision Rate} = \text{Error Pkt Cycles} / \text{Error Free Pkt Cycles} \leq 1 / 2W_{base}$$

A base window size of 16 is used. This implies that there are an average of 8 randomising slots of width Beta2 and one slot of width Beta1 between each packet. Also, the width of the Beta2 period is crucial to efficient utilisation of the channel.

The algorithm for Predictive CSMA is in A.2.

6.6 Idle channel detection

The idle channel condition is asserted whenever the following two conditions are met:

- 1) The current channel state reported by the physical layer via the P_Data_Indication () primitive is low; and
- 2) No transition has been detected during the last period of Beta1. Note that the MAC sublayer may be configured to ignore transitions during a portion of the Beta1 period. This portion of time that transitions are ignored (the channel is assumed to be idle during this time even in the presence of transitions) is called the indeterminate time (see 6.11 for the details).

The length of the Beta1 period is defined by the following constraint:

$$\text{Beta1} > 1 \text{ bit time} + (2 \times \text{Tau}_p + \text{Tau}_m) \quad (2)$$

The first term assumes a data encoding method that guarantees a transition and/or carrier during every bit time. If encoding methods are used that do not meet this constraint, then the first term must be adjusted to be the longest time that the channel may appear idle without being idle, i.e., the longest run in legal data transmission without a transition and/or carrier asserted on the medium. The second term takes care of propagation and turnaround delays, that are:

Tau_p is the physical propagation delay defined by the media length;

τ_m is the detection and turnaround delay within the MAC sublayer; this is the period from the time the idle channel condition is detected, to the point when the first output transition appears on the output. On media where there is a carrier, this time must include the time between turning on the carrier, and it being asserted as a valid carrier on the medium.

6.7 Randomising

At the beginning of the randomising period, a node wishing to transmit generates a random delay T (transmit) from the interval $(0.. (BL \times W_{base})-1$. The node then waits for this period, while continuing to monitor channel status; if the channel is still idle when the delay expires, the node transmits.

The transmit delay T (transmit) is an integer number of randomising slots of duration β_2 ; the length of the randomising slot must meet the following constraint:

$$\beta_2 > 2 \times \tau_p + \tau_m \quad (3)$$

Parameters τ_p and τ_m are defined in 6.6.

6.8 Backlog estimation

The predictive aspect of the MAC algorithm is based on backlog estimation. Each node maintains an estimate of the current channel backlog BL , that is incremented as a result of sending or receiving an MPDU and decrements periodically — once every packet cycle. The increment to the backlog is encoded into the link layer header, and represents the number of messages that the packet shall cause to be generated upon reception. The backlog is initially set to one. After sending or receiving a packet with a non-zero backlog increment, the node's backlog estimation is incremented by the backlog increment. The maximum backlog value is 63. If the backlog exceeds 63, then the backlog overflow statistic is incremented (see 13.7.14 and B.8).

The backlog decrements under one of the following conditions:

- On waiting to transmit: If W_{base} randomising slots go by without channel activity.
- On receive: If a packet is received with a backlog increment of '0'.
- On transmit: If a packet is transmitted with a backlog increment of '0'.
- On idle: If a packet cycle time expires without channel activity.

The packet cycle timer is reset to its initial value whenever the backlog is changed. It is started (begins counting down at its current value) whenever the MAC layer becomes idle. An idle MAC layer is defined as:

- 1) not receiving;
- 2) not transmitting;
- 3) not waiting to transmit;
- 4) not timing β_1 ;
- 5) not waiting for priority slots; and
- 6) not waiting for the first W_{base} randomising window to complete.

On transition from idle to either transmit or receive, the packet cycle timer is halted.

The backlog always has a value ≥ 1 . The algorithm post-increments rather than pre-increments the backlog by the amount associated with the MPDU being transmitted, because the number of expected responses is of no importance until after transmitting the MPDU.

6.9 Optional priority

On a channel by channel basis, the protocol supports optional priority. Priority slots, if any, follow immediately after the Beta1 period that follows the transmission of a packet (Figure 7). The number of priority slots per channel ranges from 0 to 127. Priority slots are typically not contended for, but rather are uniquely assigned to nodes on the channel. Nodes that have been assigned a priority slot do not have to use it with every message; the node decides on a message by message basis whether or not to use the assigned priority slot. This determination is made by examining the priority bit within the LPDU header (Figure 5).

It is possible to assign all the nodes on the channel the same priority slot. An example of an architecture where this makes sense would be one where there is a background of peer-to-peer activity, but a single master that cycles around doing something to each node (such as network management, polling, etc.). By giving each node the same slot, and having it used only for this purpose, these transactions (from the single master to multiple slaves) would tend to be completed ahead of the background traffic.

An application may decide that a message is high priority and attempt to send it as such. If the node does not have a priority slot assigned to it, the message shall go out in the usual way, except that the priority bit in the layer 2 header shall be set. If, subsequently, the packet passes through a router that has a priority slot on its destination channel, the packet shall be sent using the priority of the router. If the router does not have a priority slot, the message shall be forwarded in the usual way, with the priority bit in the layer 2 header remaining set.




Figure 7 — Allocation of priority slots within the Busy Channel Packet Cycle

The protocol provides no synchronisation among the nodes. Therefore, if the channel has been idle for longer than the randomising period ($\text{Beta1} + \text{number of priority slots} + D_{\text{mean}}$ above), access to the link is random without regard to priority. Once the link returns to the busy state, access to the link shall be in priority order.

If a priority message requires:

- acknowledgement (acknowledged messaging);
- response (request/response messaging);
- challenge (in response to an authenticated acknowledged message or authenticated request); or
- reply (in response to an authentication challenge).

The responding node shall attempt to send a priority acknowledgement/response/challenge/reply by setting the priority bit in the layer 2 header. If a high priority message is generated within a node, it is sent prior to any queued packets of normal priority. Multiple high priority packets are sent in FIFO order. If the application attempts to send a high priority message while its node is sending a packet, the packet in progress completes first.

If a channel has priority slots and a node has multiple messages queued within it, it shall not send them in consecutive packet cycles. In the case where a node has a packet to send, and it has sent a

packet in the previous packet cycle, the node does not use its normal medium access algorithm in the current cycle. Instead it attempts to access the medium using a slightly modified version of the non-priority MAC algorithm. The modified version of the algorithm is that the transmitter node waits out the Beta1 time after the priority packet it just transmitted, then it waits for all the priority slots to go by, then it waits for one window of randomising slots to go by (16 Beta2 slots). At this point it randomises its access to the network using the current channel backlog estimate. If the node is not successful in the current packet cycle, it may use its priority slot in the subsequent packet cycle.

6.10 Optional collision detection

The physical layer may optionally notify the MAC sublayer of a detected collision. The MAC sublayer can be configured to check for collision detection notification any time during packet transmission.

Collision resolution may be implemented by means of collision detection. A bit pattern unique to each node on the channel may be inserted before the preamble field to resolve collisions. Such a physical layer must define a sufficiently long preamble after the arbitration pattern so that transmitting nodes that lose the arbitration for a packet cycle can turn around and receive the incoming packet from the node that just won the arbitration.

Collision detection, if used, shall only be enabled upon transmission of a packet. When a collision is detected in the MAC sublayer, the backlog is incremented. Receivers do not detect collisions, rather they see them as packets that are too short, or have incorrect CRCs or sometimes they are seen as just spurious transitions for which bit synchronisation cannot be achieved. When a collision is detected, the backlog is incremented, and the collision statistic is incremented (see 13.7.14 and B.8).

The MAC sublayer attempts to re-transmit the packet upon notification of a collision. It obeys the following rules:

- 1) If a collision is detected on two successive attempts to transmit a priority packet in the node's priority slot, the next attempt to transmit the priority packet shall not use the configured priority slot, but rather shall be in a slot picked according to the non-priority MAC algorithm. The priority bit in the layer 2 header of the packet shall remain set in this case.
- 2) Whenever a collision is detected by a transmitting node, that transmitting node increments its estimate of the channel backlog by 1.
- 3) Whenever a collision is detected on 256 successive attempts to transmit a packet, the packet is discarded.

6.11 Beta1, Beta2 and Preamble Timings

A node may be implemented to support one or more media. If implemented to support multiple media, its preamble length and Beta1 and Beta2 times must be configurable to support the relevant physical communication media. Beta2 is the duration in time of a media access time-slot (either randomising or priority slot). The MAC layer timers for Beta1 are provided for both the transmitter in the previous packet cycle as well as the receiver. This is to correct for differences in the time base for the end of the preceding packet between transmitters and receivers. Note that in this family of physical layer standards the timings are with reference to the timings observable on the medium itself, while these timings are in reference to the protocol processor's reference. For example, imagine a transceiver that added bits of error correction code to the actual packet. From the transmitting protocol processor's reference the end of the packet would be sent before these bits were added to the packet, while the receiving protocol processor's time reference would show packet end at the end of the packet including the error correction bits. Thus, the need for the ability to specify a difference in the timing depending upon whether a node is a transmitter or a receiver for a given packet. In addition there are two communication configurations (comm_type in B.7) with different formula for calculating Beta1 based on the type.

A node must be able to generate one of five base time periods to generate Beta1 and Beta2 slots of the right duration.

The formulae for Beta1, Beta2, and the preamble are shown below.

CT is a time base used to generate Beta1 and Beta2 slots and the preamble. Depending on the media type(s) supported, each node must support one or more of the following values for CT: 600 ns, 1,2 µs, 2,4 µs, 4,8 µs, 9,6 µs.

v , a tuning parameter, is in the range 0 to 255 inclusive. There are 3 tuning parameters. These are represented as v_1 , v_2 and v_3 in the formula below.

$f()$ is a function that returns a time delay to compensate for other slower nodes on a channel that may generate actual values of CT below the nominal for a channel.

$$\text{Beta2} = \text{CT} \times (40 + 20 \times v_1) \quad (4)$$

There are four formulae for computing Beta1. The formula to use depends on a bit field in the configuration structure, `comm_type`, listed in B.7, and whether the timing is done immediately following the receipt or the transmission of a packet. `Comm_type` can have one of two values: 1 or 2. The selection of the `comm_type` determines the behaviour of the MAC sublayer in the following ways:

`Comm_type` = 1:

- 1) An indeterminate time is defined during the Beta 1 period in which all transitions on the channel are ignored. This period starts following the end of any packet (transmitted or received). Its duration is defined below. Following the indeterminate time and before the first Beta2 slot, the MAC sublayer repeatedly waits for a period of duration of one Beta2 slot to pass with no transitions on the channel before proceeding (note that if a valid preamble is detected during this period, an attempt shall be made to receive the incoming packet). This Beta2 slot duration accounts for the Beta2 slot duration component of the total Beta1 time.
- 2) The transmitted length of the preamble is under the control of the MAC sublayer.
- 3) The MAC sublayer ignores collisions occurring during the first 25 % of the transmitted preamble. It optionally (according to the `cd_tail` field described in B.7) ignores collisions reported following the transmission of the CRC but prior to the end of transmission.
- 4) If a collision is detected during preamble transmission, the MAC sublayer can terminate the packet if so configured. Collisions detected after the preamble has been sent do not terminate transmission.

`Comm_type` = 2:

- 1) No indeterminate time is defined at the MAC sublayer. If there is an indeterminate time, it shall be enforced by the physical layer.
- 2) The MAC sublayer is configured to either control the transmitted length of the preamble or to have the transmitted length of the preamble controlled by the physical layer.
- 3) The MAC sublayer shall always terminate the packet upon notification of a collision.
- 4) The MAC sublayer reconfigures the physical layer prior to transmission, if necessary, to inform it of a change in transmission path selection (alternate path versus no alternate path).

The formulae for Beta1 for the four cases of transmitting, receiving, `comm_type` = 1 and `comm_type` = 2 are as follows:

$$\begin{aligned} \text{Beta1(after transmission)} &= \text{CT} \times (583 + f(\text{xmit_interpacket})) + \text{Beta2} \{\text{for comm_type}=1\} \\ \text{Beta1(after reception)} &= \text{CT} \times (565 + f(\text{recv_interpacket})) + \text{Beta2} \{\text{for comm_type}=1\} \\ \text{Beta1(after transmission)} &= \text{CT} \times (624 + f(\text{xmit_interpacket})) + \text{Beta2} \{\text{for comm_type}=2\} \\ \text{Beta1(after reception)} &= \text{CT} \times 602 + f(\text{recv_interpacket}) + \text{Beta2} \{\text{for comm_type}=2\} \end{aligned} \quad (5 \text{ to } 8)$$

$$f(v) = (v < 128) ? (41 \times v_2) : 145 \times (v_2 - 128) \quad (9)$$

Parameters xmit_interpacket and recv_interpacket have ranges from 0 to 255 and are parameters stored in the Configuration Structure (B.7).

The two formulae for computing the indeterminate time for the MAC sublayer are as follows:

$$\begin{aligned} \text{IDT(after transmission)} &= \text{CT} * (313 + f(\text{xmit_interpacket})) \{\text{for comm_type} = 1\} \\ \text{IDT(after reception)} &= \text{CT} * (295 + f(\text{recv_interpacket})) \{\text{for comm_type} = 1\} \end{aligned} \quad (10 \text{ to } 11)$$

CT, f(x), xmit_interpacket and recv_interpacket are as defined for the Beta1 calculations. Note that in all cases the indeterminate time is constrained to be less than the total Beta1 time.

Preamble length is either controlled by the protocol processor or by the transceiver. When the protocol processor controls the preamble, the formula for all possible values of preamble length is shown below. For this formula the variable v has a range of from 0 to 253 inclusive. CT is as defined above.

$$\text{Preamble} = \text{CT} \times (219 + 32 \times v_3) \quad (12)$$

When the transceiver controls the preamble length (an option available when comm_type = 2), the minimum preamble length allowed is 181 µs. This is the value corresponding to a protocol processor with a 600 ns timer value. This value scales with the time base, CT. When the transceiver controls the preamble length, the maximum preamble length is determined by the transceiver.

Beta1, Beta2 and preamble timings for each transceiver type compatible to this standard are noted in the relevant physical layer specification.

7 Link layer

7.1 Assumptions

The Link layer assumes that CRC errors due to both collisions and transmission errors occur with some probability P_e , and that P_e is small enough so that link level error recovery is not needed.

The above assumption means that successful end-to-end communication is only possible when the sum of error probabilities along the communication path is much less than one.

$$\text{SUM}(P_e) \ll 1$$

In networks where P_e is constant, the maximum communication distance D (network or group diameter) must be:

$$D \ll 1/P_e$$

7.2 Service provided

The Link layer provides subnet-wide, ordered, unacknowledged LPDU delivery with error detection but no error recovery. A corrupted frame is discarded as soon as its CRC check fails.

7.3 CRC

The CRC is computed over the entire NPDU including the L2Hdr field. The CRC is generated using the polynomial:

$$X^{16} + X^{12} + X^5 + 1 \text{ (the CCITT CRC-16 standard).}$$

For each NPDU, the CRC register is initialised to all ones. Figure 8 shows an example of the time behaviour of the CRC shift register that implements the above polynomial. The register bits are represented by the columns labelled bit 0 to bit 15. The data, over which the CRC is computed, appears in the column labelled `crc_in`. The register is initialised to all ones. The data is then presented serially to the register starting with bit 7 of byte 1. Each row of the table shows the register state at a particular bit time. The register continues to input data and compute the CRC as long as the compute mode is true (`mode compute = 1`). The compute mode going false signals the end of data and the end of the CRC computation.

Following data input, the sixteen (16) bits of CRC data are shifted out serially as shown by the column labelled `nrz_out`.

When the link layer receives a packet with a CRC error or a packet that is less than 8 bytes in length, a transmission error statistic is incremented (see 13.8.2), and the packet cycle timer is started but not reset first, unlike after the reception of a good packet. If a packet is received but is too long for the input buffer, or there are no input buffers, the missed packet statistic is incremented (see 13.8.2).

For a normative description of the CRC-16 computation, refer to the pseudocode example in A.3.

IECNORM.COM : Click to view the PDF of ISO/IEC 14908-1:2012

| Comment | mode compute | crc_in | Bit 0 | Bit 1 | Bit 2 | Bit 3 | Bit 4 | Bit 5 | Bit 6 | Bit 7 | Bit 8 | Bit 9 | Bit 10 | Bit 11 | Bit 12 | Bit 13 | Bit 14 | Bit 15 | nrz_out |
|------------|--------------|--------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|--------|--------|--------|--------|--------|--------|---------|
| initialize | | | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | |
| Byte1 bit7 | 1 | 0 | 1 | 1 | 1 | 1 | 1 | 0 | 1 | 1 | 1 | 1 | 1 | 1 | 0 | 1 | 1 | 1 | 0 |
| 6 | 1 | 1 | 0 | 1 | 1 | 1 | 1 | 1 | 0 | 1 | 1 | 1 | 1 | 1 | 1 | 0 | 1 | 1 | 1 |
| 5 | 1 | 1 | 0 | 0 | 1 | 1 | 1 | 1 | 1 | 0 | 1 | 1 | 1 | 1 | 1 | 1 | 0 | 1 | 1 |
| 4 | 1 | 1 | 0 | 0 | 0 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 0 | 1 |
| 3 | 1 | 1 | 1 | 0 | 0 | 0 | 1 | 0 | 1 | 1 | 1 | 0 | 1 | 1 | 0 | 1 | 1 | 1 | 1 |
| 2 | 1 | 0 | 1 | 1 | 0 | 0 | 0 | 0 | 0 | 1 | 1 | 1 | 0 | 1 | 0 | 0 | 1 | 1 | 0 |
| 1 | 1 | 0 | 1 | 1 | 1 | 0 | 0 | 1 | 0 | 0 | 1 | 1 | 1 | 0 | 0 | 0 | 0 | 1 | 0 |
| 0 | 1 | 1 | 0 | 1 | 1 | 1 | 0 | 0 | 1 | 0 | 0 | 1 | 1 | 1 | 0 | 0 | 0 | 0 | 1 |
| Byte2 bit7 | 1 | 1 | 1 | 0 | 1 | 1 | 1 | 0 | 1 | 0 | 0 | 1 | 1 | 1 | 0 | 0 | 0 | 0 | 1 |
| 6 | 1 | 0 | 0 | 1 | 0 | 1 | 1 | 1 | 1 | 0 | 1 | 0 | 0 | 1 | 1 | 0 | 0 | 0 | 0 |
| 5 | 1 | 0 | 0 | 0 | 1 | 0 | 1 | 1 | 1 | 1 | 0 | 1 | 0 | 0 | 1 | 1 | 0 | 0 | 0 |
| 4 | 1 | 1 | 1 | 0 | 0 | 1 | 0 | 0 | 1 | 1 | 1 | 0 | 1 | 0 | 1 | 1 | 1 | 0 | 1 |
| 3 | 1 | 1 | 1 | 1 | 0 | 0 | 1 | 1 | 0 | 1 | 1 | 0 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| 2 | 1 | 0 | 1 | 1 | 1 | 0 | 0 | 0 | 1 | 0 | 1 | 1 | 1 | 0 | 0 | 1 | 1 | 1 | 0 |
| 1 | 1 | 0 | 1 | 1 | 1 | 1 | 0 | 1 | 0 | 1 | 0 | 1 | 1 | 1 | 1 | 0 | 1 | 1 | 0 |
| 0 | 1 | 0 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 0 | 1 | 0 | 1 | 1 | 0 | 1 | 0 | 1 | 0 |
| Byte3 bit7 | 1 | 1 | 0 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 0 | 1 | 0 | 1 | 1 | 0 | 1 | 0 | 1 |
| 6 | 1 | 1 | 1 | 0 | 1 | 1 | 1 | 0 | 1 | 1 | 1 | 0 | 1 | 0 | 0 | 1 | 0 | 1 | 1 |
| 5 | 1 | 1 | 0 | 1 | 0 | 1 | 1 | 1 | 0 | 1 | 1 | 1 | 0 | 1 | 0 | 0 | 1 | 0 | 1 |
| 4 | 1 | 0 | 0 | 0 | 1 | 0 | 1 | 1 | 1 | 0 | 1 | 1 | 1 | 0 | 1 | 0 | 0 | 1 | 0 |
| 3 | 1 | 0 | 1 | 0 | 0 | 1 | 0 | 0 | 1 | 1 | 0 | 1 | 1 | 1 | 1 | 1 | 0 | 0 | 0 |
| 2 | 1 | 0 | 0 | 1 | 0 | 0 | 1 | 0 | 0 | 1 | 1 | 0 | 1 | 1 | 1 | 1 | 1 | 0 | 0 |
| 1 | 1 | 0 | 0 | 0 | 1 | 0 | 0 | 1 | 0 | 0 | 1 | 1 | 0 | 1 | 1 | 1 | 1 | 1 | 0 |
| 0 | 1 | 0 | 1 | 0 | 0 | 1 | 0 | 1 | 1 | 0 | 0 | 1 | 1 | 0 | 0 | 1 | 1 | 1 | 0 |
| Crc bit 15 | 0 | | 0 | 1 | 0 | 0 | 1 | 0 | 1 | 1 | 0 | 0 | 1 | 1 | 0 | 0 | 1 | 1 | 0 |
| 14 | 0 | | 0 | 0 | 1 | 0 | 0 | 1 | 0 | 1 | 1 | 0 | 0 | 1 | 1 | 0 | 0 | 1 | 0 |
| 13 | 0 | | 0 | 0 | 0 | 1 | 0 | 0 | 1 | 0 | 1 | 1 | 0 | 0 | 1 | 1 | 0 | 0 | 0 |
| 12 | 0 | | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 1 | 0 | 1 | 1 | 0 | 0 | 1 | 1 | 0 | 1 |
| 11 | 0 | | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 1 | 0 | 1 | 1 | 0 | 0 | 1 | 1 | 1 |
| 10 | 0 | | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 1 | 0 | 1 | 1 | 0 | 0 | 1 | 0 |
| 9 | 0 | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 1 | 0 | 1 | 1 | 0 | 0 | 0 |
| 8 | 0 | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 1 | 0 | 1 | 1 | 0 | 1 |
| 7 | 0 | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 1 | 0 | 1 | 1 | 1 |
| 6 | 0 | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 1 | 0 | 1 | 0 |
| 5 | 0 | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 1 | 0 | 0 |
| 4 | 0 | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 1 | 1 |
| 3 | 0 | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 0 |
| 2 | 0 | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 1 |
| 1 | 0 | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 1 |
| 0 | 0 | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |

Figure 8 — CRC register state behaviour example

7.4 Transmit algorithm

The pseudocode Transmit algorithm is in A.3.

Receive Algorithm

A valid frame starts with the channel active state, and terminates with the channel idle state. Upon reception, valid frames are processed as defined below; invalid frames are discarded. The pseudocode Receive algorithm is in A.4.

8 Network layer

8.1 Assumptions

This protocol supports a variety of topologies in order that the requirements from many application areas can be met. Within a single channel, the topology can be a bus, a ring, a star, or “free” (see Figure 9). Free topology is defined as a total wire specification with no other rules, and a single termination placed anywhere on the network. Thus, the set of all free topologies includes a ring, a star, a bus and virtually any other combination of these constructs.




Figure 9 — Single channel topologies

The protocol supports physical layer repeaters as well as store-and-forward repeaters to repeat packets from one channel to another. The protocol also supports bridges to repeat all packets on the bridge's domain(s) from one channel to another. Additionally, both learning and configured routers are supported to segment traffic and thus increase total system performance.

In networks where there is a possibility of more than one path from one node to another, there is a danger of packets looping indefinitely. In these networks, configured routers must be used to impose a logical tree structured topology on top of the physical looping topology.

If there is a desire to use repeaters, bridges, and learning routers, then control of the topology must be maintained so that no loops exist. To avoid routing loops within a domain, domain topology must be tree-structured as shown in Figure 10. Store-and-forward repeaters may only be used if they connect two different channels together; store-and-forward repeaters that repeat on the same channel are not supported. This restriction is necessary for an order-preserving network.

If any node receives a packet with a protocol version number other than a version number it supports, the packet is discarded.




Figure 10 — Typical tree-like domain topology

8.2 Service provided

This network layer provides a connection-less network service facilitating domain wide packet delivery with the following attributes:

- *Unacknowledged Unicast, Multicast, and Broadcast.* Depending on its destination address, the packet submitted is delivered to one node, multiple nodes, or all nodes within the domain (or optionally all nodes on a specified subnet within the domain). This delivery occurs with some probability $p \leq 1$;
- *Lossiness.* The network layer supports no re-transmissions or acknowledgments. The probability of delivery decreases with the number of channels traversed;
- *Order Preserving.* Loop-free topology (accomplished logically with configured routers or physically via topological control) coupled with the absence of single channel store and forward repeaters provides natural ordering;
- *No Segmentation.* No message segmentation and/or message re-assembly are performed anywhere within the network layer.

When learning routers are used, the routers discover the topology by examining the network layer address fields in the packets. The learning algorithm imposes no additional traffic overhead on the network. It assumes that the domain is loop free, and it learns about the location of subnets by observing the source addresses of NPDUs being routed. NPDUs addressed to groups are routed by flooding, with the NPDUs being propagated through the entire domain.

The network layer suppresses outgoing messages if the node is not in the hard offline state (see 13.4) or configured state (e.g. unconfigured), except for manual service request messages, responses, and ACKs. These excepted messages can be sent in any state.

8.3 Service interface

The Network service interface consists of the Send_Packet () service request and the Rcv_Packet () indication, as shown in Figure 11. Again this interface is provided for explanation purposes. Actual implementations may, for example, combine this layer with the transport layer and only expose the transport layer interface.




Figure 11 — Network service interface

The syntax of these two interface primitives is:

```
Send_Packet (address_pair, pduType, PDU, priority, delta_BL, Alt_path)
Rcv_Packet (address_pair, pduType, PDU, priority)
```

8.4 Internal structuring of the network layer

The network layer performs two functions—address recognition and routing—as shown in Figure 12.




Figure 12 — Network layer—internal structure

8.5 NPDU format

NPDU format is shown in Figure 13. An NPDU carries and encapsulates either a TPDU, SPDU, AuthPDU or APDU. There are no NPDUs defined for internal network layer use. The numbers above each field in Figure 13 specify the field size in bits. The symbolic field values used in the figure are assigned in the order shown, as enumerated ranges (0, 1, 2, 3, ..., n). For example, a value of 3 in the PDU_Fmt field signifies that the enclosed PDU is an APDU. For additional details, including the bit/byte transmission order, refer to Annex D.




Figure 13 — NPDU format

8.6 Address recognition

Each node compliant to this International Standard performs address recognition. Address recognition at a node depends on the node's state. In the Unconfigured state, all broadcast messages and messages that match a node's Unique_Node_ID are received. In the Configured state, messages must either match the Unique_Node_ID or match the domain and be either broadcast, group (i.e., multicast) or unicast messages. To match the domain both the domain length and the domain address must match. For broadcast messages, the subnet must match unless the broadcast message is sent domain-wide. For a group message, the node must be a member of the group, i.e., one of the group addresses must match. For a unicast message, subnet as well as node numbers must match. The match of the node number is a comparison of the entire byte even though the node number is defined as seven bits.

In this subclause the information that must be kept by every node is identified without specifying the address-matching algorithm, that is implementation specific. For an example of an actual implementation of these data structures, refer to A.14.

Any packet received by a node with a protocol version number not supported by the node shall be discarded.

A packet whose source subnet/node address matches that in the matching domain is discarded.

When not in the configured or the hard-offline state, only broadcast (domain-wide or subnet) or matching Unique_Node_ID messages are received. The receive transaction source address is saved based on the actual domain in which the message was received (the flexible domain). Any responses are returned on that domain with a subnet/node number of 0x00/0x80. Either the implementation shall support one flexible domain shared among all receive transactions or the implementation shall support one flexible domain per receive transaction.

8.7 Routers

A router performs the routing function for a specific domain. The routing function is independent of the network layer address recognition function. Thus, a router also has its own network addresses and can be addressed like any other node for purposes of network management and diagnostics. A router connects two sets of subnets. A router is a logical rather than physical entity; more than one router may be housed within a single physical package. Routers have four modes that may be set with network management messages: repeater, bridge, learning, and configured. Routers with their mode set to learning, automatically learn the subnet topology of the network. Routers with their mode set to configured have their routing tables statically configured with network management messages to enforce a specific topology and to provide information on group address topology. Similarly, a router may be set to be a bridge or repeater using the network management messages to set its mode. The same subnets may exist on both sides of a bridge or repeater.

A router uses three routing functions: ROUTE_{uc}(), ROUTE_{mc}(), and ROUTE_{bc}() to forward NPDUs. The first function specifies how to forward NPDUs addressed to subnets, the second how to forward NPDUs addressed to groups, and the third how to forward NPDUs when they are broadcast. The functions are tables, where each entry has the following form:

```
ROUTEuc (DestSubnet) = one of (forward, discard)
ROUTEmc (DestGroup) = one of (forward, discard)
ROUTEbc (DestSubnet) = one of (forward, discard)
```

The entry for an address X specifies whether an NPDU addressed to X should be forwarded or discarded. These functions are called from the side of the router on which the packet was received—that is, the algorithm in A.5 executes independently on each side of the router and makes all routing decisions for packets arriving at the side on which it runs. Each side of the router shall have a different set of tables that have the information as to whether the packet should be passed across the router or not. For configured routers, these tables are initialised during the network configuration of the router and must be updated if the topology changes. Learning routers discover the contents of their subnet

tables by observing the source addresses of the packets (see A.6), but cannot learn the topology of a group. Therefore, learning routers always pass group messages to the other side.

8.8 Routing algorithm

The pseudocode for the routing algorithm is in A.5.

8.9 Learning algorithm — subnets

The subnet routing table defining the routing function $ROUTE_{uc}()$ is created by the algorithm in A.6. Upon initialisation, forwarding is used for all subnet addresses. The algorithm subsequently learns about the location of subnets by observing the source addresses of NPDUs being routed. Again, this algorithm executes on each side of the router independently.

9 Transaction control sublayer

9.1 Assumptions

The transaction sequencing protocol described in this clause uses 4-bit transaction numbers that are allocated by the sender and used by the receiver to detect duplicate packets. This sublayer provides end to end protocol integrity by allowing the receiver to only act upon a packet once, even if several retries for the initial packet are correctly received by the receiver. It is assumed that the network is either order preserving or, if it is not, that packets are delayed approximately uniformly in the multiple paths that they traverse from source to destination. The difference in packet propagation time when there are multiple paths from a given source to a destination must be less than the time it takes for the source to complete one transaction (via an acknowledgement on the shortest path) and begin a second transaction to the same destination. Stale acknowledgements and responses are detected as duplicates, but stale packets that initiate a transaction and arrive after a subsequent transaction has started will not be detected as duplicates.

The transaction control sublayer may pass a transaction to the higher layers for processing. In some implementations, it may be possible for the upper layers to never respond to the transaction control sublayer. If such a situation exists, the transaction control sublayer can defend itself from such poorly behaved upper layers. During the time that the transaction control sublayer is waiting for a response from the upper layers, the transaction record can be locked and not be de-allocated even if the receive transaction timer expires. Such a transaction is only de-allocated when the upper layers finally respond, or when there are no more transaction records available and one is needed. Then, a locked transaction record may be used for the new transaction. Use of this mechanism is implementation dependent.

In the general case, the number of concurrent outgoing transactions is restricted to a single priority and a single non-priority transaction. This restriction is due to the fact that acknowledgements/responses from either a subnet/node addressed message/request or a Unique Node ID addressed message/request are indistinguishable. Implementations that restrict the use of one of these addressing modes may support multiple, concurrent transactions. Receive transactions are shared among the transport and session layers. Transactions at either layer can perform duplicate detection.

The transaction timer, receive timer, and retry count interact to establish the reliability of the duplicate detection mechanism. It is assumed that the receive timer is set to be long enough to cover the configured number of retries, yet short enough so that the transaction ID does not wrap around causing a new transaction to be falsely detected as a duplicate transaction. In an implementation, it is required to have a transaction space for all priority transactions and a second transaction space for all non-priority transactions. If the sender wishes to send a packet to a given destination and the transaction ID for the last message sent to that destination is identical to the current transaction ID, the transaction ID is incremented. An optional enhancement is to have a separate priority and non-priority transaction space for every destination address. In this second case, the sender remembers the last transaction ID used per destination address. In any case an implementation shall defend against the

situation that acknowledgements/responses cannot be differentiated from each other when using subnet/node addressing or Unique Node ID addressing. Other implementations are permitted as long as the duplicate detection mechanism remains robust in all of the error cases and all of the addressing formats in use by the node.

9.2 Service provided

The transaction control sublayer is responsible for the common functions related to transaction ordering, sequencing, and duplicate detection. It provides the following services:

- **Outgoing Sequencing.** To guarantee ordering among outgoing transport messages and session layer requests, the transaction control sublayer controls the allocation of send transaction numbers. It limits the number of concurrent transactions to any destination to ≤ 1 priority and ≤ 1 non-priority transactions;
- **Incoming Sequencing and Duplicate Detection.** The transaction control sublayer provides duplicate detection.

9.3 Service interface

Access to transaction control services is facilitated by the interface depicted in Figure 14.




Figure 14 — Transaction control service interface

The syntax and semantics of the interface primitives are:

```
New_Trans (Priority, Dest_addr) -> (Trans_No)
    is used to obtain a transaction number for a new outgoing transaction

Validate (Priority, Trans_No, Dest_addr) -> (result)
    where result = one of (current, not_current), verifies that Trans_No is in
    the transmit window

Trans_Done (Priority, Trans_No, Dest_addr)
    notification of an outgoing transaction completion

Compare (T1, T2) -> (result)
    where result is one of (new, duplicate ); defines the relationship of T1
    relative to T2, where both T1 and T2 are receive transaction numbers
```

9.4 State variables

To support the allocation of transaction numbers, the transaction control sublayer uses a number of destination records shown below.

```
Transaction_CTRL_Record = record
    PriTX                True or False
    Trans_No:            (0..15); initial value = 0;
    In_Progress:        boolean;
end;
```

9.5 Transaction control algorithm

The pseudocode algorithm in A.7 is a version of the transaction control algorithm that provides only two transaction spaces – one for all priority transactions and one for all non-priority transactions. In any implementation, the first transaction ID provided by `New_Trans()` after a reset shall be 0 for every transaction space provided by the implementation. `New_Trans()` shall then increment the transaction ID within the space from 1 to 15 and continue again with 1 so that the transaction ID 0 is used exclusively by the first transaction per transaction space after a reset.

In general, any transaction control algorithm shall follow the following basic operation:

- When a node has a packet to send using the transaction control algorithm, the sender node picks a transaction ID and sends the packet.
- Upon receipt of that packet, the receiver node searches its currently active receive transactions for a transaction that matches the source and destination address of the packet, the priority attribute, and the transaction ID.
- If there is no match a new record is allocated.
- If everything but the transaction ID matches and the existing transaction is not locked, then the preceding transaction is assumed to have completed successfully and the receive transaction record may be reused with the new transaction ID inserted into it. Processing of the incoming packet cannot proceed until a receive transaction is allocated for it.
- Once the receiver has allocated the transaction record, it starts a receive transaction timer for that record. The value of the receive transaction timer is 8 seconds for a `Unique_ID` addressed message, the value of the non-group receive timer for a subnet/node addressed message, and, for group addressed messages, the receive transaction timer configured for the group. The record will be de-allocated upon the expiration of this timer unless the transaction record becomes locked (see 9.1).
- Subsequent packets that arrive at the receiver node that match the transaction ID, source address, destination address and priority attribute of an existing transaction will be considered duplicates by the receiver node.
- Packets detected as duplicates are responded to according to the protocol service requested, but are either not delivered to the application, or if they are delivered to the application, they are delivered along with the notification that they are duplicate packets.

10 Transport layer

10.1 Assumptions

The Transport protocol makes no assumptions apart from relying on the transaction control sublayer for correct TPDU sequencing and duplicate detection.

10.2 Service provided

The transport layer provides the following services:

- Reliable Multicast and Unicast. The transport protocol supports both multicast within a group, and multicast to a group with the sender not being a member of the group. If the service requires acknowledgements or responses, then multicast to a group that the sender is not a member of requires the transport layer to be told that the group size is the actual group size plus one. All reliable services have the following attributes:
 - (a) reliable delivery with best effort determined by the number of retries;
 - (b) assuming the layer 4 timers are set correctly, duplicate detection is provided in all cases except when the sender or receiver just reset. In this case, the reset node shall start with

transaction number 0. This may result in a transaction in progress between the two nodes not to be acted upon at all, but acknowledged/responded to by the receiver;

- (c) partial ordering—ordering is preserved but a message is not delivered when delivery fails within the specified number of retries; and,
- (d) immediate re-synchronisation—following a network partitioning, the very first message is delivered.
- Unacknowledged-Repeated Multicast and Unicast. These services differ from the reliable ones described above only in that no acknowledgement is expected, and that the message is sent repeatedly until the number of repetitions is equal to the retry count. When using this service, the limit of 64 members in a group does not apply—the only limit on the number of members in a group addressed via this service is the number of nodes in a domain.

Groups in this International Standard are symmetric in that every member of the group can both send and receive.

10.3 Service interface

The service interface provided to the session and application layers has the form shown in Figure 15.




Figure 15 — Transport interface to upper layers

The syntax and semantics of the transport layer interface are:

```

Send_Message (Address, APDU, priority, ServiceType, alt_path) -> (TID)
Trans_Completed (TID, Result)
Rcv_Message (APDU)
  
```

TID, above, is a unique identifier for the transaction.

10.4 TPDU types and formats

TPDU syntax is shown in Figure 16; the number above each field specifies the field size in bits. The symbolic field values shown in the picture are mapped onto numeric ranges (0, 1, 2, 3...) in the order shown. Additional details, such as the bit/byte transmission order, are defined in Annex D. Timers and counters used to transmit retries, count retries, and time out transaction IDs, are described in B.4.11.




Figure 16 — TPDU types and formats

The *Acknowledged Message* (ACKD) TPDU (see Figure 34) is used for the first transmission of a message. It is used with addressing formats #1, #2a, and to a limited extent #3. Unlike the Unacknowledged message TPDU, it must be acknowledged by all addressed recipients, thus the transport layer provides the number of acknowledgements expected to the link layer for encoding into the link layer header. This TPDU is used for acknowledged initial TPDUs (both unicast and multicast) as well as unicast reminders. Multicast reminders are covered below. Refer to Figure 36 or Figure 34 to review the addressing formats.

The *Unacknowledged-repeated Message* (UnACKD_RPT) TPDU is identical to its acknowledged counterpart with one exception: on its reception, no acknowledgements are returned to the sender. This TPDU is used with no modifications for the unacknowledged-repeated service. For this type of message the transport layer provides a backlog increment equal to the number of retries on the first message and a backlog increment of zero on all subsequent transmissions within the transaction. Simple unacknowledged messages are only sent once, have no TPDU header, and thus have no duplicate detection.

The *Message-Reminder* (REM/MSG) TPDU facilitates selective soliciting of acknowledgements for multicast transactions. REM/MSG type 5 is used when the highest numbered group member from which the sender has received an acknowledgement is < 16 ; this TPDU contains both the member list (M_List []), that is an array of bits, and the APDU. The Length field specifies (in bytes) the size of the M_List field. A value of 0 in the bit field M_List [X] indicates that member X's acknowledgement has not been received by the sender, whereas a value of 1 indicates that the acknowledgement has been received. Bit locations within a byte are assigned right to left with bit number zero on the right. When Length = 0, the M_List[] field is absent and the meaning is "all members should acknowledge." The backlog increment for this message is the number of acknowledgements that have not yet been received.

Type 4 is a plain reminder, without an APDU (see Figure 16). It is used in cases where the highest numbered member that has acknowledged the message is ≥ 16 . Acknowledgements are solicited using the TPDU pair (REMINDER, ACKD) and this pair is logically equivalent to a single type 5 REM/MSG TPDU used when the members needing to acknowledge may be encoded within the type 5 format. (This separate solution is provided for large groups because of the need to limit maximum TPDU size.) This message always has a backlog increment of zero. The ACKD message that immediately follows its transmission has its backlog increment set to the number of acknowledgements that are yet to be received.

The *Acknowledgement* (ACK) TPDU is null. It uses addressing format #2a (unicast acknowledgement) or #2b (group acknowledgement). The Trans_No field conveys the transaction being acknowledged. Acknowledgements always inherit the priority and alt_path attributes of the original message.




Figure 18 — Transport protocol—Send FSM

10.8 Receive algorithm

Message reception uses the timer-based mechanism. Figure 19 shows the receive FSM for a single transaction, while the algorithm in A.9 specifies full details.




Figure 19 — Transport protocol—Receive FSM

10.9 Receive transaction record pool size and configuration engineering

10.9.1 General

Space for the Receive Transaction Record (RTR) pool defined in 9.5 and A.9, may be fixed for an implementation, or may be allocated at the time the application program is linked with the protocol code. The size of the RTR pool limits the number of *concurrent receive* operations on a node ("concurrent" means concurrent within the context of Rcv_Timer) and should be engineered according to the number of concurrent transactions expected within the receive timer interval. If an attempt is made to allocate a receive transaction record and none are available, the receive transaction full statistic is incremented (see 13.8.2).

10.9.2 Number of retries

The number of retries should be large enough to ensure that message delivery is successfully completed with acceptable probability, e.g., $\geq 99\%$. However, the upper bound of the number of retries in this International Standard is 15.

If the delivery failure probability of a single attempt is p , then the probability that message delivery within a group of n succeeds in $\leq k$ attempts is shown in the following formulae. (It is assumed that the single attempt probability p is the same for all destinations.)

$$P \{ \text{no retry} \} = (1-p)^n$$

$$P \{ \leq k \text{ retries} \} = \sum_{i=0}^k \binom{k+1}{i} p^i (1-p)^{(k-i+1)} (1-p^{(k-i+1)})^{(n-1)}$$

(13)

$k \geq 0, n \geq 2$

NOTE For a single channel $p = (1/2w + p_e)$, where w is the size of the MAC layer randomising window and p_e is the probability of packet loss because of a transmission error.

The above probabilities are graphed in Figure 20. Given a group size and the error probability p , the required number of retries for, say 99,5 % probability of success, can be read off the graph.




Figure 20 — Probability of transaction completion in k Retries

Pragmatic considerations should be respected in any real system design. For example, there is no need for a large number of retries with transactions that are repeated periodically. Additionally, when the acknowledgements to a multicast message would take up a significant percentage of the bandwidth of the channel, it is more likely that a message will be properly delivered using the “unacknowledged-repeated” service rather than the acknowledged multicast service. In practice, it is expected that a Retry_Count in the (2.to.5) range will cover most situations.

10.9.3 Transport layer timers

There are three timers used by the transport layer protocol. They are the:

- Xmit_Timer the layer 4 retransmission timer
- Repeat_Interval_Timer the UNACKD_RPT interval timer
- Rcv_Timer the receive record timer (see A.9 and 10.9)

These timers are active for every transaction. On the sender’s side, either the Repeat_Interval_Timer or the Xmit_Timer is active, while on the receive side, the Rcv_Timer is active. Xmit_Timer is reset on

every ACK TPDU or Authentication challenge reception, while Rcv_Timer is reset whenever a MSG or MSG/REM TPDU that has a new transaction number is received for this destination. The Repeat_Interval_Timer determines the interval between the UNACKD_RPT packets sent by the sender. The recommended methodology for calculating the timer values is shown in Figure 21. These recommendations are for unicast transactions across a single channel. For multi-channel networks, the calculation depends upon the speed of the router and the number of buffers. Multicast transactions need somewhat longer receive transaction values since multicast transactions take longer to complete even when there are no retries needed. Since buffering and clock rates are adjustable, the system designer must make some measurements to set the timers and retry counts correctly within each node.

| | |
|---|---|
| Retry Count = 2 to 5 | (see 10.9.2 and Figure 20) |
| $Xmit_Timer \geq 3 * \text{packet cycle time} + \text{margin}$ | (margin = best case tx completion time) |
| $Rcv_Timer \geq Xmit_Timer * (\text{Retry_Count} + 2)$ | |
| where: | |
| <p>“3 * packet cycle time” assumes that the average station on the channel must wait two packet cycles of delay to access the network. Then, following network access, the transmission time of the average packet (also the packet cycle time) is added to the timer value. Finally, the time it takes the receiver to process the packet and send the acknowledgement is added. This is a function of the clock speeds of the associated nodes.</p> | |

Figure 21 — Methodology for calculating timer values

All messages using the Unique_Node_ID use an 8-second receive timer, regardless of the configured value of the non-group receive timer. All non-group messages use the non-group receive timer.

11 Session layer

11.1 Assumptions

The session layer makes no assumptions apart from relying on the transaction control sublayer for correct SPDU sequencing and duplicate detection.

11.2 Service Provided

The session layer provides a single service:

- Request-Response. This service facilitates application communication similar to a remote procedure call. In particular, it allows a client to make a request to a remote server and receive a response to this request.
- *Non-idempotent* transactions are to be executed “*at most once*” (i.e., exactly once or not at all). Non-idempotent transactions are those where the action depends on a prior state, such as “open the valve an additional 10 %.” The protocol considers a transaction to be non-idempotent if and only if its response length is ≤ 1 byte.
- Requests with response length > 1 byte are considered *idempotent*; such requests may be executed “*several times*” (i.e., zero or more times). Idempotent transactions are those where the action may be repeated any number of times, and the effect is the same. An example of an idempotent command is “read the first 10 table values”.
- The distinction between idempotent and non-idempotent transactions is based upon the size of the response, in order to limit the amount of storage required for transaction records within a node. If a transaction has a response length > 1 byte but may not be executed more than once, *it is the responsibility of the application to save the response and send it again*. The session layer facilitates this in that notification that the request is a duplicate is provided to the application layer by the session layer.

- A request-response transaction fails unless the server response is generated within the limit imposed by the Request-Response timers and re-transmissions (see 10.8).

11.3 Service interface

The service interface to the application layer has the form shown in Figure 22.




Figure 22 — Session layer interface to application layer

The syntax of the service interface primitives is given below. TID is a unique identifier for the transaction. See A.7 for implementation details. Duplicate is a Boolean that, when true, indicates that the client is retrying a previously executed request. Result is a Boolean; true and false denotes success and failure respectively.

- Send_Request (Address, APDU, priority) -> (TID) {client}
- Partial_Response (TID, APDU, priority)
- Trans_Completed (TID, Result)
- Rcv_Request (TID, APDU, duplicate, priority) {server}
- Send_Response (TID, APDU, priority)

IECNORM.COM : Click to view the full PDF of ISO/IEC 14908-1:2012

11.4 Internal structure of the session layer

The session layer is internally structured as shown in Figure 23.




Figure 23 — Session layer—internal structuring

The Request-Response protocol accesses the Authentication server via the following three calls (details in 11.11). The transport layer also accesses the Authentication server with the same three calls.

| | |
|---|----------------|
| Initiate_Challenge(RR,PDU) -> (null) | { challenger } |
| Reply(XR, PDU)-> (null) | { challengee } |
| Process_Request(RR,PDU) -> (pass/fail); | { challenger } |

11.5 SPDU types and formats

SPDU formats are shown in Figure 24, where the number above each field specifies the field width in bits. The symbolic values shown in the picture are mapped onto numeric ranges (0, 1, 2, 3, ...) in the order shown.




Figure 24 — SPDU types and formats

The Request-Response protocol uses three basic PDU types: Request (REQUEST), Response (RESPONSE), and combined Request-Reminder (REM/MSG). The syntax (packet layout) and semantics (packet processing) of these three basic SPDU types correspond closely to that of ACKD, ACK, and REM/MSG TPDUs. Note that although the session layer makes use of the transport layer features internally, no transport layer encoding exists separately in a packet with an SPDU. That is, a packet may have either a TPDU or an SPDU.

The *Request* (REQUEST) SPDU is used with the first transmission of the request. It employs addressing formats #1, #2a, and to a limited extent #3 and #0 (see Figure 34). Address format #0 is used by a special network management command to broadcast a request searching for any nodes that have not been configured. Address format #3 is then used to configure those nodes that respond to this special network management command. The session layer provides a backlog increment to the lower layers equal to the number of responses expected.

The *Request-Reminder* (REM/MSG) SPDU facilitates selective soliciting of responses. REM/MSG type 5 is used in groups where the highest member number needing to acknowledge is < 16; this SPDU contains both the member list (M_List []), that is an array of bits, and the APDU (i.e., the request itself). The Length field specifies (in bytes) the size of the M_List field. A value of 0 in M_List [X] indicates that member X's response has not been received by the requester, whereas a value of 1 indicates that the response has been received. Bit locations are assigned right to left within each byte with bit 0 being the rightmost bit in the byte. The backlog increment encoded with the REM/MSG is equal to the number of remaining responses outstanding.

Type 4 is a plain reminder, without a request (see Figure 24). It is used where the highest member number needing to acknowledge the reminder is ≥ 16; in this case, responses are solicited using the SPDU pair (REMINDER-type 4, REQUEST-type 0) and this pair is logically equivalent to a single type 4 REM/MSG SPDU used in small groups. (A separate solution is provided for large groups because of

the need to limit maximum SPDU size.) Finally, when Length = 0 the M_List[] field is absent and the meaning is "all members should acknowledge." The backlog increment for the REMAINDER – type 4 message is always zero, while the REQUEST that immediately follows it contains the backlog increment for the number of responses that are still outstanding.

The *Response* (RESPONSE) SPDU uses addressing format #2a (unicast acknowledgement) or #2b (group acknowledgement). The Trans_No field conveys the transaction being acknowledged. The length of the APDU implicitly defines the type of transaction: if the response can be stored in a single byte, the transaction is treated as non-idempotent. Otherwise the transaction is treated as idempotent. Responses inherit the priority and alt_path attributes of the Request packet.

Authenticated SPDUs (Auth bit set to '1') identify requests that are to be authenticated by the recipient. In all other respects, they are identical to the SPDUs that are not authenticated.

Authentication. The authentication server is a single server contained in Layer 4 and available to the transport and session layer protocols. It provides a one-way authentication service. It is the client's responsibility to initiate authenticated transactions when required. Setting the Auth bit in the SPDU or TPDU does this. When a TPDU or SPDU is received with the Auth bit set, the server shall challenge using the "challenge" AuthPDU. The FMT field in the authentication PDU shall be set to the same value as in the address format field of the NPDU header in the message being challenged. The client then computes a transformation based upon the server's challenge, the original APDU sent by the client, and the client's authentication key. The result of this transformation is sent to the server using the "reply" AuthPDU. The FMT field in the reply shall be set to the same value as the FMT field in the corresponding challenge AuthPDU. When the server receives the reply, its contents are compared to the transformation computed by the server. If they match, the transaction is authenticated. In all cases the SPDU/TPDU is passed to the application layer for processing along with notification as to whether the authentication failed or succeeded. Note that if the application layer on the server node has no requirement for authentication of the particular transaction, it may choose to honour the request even if the authentication failed. If the application layer chooses not to honour the request, it simply discards the APDU without further processing.

11.6 Protocol timing diagrams

The protocol timing diagrams in Figure 25 and Figure 26 are intended to provide an intuitive feeling for the session layer protocols and to augment (but not to replace) the protocol specification in 11.7 to 11.13. Note again that for needed acknowledgements from group member numbers < 16, the REM/MSG SPDU is used and is functionally equivalent to the (REMINDER, REQUEST) pair.




Figure 25 — Non-Idempotent request with multiple SPDU losses

IECNORM.COM : Click to view the full PDF of ISO/IEC 14908-1:2012




Figure 26 — Secure idempotent request with multiple SPDU losses

11.7 Request-response state variables

Like the Transport protocol, the Request-Response protocol maintains one Transmit record per transaction in progress, and a shared pool of Receive records facilitates message reception. As shown in A.9, these records differ in minor details from those used by the Transport protocol.

11.8 Request-response protocol — client part

A simplified FSM for the client part of the Request-Response protocol is shown in Figure 27. The detailed specification is in A.9.




Figure 27 — Request-response protocol—client FSM

11.9 Request-response protocol — server part

A simplified FSM for the server part of the Request-Response protocol is shown in Figure 28, with the full description in A.9. The protocol treats all transactions with response size > 1 byte as idempotent, implying that it may execute them more than once. Transactions with response size of only 1 byte are never executed more than once.




Figure 28 — Request-response protocol—simplified server FSM

11.10 Request-response protocol timers

The two timers - Xmit_Timer and Rcv_timer - used by the Request-Response protocol follow the function and the form of Transport timers. The recommended values are identical to those for the transport layer as defined in 10.9.3, with the exception that if the request takes a significant amount of processing time on the server (relative to the transaction time), that time should be included in the calculations.

11.11 Authentication protocol

The Authentication server is implemented in the transport layer. It is accessible by the session layer as well as the transport layer. It is discussed in this subclause to include explanations of the additional interactions needed for the session layer. It relies on the duplicate detection mechanism in the transaction control sublayer, and no other transport layer services. Authentication allows a server to verify the identity of the requester. Use of this service is generally controlled by network management commands that specify the messages/network variable exchanges to be authenticated. Only transactions using acknowledged or request/response services may be authenticated. Messages received on the flex domain are not authenticated. The network management authentication bit is honoured only when the node is in the configured or hard offline states. A checksum error over the node's network configuration memory shall cause the node to go to the unconfigured state.

The Authentication protocol has two asymmetric parts: the challenger and the challengee. The authentication process is initiated by the challenger by generating a random number X ; next, the challengee responds with $Y = E(X, \text{msg})$, an encryption of X and the original message using a private key; and finally the challenger compares Y with its own version of $E(X, \text{msg})$, and makes a pass/fail decision based on the outcome of the comparison. The Authentication algorithm described in A.9 defines both the challenger and the challengee functions. All the server calls are synchronous.

11.12 Encryption algorithm

The encryption algorithm, described in detail in A.9 facilitates one way encoding rather than real encryption. It uses a 48-bit encryption key, K , a variable length APDU, $A[\text{len}]$, and a 64-bit input string, R , to produce a 64-bit output string, Y . Desirable properties of the random number R are defined in 11.14. Any 48-bit number is a valid encryption key.

11.13 Retries and the role of the checksum function

The checksum function, defined in A.12, is used for validating APDUs in client retries. The client shall retry if any of the original message, the challenge, the reply, or the acknowledgement/response is lost. Upon receiving a retry, the action taken by the server is a function of the transaction state as follows:

| | |
|-------------------|--|
| waiting | server is waiting for the authentication record. In this case, server shall attempt to allocate the record again. |
| authenticating | server has issued a challenge and is waiting for a reply. In case, the server simply reissues the same challenge (with same random number). |
| authenticated | authentication exchange has completed, with successful verification. If the original message was acknowledged, then the acknowledgement is reissued and the retry is discarded. If the original message was a request of an unknown type, then it is assumed that the application is still composing the response, so the retry is discarded. If the original message was a non-idempotent request, the response is reissued and the retry is discarded. If the original message was an idempotent request, then the retry APDU shall either be saved, or a checksum shall be computed over it as an alternative to save memory. The result is compared with that saved from the original message (actual message contents or checksum). If they do not match, the retry is marked as not authenticated. In any case, the retry is delivered to the application. |
| not authenticated | authentication exchange has completed without successful verification. The action taken is identical to that for the "authenticated" state, except no encryption/comparison is done for idempotent requests. |

Note that messages received on the flexible domain are not authenticated.

11.14 Random Number Generation

The random number generator used by the authentication protocol should have the following properties:

- i) R, the number generated is mathematically random and unpredictable;
- ii) generator does not generate predictable values after events such as power failure or rebooting.

11.15 Using Authentication

The authentication scheme must be correctly used to provide maximum security. One problem that the user should be aware is the transportation of authentication keys in the open using a network management command. This problem can be overcome by using the increment authentication key network management command (see 13.7.6 and A.11) rather than the network management command that provides an absolute value for the key (see 13.7.4 and A.30).

12 Presentation/application layer

12.1 Assumptions

The application layer makes no assumptions apart from relying on the transaction control sublayer for correct TPDU/SPDU sequencing and duplicate detection. The provided functions of the presentation layer are specified as a part of the APDU header. In particular, when the APDU header indicates that the APDU is a network variable update, the header has presentation information encoded within it because it tells the node how to interpret the APDU data.

12.2 Service provided

The presentation/application layer provides six services:

- Network Variable Propagation. This service sends messages that are interpreted by the receiver(s) as network variable updates. A special two-byte header is used to convey the presentation layer information that the APDU is to be interpreted as a network variable. Network variables are propagated using any of the protocol services. Request/Response is used when network variables are polled.
- Network Variable Aliasing. This service allows multiple network variable inputs or outputs to be aliased to a primary network variable. Then when the application updates a primary network variable output, additional packets are also sent for the network variable aliases corresponding to the primary. When a primary input or an aliased input is updated from the network, the application receives an event that the primary variable has changed its value.
- Generic Message Passing. An application may construct an arbitrary message, addressed using any of the addressing modes;
- Network Management Messages. These messages are described in detail in 13.7;
- Network Diagnostic Messages. These messages are typically initiated by a network management tool to test that nodes are fully operational, and to take corrective action around problem areas. These messages are described in detail in 13.8;
- Foreign Frame Transmission. These messages originate external to an environment of this standard, and are destined for nodes also external to the environment. This function is provided as a means to use this protocol as a gateway between two such external nodes, or to tunnel other protocols through this protocol.

12.3 Service interface

The service interface to the application program has the form shown in Figure 29.




Figure 29 — Application layer interface

The service primitives at the application layer interface are described in Table 1 below. Most of them require no parameters. Instead, they operate on the data structures `msg_out`, `msg_in`, `resp_out` and `resp_in`, described in A.12.

Table 1 — Application layer primitives

| Service interface primitive | Description |
|------------------------------------|--|
| <code>msg_alloc()</code> | This Boolean primitive allocates a non-priority buffer for an outgoing message. It returns TRUE if a <code>msg_out</code> data structure has been allocated. It returns FALSE if a <code>msg_out</code> data structure cannot be allocated. If it returns FALSE, the application program can continue with other processing if necessary rather than waiting for a free message buffer. |
| <code>msg_alloc_priority()</code> | This Boolean primitive allocates a priority buffer for an outgoing message. It returns TRUE if a priority <code>msg_out</code> data structure has been allocated. It returns FALSE if a priority <code>msg_out</code> data structure cannot be allocated. If it returns FALSE, the application program can continue with other processing if necessary rather than waiting for a free priority message buffer. |
| <code>msg_send(msg_out)</code> | This primitive sends a message in the <code>msg_out</code> data structure. |
| <code>msg_cancel()</code> | This primitive cancels the message currently being built. It frees the associated buffer, allowing another message to be constructed. |
| <code>msg_free()</code> | This primitive frees the <code>msg_in</code> data structure for an incoming message. |
| <code>resp_alloc()</code> | This Boolean primitive allocates a buffer for an outgoing response. It returns TRUE if a <code>resp_out</code> data structure has been allocated. It returns FALSE if a <code>resp_out</code> data structure cannot be allocated. |
| <code>resp_send(resp_out)</code> | This primitive sends a response in the <code>resp_out</code> data structure. |
| <code>resp_cancel()</code> | This primitive cancels the response currently being built. It frees the associated <code>resp_out</code> data structure, allowing another response to be constructed. |
| <code>resp_free()</code> | This primitive frees the <code>resp_in</code> data structure for an incoming response. |
| <code>msg_receive(msg_in)</code> | This primitive receives a message in the <code>msg_in</code> data structure. |
| <code>resp_receive(resp_in)</code> | This primitive receives a response in the <code>resp_in</code> data structure. |
| <code>msg_completes()</code> | This Boolean primitive evaluates to TRUE when an outgoing message completes (that is, either succeeds or fails). |

`msg_out` and `msg_in` can have any of the formats described in 12.4.

12.4 APDU types and formats

The APDU consists of a header followed by the application data. The header is a single byte, that is followed by a second byte only if the header specifies that network variable information is to follow. The data structure for the APDU is given below:

```
struct message
{
    byte destin_type;
    byte data[];
};
```

where data is an open ended array and destin_type is one of the following:

- 00xxxxxx generic application message (64 codes)
- 1dxxxxxx a network variable message; "d" indicates direction: 1 for outgoing, 0 for incoming. The remaining code bits are combined with the first data byte to form a 14 bit network variable selector.
- 011xxxxx a network management message (32 codes)
- 0101xxxx a diagnostic message (16 codes)
- 0100xxxx foreign frame (16 codes)

The rest of the APDU is defined with the first byte received as leftmost and the last byte received as rightmost. Any 2- or 4-byte quantities stored in the APDU are stored with the most significant byte on the left. The leftmost bit in a byte is the most significant bit. Arrays are stored with the lowest numbered element on the left. Structure fields are also stored left to right.

Every node compliant to this standard shall be able to receive, as a minimum, an APDU of 16 bytes of data, plus the destin_type.

The application protocol data unit (APDU) has the format shown in Figure 30:




Figure 30 — APDU format

For description of the network management message codes, see 13.7; for diagnostic message codes, see 13.8.

12.5 Protocol diagrams

Figure 31 shows a Non-Idempotent multicast transaction with a loss of both the initial APDU and the ACK TPDU.




Figure 31 — Application protocol diagram for multicast acknowledged transaction




Figure 32 — Application protocol diagram for multicast request/response transaction

Figure 32 shows an Idempotent Multicast Request/Response transaction with a loss of both the Request and Response

12.6 Application protocol state variables

The address format data structures are listed in A.14. The msg_out, msg_in, resp_out, and resp_in structures use these address formats to direct messages to their destinations.

12.7 Request - response messaging in offline state

When using the request/response mechanism either explicitly, or implicitly as with a network variable poll, it is possible to issue a request to a node where the application program is offline, and thus unable to respond. When this condition occurs, what happens depends on whether the response is to a network variable poll or to any other message. If the response is to an application message, the destin_type in the APDU shall be set to 63. When the response is to a foreign frame, the destin_type in the APDU shall be set to 79. When the response is to a network variable poll the response shall contain the network variable selector, but shall not have any associated data. This is also the response received if one attempts to poll a network variable on a node that has no matching selector, or if an authenticated poll fails.

12.8 Network variables

12.8.1 General

Network variables are logical inputs and outputs on a node. Multiple network variables may be defined on any node, thus network variable messaging permits the propagation of a specific data value from one node to one or more other nodes. Network variables are implemented as a special type of application message where the most significant bit of the APDU is set to 1. They have properties of direction (either input or output), properties of propagation (polled, synchronous), and properties of communication services (priority, acknowledged, unacknowledged, unacknowledged but repeated, authenticated). Network variables may be in connections. Input network variables are updated with a new value only when they receive that new value from an output network variable. Polled network variables are only propagated when the requestor sends a request/response message containing the network variable selector to the node.

A network variable is propagated at the discretion of the application. For example, the network variable might be propagated any time the variable is written to or, alternatively, any time it is changed. In any case, the application must ensure that the propagated data for a multi-byte network variable is consistent within itself. A non-polled output network variable may be 'synchronous.' In this case all values written by the application shall be propagated onto the network. Conversely, a non-synchronous network variable does not require that all values assigned to the network variable actually get propagated onto the network. How, an application propagates non-synchronous network variables is implementation dependent. Network variables are configured when they are connected for propagation using any of the lower layer protocol services such as priority, authentication, acknowledgements, etc.

A network variable connection is defined when a network variable on a sender node is configured to have selector value that matches the selector value of a network variable defined on one or more receiver nodes and that network variable is bound via an address table entry to the other node or nodes. A node may have an output network variable defined on it that is connected to one of its own input network variables. This connection is called a turnaround connection even if the output is also sent to another receiver node across the network.

Nodes do not send network variable messages when they are in the offline state. The only exception to this is when a network variable is polled on a node that is offline. In this case, the node responds to the network variable poll message with the proper selector value for the network variable, but no data for the value of the network variable.

Network variables may have aliases. An alias network variable inherits the length, direction and type of the network variable it is aliased to (the primary). Aliased network variables always have a different network variable selector value, and may have a different destination address than the primary network variable. This allows, in effect, multiple selector values to be associated with a single network variable. Multiple selector values are useful to allow network variable connections where the constraint of a single network variable selector would result in selector conflicts (the same selector value in use for multiple variables on a single node).

12.8.2 Network variable processing

Whenever an application program updates an output network variable, the application layer first checks to see if there are any readers of the variable on the network. Checking for the network variable having an associated address table entry does this. If there is such an entry, the application layer encodes a packet containing the network variable selector and the network variable value. This packet is then sent to the lower layers for processing. Next the application layer checks to see if the variable has aliases. If aliases exist, then packets are formed with the alias selector values along with the value of the primary network variable. Each of these packets is also sent to the lower layers for processing.

When a network variable update arrives at the receiving application layer, the selector value is compared against the selectors within the receiver node. If there is no match, the update is discarded.

If there is a match, a second check is performed against the matching selector to see if it corresponds to a primary network variable or an alias. If the selector corresponds to a primary network variable, then the application layer updates the primary value. If the selector is for a network variable alias, then the application layer updates the primary network variable's value.

12.9 Error notification to the application program

12.9.1 General

Regardless of whether the application program is using network variables or sending messages, it always has available to it the status of the last transaction.

12.9.2 Error notification for messages

Messages have three events associated with them: completion, success, or failure. Completion means that the transaction has completed (either successfully or not). For acknowledged transactions, success is defined as all acknowledgements having been received. For request/response transactions, success is defined as a response having been received from all of the intended recipients. In this case, it is up to the application to check the response code to see that the intended node was not offline. For unacknowledged transactions, the transaction succeeds when the transaction completes (when the message is sent). For unacknowledged-repeated transactions the transaction completes and succeeds when the message has been sent the requested number of times.

This International Standard does not define any failure events for unacknowledged transactions. However, specific implementations may post failure events for unacknowledged transactions due to internal errors that may occur during the transmission of a message. Acknowledged transactions provide failure notification to the application when the expected number of acknowledgements is not received. Request-response transactions fail when one or more of the responses are not received.

12.9.3 Error notification for network variables

For network variables, the completion event is posted when the transaction completes. This is identical to messages. Again, as with messages, unacknowledged updates can post failure events due to error conditions detected on the transmitting node. For acknowledged network variable updates, success is defined as all expected acknowledgements having been received. Failure is then defined as one or more expected acknowledgements not being received. Network variables always use the request-response mechanism when they are polled. Polled network variable updates succeed when the target nodes have returned all of the values. A failure event is posted to the application when either:

- i) all of the responding targets did not have valid data (no matching network variable or offline), or
- ii) one or more of the expected responses did not arrive. Note that for aliases, rule (ii) applies to the responses for the primary and aliases collectively.

There is a single exception to rule (i): a polled network variable that is connected to another network variable on the same node and is also in a connection with one or more network variables on other nodes will post a failure event to the application if all of the other nodes return offline responses to the poll. This is true even if the node with the turnaround connection responds successfully to its own poll.

13 Network management & diagnostics

13.1 Assumptions

Network Management and Network Diagnostic (NM/ND) services are application level procedures that use the session layer. This means that network management and diagnosis is only possible when the session layer (and all the underlying layers) are functioning properly.

With a few exceptions, all NM/ND commands either examine or modify contents of memory locations in one fashion or another. A portion of the various data elements that reside in non-volatile memory, such as address assignment, are supported with their own NM/ND commands for reporting and updating, allowing a more controlled execution of these operations within the protocol processor. Other areas can be read or written using special addressing modes of the read and write memory commands. Thus, users of move and change types of commands need not concern themselves with the physical layout of the non-volatile memory. Those needing to download applications must understand the physical layout of non-volatile memory (although even this information can be wholly contained within a download file).

13.2 Services provided

The Network Management and Diagnostics services provide the following capabilities:

- Address Assignment: the assignment of all address components (except the Unique_Node_ID);
- Node Query: the querying of node status and essential statistics;
- Router table maintenance.

With a few minor exceptions, network management operations are implemented as remote procedure using the underlying request-response service provided by the session layer. See 11.5.

13.3 Network management and diagnostics application structure

Network Management is a distributed application with multiple *clients* and multiple *servers*. Server functions must be supported on all nodes, whereas client functions need only be supported on nodes used as network management devices.

13.4 Node states

A node can be in one of four states. These states are maintained in non-volatile memory and have the values listed in parenthesis after the state name. These states are reported in the response to the Query Status network diagnostic command. The numbers in parentheses are enumerated values of node_state (see 13.8.2).

Applicationless: (3) no application yet loaded, application in process of being loaded, or application deemed bad due to application checksum error. No application runs in this state. The Node Status Indicator¹⁾ (a diagnostic aid optionally available in nodes based on this International Standard) is on continuously.

Unconfigured: (2) application loaded but network configuration memory is either not loaded, being reloaded, or deemed bad due to a network configuration memory checksum error. A specific implementation of this standard may allow a program to make the node go to the unconfigured state. The program determines if an application runs in this state. The Node Status Indicator flashes at a one-second rate. [An application-initiated transition to the unconfigured state shall clear the authentication keys.]

Hard-offline: (6) application loaded but not running. The network configuration memory is considered valid in this state; the network management authentication bit is honoured. The Node Status Indicator is off.

Configured: (4) normal node state. The application is running and the network configuration memory is considered valid. This is the only state in which messages for the application layer are received. In all other states, they are discarded. The Node Status Indicator is off. The configured state has an

1) (INFORMATIVE) The standard colour for the Node Status Indicator is yellow.

additional modifier that is the online/offline condition. This condition is not necessarily maintained in non-volatile memory. The states and online/offline condition are controlled via different mechanisms. However, they are reported together in the status command.

Note that there is a subtle distinction between being in the *configured* or *unconfigured* states and a node being referred to as either configured or unconfigured. A node in the *configured* or *unconfigured* state is as described above. However, a node is referred to as configured if it is in either the *hard-offline* state or the *configured* state (having valid network configuration memory contents in either case). A node is referred to as unconfigured if it is either in the *applicationless* or *unconfigured* states (no valid network configuration memory contents in either case). The network management authentication bit is honoured only when the node is in the *configured* state or the *hard-offline* state.

13.5 Using the network management services

13.5.1 General

Most Network Management PDUs (NMPDUs) are conveyed within session layer requests and/or responses. By default, an NMPDU inherits either the request or the response attribute of the enveloping SPDU. However, some requests, are conveyed within TPDU rather than SPDUs. Commands that use TPDU are so noted. Some commands, such as Query_ID() may be sent using broadcast addressing and request/response service. Such a command will succeed when at least one response is returned from the network.

When configured to do so, most NM/ND transactions must be authenticated in order to take effect. Authentication is not possible for messages that are addressed using Unique_Node_ID addressing where the server is not in the same domain as the one that the client used to initiate the request. Commands that do not require authentication to be executed are so noted.

If a node does not understand a particular network management request, it shall return a failed response. See 13.7 for encoding of network management responses.

13.5.2 Addressing considerations

The transmit transaction timer value of the client node must be extended to handle the lengthy delays involved with any command that alters non-volatile memory. When Unique_Node_ID addressing is used, the server node automatically extends the non-group receive transaction timer to about 8 seconds. This allows this timer to be tuned for normal application traffic without concern for lengthy network management transactions.

The recommended addressing mode for initially using these commands on a node is Unique_Node_ID. Once the node has been assigned an adequate non-group receive timer value (for duplicate detection) and a domain, subnet, and node field then subnet/node addressing is recommended.

Unique_Node_ID addressed messages are received regardless of the domain in which they are sent. Unconfigured nodes shall also accept any subnet or domain wide broadcast regardless of the domain. In both of these cases, acknowledgements and responses are returned on the domain in which the message was received with a source subnet/node pair of 0/0. Messages received in a domain in which the node is not a member (either because the node is unconfigured or not in the domain) are termed as being received on the Flexible domain. Some commands are not permitted under these circumstances and are noted in the descriptions of the network management commands starting at 13.7.2.

A significant advantage of using Unique_Node_ID addressing for network management commands is that if a node accidentally becomes unconfigured (e.g., due to a checksum error resulting from a power failure while changing the network configuration memory), the network management tool does not lose its ability to communicate with the node.

13.5.3 Making network configuration changes

The paradigm for making network configuration changes within a node is as follows:

- 1) Alter the node state or condition (optional);
- 2) Perform the change or changes;
- 3) Update the configuration checksum (only necessary if not done in step 2);
- 4) Return to step 2 if more needs to be done;
- 5) Restore the node state or condition if changed in step 1;
- 6) Reset the node if communication parameter changes were made and it is desired that they take effect.

13.5.4 Downloading an Application Program

The paradigm for downloading applications is as follows:

- 1) Take the node offline;
- 2) Alter the node state to *applicationless*;
- 3) Send messages to the node that load the application into the node's memory;
- 4) Reset the node;
- 5) Compute the application checksum.
- 6) Enter the unconfigured state.

At this point, the network configuration memory can be loaded. Note that when loading an application followed by loading of the network configuration memory, a node comes up in the offline condition.

13.5.5 Error handling conditions (informative)

There are several classes of errors to consider:

Transaction Failures: If a transaction fails (i.e., the desired acknowledgement or response is not received), it is best to attempt to get to a known state rather than simply retry the transaction. If network management authentication is turned on, returning to a known state should include attempting authenticated transactions using different keys (e.g., the current key, the previous key, etc.) until success is achieved.

Node Resets or Power Cycles: if a node resets while a network management command is in progress, the reset will likely manifest itself as either a communication problem or a transaction failure. When non-volatile memory writes are involved, depending on the implementing technology, the location being modified at the time of the reset may become corrupted.

A reset during a *memory refresh* command could result in the corruption of the network configuration memory or application program. Either could be catastrophic depending on the scope of knowledge in the network management tool. An option here is to put early power down detection on the network management tool and only issue refresh commands (with no retries) when the power appears stable (assuming the client and server share a common power source).

Read/Write Protect Violations: if a node is read/write protected, attempts to write to the application code area are denied. The client can verify that a write memory attempt failed for this reason by reading the `read_write_protect` field of the `read_only_data` structure.

Other adverse effects, such as address table and domain changes, need to be carefully handled and understood by the client. A request can produce a response in a new domain, for example.

Every network node maintains two checksums, one over the network configuration memory and one over the application memory. Following the completion of any of the network addressing commands that alter the network configuration memory, a new configuration checksum is calculated and updated. This adds time to the execution of these commands, and the client should take this into account before sending the next message to the target node. This delay should always take into account the non-volatile memory write time multiplied by the number of bytes altered. The delay per byte can be as long as 20 ms. Therefore an *update address* command should have a transmit transaction timeout of at least $(20 \bullet 5 + 30)$ ms, or 130 ms.

Commands that automatically update checksums are noted.

An implementation may choose to validate the parameters to a given network management command. Not all senders of network management commands actually send commands of the exact length. This makes validation based upon the length of the command more difficult. Senders of network management commands shall not exceed the lengths tabulated below.

The response to an invalid NM/ND command should be a failed response. Length validations are based on the chart below. Note that if there is more than one number listed for a given command, then a parameter set that is valid for a smaller size must also be accepted if padded to the larger size. Escape commands are issued by setting a parameter to the command to 0xFF. The escape commands and rules are noted in this clause and in the data structures in Annex A.

IECNORM.COM : Click to view the full PDF of ISO/IEC 14908-1:2012

| Command | Code(hex) | Data Size | |
|------------------------|-----------|-----------|--|
| Query Status | 51 | 0 | |
| Proxy Agent | 52 | 12 | (Unique Node ID addressing) |
| Proxy Agent | 52 | 6 | (All other address formats) |
| Proxy Target | 52 | 1 | |
| Clear Status | 53 | 0 | |
| Report Transceiver Sts | 54 | 0 | |
| Query ID | 61 | 1 | |
| Query ID (conditional) | 61 | 5+n | (n=number of conditional bytes) |
| Respond To Query | 62 | 1 | |
| Join Domain | 63 | 16 | |
| Leave Domain | 64 | 1 | |
| Security | 65 | 7 | |
| Modify Address | 66 | 5 | (turnaround only) |
| | | 6 | (non-turnaround only) |
| Report Address | 67 | 1 | |
| Report NV | 68 | 1 | (non-escaped only) |
| | | 3 | (escaped only) |
| Update Address | 69 | 5 | |
| Query Domain | 6a | 1 | |
| Modify NV | 6b | 4 | (regular update) |
| | | 5 | (alias update) |
| | | 5 | (null alias update, primary==0xff) |
| | | 6 | (escaped regular) |
| | | 7 | (escaped alias) |
| | | 9 | (double escaped alias) |
| Node Mode | 6c | 1 | (not for state change) |
| | | 2 | (for state change) |
| Read Memory | 6d | 4 | |
| Write Memory | 6e | 5+n, 16 | (n=number of bytes to write) |
| Checksum Recalculate | 6f | 1 | |
| Install | 70 | 0 | (basic application wink) |
| Install | 70 | 1 | (For multiple protocol stacks/node) |
| Install | 70 | 9 | (definition of network variables) |
| Install | 70 | 5 | (removal of network variables(nv)) |
| Install | 70 | 7 | (query nv self documentation(sd) text) |
| Install | 70 | 4 | (all other query nv commands) |
| Install | 70 | 5 | (query node information) |
| Install | 70 | 20 | (update nv name) |

| Command | Code(hex) | Data Size | |
|----------------|-----------|-----------|---|
| Install | 70 | 7+N | (update nv self documentation text) |
| Install | 70 | 7 | (update network variable rate estimate) |
| Install | 70 | 5 | (update network variable SNVT index) |
| Install | 70 | 5 | (NM_GET_CAPABILITY_INFO) |
| Install | 70 | 4+N | (NM_SET_NV where N is the NV size) |
| Install | 70 | 4 | (NM_NODE::NM_INITIALIZE) |
| Install | 70 | 7 | (NM_DOMAIN::NM_INITIALIZE) |
| Install | 70 | 20 | (NM_DOMAIN::CREATE / UPDATE) |
| Install | 70 | 5 | (NM_DOMAIN::NM_ENUMERATE request) |
| Install | 70 | 18 | (NM_DOMAIN::NM_ENUMERATE resp) |
| Install | 70 | 12 | (NM_DOMAIN::NM_SET_AUTH) |
| Install | 70 | 7 | (NM_ADDRESS::NM_INITIALIZE) |
| Install | 70 | 12 | (NM_ADDRESS::CREATE/ NM_UPDATE) |
| Install | 70 | 5 | (NM_ADDRESS::NM_ENUMERATE) |
| Install | 70 | 10 | (NM_ADDRESS::NM_ENUMERATE resp) |
| Install | 70 | 7 | (NM_NV_CONFIG::NM_INITIALIZE) |
| Install | 70 | 7 | (NM_NV_CONFIG::CREATE/ UPDATE) |
| Install | 70 | 5 | (NM_NV_CONFIG::NM_ENUMERATE) |
| Install | 70 | 10 | (NM_ENUMERATE resp) |
| Install | 70 | 7 | (NM_ALIAS_CONFIG::NM_INITIALIZE) |
| Install | 70 | 14 | (NM_ALIAS_CONFIG::CREATE/UPDATE) |
| Install | 70 | 5 | (NM_ALIAS_CONFIG::NM_ENUMERATE) |
| Install | 70 | 12 | (NM_ALIAS_CONFIG::NM_ENUMERATE resp) |
| Memory Refresh | 71 | 4 | |
| Query SI Data | 72 | 3 | |
| NV Fetch | 73 | 1 | (non-escaped only) |
| | | 3 | (escaped only) |

13.6 Using router network management commands

The router shall follow the normal protocol processor “states” and must be in the Application/Configured state in order to operate fully as a router.

All of the commands that affect the routing tables affect only a single router half. The NM Node Mode command for OFFLINE, ONLINE, and RESTART shall automatically affect BOTH router halves.

For a router, ONLINE means that the router shall operate normally as described. OFFLINE means that the router performs no forwarding; all packets not addressed to the router that appear in the packet buffer circular lists are dropped. Other than the dropping of these packets, an OFFLINE router continues to perform normally.

A router shall ignore a certain group of Network Management commands. These commands are the broadcast Node Mode commands. This group of commands are ignored to prevent a broadcast

RESTART or OFFLINE command from stopping the router and preventing the same broadcast command from reaching destinations on the other side of the router. Routers therefore must be RESTARTed or taken OFFLINE individually when desired. To support this, it must be possible to initiate a unique *Manual Service Request* for the router.

13.7 NMPDU formats and types

13.7.1 General

This subclause lists Network Management APDU (NMPDUs), using a notation similar to C structure definitions. The bit and byte ordering rules defined in Annex D apply, with the most significant bit of each byte being transmitted first; the first byte of a record is considered the least significant byte of that record. In the value section of the descriptions, the value corresponds to a command number or a response code for that message.

The first byte of all NMPDUs contains the Destination/Type data that, for NM requests and commands, is always (binary):

011xxxx

The <xxxx> field contains the command code.

Responses that have been generated by the execution of these NM commands are directed to the Application, as specified by the first byte of the APDU:

00pxxxx

The <p> field is set to one if the operation succeeded, or zero if it failed. Failures are usually due to range errors (table boundaries) or non-volatile memory write failures. The <xxxx> field echoes the original NM command code.

The first byte of all ND message APDUs contains the Destination/Type data of:

0101xxxx

The <xxxx> field contains the command code.

ND responses have the following format, where <p> is the same as in NM responses and <xxxx> mirrors the original command:

00p1xxxx

The implications of this are that all NM/ND requests are delivered to the NM/ND layer, while all NM/ND responses are delivered to the application layer. It is assumed that the responses are to be processed at the application layer.

In this International Standard, only the command field value is described. The <p> field and the destination code are not included but are assumed to be in place.

Single byte responses are provided for NM operations that are considered non-idempotent.

NOTE 13.7 uses "byte" for 8-bit items and "uint16" for 16-bit items.

13.7.2 Query ID

Query_ID() requests a node, or a set of nodes, to report its Unique_Node_ID to the requester. Typically this request is addressed on a single domain as a subnet-wide broadcast, implying that the

client has knowledge of at least the domain and may be taking orderly probes at subnet addresses in order to interrogate a set of nodes. The data structures used are described in A.15.

To query unconfigured nodes, the selector value within the Query_ID_Request record is set to '0'. In order to query nodes whose "respond to query" bit is set (see following command), the selector value is '1'. To query nodes that are unconfigured and whose "respond to query" bit is set, the selector value is "2". Either the subnet or domain wide broadcast addressing mode is typically used. This command never requires authentication to be executed.

If supplied, the address and data fields are used as additional qualifiers. The address mode and address field are used to form an address (see "read memory" for a description of this process); "count" bytes (1–11) of data starting at that address are then compared with the supplied data. Only if they match does the Query ID proceed (as specified by the "selector").

For this command only, read protect is assumed to be always on. If the address and count fall in a read protected area (such as where the authentication keys are stored), no response is returned.

13.7.3 Respond to query

This command sets or clears the "respond to query" bit in the target node(s). When set, the target shall respond to Query_ID() requests that have a selector of '1'. It shall continue in this mode until the node is reset or its bit is cleared via command. This command is used for network topology interrogation. The "on" version is usually addressed as subnet broadcast, using the unacknowledged-repeated service. The "off" version is addressed to a specific node once it has been interrogated. This command never requires authentication to be executed. The data structures are defined in A.16.

13.7.4 Update domain

This command updates one of the domain entries in the server, using the data structures in A.17. Note that the most significant bit of the node field must be set. Execution of this command updates the network configuration memory checksum. If a node can only be in a single domain, attempts to assign domain index '1' shall return an error. If the domain to be updated is the same as the domain in which the modify message was sent, and the node is in the "configured" state, then the response shall come back on the new domain and thus shall not be received by the sender. This command may also be used to leave a domain by setting the domain length to 0xFF, setting the subnet and node addresses to zero, and invalidating the authentication key. Note that the side effects of resetting the node and going to the unconfigured state that automatically occur when using the Leave Domain command will not occur when the domain is left using this command.

Since the encryption key is propagated in the clear, this request should only be used when physical network security can be guaranteed (or security is achieved through other means).

13.7.5 Leave domain

The node must honour this command even if it still has addresses assigned within this domain. Internally, the node's domain length is set to 0xFF, and the subnet and node addresses are set to zero. Also, the authentication key is cleared. The network configuration memory checksum is updated during the execution of this command. If the domain to be left is the domain on which the request was received and the node is *configured*, no response is sent. If the domain being left is the last domain in which the node is configured, the node automatically enters the unconfigured state and resets. The data structures used are shown in A.18.

13.7.6 Update key

This command is used for updating encryption keys, using the data structures in A.19. The domain to be used is specified in the message. The encrypt_key bytes are added to the existing key in a bitwise fashion (no carry). The network configuration memory checksum is updated by this command.

13.7.7 Update address

This command is executed by index. If the address table entry does not exist, the <p> bit in the response shall be zero. The network configuration memory checksum is updated by this command. No cross-checking for duplicate addresses or groups is performed.

The form of each address entry in the address table is described in A.20

13.7.8 Query address

This command reports an entry within the node's address table, given an index. The data structures used are in A.21.

13.7.9 Query network variable configuration

This command reports the entry in the node's nv_config table, by index number; the entry must exist in the table. The data structures used are in A.22.

This command can also be used to query the node's alias table. The same data structures are used for alias queries as for network variable queries (see A.22). When used for aliases, the index in the command data structure is the alias entry index and the primary index is the index of the primary network variable corresponding to the indexed alias.

13.7.10 Update group address

This command is used to update a group entry in an address table; it is typically addressed by group. The group size, timer indices, and retry count are updated. The group member field is left unchanged. The entry is updated based on the domain in which the command was received because group addresses are only unique within a specific domain. Therefore, this command is disallowed for the flexible domain. This command updates the network configuration memory checksum. The data structures used are in Annex A.23.

This operation shall update only the first matched instance of the group address.

13.7.11 Query domain

This command is used to retrieve the domain information for one of the two domains in a node. If the second domain is requested and room for only one domain exists, the response contains the command failure indication. The data structures used are in A.24.

13.7.12 Update network variable configuration

This command is used to add or modify entries to or from the node's nv_cnfg table, by an index number. There must be free space in the nv_cnfg table for the entry. The address table index may be set to 0 to 15, where 15 indicates that no address table entry is associated with the network variable. The network configuration memory checksum is updated by this command. For a network variable with index X, a network variable selector with the value 0x3FFF-X implies that the network variable is not in a logical connection (i.e., is not bound). The data structures used are in A.25.

This command can also be used to update the node's alias table. The same data structures are used for alias configuration table updates as for network variable configuration table updates (see A.25). When used to update the alias configuration table, the index in the command data structure is the index of the alias entry index and primary index is the index of the primary network variable corresponding to the indexed alias.

13.7.13 Set node mode

This request instructs the application to enter either the offline or online condition, to reset the entire node via an internal reset, or to change the state of a node. When offline, the application program is halted and NM/ND commands continue to be processed. The online request instructs the application scheduler to leave the offline condition and resume operation of the application. One use of the offline condition is for suspending the application during application non-volatile memory downloading.

The service type used for this command varies. For online and offline, no response is ever returned so request-response cannot be used. The receiver will honour a request using the request-response service, however, the state transitions for online and offline prevent the response from being sent. Confirmation of the change in condition is achieved via issuance of a *status request*. For state changes, request-response should be used. Since the state is part of the application, the application checksum is updated. For reset, only the unack'd (or ack'd if authentication is required) service type is used. This message is confirmed with a sequence of network management commands. First the node's status is cleared. Then the node is issued a reset. Finally, the status request command is issued to the node. Note that failure to confirm the reset may indicate that the initial unack'd message was lost, necessitating a retry of the exchange. The data structures used are in Annex A.26.

13.7.14 Read memory

This command is used to read memory. If read/write protect is on, only the read_only_data, config_data, and RAM or non-volatile memory data areas can be read.

The "count" field contains the number of bytes to be read. This number should not exceed 16 unless the target node has buffers sufficiently large to accommodate the additional data. Addresses to read may be specified relative to the read-only structure (see B.1), relative to the configuration structure (B.6), relative to the statistics structure (B.7), or may be absolute addresses. The absolute addressed memory space that can be read is up to 65 535 bytes in length starting from an implementation specific physical offset. A read of absolute memory location 0 with a count of 1 byte returns the original system image version number. This can be used to determine system capabilities when the firmware version number indicates a custom version. The custom version is assumed to be derived from the original system image and thus inherits its capabilities. The data structures used are in A.27.

13.7.15 Write memory

There are two forms of this command: one form resets the protocol processor after writing, the other does not. Confirmation of the reset form must be performed by reading back memory using *read memory*. The non-reset form produces a response and is conveyed via request-response. The reset form is conveyed using unacknowledged or unacknowledged-repeated service. The network configuration memory checksum and/or application checksum are optionally updated. A node compliant to this International Standard is not required to support write memory commands that span memory technologies. For example, a single write command that writes both flash EPROM memory and EEPROM memory need not be supported.

If read/write protect is on, only the config_data_struct (see Annex B) can be written. The byte count should be limited to 11 bytes unless the target node has buffers that are sufficiently large to handle more. Addresses to write may be specified relative to the configuration structure (see B.6), relative to the statistics structure (see B.7), or may be absolute addresses. Just like in the Read Memory command, absolute addresses can be written in a space up to 65 535 bytes in length starting from an application specific physical offset. The data structures used are in A.28.

13.7.16 Checksum recalculate

This command forces the protocol processor to compute and store a new network configuration memory or application checksum. It should be used at the end of any Network Management sessions that alter the network configuration non-volatile memory image or application non-volatile memory/RAM image (unless those commands have specifically performed this operation already, as with the address commands). All nodes shall checksum their network configuration non-volatile

memory. A checksum of the application image is optional. Nodes that do not compute application checksums always report success when commanded to recalculate their application checksums via this command. The data structures used are in A.29.

13.7.17 Install

This command is used during installation for a variety of purposes. The primary purpose is to force the execution of an application specific wink function. For example, the wink function may blink a light attached to the node for positive node identification. The wink function, if implemented, shall execute even if the node is in an unconfigured state.

A second purpose of this command is to allow multiple protocol processors to exist with a single application. Each protocol processor would have its own unique node ID and associated domain and address tables. This second form of the command allows individual queries to the protocol processors for installation purposes. The scenario of use is that the application is installed by issuing a manual service request to get the unique node ID. Then this command is used to query the application about how many protocol processors are attached to it. With each request, the application responds with the information contained in the manual service response message for the next protocol processor along with a network interface number. Once all the network interfaces have been identified, commands to get the next network interface fail. This command is seldom used, and will likely not be used in the future due to the wide range of protocol processor capabilities enabled by this Standard.

A third purpose of this command is to support the dynamic (run-time/install time versus compile time) creation and deletion of network variables. Support of this feature is optional due to its resource constraints. These commands, that are an extension of the Install command, provide methods to query Self Identification/Self Documentation (SI/SD) data, update SI/SD data, inform the node of a new Network Variable addition, or the removal of an existing Network Variable.

A fourth purpose of this command is to extend the limitations on domain membership and group membership by increasing the upper limit on domain membership to as many as 65 535 (implementations may support less), and increase address table entries to an upper limit of 65 535 (again, an implementation may support less). Support of this feature is optional due to its resource constraints.

The general format of the install commands for the first three purposes is:

<Application Command> <Application Specific Data Fields>

To extend the limitations on domain and group membership, the command structure above is generalised. In this new structure, a node is viewed as having resources (such as network variable configuration table entries) that are managed with commands. Some commands act upon the entire class of resource, while others act upon a specific instance of the resource where that instance is selected by an index parameter (such as an address table index). Resources may have properties that can be set or read. The general format of the install commands for this family of commands, the *extended network management commands*, is:

<Application Command> <Resource> <Resource/Command Specific Data>

The resource field appears with commands 0x20 or greater. Commands 0 to 6 are legacy commands and do not use the extended format. Commands 7 to 0x1F are for non-resource specific commands, and do not have the resource field.

For commands that operate on an instance of a resource, a resource index is also required. For commands that operate on a property of the resource, either a special command or an explicit property field is required.

Resource

A resource is an object, such as an address table entry, that can be configured or queried. A resource may be dynamic or static (both exemplified by network variables), and may have properties that can be acted upon. A resource is specified by an 8-bit resource class id, and a resource index that refers to a specific instance of a resource. The base and size of the index depends on the resource, but is typically zero-based and one or two bytes. When a command acts on the entire resource class, the resource index may be absent. If a command can act on either a resource instance or all instances, then by convention an all 1's index indicates all instances.

The resource class id is partitioned into 125 system resources, 125 device-specific (or application-specific) resources, and 4 values reserved for future expansion. No device-specific resources are currently defined. The following table defines the range and currently defined resource codes:

Table 2 — Resource codes

| Resource Class ID | Mnemonic | Description |
|-----------------------------------|-----------------|---|
| System Resources (MSB=0) | | |
| 0x00 | | (reserved for future use) |
| 0x01 | NM_NODE | Node |
| 0x02 | NM_DOMAIN | Domain Entry |
| 0x03 | NM_ADDRESS | Address Table Entry |
| 0x04 | NM_NV_DEF | Network Variables definition (static and dynamic) |
| 0x05 | NM_NV_CONFIG | Network Variables Configuration |
| 0x06 | NM_ALIAS_CONFIG | Alias Configuration |
| 0x07 – 0x7E | | (undefined) |
| 0x7F | | (reserved for future use) |
| Device-Specific Resources (MSB=1) | | |
| 0x80 | | (reserved for future use) |
| 0x81-0xFE | | (undefined) |
| 0xFF | | (reserved for future use) |

Property

A resource generally has properties that may be get or set. The format for specifying a property is to use the commands NM_SET and NM_GET, and define a 1-byte property ID field following the resource. The scope of the property depends on the resource. The space of the property ID is partitioned as follows:

Table 3 — Space of the property ID

| | |
|--------------|------------------------------|
| 0x00 | (reserved for future use) |
| 0x01 to 0x7E | Common Properties |
| 0x7F | (reserved for future use) |
| 0x80 | (reserved for future use) |
| 0x81 to 0xFE | Resource-Specific Properties |
| 0xFF | (reserved for future use) |

If a resource has a collection of properties of the same type (multiple instances), then an additional property index shall be defined in the request data structure following the resource index.

All of the resources defined use special command(s) for each property, and the properties are single-instance.

For both versions of the commands, the first byte of the response to the command must be either 0x30 to indicate the command was successful, or 0x10 to indicate the command failed. Additional bytes of the response, if any, depend on the application command type. For application commands with a command code greater than 0x6, failures are reported by having the first byte of the response set to 0x10, followed by a one byte cause value:

```
typedef struct {
    unsigned cause;
} NM_wink_negative_response;
```

The complete list of application commands for the install message are:

| | |
|----------------------------|---|
| APP_WINK (0) | Command the application to perform some visible or audible action. |
| APP_INSTALL (1) | Find all the network interfaces for an application. |
| APP_NV_DEFINE (2) | Create a new dynamic NV definition. |
| APP_NV_REMOVE (3) | Remove an existing dynamic NV definition. |
| APP_QUERY_NV_INFO (4) | Query SI/SD data for an NV. |
| APP_QUERY_NODE_INFO (5) | Query SI/SD data for the node. |
| APP_UPDATE_NV_INFO (6) | Update SI/SD data for an NV. |
| NM_GET_CAPABILITY_INFO (7) | Query the node capabilities (address table size, etc.). |
| NM_SET_NV (8) | Write a network variable selected by the index. |
| NM_INITIALIZE (0x20) | Remove a dynamic resource or reset a static resource. |
| NM_CREATE (0x21) | Create a dynamic resource at a specified index. |
| NM_REMOVE (0x22) | Remove a resource. |
| NM_SET (0x23) | Set the indicated property. |
| NM_GET (0x24) | Get the indicated property. |
| NM_UPDATE (0x25) | Modify a resource definition or configuration. |
| NM_ENUMERATE (0x26) | Return the specified or next instance. |
| NM_SET_AUTH (0x81) | Update the authentication key and network management authentication for specified or all domains. |

Following are the definitions of the application specific data fields by command type.

APP_NV_DEFINE

This command adds a new or modifies an existing NV definition. If an attempt is made to add or modify the definition of an NV that is part of the node's fixed NV interface, or the index exceeds the maximum supported by the node, the node will report command failed.

After a successful define, the application is responsible for setting the network variable configuration to default values (unbound selector, correct direction, etc) such that a subsequent NV config query command shows the correct default attributes for the newly defined NV.

The message data structure contains the following fields:

| | | |
|-------------------|------------|--|
| APP_NV_DEFINE (2) | | As defined above. |
| unsigned | nvIndexHi | The high order byte of the NV index. |
| unsigned | nvIndexLo | The low order byte of the NV index. |
| unsigned | arrayLenHi | The high order byte of the number of elements in the NV array. The value is 0 if the NV is not an array. |
| unsigned | arrayLenLo | The low order byte of the number of elements in the NV array. The value is 0 if the NV is not an array. |
| unsigned | nvLen | The number of bytes in the NV value (1 to 31). |
| unsigned | nv_dflts | Default configurable attributes of the NV. Encoded as a single byte. Includes direction, priority, authentication, and service type. |
| unsigned | nv_attr | Attributes of the NV. Encoded as a single byte. (See definition below.) |

APP_NV_REMOVE

This command removes one or more existing NV definitions. The NV index must be within the area of the interface that is specified to be dynamic. If the NV index specified is within the node's fixed interface, the command will fail. The command will succeed even if the specified set of NVs is not currently defined or exceeds the maximum number of NVs supported by the node. After a successful remove, the application is responsible for setting the network variable configuration to default values (unbound selector, correct direction, etc) such that a subsequent NV config query command shows the correct default attributes for an undefined NV.

The command contains the following fields:

| | | |
|------------------|-----------|---|
| APP_NV_REMOVE(3) | | As defined above. |
| unsigned | nvIndexHi | The high order byte of the NV index of the first NV definition to be removed. |
| unsigned | nvIndexLo | The low order byte of the NV index of the first NV definition to be removed. |
| unsigned | nvCountHi | The high order byte of the number of NVs to remove. |
| unsigned | nvCountLo | The low order byte of the number of NVs to remove. |

APP_QUERY_NV_INFO

This command queries self-documentation data about a specific NV. It contains the following fields:

APP_QUERY_NV_INFO (4)

| | | |
|----------|------------------------|---|
| unsigned | nv_info | The self-documentation data being requested. Current values are: |
| | NV_INFO_DESC (0) | Basic attributes of the NV, array information, how the NV was defined, and indication of available additional self-documentation. |
| | NV_INFO_RATE_EST (1) | Average and maximum rate estimates defined for the NV. |
| | NV_INFO_NAME (2) | The name of the network variable. |
| | NV_INFO_SD_TEXT (3) | The self-documentation text string associated with the NV. |
| | NV_INFO_SNVT_INDEX (4) | The index of the SNVT. |
| unsigned | nvIndexHi | The high order byte of the NV index. |
| unsigned | nvIndexLo | The low order byte of the NV index. |
| unsigned | offset_hi | If nv_info is NV_INFO_SD_TEXT, the high order byte of the offset of the requested data. |
| unsigned | offset_lo | If nv_info is NV_INFO_SD_TEXT, the low order byte of the offset of the requested data. |
| unsigned | length | If nv_info is NV_INFO_SD_TEXT, the number of bytes requested. The response data structure depends upon the data requested. |

If the data requested is NV_INFO_DESC, the following response is sent:

| | | |
|----------|------------------|--|
| unsigned | length :5 | The length of the NV value, in bytes. Encoded as 0 if the NV is currently undefined. |
| unsigned | origin :3 | How the NV was created. One of the following values: |
| | NV_UNDEFINED (0) | The NV is not currently defined. |
| | NV_STATIC (1) | The NV was statically defined (cannot be removed). |
| | NV_DYNAMIC (2) | The NV was dynamically defined (can be removed). |
| unsigned | nv_dflts | Default configurable attributes of the NV. Encoded as a single byte. Includes direction, priority, authentication, and service type. |
| unsigned | nv_attr | Basic attributes of the NV. |
| unsigned | nv_exten | Extension bits. Indicators of additional SI/SD data that are available. |
| unsigned | nv_array | NV array attributes. |
| unsigned | nv_name[16] | Optional field. If included, the nm_supplied bit must also be set in the ext field. The name of the NV without array subscripts. |

If the requested data is NV_INFO_RATE_EST, the following response is sent:

| | | |
|----------|-------------|---|
| unsigned | nv_rate_est | The encoded average rate estimate for the NV. |
| unsigned | nv_rate_est | The encoded maximum rate estimate for the NV. |

If the requested data is NV_INFO_NAME, the following response is sent:

unsigned nv_name[16] The name of the NV. If NV is part of an array, the name does not include the array subscript. Zero-terminated if length is less than 16 characters.

If the requested data is NV_INFO_SD_TEXT, the following response is sent:

unsigned length The number of bytes of SD Text data returned.
unsigned text[*] The SD text data segment. The actual text array size is dependent upon the preceding length value.

If the requested data is NV_INFO_SNVT_INDEX, the following response is sent:

unsigned snvt_type_index The index of the Standard Network Variable Type associated with the NV. Encoded as zero if the NV is not a SNVT.

APP_QUERY_NODE_INFO

This command queries self-documentation data about the node. It contains the following fields:

APP_QUERY_NODE_INFO (5)

unsigned node_info The self-documentation data being requested. Values are:
 NODE_INFO_SD_TEXT (3) The self-documentation text string associated with the node.
unsigned offset_hi If node_info is NODE_INFO_SD_TEXT, the high order byte of the offset of the requested data.
unsigned offset_lo If node_info is NODE_INFO_SD_TEXT, the low order byte of the offset of the requested data.
unsigned length If node_info is NODE_INFO_SD_TEXT, the number of bytes requested.

The response data structure depends upon the data requested. If the requested data is NODE_INFO_SD_TEXT, the following response is sent:

| | | |
|----------|---------|--|
| unsigned | length | The number of bytes of SD Text data returned. |
| unsigned | text[*] | The SD text data segment. The actual text array size is dependent upon the preceding length value. |

APP_UPDATE_NV_INFO

This command updates self-documentation data about a specific NV. In general, update messages cannot be relied upon to be validated by the target application. The initiator must perform all validation. This message contains the following fields:

APP_UPDATE_NV_INFO (6)

| | | |
|----------|------------------------|--|
| unsigned | nv_info | The self-documentation data being updated. Current values are: |
| | NV_INFO_RATE_EST (1) | Average and maximum rate estimates defined for the NV. |
| | NV_INFO_NAME (2) | The name of the network variable. |
| | NV_INFO_SD_TEXT (3) | The self-documentation text string associated with the NV. |
| | NV_INFO_SNVT_INDEX (4) | The index of the SNVT. |
| unsigned | nvIndexHi | The high order byte of the NV index. |
| unsigned | nvIndexLo | The low order byte of the NV index. |

The remaining data fields are dependent upon the nv_info value specified. If the specified nv_info is NV_INFO_RATE_EST, the following data is provided:

| | | |
|----------|---------------|---|
| unsigned | clear_mre: 1 | If set, clear the NV's maximum rate estimate value, and indicate that this data is not available. |
| unsigned | clear_re: 1 | If set, clear the NV's rate estimate value, and indicate that this data is not available. |
| unsigned | update_mre: 1 | If set, update the NV's maximum rate estimate value. Also, indicate that the maximum rate estimate data is available. |
| unsigned | update_re: 1 | If set, update the NV's rate estimate value. Also, indicate that the rate estimate data is available. |
| unsigned | nv_rate_est | The encoded average rate estimate for the NV. |
| unsigned | nv_rate_est | The encoded maximum rate estimate for the NV. |

If the specified nv_info is NV_INFO_NAME, the following data is provided:

| | | |
|----------|-------------|--|
| unsigned | nv_name[16] | The null (zero) terminated name of the NV. The name does not include the array subscripts. |
|----------|-------------|--|

If the specified nv_info is NV_INFO_SD_TEXT, the following data is provided:

- unsigned length The number of bytes of SD Text data being updated.
- unsigned offset_hi The high order byte of the offset of the data to be updated.
- unsigned offset_lo The low order byte of the offset of the data to be updated.
- unsigned text[*] The SD text data segment. The actual text array size is dependent upon the preceding length value.

If the specified nv_info is NV_INFO_SNVT_INDEX, the following data is provided:

- unsigned snvt_type_index The index of the Standard Network Variable Type associated with the NV. Encoded as zero if the NV is not a SNVT.

The following data structures are referenced in the preceding message definitions:

- nv_attr This data structure describes the basic attributes of a specific network variable. It contains the following fields:
 - unsigned nv_sync: 1 If set, all values assigned to the NV are propagated, in their original order. Mutually exclusive with nv_polled.
 - unsigned nv_polled: 1 If set, the output NV's value is sent only in response to a poll. Updates are not generated when the application updates the NV value.
 - unsigned nv_offline: 1 If set, the node should be taken offline before updating the value of the network variable.
 - unsigned nv_service_type_config: 1 If set, the NV's service type attribute is configurable.
 - unsigned nv_priority_config: 1 If set, the NV's priority attribute is configurable.
 - unsigned nv_auth_config: 1 If set, the NV's authentication attribute is configurable.
 - unsigned nv_config_class: 1 If set, the NV is a configuration NV.
 - unsigned snvt_type_index The index of the Standard Network Variable Type associated with this NV. Zero if the NV is not a SNVT.
- nv_exten This data structure indicates what additional self-documenting data is available for a specific network variable. It contains the following fields:
 - unsigned mre: 1 If set, the NV's maximum rate estimate is available.
 - unsigned re: 1 If set, the NV's average rate estimate is available.
 - unsigned nm: 1 If set, the NV's name is available.
 - unsigned sd: 1 If set, the NV has a self-documenting text string.
 - unsigned nm_supplied: 1 Applies only to APP_QUERY_NV_INFO response for NV_INFO_DESC. If this bit is set, then the nv_name is also provided in the response, following the existing data fields.

| | | |
|----------|--------------------------|--|
| nv_array | | This data structure provides the array attributes for a specific network variable. It contains the following fields: |
| | unsigned count_hi | Total number of NVs in the array. An unsigned 16 bit number. |
| | unsigned count_lo | |
| | unsigned element_hi | The index of the NV within the array. Encoded as a zero |
| | unsigned element_lo | if the current NV is not a member of an array. |
| | | |
| nv_dflds | | This data structure provides the default values for the configurable attributes for a specific network variable. It contains the following fields: |
| | unsigned nv_direction: 1 | The default direction of the NV. |
| | unsigned nv_auth: 1 | The default authentication setting of the NV. |
| | unsigned nv_priority: 1 | The default priority setting of the NV. |
| | unsigned nv_service: 2 | The default service type of the NV. |

Extended network management commands

NM_GET_CAPABILITY_INFO

This command returns the capabilities of nodes that support no Self Identification (SI) data, or SI data versions 0 and 1. It can be viewed as returning the SI data relative to the Alias Record (alias_field). The purpose of the command is to allow a network manager to obtain the node's capability information near the end of the SI data versions 0 and 1 without having to scan the preceding and variable NV records, or to obtain the information when the node does not have SI data.

The response data has the following subclauses as described in SI Versions 0 and 1. Note that the Alias Record (alias_field) can be one or three bytes; the network manager must compute the offset of the Compatibility Record accordingly.

| | | |
|--------------------------------|----------------------|------------------------|
| Alias Record (1 or 3 bytes) | Compatibility Record | Capability Info Record |
|--------------------------------|----------------------|------------------------|

NM_SET_NV

This command sets a network variable to the value specified in the command. The length of the nv must match the defined length on the receiving node otherwise a negative response is returned. The nv is specified in the command by its nv index. This command is honoured even if the receiving node is offline. If the receiving node is offline, no update event is posted to the application.

Resource commands

The following set of extended network management commands are the commands to manage node resources.

Node Commands (NM_NODE)

The node resource supports the following command:

NM_NODE::NM_INITIALIZE

This command clears the configuration data of the node, in the following sequence:

- 1) Initialises all NV and alias configuration table entries of each class (see NM_INITIALIZE/NM_NV_CONFIG).
- 2) Initialises all address table entries (see NM_INITIALIZE/NM_ADDRESS).
- 3) Initialises all domain table entries (see NM_INITIALIZE/NM_DOMAIN).
- 4) Clears the network management authentication bit in the config data structure.
- 5) Sets the node's priority to zero.
- 6) Removes all dynamic NVs.
- 7) Optionally go to a specified state.

The field state is used only if non-zero. When specified, it indicates the state the node is to go to upon completion of the initialisation.

Domain commands (NM_DOMAIN)

NM_DOMAIN::NM_INITIALIZE

This command initialises a range of domain table entries to the empty value. This is semantically equivalent to the Leave Domain command described in 13.7.5 except that it never causes a node reset and it supports many more domain indices. The response is the standard response code format defined above.

To initialise one entry, specify both index and index_end to the index of the entry. To initialise all entries, specify index to be 0 and index_end to be all 1's. To initialise all entries at or greater than an index, specify index_end to be all 1's. Invalid indices are ignored and fail silently.

If the command leaves no other domain entries to be configured, the node goes to the unconfigured state.

NM_DOMAIN::NM_CREATE

This command uses the same data structure and has the same effect as NM_DOMAIN::NM_UPDATE. The response is the standard response code format defined above.

NM_DOMAIN::NM_UPDATE

This command updates a domain table entry. It is equivalent to the Update Domain command in 13.7.4, but supports a 16-bit domain index. The response is the standard response code format defined above.

NM_DOMAIN::NM_ENUMERATE

This command queries a domain table entry, or the next entry if the specified entry is empty. See B.2 for this structure.

Enumeration rules

At each successive enumeration, the requestor should specify the request's index to be 1 greater than the index returned from the previous response.

Only entries with a valid domain length (0, 1, 3, 6) are returned.

NM_DOMAIN::NM_SET_AUTH

This command is used to set the authentication key. The response is the standard response code format defined above.

Address table commands (NM_ADDRESS)**Expanded address table structure**

To accommodate the larger domain index, the address table entry will be appended with a 2-byte domain index. The address structures for group, subnet/node, and broadcast are affected.

The structure for the group address contains the new field “restriction”, allowing a node to send or receive messages to a group for which it is not a member. The response is the standard response code format defined above.

```
typedef enum
{
    GRP_NORMAL          = 0,
    GRP_OUTPUT_ONLY    = 1,
    GRP_INPUT_NO_ACK   = 2,
} group_restriction;
```

GRP_NORMAL – This is the normal node and is the typical default. All legacy implementations of this International Standard would use this if they did not want to modify the protocol code to support more address table entries as described in these extended network management commands.

GRP_OUTPUT_ONLY – The group is used for output only; the node must not use the entry to match the destination address of incoming addresses. This mode allows a node to send an implicitly addressed message to a group without being its member. The member id is not used and may be set to zero.

GRP_INPUT_NO_ACK – The node will receive incoming messages on that group but would not return ACKS, responses, or issue challenges; the member id may be set to zero. This mode allows a node to monitor group messages without being a member of the group. The member id is not used and may be set to zero.

NM_ADDRESS::NM_INITIALIZE

This command initialises a range of address table entries to the “empty” value. The entire entry is zeroed. The response is the standard response code format defined above.

To initialise all entries, specify index to be 0 and index_end to be all 1’s. To initialise all entries at or greater than an index, specify index_end to be all 1’s. When some indices are valid and some are invalid in a range of indices, invalid indices are ignored and fail silently.

NM_ADDRESS::NM_CREATE

This command uses the same data structure and has the same effect as NM_ADDRESS::NM_UPDATE. The response is the standard response code format defined above.

NM_ADDRESS::NM_UPDATE

This command is used to update an address table entry. Address table entries with an index greater than 14 must use this command. The response is the standard response code format defined above.

NM_ADDRESS::NM_ENUMERATE

This command queries an address table entry, or the next entry if the specified entry is empty.

Enumeration rules

At each successive enumeration, the requestor should specify the request's index to be 1 greater than the index returned from the previous response.

Only in-use entries are returned. Unused entries are ones whose first two bytes are zero.

NV configuration commands (NM_NV_CONFIG)

The network variable configuration table is used for static, and dynamic NVs, but not aliases. The table is indexed by a flat nv index corresponding to that used for the NM_NV_DEF command.

NV Configuration Table Entry Structure

The network variable configuration entry nv_struct is expanded to accommodate the extended network management command features. The new version is nv_struct_ext.

The index of the target nv; used when the nv configuration entry is used to target a single NV. This field is valid if its value is not 0xFFFF, and either bits nv_read_by_index or nv_write_by_index is set. If nv_read_by_index is set, the node may use NV_FETCH to fetch the target NV at the indicated index. If nv_write_by_index is set, the node may use NM_SET_NV to write to the target NV at the indicated index. The target node's address is indicated in the address table entry whose index is indicated by nv_addr_index.

NM_NV_CONFIG::NM_INITIALIZE

This command initialises a range of nv configuration entries to the "unbound" value. Each NV array element is treated as a separate entry.

To initialize all entries, specify index to be 0 and index_end to be all 1's. To initialize all entries at or greater than an index, specify index_end to be all 1's. Invalid indices are ignored and fail silently. The response is the standard response code format defined above.

The fields are initialised as follows:

| Field | Initial Value |
|-------------------|---------------|
| nv_priority | unchanged |
| nv_direction | unchanged |
| nv_selector_hi/lo | unchanged |
| nv_turnaround | 0 |
| nv_service | unchanged |
| nv_auth | unchanged |
| nv_write_by_index | 0 |
| nv_read_by_index | 0 |
| nv_remote_nm_auth | 0 |
| nv_service | unchanged |
| nv_addr_index | 0xFFFF |
| Unused fields | 0 |
| nv_target_index | 0xFFFF |

NM_NV_CONFIG::NM_CREATE

This command uses the same data structure and has the same effect as NM_NV_CONFIG::NM_UPDATE. The response is the standard response code format defined above.

NM_NV_CONFIG::NM_UPDATE

This command is used to modify an nv or alias configuration entry. Each NV array element is treated as a separate entry. The response is the standard response code format defined above.

NM_NV_CONFIG::NM_ENUMERATE

This command queries an nv config table entry, or the next allocated entry if the specified entry is not allocated. Allocation means the corresponding NV is allocated. Each NV array element is enumerated as a separate entry.

Enumeration rules

At each successive enumeration, the requestor should specify the request's index to be 1 greater than the index returned from the previous response.

The enumeration returns only bound NVs (one with either a bound selector, or whose address table index is not 0xffff).

Alias configuration commands (NM_ALIAS_CONFIG)

The alias configuration table is used for aliases of primary network variables.

Alias configuration table structures

The alias entry contains the expanded nv_struct_ext and a 16-bit index of the primary NV. Unlike the structure defined in A.22 and A.25 that has a "short" version with an 8-bit primary index and a "long" version with a 3 bytes primary index, the alias_struct_ext below will be uniformly used in all platforms that support the extended command set.

NM_ALIAS_CONFIG::NM_INITIALIZE

This command initialises a range of alias entries to the "unbound" value.

To initialise all entries, specify index to be 0 and index_end to be all 1's. To initialise all entries at or greater than an index, specify index_end to be all 1's. Invalid indices are ignored and fail silently. The index fields in this structure are alias indices. The alias index is relative to the beginning of the alias table.

The fields are initialised as follows:

| Field | Initial Value |
|----------------------------|---------------|
| alias_nv.nv_priority | 0 |
| alias_nv.nv_direction | 0 |
| alias_nv.nv_selector_hi/lo | 0 0xFFFF |
| alias_nv.nv_turnaround | 0 |
| alias_nv.nv_service | 0 |
| alias_nv.nv_auth | 0 |
| alias_nv.nv_write_by_index | 0 |
| alias_nv.nv_remote_nm_auth | 0 |
| alias_nv.nv_selection | 0 |
| alias_nv.nv_addr_index | 0 |
| alias_nv.nv_read_by_index | 0 |
| Unused fields | 0 |
| alias_primary | 0xFFFF |

NM_ALIAS_CONFIG::NM_CREATE

This command uses the same data structure and has the same effect as NM_ALIAS_CONFIG::NM_UPDATE. The response is the standard response code format defined above.

NM_ALIAS_CONFIG::NM_UPDATE

This command is used to update an alias configuration entry. The response is the standard response code format defined above.

NM_ALIAS_CONFIG::NM_ENUMERATE

This command queries an alias configuration entry, or the next allocated entry if the specified entry is not allocated.

Enumeration Rules

At each successive enumeration, the requestor should specify the request's index to be 1 greater than the index returned from the previous response.

The data structures used for all the install command messages are in A.30.

Backward Compatibility

A node that supports the extended command set, ECS, must continue to support the legacy Network Management commands as defined in this International Standard. However, once a node has been written by any extended commands, it is considered to operate in the extended mode, and shall return a negative response to the following legacy commands. The hexadecimal command codes from this standard are included for reference.

The ECS command set contains spare bits for some of the fields. These are reserved for future use. In order to provide for backward compatibility in the future, all unused bits must be set to zero.

ECS implementations built on top of pre-ECS protocol stacks may be able to respond negatively only to network variable commands. Such nodes would have the EXTCAP_INCOMING_GROUP_RESTRICTED capability flag set. This is acceptable as long as one of the following is true:

- 1) 1. The node has no more than 15 bindable message tags.
- 2) 2. The node has at least one static network variable.

Commands Requiring a negative response if operating in extended mode:

- NM_query_nv_config (0x68)
- NM_update_nv_config (0x6B)
- NM_update_group_addr command (0x69)
- NM_query_address (0x67)
- NM_update_address (0x66)
- NM_update_domain (0x63)
- NM_query_domain (0x6A)
- NM_leave_domain (0x64)

These restrictions, responding negatively to the legacy commands if a node can, or otherwise living within the limits of no more than 15 bindable message tags or having at least one static network variable allows a legacy network manager to perform database recovery on the network without destroying the operation of the nodes that support the extended network management command set. Otherwise, the recovery of the network database from the nodes will be inconsistent and could result in a catastrophic network outage with no backup network database (since database recovery was invoked to begin with).

Message Handling

Message Size

The node will return failure if a command data is not the exact size as defined. In the future, extensions to command data or addition of new commands will be signaled by a node via a higher version number in the field `snvt_capability_info.ver_nm_max`. In the future, the response to the `NM_GET_CAPABILITY_INFO` command may be lengthened in a backward compatible way without affecting the version number to accommodate new capabilities. In this case, if the requestor receives a response to the `NM_GET_CAPABILITY_INFO` command with more information than expected, the requestor can use the response data that it understands and ignore the rest of the returned response.

13.7.18 Memory refresh

This command causes the node to rewrite the existing contents of non-volatile memory at a specified address for a specified number of bytes. This can be used to periodically rewrite the contents of non-volatile memory to extend the retention time of the memory contents. An error is returned if a refresh of memory is requested and none exists at the specified address. Also, if "offset" falls beyond the end of the non-volatile memory area, an error is returned. In this way, the sender of these commands can simply increment the offset until an error is returned. The count should be limited to 8 if the target is online and could be as high as 38 if the target is offline. The data structures used are in A.31. If the non-volatile memory can be written by sector only, the count and offset values refer to entire sectors instead of individual bytes.

13.7.19 Query SI

This command is used to retrieve self-identification (SI) data for a node and for its network variables if this information is located outside the addressable memory space of the protocol processor (e.g., in the memory space of a co-processor). The field 'si' in the structure described in B.1.1 is a pointer to the address where a node's self-identification data is located. A null (0) address indicates that that node provides no self-identification data. A non-null address that does not consist of all 1's points to the address where this data is located. In this case, the data is read directly with a read memory

command. An address consisting of all 1's indicates that the self-identification information is located outside the addressable memory space of the protocol processor. The Query SI command must be implemented on the protocol processor in that case to read the self-identification data.

The device issuing this command need know nothing about physical addresses on the co-processor; instead the requester only deals with offsets. The requester starts with an offset of 0 and then bumps the offset for each subsequent request. The byte count shall be limited to 16 unless the target node has sufficiently large buffers to handle larger counts. The data structures used are in A.32.

13.7.20 Network variable value fetch

This message is used to poll network variables. It has two advantages over the network variable poll message: it uses the network variable index and is thus independent of network variable selector assignments, and it also obtains the value regardless of the node's online/offline condition. The data structures used are in A.33.

13.7.21 Manual service request message

This message is unlike the other network management messages in that it is an unsolicited message. It is sent over the network from a node when a Manual Service Request for that node is initiated. The message is sent as a domain-wide broadcast on domain length 0 with a source subnet 0 and node address of 0. The data structures used are in A.34.

13.7.22 Network management escape code

One of the network management command codes is reserved as an escape. The value of the escape code is 0x7D. Sending the escape code as the network management command causes the first two bytes of the APDU to be interpreted as additional command codes. This capability allows the network management protocol to be extended in product specific ways.

If a node responds to network management messages that use the network management escape code, then that node shall always respond to the Product Query command. All other commands are product specific and are documented with the products. The response to this command has two forms. The short form contains only a single byte to specify the product. The complete form contains:

- response code,
- product byte (as in the short form),
- two byte field for the model number,
- single byte for the firmware version,
- byte for the device configuration or mode, and
- byte for the transceiver type.

The single byte product specification codes are reserved and must be allocated to ensure no conflict among implementations. In the complete response form, the value of the device configuration options/modes byte returned is zero unless the device can be put into several modes or device configurations. In this case, the byte contains the current mode or configuration of the device.

Success or failure is reported on the escape code rather than on the subcode or command. The data structures used are in A.35.

13.7.23 Router mode

This request instructs the router to perform one of several router-related tasks. The “resume” command returns the router from the “all flood” state. The “init router tables” command copies all routing tables from non-volatile memory into the RAM tables (if a configured router) or sets all RAM tables to flood (if a learning router); this is the same action that occurs after node reset. The “mode all flood” command causes the router to forward all packets in the domain. The Router Mode command affects both router halves, and is conveyed via the Request-Response protocol. Note that the normal Network Management Node Mode request may be used to take the entire router offline and online. The data structures used are in A.36.

13.7.24 Router clear group or subnet table

This request is used to clear all entries in either the group or subnet routing table for a single domain for a *single router half*. The command is segmented to cover 8-byte sections in order to prevent lengthy non-volatile memory write operations. This command is conveyed via the Request-Response protocol. The network configuration memory checksum in non-volatile memory is updated. The data structures used are in A.37.

13.7.25 Router group or subnet table download

This request is used to configure the entire group or subnet table in non-volatile memory for the specified domain for a single router half. The download function is broken into 8-byte sections. This command is conveyed via the Request-Response protocol. The network configuration memory checksum in non-volatile memory is updated. The data structures used are described in A.38.

13.7.26 Router group forward

This request sets the forwarding flag in the routing table for a given group in the specified domain. This command is conveyed via the Request-Response protocol. The network configuration memory checksum in non-volatile memory is updated if changed. The data structures used are described in A.39.

13.7.27 Router subnet forward

This request sets the forwarding flag in the routing table for a given subnet in the specified domain. This command is conveyed via the Request-Response protocol. The network configuration memory checksum in non-volatile memory is updated if changed. The data structures used are described in A.40.

13.7.28 Router Do Not forward group

This request clears the forwarding flag in the routing table for a given group in the specified domain. This command is conveyed via the Request-Response protocol. The network configuration memory checksum in non-volatile memory is updated if changed. The data structures used are described in A.41.

13.7.29 Router Do Not forward subnet

This request clears the forwarding flag in the routing table for a given subnet in the specified domain. This command is conveyed via the Request-Response protocol. The network configuration memory checksum in non-volatile memory is updated if changed. The data structures used are described in A.42.

13.7.30 Router group or subnet table report

This request is used to report the current settings of either group or subnet tables in non-volatile memory or RAM for the specified domain for a single router half. The report function is broken into 8-

byte sections. This command is conveyed via the Request-Response protocol. The data structures used are described in A.43.

13.7.31 Router status

This request is used to report the router network configuration memory and flood/normal modes. It is conveyed via the Request-Response protocol. The data structures used are described in A.44.

13.7.32 Router half escape code

Although this is not in itself a network management command, it is included in this subclause for completeness. When this code is placed at the start of the APDU and is followed by any Network Management or Network Diagnostic command, that command shall be passed over to the other router half for processing. Any responses shall be returned in the normal manner.

```
byte command; /* Destination: NM, code: 30 */
```

13.8 DPDU types and formats

13.8.1 General

Most Diagnostic PDUs (DPDUs) are conveyed within session layer Requests and/or Responses. By default, a DPDU then inherits either the request or the response attribute of the enveloping SPDU.

This subclause lists DPDUs. The bit and byte ordering rules defined in Annex A apply, with the most significant bit of each byte being transmitted first; the first byte of a record is considered the least significant byte of that record. In the value section of the descriptions, the value corresponds to a command number or a response code for that message. In addition, the string "+ pass/fail" means that a single bit flag is set in the high order bit of the response to indicate that the command was either successful or that it failed.

13.8.2 Query status

This command gives a snapshot of a node's health. It conveys error statistics, reset information, the node state, the error log, the system image version, and the protocol processor model number. The error statistics, reset cause, and error log can all be cleared via the "clear status" command. Note that the statistics are also cleared whenever the node resets. This command never requires authentication to be executed. The data structures used are described in A.45.

The fields are defined as follows:

- `transmission_errors`: This is a count of the number of transmission errors that have occurred on the network. A transmission error is detected via a CRC error during packet reception or as a packet that is less than 8 bytes long. This could result from a collision, a noisy medium, signal attenuation, etc.;
- `transaction_timeouts`: This is a count of the number of timeouts that have occurred in attempting to carry out acknowledged or request/response transactions. A timeout occurs when a node fails to receive all the expected acknowledgments or responses after retrying the configured number of times at the configured interval;
- `receive_transaction_full`: This counter reflects the number of times an incoming unackd_rpt, ackd or request message was lost because there were no receive transaction records available;
- `lost_messages`: This is the number of messages that were addressed to the node that were thrown away because there was no application buffer available for the message;

- missed_messages: This is the number of messages that were on the network but could not be received because there was no network buffer (packet buffer) available for the message or the network buffer was too small to receive the message;
- reset_cause: This byte contains the reset cause information. This identifies the source of the most recent reset. The values for this byte are as follows (X => don't care):
 - Power-up reset 0bXXXXXXXX1
 - External reset 0bXXXXXXXX10
 - WDT reset 0bXXXX1100
 - Software-initiated reset 0bXXX10100
- node_state: This contains both the node state and node condition (as defined in the "Node State" section in the network management section).

The node_state structure is shown below:

```
struct node_state
{
    unsigned          :4; // application specific
    unsignedoffline :1; // 1=>Offline,0=>Online
    unsignedstate   :3; // 2=>Unconfigured
                       // 3=>Applicationless
                       // 4=>Configured
                       // 6=>Hard offline
};
```

Generally, a node will only have the offline field set if it is in the configured state. However, if a node is told to transition from the configured state to another state while it is offline, the node_state may show both offline as set and a state other than configured.

Examples of node_state values when viewed as a byte field are shown below:

| | | |
|-------------------------|------|---|
| Unconfigured | 0x02 | |
| Unconfig/App-less | 0x03 | |
| Configured/online | 0x04 | |
| Configured/hard-offline | 0x06 | /* Permanent offline */ |
| Configured/offline | 0x0C | /* Non-reset retained offline */ /* (note this is actually an */ /* encoding of the node state */ /* of "configured" and the */ /* offline condition) */ |
| Configured | 0x8C | /* Non-reset retained bypass- */ /* mode offline Like config- */ /* ured/offline except that */ /* the application went off- */ /* line in bypass mode */ |

- version: The version number reflects the version of the protocol implementation residing in the protocol processor and may be used by a network management tool for computing addresses to non-volatile memory data fields not supported by the standard NM address assignment/reporting commands. The version number is 1 to 127 for implementations containing no additional, application specific customization, and 128 to 255 for implementations with additional, application specific features. 255 is a special escape version that means more version number information is available via other commands;
- error_log: The error log contains the most recent error logged by the system. A value of 0 indicates no error. An error in the range 1..127 is an application error and unique to the application. An error in the range 128..255 is a system error. While the errors a given instance of the protocol can detect and report is implementation specific, the following are the currently allocated error numbers allocated for system errors.

IECNORM.COM : Click to view the full PDF of ISO/IEC 14908-1:2012

| | | |
|--------------|--|--|
| 0x81 | Bad Event | The application processor's scheduler has an event table. It contains encoded representations of the various when clauses in the program. If the scheduler encounters a illegal event code, this error is logged. |
| 0x82 | NV Length | If an incoming NV update has a length that differs from the length of the matching input NV in the application, this error is logged and the NV update is discarded. |
| 0x83 | NV Short | If an incoming NV update is missing the second byte of the selector, this error is logged. |
| 0x84 | EE Write Fail | After each write to EEPROM, the result is read back. If there is a mismatch, this error is logged. |
| 0x85 | Bad Address Type | If the type field in the address table is illegal, this error is logged. |
| 0x88 | Sync NV | When NVs are written to, a bit array is updated to indicate an update needs to be transmitted. In "post_events", this bit array is examined and a message is generated for each NV that is so marked and its bit is cleared. However, if no buffer is available, the application goes into preemption mode. If while in preemption mode, a sync NV whose bit is set is written to by the application, then this error is logged. |
| 0x8A | Invalid Domain | An attempt is made to send a message using a domain table entry that has a length byte that does not yield 0 when AND'ed with 0xF8. The message is discarded. |
| 0x8D | Invalid Address Index | An attempt was made to access the address table using an out of range index. This could occur when using any of the address table related NM commands, or when sending explicit messages or NVs using the address table. |
| 0x93 | Invalid NV Index | An attempt was made to access the NV config or NV alias table using an out of range index. This could occur when using any of the NV table related NM commands, or when formulating an NV update message. |
| 0x9A | Illegal Transceiver Register Address | An attempt was made to access a special purpose mode transceiver register using an out of range index. This could occur when accessing a transceiver register using the "retrieve_xcvr_status" function. |
| 0x9B | Transceiver Register Operation Failure | A timeout occurred waiting for the MAC layer to get a chance to query the special purpose mode transceiver. |
| 0xA1 | Self-Installation Semaphore | |
| 0xA2 | Read/Write Semaphore | |
| 0xC0 to 0xDF | State Byte Semaphore | The error log byte is used in certain cases for saving state information across unexpected. |

— model_number: The model number is the protocol processor model.

The model and version numbers together can be used to determine the exact firmware image in use by a node.

13.8.3 Proxy status

This command can be used to deliver a command to one or more target nodes via an agent node. The proxy command is sent to an agent along with a target address in the APDU. The agent node relays the command to the target and then relays the response back to the original requester. The agent repeats the message from the requestor verbatim except for the target address being removed. The proxy command can only be used to relay a status request or a query id (*unconfigured*) request. Although this command never itself requires authentication to be executed, if the original request is marked to be authenticated, the relayed request to the target shall also be so marked.

The original requester specifies the target address via data in the form of an address table entry in the APDU. The agent node uses this to determine the destination address and the retry/timeout values used during the transaction. There is one exception—the domain bit is ignored (the message is always relayed in the same domain in which it was received). Note that the retry/timeout values supplied in the target address should result in a transaction duration that is shorter than those used by the original requester. In general, this command works best if the agent and target are on the same channel. The data structures used are described in A.46.

The response data received by the original requester shall be identical to that which would have been received as a result of a direct request to the target. Note that in the case of a query id (*unconfigured*) broadcast, a direct message could result in multiple responses, whereas a proxy command sent to a single agent with a broadcast target would result in only a single response to the original requester.

This command is disallowed if the agent receives the request on a flexible domain.

Finally, if the agent node is in the process of sending outgoing transactions, it may not be able to deliver the relayed request immediately. Depending on how long this is delayed, the response may not be received by the original requester in time, even after several retries. Therefore, a transaction failure for a proxy command is more likely than for other transactions; this should be taken into account when drawing conclusions from same. Also, in order for the proxy command to work, the agent node must have at least two application input buffers.

13.8.4 Clear status

This command clears a subset of the information in the status response. The statistics information, the extended statistics information, the reset cause register and the error log are cleared by this command. A node that does a status request on a periodic basis may choose to use a clear command following each successful status response. The data structures used are described in A.47.

13.8.5 Query transceiver status

This command retrieves the status register information from a transceiver. It fails if there is no transceiver on the node, or if communication with the transceiver fails. It returns seven registers' worth of data regardless of the number of registers that the transceiver actually supports. It is up to the controller to know how many registers are valid. The data structures used are described in A.48.

Annex A (normative)

Reference implementation

A.1 General

This annex specifies a reference implementation of this standard. To do so it uses machine-independent pseudocode algorithms that define functions within the protocol and descriptions of the related data structures. These algorithms are extracted from a working reference implementation. To make a working implementation to verify the algorithms, it was necessary to define a boundary and an interface between the protocol processor and the physical layer as well as a boundary between the protocol application layer and the actual application. These interfaces are informative. Also, there are places in the reference implementation where a particular function could be accomplished in several ways. These are also noted as informative exceptions.

This reference implementation includes machine-dependent implementation details for a Motorola MC68360 processor called out in the code.

Note: The body of this standard has preference in case of functions specified in the body but not included in this annex and in case of inconsistencies between the body and the annex.

Sections written in *Lucida Console* underlayed **yellow** are not normative because they are hardware dependent.

Sections written in *Courier New Italic* underlayed in **blue** are normative but hardware dependent.

Sections written in *Courier New* underlayed in **green** are normative and hardware independent.

A.2 Predictive CSMA algorithm

```

/*****
  File:      spm.c
  Version:   1.7
  Reference: None
  Purpose:   MAC sublayer, comm_type = 2 using SPI port on 360.
             This does not support continuous frame exchange.
             This files also has functions to support
             io buttons for testing purpose such as
             manual service request, reset, io pin, and LEDs.
  Note:      None.
  To Do:     None.
*****/

/* START INFORMATIVE - Direct Mode */
/* This implementation is for transceivers that work with the MAC
 * sublayer configured for comm_type = 2 only.
 * If the implementation needs to support transceivers with the MAC
 * sublayer configured for comm_type = 1,

```

```
* this example serves only as a starting point for such an
* implementation. */
/* END INFORMATIVE - Direct Mode */

/*****
Section: Includes
*****/
#include <string.h>
#include <stdlib.h>

#include <cnp_1.h>
#include <node.h>
#include <link.h>
#include <physical.h>

/*****
Section: Constant Definitions
*****/
/* Used to indicate how often to check status of i/o buttons */
#define PHYIO_CHECK_INTERVAL 0,1 /* In Seconds */

/* Macro sets bit B of 16 bit word X */
#define SET_BIT(B,X) (((0x0001U << (B)) | (X))

/* Macro Clears bit B of 16 bit word X */
#define CLEAR_BIT(B,X) (( ~(0x0001U << (B)) ) & (X))

/* Dual Port Ram Base on Arnewsh Board */
#define DPRB 0x01000000UL

/* SPI Parameter Ram Base */
#define SPIB (DPRB + 0xD80UL)

/* SCC2 Parameter Ram Base */
#define SCC2B (DPRB + 0xD00UL)

/* Register Base = DPRB + 4 k */
#define REGB (DPRB + 0x1000UL)

/* 16bit CPM Command Register */
#define CR (REGB + 0x5C0UL)

/* 16 bit Serial DMA Config Register */
#define SDCR (REGB + 0x51EUL)

/* 24(32)bit CPM Interrupt Config Reg.*/
#define CICR (REGB + 0x540UL)

/* 32 bit CPM Interrupt Pending Reg. */
#define CIPR (REGB + 0x544UL)

/* 32 bit CPM Interrupt Mask Reg. */
#define CIMR (REGB + 0x548UL)

/* Clear CISR bit by writing a 1*/
/* 32 bit CPM Interrupt Service Register*/
#define CISR (REGB + 0x54CUL)

/* 32 bit SI Clock Route */
#define SICR (REGB + 0x6ECUL)

/* 16 bit SPI Mode Register */
#define SPMODE (REGB + 0x6A0UL)

/* Clear SPIE bit by writing a 1*/
/* 8 bit SPI Event Register */
#define SPIE (REGB + 0x6A6UL)

/* 8 bit SPI Mask Register */
#define SPIM (REGB + 0x6AAUL)

/* 8 bit SPI Command Register */
#define SPCOM (REGB + 0x6ADUL)
```



```

/* 32 bit SCC2 general mode register low */
#define GSMRL2          (REGB + 0x620UL)

/* 32 bit SCC2 general mode register high */
#define GSMRH2          (REGB + 0x624UL)

/* 16 bit SCC2 protocol specific mode reg */
#define PSMR2           (REGB + 0x628UL)

/* 16 bit SCC2 transmit on demand */
#define TODR2           (REGB + 0x62CUL)

/* 16 bit SCC2 Data sync register */
#define DSR2            (REGB + 0x62EUL)

/* Clear SCCE bit by writing a 1 */
/* 16 bit SCC2 event register */
#define SCCE2           (REGB + 0x630UL)

/* 16 bit SCC2 mask register */
#define SCCM2           (REGB + 0x634UL)

/* 8 bit SCC2 status register */
#define SCCS2           (REGB + 0x637UL)

/* 32 bit Baud rate gen config register */
#define BRGC2          (REGB + 0x5F4UL)

/* 16 bit port A data direction reg */
#define PADIR          (REGB + 0x550UL)

/* 16 bit port A pin assignment reg */
#define PAPER          (REGB + 0x552UL)

/* 16 bit port A open drain register */
#define PAODR          (REGB + 0x554UL)

/* 16 bit port A data register */
#define PADAT          (REGB + 0x558UL)

/* 32 bit port B direction register */
#define PBDIR          (REGB + 0x6B8UL)

/* 32 bit port B pin assignment register */
#define PBPAR          (REGB + 0x6BCUL)

/* 16 bit port B open drain register */
#define PBODR          (REGB + 0x6C2UL)

/* 32 bit port B data register */
#define PBDAT          (REGB + 0x6C4UL)

/* 16 bit port C direction register */
#define PCDIR          (REGB + 0x560UL)

/* 16 bit port C pin assignment reg */
#define PCPAR          (REGB + 0x562UL)

/* 16 bit port C special options */
#define PCSO           (REGB + 0x564UL)

/* 16 bit port C data register */
#define PCDAT          (REGB + 0x566UL)

/* 16 bit port C interrupt register */
#define PCINT          (REGB + 0x568UL)

/* Timer Related Constants */
/* 16 bit timer general config register */
#define TGCRCR         (REGB + 0x580UL)

/* 16 bit timer reference reg 1 */

```

```
/* or 32 bit cascaded 1 & 2 */
#define TRR1 (REGB + 0x594UL)

/* 16 bit timer counter reg 1 */
/* or 32 bit cascaded 1 & 2 */
#define TCN1 (REGB + 0x59CUL)

/* 16 bit timer mode register 4 */
#define TMR2 (REGB + 0x592UL)

/* 16 bit timer reference register 4 */
#define TRR2 (REGB + 0x596UL)

/* 16 bit timer capture register 4 */
#define TCR2 (REGB + 0x59AUL)

/* 16 bit timer counter register 4 */
#define TCN2 (REGB + 0x59EUL)

/* 16 bit timer event register 4 */
#define TER2 (REGB + 0x5B2UL)

/* ISR defines */
/* Interrupt vector base on Arnewsh Board*/
#define VBASE 0x00000000UL

/* User Interrupt vector num 3 MSbits */
#define UIVN_MSB 0x4U

/* SPI Int.vector num 5 LSBits from CPIC table*/
#define SPIVN_LSB 0x5U

/*****
8 bit vector number = 3 msb set by user, 5 lsb from CPIC table shift
UIVN_MSB left 5 to bits 7 6 5 then OR with SPIVN_LSB to get vector
number vector address is 4 times vector number + vector base
*****/
/* 32 bit SPI Int. vector address */
#define SPIV (((UIVN_MSB << 5) | SPIVN_LSB) * 4UL) + VBASE)

/* need an ISR for int error since int. error cannot be masked */
/* CPM int. error int. vector, num 5 LSB */
#define CERRVN_LSB 0x0UL

/* cpm error iv */
#define CERRV (((UIVN_MSB << 5) | CERRVN_LSB) * 4UL) + VBASE)

/* spurious interrupt exception vector */
#define SPURINTV 0x60U + VBASE

/* bus error exception vector */
#define BUSERRV 0x8U + VBASE


/* SPI Channel Number for CPM Command Register Commands */
#define SPI_CH_NUM 0x5U

/* SCC2 channel number for CPM Command Register Command */
#define SCC2_CH_NUM 0x4U

/* Opcode for CPM Com. Reg. to Init Tx Rx Param Ram */
#define INIT_TRP_OPCODE 0x0U

/* number of receive (transmit) BDs for SPI */
#define NUM_BD 0x1U

/* RBD_BASE and TBD_BASE must be divisible by 8 */
/* receive buffer descriptor base */
#define RBD_BASE (DPRB + 0x500UL)
```



```

/* put Transmit buffers right after Receive, 8bytes per BD */
/* transmit buffer descriptor base */
#define TBD_BASE (RBD_BASE + (NUM_BD * 0x8U))

/*****
FCR_INIT
    bits 7 to 5 unused,
    bit 4, Mot big endian = 1
    bits 3 to 0, function code dma = 8
*****/
/* SPI Param Function Code Register Init */
#define FCR_INIT      0x18U

/* max length of receive buffers 2 bytes per buffer*/
#define MAX_BUF_LEN 0x2U

/* CP Interrupt Request Level */
#define CPIR_LEVEL 0x4U

#define NUM_BD_SCC2      0x1U

/* scc2 receive buffer descriptor. base */
#define RBD_BASE_SCC2 (DPRB + 0x440UL)

/* scc2 transmit bd base */
#define TBD_BASE_SCC2 (RBD_BASE_SCC2 + (NUM_BD_SCC2 * 8U))

/* max buffer length scc2 */
#define MAX_BL_SCC2      16U

/* length of history arrays */
#define NUM_HIST 512

/* time limit before xcvr resets */
#define RESET_COUNT_LIMIT 0xFFFF

/* number of ticks to delay during restart processing */
#define RESTART_DELAY_TICKS 165000UL

/* Constants related to Channel Access Algorithm */
/* maximum size of backlog for access algorithm */
#define MAX_BACKLOG 63U

/* # of additional slots per backlog increment */
#define W_BASE 16U

/* used in conversion from this specification's
reference time to clock ticks on the 360 */
#define NICS_TICKS_BASE 480UL

/* used in computation of SPI-SPM bit clock */
#define BIT_CLOCK_BASE 312500UL

/* used in computation of bit clock */
#define RATIO_BASE 3UL

/*****
Implementation specific timing adjustments to channel access algorithm
This is where one would add or subtract from the respective times to
account for differences between the implementation specific delays and
latencies and those in this specification.
*****/
/* adjustment to the beta1 slot time */
#define BETA1_ADJUST_TICKS 0

/* adjustment to the beta2 slot time */
#define BETA2_ADJUST_TICKS 0

/* adjustment to the cycle timer time */
#define CYCLE_ADJUST_TICKS 0

/* adjustment to the begin of packet tx */
#define WAIT_TX_ADJUST_TICKS 0

```

```

/*****
Section: Type Definitions
*****/
/* 68360 communications processor register definitions */

typedef struct /* CP Command Register 16 bit */
{
    unsigned reset : 1; /* reset CPM */
    unsigned      : 3; /* unused */
    unsigned opcode : 4; /* opcode for command */
    unsigned chnum  : 4; /* channel number selects which port
                        SPI, SCC etc */
    unsigned      : 3; /* unused */
    unsigned flag   : 1; /* flag, command executes when set,
                        cp clears when done */
} CPCommandReg;

typedef struct /* Serial DMA Config Register 16 bit */
{
    unsigned      : 1; /* unused */
    unsigned frz   : 2; /* freeze */
    unsigned      : 2; /* unused */
    unsigned sism  : 3; /* SDMA interrupt service mask */
    unsigned      : 1; /* unused */
    unsigned said  : 3; /* SDMA arbitration ID */
    unsigned      : 2; /* unused */
    unsigned inte  : 1; /* interrupt error */
    unsigned intb  : 1; /* interrupt break point */
} SDMAConfigReg;

typedef struct /* CPM interrupt configuration register 32 bit */
{
    unsigned      : 8; /* unused */
    unsigned scdp : 2; /* scc port for priority slot d */
    unsigned sccp : 2; /* scc port for priority slot c */
    unsigned scbp : 2; /* scc port for priority slot b */
    unsigned scap : 2; /* scc port for priority slot a */
    unsigned irl : 3; /* interrupt request level */
    unsigned hpi : 5; /* highest priority interrupt */
    unsigned vba : 3; /* vector base address number offset */
    unsigned      : 4; /* reserved */
    unsigned sps  : 1; /* spread priority scheme */
} CIconfigReg;

/* CPM interrupt source 32 bit, same type for CIPR CIMR CISR */
typedef struct
{ /* names correspond to sources */
    unsigned pc0 : 1; /* bit 31 */
    unsigned scc1 : 1;
    unsigned scc2 : 1;
    unsigned scc3 : 1;
    unsigned scc4 : 1;
    unsigned pc1 : 1;
    unsigned timer1 : 1;
    unsigned pc2 : 1; /* bit 24 */
    unsigned pc3 : 1; /* bit 23 */
    unsigned sdma : 1;
    unsigned idma1 : 1;
    unsigned idma2 : 1;
    unsigned      : 1; /* unused */
    unsigned timer2 : 1;
    unsigned rtt : 1;
    unsigned      : 1; /* bit 16 unused */
    unsigned pc4 : 1; /* bit 15 */
    unsigned pc5 : 1;
    unsigned      : 1; /* unused */
    unsigned timer3 : 1;
    unsigned pc6 : 1;
    unsigned pc7 : 1;
    unsigned pc8 : 1;
    unsigned      : 1; /* bit 8 unused */
    unsigned timer4 : 1; /* bit 7 */
}

```

```

    unsigned pc9      : 1;
    unsigned spi      : 1; /* bit 5 */
    unsigned smc1     : 1;
    unsigned smc2     : 1; /* also pip */
    unsigned pc10     : 1;
    unsigned pc11     : 1;
    unsigned          : 1; /* bit 0 unused */
} CISourceReg;

/* serial interface clock route register 32 bit*/
typedef struct
{
    unsigned gr4      : 1; /* grant support for scc4*/
    unsigned sc4      : 1; /* connection for scc4*/
    unsigned r4cs     : 3; /* receive clock source for scc4*/
    unsigned t4cs     : 3; /* transmit clock source for scc4*/
    unsigned gr3      : 1; /* grant support for scc3 */
    unsigned sc3      : 1; /* connection for scc3 */
    unsigned r3cs     : 3; /* receive clock source for scc3 */
    unsigned t3cs     : 3; /* transmit clock source for scc3 */
    unsigned gr2      : 1; /* grant support for scc2 */
    unsigned sc2      : 1; /* connection for scc2 */
    unsigned r2cs     : 3; /* receive clock source for scc2 */
    unsigned t2cs     : 3; /* transmit clock source for scc2 */
    unsigned gr1      : 1; /* grant support for scc1 */
    unsigned sc1      : 1; /* connection for scc1 */
    unsigned r1cs     : 3; /* receive clock source for scc1 */
    unsigned t1cs     : 3; /* transmit clock source for scc1 */
} SIClockRouterReg;

typedef struct /* SPI command register 8 bit*/
{
    unsigned str : 1; /* start transmit and receive */
    unsigned res : 7; /* reserved write with zeros */
} SPICommandReg;

typedef struct /* SPI mode register 16 bit */
{
    unsigned          : 1; /* unused */
    unsigned loop     : 1; /* local loop back */
    unsigned ci       : 1; /* clock invert */
    unsigned cp       : 1; /* clock phase */
    unsigned div16    : 1; /* divide brgclk by 16 for spiclk */
    unsigned rev      : 1; /* reverse data from big endian to
                           little endian */
    unsigned ms       : 1; /* master slave */
    unsigned en       : 1; /* enable SPI */
    unsigned len      : 4; /* number of bits per char = len + 1 */
    unsigned pms      : 4; /* prescale modulus select, divide
                           down clock */
} SPIModeReg;

typedef struct /* SPI event and mask registers 8 bit */
{
    unsigned          : 2; /* unused */
    unsigned mme      : 1; /* multi-master error */
    unsigned txe      : 1; /* transmit error */
    unsigned          : 1; /* unused */
    unsigned bsy      : 1; /* busy error */
    unsigned txb      : 1; /* transmit buffer complete */
    unsigned rxb      : 1; /* receive buffer complete */
} SPIEventMaskReg;

typedef struct /* SPI Parameter RAM 40 bytes*/
{
    uint16 rbase; /* base address of receive BD's, set by user */
    uint16 tbase; /* base address of transmit BD's, set by user */
    uint8 rfcr; /* receive function code, set by user */
    uint8 tfcr; /* transmit function code, set by user */
    uint16 mrblr; /* maximum receive buffer length register,
                  set by user */
    uint32 rstate; /* rx internal state */
    uint32 ridp; /* rx internal data ptr */
}

```

```

uint16 rbptr; /* rx BD ptr */
uint16 ribc; /* rx internal byte count */
uint32 rtemp; /* rx temp */
uint32 tstate; /* tx internal state */
uint32 tidp; /* tx internal data ptr */
uint16 tbptr; /* tx BD ptr */
uint16 tibc; /* tx internal byte count */
uint32 ttemp; /* tx temp */
} SPIParamRam;

```

```

typedef struct /* Receive Buffer Descriptor 8 bytes */
{
    unsigned e : 1; /* empty buffer ready to receive*/
    unsigned : 1; /* unused */
    unsigned w : 1; /* wrap final bd so wrap to top */
    unsigned i : 1; /* interrupt, set rxb bit in spie register
                    when filled */
    unsigned l : 1; /* last, if slave then buffer has last bit */
    unsigned : 1; /* unused */
    unsigned cm : 1; /* continuous mode buffer can be overwritten
                    e always 1 */
    unsigned : 7; /* unused */
    unsigned ov : 1; /* receiver overrun only when slave */
    unsigned me : 1; /* multiple master error */
    uint16 dataLen; /* data length = number of bytes written
                    into buffer */
    SPMRxFrame * dataPtr; /* ptr to buffer of data */
} RBufferDesc;

```

```

typedef struct /* Transmit Buffer Descriptor 8 bytes */
{
    unsigned r : 1; /* ready to transmit buffer */
    unsigned : 1; /* unused */
    unsigned w : 1; /* wrap final bd so wrap to top */
    unsigned i : 1; /* interrupt, set txb bit in spie register
                    when sent */
    unsigned l : 1; /* last, if slave then buffer has last bit */
    unsigned : 1; /* unused */
    unsigned cm : 1; /* continuous mode buffer can be re-sent
                    r always 1 */
    unsigned : 7; /* unused */
    unsigned un : 1; /* transmit underrun only when slave */
    unsigned me : 1; /* multiple master error */
    uint16 dataLen; /* data length = number of bytes to send
                    from this buffer */
    SPMTxFrame * dataPtr; /* ptr to buffer of data */
} TBufferDesc;

```

```
/* scc structs */
```

```

typedef struct /* general scc mode register high 32 bit */
{
    unsigned : 15; /* unused */
    unsigned gde : 1; /* glitch detect enable */
    unsigned tcrc : 2; /* transparent crc */
    unsigned revd : 1; /* reverse data */
    unsigned trx : 1; /* transparent receiver */
    unsigned ttx : 1; /* transparent transmitter */
    unsigned cdp : 1; /* cd pulse */
    unsigned ctsp : 1; /* cts pulse */
    unsigned cds : 1; /* cd sampling */
    unsigned ctss : 1; /* cts sampling */
    unsigned tfl : 1; /* transmit fifo length */
    unsigned rfw : 1; /* receive fifo width */
    unsigned txsy : 1; /* transmitter synchronized to receiver */
    unsigned synl : 2; /* sync length */
    unsigned rtsm : 1; /* rts mode */
    unsigned rsyn : 1; /* receive sync timing */
} GSMRegHigh;

```

```
typedef struct /* general scc mode register low 32 bit */
```

```

{
    unsigned : 1; /* unused */
    unsigned edge : 2; /* DPLL clock edge */
    unsigned tci : 1; /* transmit clock invert */
    unsigned tsnr : 2; /* transmit sense bits */
    unsigned rinv : 1; /* dpll receive invert data */
    unsigned tinr : 1; /* dpll transmit invert data */
    unsigned tpl : 3; /* transmit preamble length */
    unsigned tpp : 2; /* transmit preamble pattern */
    unsigned tend : 1; /* transmit frame ending */
    unsigned tdc : 2; /* transmit divide clock rate */
    unsigned rdc : 2; /* receive dpll clock rate */
    unsigned renc : 3; /* receiver decoding method */
    unsigned tenc : 3; /* transmitter encoding method */
    unsigned diag : 2; /* diagnostic mode */
    unsigned enr : 1; /* enable receive */
    unsigned ent : 1; /* enable transmit */
    unsigned mode : 4; /* channel protocol mode */
} GSMRegLow;

typedef struct /* SCC event/mask register 16 bit */
{
    unsigned : 3; /* unused */
    unsigned glr : 1; /* glitch on receive */
    unsigned glt : 1; /* glitch on transmit */
    unsigned dcc : 1; /* dpll carrier sense changed */
    unsigned : 2; /* unused */
    unsigned gra : 1; /* graceful stop complete */
    unsigned : 2; /* unused */
    unsigned txe : 1; /* transmit error */
    unsigned rch : 1; /* receive character or long word */
    unsigned bsy : 1; /* busy condition */
    unsigned tx : 1; /* buffer transmitted */
    unsigned rx : 1; /* buffer received */
} SCCEventMaskReg;

typedef struct /* scc status register 8 bit */
{
    unsigned : 6; /* unused */
    unsigned cs : 1; /* carrier sense */
    unsigned : 1; /* unused */
} SCCStatusReg;

typedef struct /* SCC Parameter RAM Transparent mode 56 bytes */
{
    uint16 rbase; /* base address of receive BD's, set by user */
    uint16 tbase; /* base address of transmit BD's, set by user */
    uint8 rfcn; /* receive function code, set by user */
    uint8 tfcn; /* transmit function code, set by user */
    uint16 mrblr; /* maximum receive buffer length register,
    set by user */
    uint32 rstate; /* rx internal state */
    uint32 ridp; /* rx internal data ptr */
    uint16 rbptr; /* rx BD ptr */
    uint16 ribc; /* rx internal byte count */
    uint32 rtemp; /* rx temp */
    uint32 tstate; /* tx internal state */
    uint32 tidp; /* tx internal data ptr */
    uint16 tbptr; /* tx BD ptr */
    uint16 tibc; /* tx internal byte count */
    uint32 ttemp; /* tx temp */
    uint32 rcrc; /* temp receive crc */
    uint32 tcrc; /* temp transmit crc */
    uint32 crcp; /* crc preset for transparent mode */
    uint32 crcc; /* crc constant for transparent mode */
} SCCParamRam;

typedef struct /* SCC Receive Buffer Descriptor 8 bytes */
{
    unsigned e : 1; /* empty buffer ready to receive */
    unsigned : 1; /* unused */
    unsigned w : 1; /* wrap final bd so wrap to top */
    unsigned i : 1; /* interrupt, set rxb bit in scc register

```

```

        when filled */
    unsigned l : 1; /* this buffer last in frame */
    unsigned f : 1; /* first in frame */
    unsigned cm : 1; /* continuous mode buffer can be overwritten
        e always 1 */
    unsigned : 1; /* unused */
    unsigned de : 1; /* dpll error */
    unsigned : 2; /* unused */
    unsigned no : 1; /* non octet error */
    unsigned : 1; /* unused */
    unsigned cr : 1; /* crc error */
    unsigned ov : 1; /* receiver overrun */
    unsigned cd : 1; /* carrier detect lost */
    uint16 dataLen; /* data length = number of bytes written
        into buffer */
    Byte * dataPtr; /* ptr to buffer of data */
} SCCReceiveBD;

typedef struct /* SCC Transmit Buffer Descriptor 8 bytes */
{
    unsigned r : 1; /* ready to transmit buffer */
    unsigned : 1; /* unused */
    unsigned w : 1; /* wrap final bd so wrap to top */
    unsigned i : 1; /* interrupt, set txb bit in scc register
        when sent */
    unsigned l : 1; /* last byte in frame in this buffer */
    unsigned tc : 1; /* transmit crc */
    unsigned cm : 1; /* continuous mode buffer can be re-sent r always 1 */
    unsigned : 7; /* unused */
    unsigned un : 1; /* transmit underrun */
    unsigned ct : 1; /* cts lost during frame transmission */
    uint16 dataLen; /* data length = number of bytes to send
        from this buffer */
    Byte * dataPtr; /* ptr to buffer of data */
} SCCTransmitBD;

typedef struct /* BRGC baud rate generator config register 32 bit */
{
    unsigned : 14; /* unused */
    unsigned rst : 1; /* reset brg */
    unsigned en : 1; /* enable brg count */
    unsigned extc : 2; /* enable external clock source */
    unsigned atb : 1; /* autobaud */
    unsigned cd : 12; /* clock divider */
    unsigned div16 : 1; /* div 16 clock */
} BRGConfigReg;

typedef struct /* port a direction register 16 bit */
{
    unsigned dr15 : 1; /* pin direction 0 = input 1 = output */
    unsigned dr14 : 1;
    unsigned dr13 : 1;
    unsigned dr12 : 1;
    unsigned dr11 : 1;
    unsigned dr10 : 1;
    unsigned dr9 : 1;
    unsigned dr8 : 1;
    unsigned dr7 : 1;
    unsigned dr6 : 1;
    unsigned dr5 : 1;
    unsigned dr4 : 1;
    unsigned dr3 : 1;
    unsigned dr2 : 1;
    unsigned dr1 : 1;
    unsigned dr0 : 1;
} PADirectionReg;

typedef struct /* port a pin assignment register 16 bit */
{
    unsigned dd15 : 1; /* 0 = general purpose io */
    unsigned dd14 : 1;
    unsigned dd13 : 1;
    unsigned dd12 : 1;

```

```

    unsigned dd11 : 1;
    unsigned dd10 : 1;
    unsigned dd9  : 1;
    unsigned dd8  : 1;
    unsigned dd7  : 1;
    unsigned dd6  : 1;
    unsigned dd5  : 1;
    unsigned dd4  : 1;
    unsigned dd3  : 1;
    unsigned dd2  : 1;
    unsigned dd1  : 1;
    unsigned dd0  : 1;
} PAPinAssignmentReg;

```

```

typedef struct /* port a open drain register 16 bit */
{
    unsigned : 8; /* unused */
    unsigned od7 : 1; /* 0 = active drive 1 = open drain */
    unsigned od6 : 1;
    unsigned od5 : 1;
    unsigned od4 : 1;
    unsigned od3 : 1;
    unsigned : 1; /* unused */
    unsigned od1 : 1;
    unsigned : 1; /* unused */
} PAOpenDrainReg;

```

```

typedef struct /* port a data register 16 bit */
{
    unsigned d15 : 1; /* value of pin */
    unsigned d14 : 1;
    unsigned d13 : 1;
    unsigned d12 : 1;
    unsigned d11 : 1;
    unsigned d10 : 1;
    unsigned d9  : 1;
    unsigned d8  : 1;
    unsigned d7  : 1;
    unsigned d6  : 1;
    unsigned d5  : 1;
    unsigned d4  : 1;
    unsigned d3  : 1;
    unsigned d2  : 1;
    unsigned d1  : 1;
    unsigned d0  : 1;
} PADataReg;

```

```

typedef struct /* PBDIR port b direction register 32 bit */
{
    unsigned : 14; /* unused*/
    unsigned dr17 : 1; /* pin with given # */
    unsigned dr16 : 1; /* pin with same # */
    unsigned dr15 : 1; /* pin with same # */
    unsigned dr14 : 1; /* pin with same # */
    unsigned dr13 : 1; /* pin with same # */
    unsigned dr12 : 1; /* pin with same # */
    unsigned dr11 : 1; /* pin with same # */
    unsigned dr10 : 1; /* pin with same # */
    unsigned dr9  : 1; /* pin with same # */
    unsigned dr8  : 1; /* pin with same # */
    unsigned dr7  : 1; /* pin with same # */
    unsigned dr6  : 1; /* pin with same # */
    unsigned dr5  : 1; /* pin with same # */
    unsigned dr4  : 1; /* pin with same # */
    unsigned dr3  : 1; /* pin with same # */
    unsigned dr2  : 1; /* pin with same # */
    unsigned dr1  : 1; /* pin with same # */
    unsigned dr0  : 1; /* pin with same # */
} PBDirectionReg;

```

```

typedef struct /* PBPAR port b pin assignment register 32 bit */
{
    unsigned : 14; /* unused*/

```

```

unsigned dd17 : 1; /* pin with given # */
unsigned dd16 : 1; /* pin with same # */
unsigned dd15 : 1; /* pin with same # */
unsigned dd14 : 1; /* pin with same # */
unsigned dd13 : 1; /* pin with same # */
unsigned dd12 : 1; /* pin with same # */
unsigned dd11 : 1; /* pin with same # */
unsigned dd10 : 1; /* pin with same # */
unsigned dd9 : 1; /* pin with same # */
unsigned dd8 : 1; /* pin with same # */
unsigned dd7 : 1; /* pin with same # */
unsigned dd6 : 1; /* pin with same # */
unsigned dd5 : 1; /* pin with same # */
unsigned dd4 : 1; /* pin with same # */
unsigned dd3 : 1; /* pin with same # */
unsigned dd2 : 1; /* pin with same # */
unsigned dd1 : 1; /* pin with same # */
unsigned dd0 : 1; /* pin with same # */
} PBPinAssignmentReg;

```

```
typedef struct /* PBODR port b open drain register 16 bit */
```

```

{
unsigned od15 : 1; /* pin with same # */
unsigned od14 : 1; /* pin with same # */
unsigned od13 : 1; /* pin with same # */
unsigned od12 : 1; /* pin with same # */
unsigned od11 : 1; /* pin with same # */
unsigned od10 : 1; /* pin with same # */
unsigned od9 : 1; /* pin with same # */
unsigned od8 : 1; /* pin with same # */
unsigned od7 : 1; /* pin with same # */
unsigned od6 : 1; /* pin with same # */
unsigned od5 : 1; /* pin with same # */
unsigned od4 : 1; /* pin with same # */
unsigned od3 : 1; /* pin with same # */
unsigned od2 : 1; /* pin with same # */
unsigned od1 : 1; /* pin with same # */
unsigned od0 : 1; /* pin with same # */
} PBOpenDrainReg;

```

```
typedef struct /* PBDAT port b data register 32 bit */
```

```

{
unsigned : 14; /* unused */
unsigned d17 : 1; /* pin with given # */
unsigned d16 : 1; /* pin with same # */
unsigned d15 : 1; /* pin with same # */
unsigned d14 : 1; /* pin with same # */
unsigned d13 : 1; /* pin with same # */
unsigned d12 : 1; /* pin with same # */
unsigned d11 : 1; /* pin with same # */
unsigned d10 : 1; /* pin with same # */
unsigned d9 : 1; /* pin with same # */
unsigned d8 : 1; /* pin with same # */
unsigned d7 : 1; /* pin with same # */
unsigned d6 : 1; /* pin with same # */
unsigned d5 : 1; /* pin with same # */
unsigned d4 : 1; /* pin with same # */
unsigned d3 : 1; /* pin with same # */
unsigned d2 : 1; /* pin with same # */
unsigned d1 : 1; /* pin with same # */
unsigned d0 : 1; /* pin with same # */
} PBDataReg;

```

```
typedef struct /* port c direction register 16 bit */
```

```

{
unsigned : 4; /* unused */
unsigned dr11 : 1; /* pin direction 0 = input 1 = output */
unsigned dr10 : 1;
unsigned dr9 : 1;
unsigned dr8 : 1;
unsigned dr7 : 1;
unsigned dr6 : 1;
unsigned dr5 : 1;

```

```

    unsigned dr4 : 1;
    unsigned dr3 : 1;
    unsigned dr2 : 1;
    unsigned dr1 : 1;
    unsigned dr0 : 1;
} PCDirectionReg;

typedef struct /* port c pin assignment register 16 bit */
{
    unsigned : 4; /* unused */
    unsigned dd11 : 1; /* 0 = general purpose io */
    unsigned dd10 : 1;
    unsigned dd9 : 1;
    unsigned dd8 : 1;
    unsigned dd7 : 1;
    unsigned dd6 : 1;
    unsigned dd5 : 1;
    unsigned dd4 : 1;
    unsigned dd3 : 1;
    unsigned dd2 : 1;
    unsigned dd1 : 1;
    unsigned dd0 : 1;
} PCPinAssignmentReg;

typedef struct /* port c data register 16 bit */
{
    unsigned : 4; /* unused */
    unsigned d11 : 1; /* value of pin */
    unsigned d10 : 1;
    unsigned d9 : 1;
    unsigned d8 : 1;
    unsigned d7 : 1;
    unsigned d6 : 1;
    unsigned d5 : 1;
    unsigned d4 : 1;
    unsigned d3 : 1;
    unsigned d2 : 1;
    unsigned d1 : 1;
    unsigned d0 : 1;
} PCDataReg;

typedef struct /* port c interrupt control register 16 bit */
{
    unsigned : 4; /* unused */
    unsigned edm11 : 1; /* edge detect mode for line*/
    unsigned edm10 : 1;
    unsigned edm9 : 1;
    unsigned edm8 : 1;
    unsigned edm7 : 1;
    unsigned edm6 : 1;
    unsigned edm5 : 1;
    unsigned edm4 : 1;
    unsigned edm3 : 1;
    unsigned edm2 : 1;
    unsigned edm1 : 1;
    unsigned edm0 : 1;
} PCInterruptReg;

typedef struct /* port c special options register 16 bit */
{
    unsigned : 4; /* unused */
    unsigned cd4 : 1; /* Carrier detect */
    unsigned cts4 : 1; /* clear to send */
    unsigned cd3 : 1; /* Carrier detect */
    unsigned cts3 : 1; /* clear to send */
    unsigned cd2 : 1; /* Carrier detect */
    unsigned cts2 : 1; /* clear to send */
    unsigned cd1 : 1; /* Carrier detect */
    unsigned cts1 : 1; /* clear to send */
    unsigned : 4; /* unused */
} PCSpecialOptionsReg;

/* Timer related TypeDefs */

```

```
typedef struct /* timer general config register 16 bit */
{
    unsigned cas4 : 1; /* cascade timer 4 */
    unsigned frz4 : 1; /* freeze timer 4 */
    unsigned stp4 : 1; /* stop timer 4 */
    unsigned rst4 : 1; /* reset timer 4 */
    unsigned gm2 : 1; /* gate mode pin 2 */
    unsigned frz3 : 1; /* freeze timer 3 */
    unsigned stp3 : 1; /* stop timer 3 */
    unsigned rst3 : 1; /* reset timer 3 */
    unsigned cas2 : 1; /* cascade timer 2 */
    unsigned frz2 : 1; /* freeze timer 2 */
    unsigned stp2 : 1; /* stop timer 2 */
    unsigned rst2 : 1; /* reset timer 2 */
    unsigned gm1 : 1; /* gate mode pin 1 */
    unsigned frz1 : 1; /* freeze timer 1 */
    unsigned stp1 : 1; /* stop timer 1 */
    unsigned rst1 : 1; /* reset timer 1 */
} TimerGenConfigReg;
```

```
typedef struct /* timer mode register 16 bit */
{
    unsigned ps : 8; /* prescaler */
    unsigned ce : 2; /* capture edge */
    unsigned om : 1; /* output mode */
    unsigned ori : 1; /* output ref interrupt enable */
    unsigned frr : 1; /* free run/restart */
    unsigned iclk : 2; /* input clock source */
    unsigned ge : 1; /* gate enable */
} TimerModeReg;
```

```
typedef struct /* timer event register 16 bit */
{
    unsigned : 14; /* unused */
    unsigned ref : 1; /* output reference event */
    unsigned cap : 1; /* input capture event */
} TimerEventReg;
```

/* structure used for byte by byte crc checking on receive */

```
typedef struct
{
    uint16 poly;
    uint16 crc;
    uint8 crcBit;
    uint8 dataBit;
    uint8 dataByte;
} CRCParam;
```

/* structures used for debugging purposes */

```
typedef struct /* contains record of SPM frame */
{
    SPMState state; /* state when received status byte */
    SPMRxFrame rf; /* RX frame */
    SPMTxFrame tf; /* TX frames */
    uint32 duration; /* time to run isr */
    uint32 start; /* start time of isr */
    uint16 rb; /* index to receive buffer */
    uint16 tb; /* index to transmit bufer */
} Record;
```

```
typedef struct /* contains history of frame records */
{
    int index; /* current record wraps around when full */
    Record records[NUM_HIST]; /* array of records */
} History;
```

```

/*****
Section: Local Globals
*****/
/* pointers to SPI registers all are constant pointers to volatiles
volatile is needed to insure mem access occurs at each reference */

static volatile CPCCommandReg * const crPtrGbl =
    (volatile CPCCommandReg *) CR;
static volatile SDMAConfigReg * const sdcPtrGbl =
    (volatile SDMAConfigReg *) SDCR;

static volatile CIconfigReg * const cicrPtrGbl =
    (volatile CIconfigReg *) CICR;
static volatile CISourceReg * const ciprPtrGbl =
    (volatile CISourceReg *) CIPR;
static volatile CISourceReg * const cimrPtrGbl =
    (volatile CISourceReg *) CIMR;
static volatile CISourceReg * const cisrPtrGbl =
    (volatile CISourceReg *) CISR;

static volatile SIClockRouterReg * const sicrPtrGbl =
    (volatile SIClockRouterReg *) SICR;

static volatile SPIModeReg * const spmodePtrGbl =
    (volatile SPIModeReg *) SPMODE;
static volatile SPIEventMaskReg * const spiePtrGbl =
    (volatile SPIEventMaskReg *) SPIE;

static volatile SPIEventMaskReg * const spimPtrGbl =
    (volatile SPIEventMaskReg *) SPIM;
static volatile SPICommandReg * const spcomPtrGbl =
    (volatile SPICommandReg *) SPCOM;

static volatile SPIParamRam * const spiParamPtrGbl =
    (volatile SPIParamRam *) SPIB;
static volatile RBufferDesc * const rbdPtrGbl =
    (volatile RBufferDesc *) RBD_BASE;
static volatile TBufferDesc * const tbdPtrGbl =
    (volatile TBufferDesc *) TBD_BASE;

/* SCC2 registers */
static volatile GSMRegLow * const gsmr12PtrGbl =
    (volatile GSMRegLow *) GSMRL2;
static volatile GSMRegHigh * const gsmrh2PtrGbl =
    (volatile GSMRegHigh *) GSMRH2;
static volatile uint16 * const dsr2PtrGbl =
    (volatile uint16 *) DSR2;
static volatile uint16 * const todr2PtrGbl =
    (volatile uint16 *) TODR2;
static volatile SCCEventMaskReg * const scce2PtrGbl =
    (volatile SCCEventMaskReg *) SCCE2;
static volatile SCCEventMaskReg * const sccm2PtrGbl =
    (volatile SCCEventMaskReg *) SCCM2;
static volatile SCCStatusReg * const sccs2PtrGbl =
    (volatile SCCStatusReg *) SCCS2;
static volatile BRGConfigReg * const brgc2PtrGbl =
    (volatile BRGConfigReg *) BRGC2;

static volatile SCCParamRam * const scc2ParamPtrGbl =
    (volatile SCCParamRam *) SCC2B;
static volatile SCCReceiveBD * const scc2rbdPtrGbl =
    (volatile SCCReceiveBD *) RBD_BASE_SCC2;
static volatile SCCTransmitBD * const scc2tbdPtrGbl =
    (volatile SCCTransmitBD *) TBD_BASE_SCC2;

/* allocate storage for scc transmit and receive buffers,
init to zeros */
static volatile Byte scc2rBufGbl[ NUM_BD_SCC2 ][ MAX_BL_SCC2 ] = {0};
static volatile Byte scc2tBufGbl[ NUM_BD_SCC2 ][ MAX_BL_SCC2 ] = {0};

/* Port A registers */
static volatile PADirectionReg * const padirPtrGbl =

```

```
(volatile PADirectionReg *) PADIR;
static volatile PAPinAssignmentReg * const paparPtrGbl =
    (volatile PAPinAssignmentReg *) PAPAR;
static volatile PAOpenDrainReg * const paodrPtrGbl =
    (volatile PAOpenDrainReg *) PAODR;
static volatile PADataReg * const padatPtrGbl =
    (volatile PADataReg *) PADAT;

/* Port B registers */
static volatile PBDirectionReg * const pbdirectionPtrGbl =
    (volatile PBDirectionReg *) PBDIR;
static volatile PBPinAssignmentReg * const pbparPtrGbl =
    (volatile PBPinAssignmentReg *) PBPAR;
static volatile PBOpenDrainReg * const pbodrPtrGbl =
    (volatile PBOpenDrainReg *) PBODR;
static volatile PBDataReg * const pbdatPtrGbl =
    (volatile PBDataReg *) PBDAT;

/* Port C registers */
static volatile PCDirectionReg * const pcdirectionPtrGbl =
    (volatile PCDirectionReg *) PCDIR;
static volatile PCPinAssignmentReg * const pcparPtrGbl =
    (volatile PCPinAssignmentReg *) PCPAR;
static volatile PCDataReg * const pcdatPtrGbl =
    (volatile PCDataReg *) PCDAT;
static volatile PCSpecialOptionsReg * const pcsoptrGbl =
    (volatile PCSpecialOptionsReg *) PCSO;
static volatile PCInterruptReg * const pcintPtrGbl =
    (volatile PCInterruptReg *) PCINT;

/* const ptr to ptr to function returning void with void params */
static volatile void (** const spivPtrGbl)(void) =
    (volatile void (**)(void)) SPIV; /* ptr to vector */
static volatile void (** const cerrvPtrGbl)(void) =
    (volatile void (**)(void)) CERRV; /* ptr to vector */
static volatile void (** const spurintvPtrGbl)(void) =
    (volatile void (**)(void)) SPURINTV; /* ptr to vector */
static volatile void (** const buserrvPtrGbl)(void) =
    (volatile void (**)(void)) BUSERRV; /* ptr to vector */

/* Timer 1-2 stuff */
static volatile TimerGenConfigReg * const tgcrPtrGbl =
    (volatile TimerGenConfigReg *) TGCR;

static volatile uint32 * const trr12PtrGbl =
    (volatile uint32 *) TRR1; /* cascaded 32 bit ref */
static volatile uint32 * const tcn12PtrGbl =
    (volatile uint32 *) TCN1; /* cascaded 32 bit timer */

static volatile TimerModeReg * const tmr2PtrGbl =
    (volatile TimerModeReg *) TMR2;
static volatile uint16 * const trr2PtrGbl =
    (volatile uint16 *) TRR2;
static volatile uint16 * const tcr2PtrGbl =
    (volatile uint16 *) TCR2;
static volatile uint16 * const tcn2PtrGbl =
    (volatile uint16 *) TCN2;
static volatile TimerEventReg * const ter2PtrGbl =
    (volatile TimerEventReg *) TER2;

/*****
Section: Globals
*****/
/* parameters for SPMIsr execution history for debugging purposes */
volatile MACParam macGbl; /* extern in physical.h */
volatile SPMPParam spmGbl; /* extern in physical.h */
volatile CRCParam crcGbl;

volatile History hBufGbl = {0}; /* Initialize to zero */

/* exception count for debugging puposes. Incremented in exception
service routines for bus error and spurious interrupt */
volatile uint32 exceptions = 0;
```

```

/* Timer for PHYIO */
MSTimer phyIOTimer;

/*-----
Section: Local Function Prototypes
-----*/
/* Special Purpose Mode Init */
static int16  SPMInit(void);

/* Special Purpose Mode Int. Service Routine */
static void   SPMIsr(void);

/* CPM int error Int. Service Routine */
static void   CErrIsr(void);

/* Spurious interrupt error ISR */
static void   SpurIntIsr(void);

/* bus error ISR */
static void   BusErrIsr(void);

/* Initialize MAC hardware timer */
static uint32 * MACTimerInit(void);

/* delay function waits for delay ticks */
static Boolean DelayTicks(uint32 delay);

/* uses MACTimer hardware timer */
static void   UpdateElapsedTimer(TimerData32 * t);
static void   StartElapsedTimer(TimerData32 * t);
/* increments backlog */
static void   IncrementBacklog(uint8 deltaBacklog);
/* decrement backlog */
static void   DecrementBacklog(uint8 deltaBacklog);

/*-----
Section: Function Definitions
-----*/
/* #define SPM_TEST */ /* To include a main to test SPM only */
/* #define SPM_HISTORY */ /* To debug without break points */

/*****
Function:  main
Returns:
Reference:
Purpose:  To test mac layer only
Comments:
*****/

#ifdef SPM_TEST
void main()
{
    long count = 0;

    PHYInitSPM();

    macGbl.tl = 8; /* 5 byte packet */
    macGbl.tc = 0;
    macGbl.tPkt[0] = 1;
    macGbl.tPkt[1] = 2;
    macGbl.tPkt[2] = 3;
    macGbl.tPkt[3] = 4;
    macGbl.tPkt[4] = 5;
    macGbl.tPkt[5] = 6;
    macGbl.tPkt[6] = 7;
    macGbl.tPkt[7] = 8;
    macGbl.tpr = TRUE;

    count = 0;
    while (macGbl.tpr != FALSE )
    {

```

```

    count++;
}

count = 0;
while (spmGbl.mode != STOP )
{
    count++;
}
return;
}

#endif

/*****
Function: PHYInitSPM
Returns:
Reference:
Purpose: Set up special purpose mode
        SPMInit() initializes all the 68360 registers
        MACTimerInit() starts up a 32 bit hardware timer (25Mhz)
        PHYEnableSPMIsr() configures the Interrupt Service Routine
Comments:
*****/
void PHYInitSPM(void)
{
    int16 initOK = 0;

    exceptions = 0; /* for debugging */

    initOK = SPMInit();

    /* initialize and start MAC hardware timer */
    spmGbl.clock = MACTimerInit();

    /* reconfigure SPI SPMODE */
    /* spmodePtrGbl->loop = 1; */ /* local loop back for test */


    hBufGbl.index = 0; /* start history at 0 */

    /* updates communications parameters
    brings out of reset and starts frame exchange
    and loads config regs
    */
    PHYEnableSPMIsr();

    return;
}

/*****
Function: SPMInit
Returns: 1 if ok, 0 if error.
Reference:
Purpose: set up special purpose mode
        Basic approach: Use SPI to tx and rx frames from xcvr.
        The spi bit clock is wired externally to clk3 input
        This is used to clock the scc2 port that generates
        the frame clock.
Comments:
*****/
static int16 SPMInit()
{
    int16 i;
    SDMAConfigReg sdcrTemp; /* for loop counter */
    CPCommandReg crTemp; /* scratch to set up sdcr */
    SCCReceiveBD srbdTemp; /* scratch */
    SCCTransmitBD stbdTemp; /* scratch */
    SCCEventMaskReg sccTemp; /* scratch */
    CIConfigReg cicrTemp; /* scratch to set up cicr */
    SPIEventMaskReg spiemTemp; /* scratch to set up spie or spim*/
    SPIModeReg spmodeTemp; /* scratch to set up spmode */

```



```

/* initialize registers and vectors*/

/* initialize SDMA Config Register */
sdcTemp.frz = 0; /* ignore freeze */
sdcTemp.sism = 7; /* level 7 interrupt mask */
sdcTemp.said = 4; /* level 4 bus arbitration priority */
sdcTemp.inte = 0; /* no error interrupts */
sdcTemp.intb = 0; /* no break interrupts */
*sdcPtrGbl = sdcTemp; /* write out sdcr */

/* set sigr */
sigrPtrGbl->sc2 = 0; /* scc2 in nmsi mode */
sigrPtrGbl->r2cs = 6; /* receive clock from clk3 */
sigrPtrGbl->t2cs = 6; /* transmit clock from clk3 */

/*****
/* initialize SCC2 Port for frame clock*/
/*****
/* initialize RBASE and TBASE in SCC2 Param RAM */
scc2ParamPtrGbl->rbase = (uint16) RBD_BASE_SCC2;
scc2ParamPtrGbl->tbase = (uint16) TBD_BASE_SCC2;

/* initialize other parts of SCC2 parameter ram using CP command */
crTemp.reset = 0; /* no cpm reset */
crTemp.chnum = SCC2_CH_NUM; /* SCC2 Channel */
crTemp.opcode = INIT_TRP_OPCODE; /* init param ram */
crTemp.flag = 1; /* start command */
*crPtrGbl = crTemp; /* write to command register */

#ifndef SIMULATION
/* wait for command to finish */
while ( crPtrGbl->flag == 1)
{
; /* Do nothing */
}
#endif

/* initialize function codes for param ram and buffer length
for scc2 */
/* endian and function code */
scc2ParamPtrGbl->rfcn = (uint8) FCR_INIT;
/* endian and function code */
scc2ParamPtrGbl->tfcn = (uint8) FCR_INIT;
/* max receive buffer length */
scc2ParamPtrGbl->mrblr = (uint16) 2;

/* initialize scc receive buffer descriptors */
srbTemp.e = 1; /* 1 = buffer ready to receive */
srbTemp.w = 0; /* 0 = don't wrap this bd */
srbTemp.i = 0; /* 0 = disable interrupts */
srbTemp.l = 0; /* 0 = not last */
srbTemp.cm = 1; /* 1 = put in continuous mode */
srbTemp.de = 0; /* clear out dpll error*/
srbTemp.no = 0; /* clear out non octet error*/
srbTemp.cr = 0; /* clear out crc error*/
srbTemp.ov = 0; /* clear out receiver overrun error */
srbTemp.cd = 0; /* clear out carrier detect lost error */
srbTemp.dataLen = 0; /* superfluous set by cp */
/* set to first buffer but change below */
srbTemp.dataPtr = &scc2rBufGbl[0][0];

for (i = 0; i < NUM_BD_SCC2; i++) /* loop thru buf descriptors */
{
scc2rbdPtrGbl[i] = srbTemp; /* assign defaults from temp */
/* assign ptr to buffer */
scc2rbdPtrGbl[i].dataPtr = &scc2rBufGbl[i][0];
}
scc2rbdPtrGbl[ NUM_BD_SCC2 - 1 ].w = 1; /* wrap last rbd */

/* initialize scc transmit buffer descriptors */
stbTemp.r = 1; /* 1 = buffer ready to transmit */
stbTemp.w = 0; /* 0 = don't wrap this bd */

```

```

stbdTemp.i = 0; /* 0 = disable interrupts */
stbdTemp.l = 0; /* 0 = not last */
stbdTemp.tc = 0; /* 0 = don't transmit crc */
stbdTemp.cm = 1; /* 1 = put in continuous mode */
stbdTemp.un = 0; /* clear out transmit underrun error */
stbdTemp.ct = 0; /* clear out cts lost error */
stbdTemp.dataLen = 2; /* set to buffer length should be
                        2 bytes */
/* set to first buffer but change below */
stbdTemp.dataPtr = &sc2tBufGb1[0][0];

```

```

for (i = 0; i < NUM_BD_SCC2; i++) /* loop thru buf descriptors */
{
    sc2tbdPtrGb1[i] = stbdTemp; /* assign defaults from temp */
    /* assign ptr to buffer */
    sc2tbdPtrGb1[i].dataPtr = &sc2tBufGb1[i][0];
}
sc2tbdPtrGb1[NUM_BD_SCC2 - 1].w = 1; /* wrap last tbd */

```

```

/* initialize port A and C for SCC2 Transparent mode operation */
padirPtrGb1->dr2 = 0; /* RXD for scc2 */
paparPtrGb1->dd2 = 1; /* rxd connect internal */

```

```

paodrPtrGb1->od3 = 0; /* not open drain for txd */
padirPtrGb1->dr3 = 0; /* TXD for scc2 */
paparPtrGb1->dd3 = 1; /* txd connect internal */

```

```

padirPtrGb1->dr10 = 0; /* clk3 sc2 */
paparPtrGb1->dd10 = 1; /* connect internal */
/* enable rts for scc2 */
pcdirPtrGb1->dr1 = 0;
pcparPtrGb1->dd1 = 1;
/* general purpose io so CD always asserted */
pcdirPtrGb1->dr7 = 1;
pcparPtrGb1->dd7 = 0;
pcsoPtrGb1->cd2 = 0;
/* use cts2 to initiate transmission. configure as gen purpose
io so always asserted low */
pcdirPtrGb1->dr6 = 1;
pcparPtrGb1->dd6 = 0;
pcsoPtrGb1->cts2 = 0; /* configure as low always */

```

```

/* set gsmr */

```

```

gsmrh2PtrGb1->tcrc = 0; /* 16 bit ccitt crc */
gsmrh2PtrGb1->revd = 1; /* 1= send msbit of each byte out first */
gsmrh2PtrGb1->trx = 1; /* receiver in transparent mode */
gsmrh2PtrGb1->ttx = 1; /* transmitter in transparent mode */
gsmrh2PtrGb1->cdp = 1; /* cd pulse mode */
gsmrh2PtrGb1->ctsp = 1; /* cts pulse mode */
gsmrh2PtrGb1->cds = 1; /* cd synchronous mode */
gsmrh2PtrGb1->ctss = 1; /* cts synchronous mode */
gsmrh2PtrGb1->synl = 0; /* receive sync on cd not on
                        sync pattern */
gsmrh2PtrGb1->tfl = 1; /* 1 byte fifo for lower transmit
                        latency */

```

```

gsmr12PtrGb1->diag = 1; /* local loop back for test*/

```

```

/* initialize transparent mode crc type */
sc2ParamPtrGb1->crccp = 0x0000FFFFUL; /* 16 bit CCITT CRC */
sc2ParamPtrGb1->crcc = 0x0000F0B8UL; /* 16 bit CCITT CRC */

```

```

/* clear any previous scc2 interrupt events, write 1 to clear */
scceTemp.glr = 1;
scceTemp.glt = 1;
scceTemp.dcc = 1;
scceTemp.gra = 1;
scceTemp.tx = 1;
scceTemp.rch = 1;
scceTemp.bsy = 1;
scceTemp.tx = 1;
scceTemp.rx = 1;

```

```

*scce2PtrGbl = scceTemp; /* write it out to SCCE2 */

/* enable/disable interrupts write 1 to enable */
scceTemp.glr = 0;
scceTemp.glt = 0;
scceTemp.dcc = 0;
scceTemp.gra = 0;
scceTemp.tx = 0;
scceTemp.rch = 0;
scceTemp.bsy = 0;
scceTemp.tx = 0;
scceTemp.rx = 0;
*sccm2PtrGbl = scceTemp; /* write it out to sccm2 */

/* clear any old scc2 interrupts from CISR */
/* clear by writing 1, spi interrupt in service */
cISRPtrGbl->scc2 = 1;

/* enable/disable system interrupt for spi in CIMR*/
CIMRPtrGbl->scc2 = 0; /* enable by writing 1 */

/*****
/* SPI Port Initialization */
*****/

/* initialize RBASE and TBASE in SPI Param RAM */
/* start of Receive BDs */
spiParamPtrGbl->rbase = (uint16) RBD_BASE;
/* start of transmit BDs */
spiParamPtrGbl->tbase = (uint16) TBD_BASE;

/* initialize other parts of SPI parameter ram using CP command */
crTemp.reset = 0; /* no cpm reset */
crTemp.chnum = SPI_CH_NUM; /* SPI Channel */
crTemp.opcode = INIT_TRP_OPCODE; /* init param ram */
crTemp.flag = 1; /* start command */
*crPtrGbl = crTemp; /* write to command register */

#ifdef SIMULATION
/* wait for command to finish */
while ( crPtrGbl->flag == 1)
{
;
}
#endif

/* initialize function codes for param ram and buffer length*/
/* endian and function code */
spiParamPtrGbl->rfcn = (uint8) FCR_INIT;
/* endian and function code */
spiParamPtrGbl->tfcn = (uint8) FCR_INIT;
/* maximum buffer length */
spiParamPtrGbl->mrblr = (uint16) MAX_BUF_LEN;

/* initialize receive buffer descriptors */
rbdPtrGbl->e = 1; /* 1 = buffer ready to receive */
rbdPtrGbl->w = 1; /* 1 = wrap this bd */
rbdPtrGbl->i = 1; /* 1 = enable interrupts of rxb */
rbdPtrGbl->cm = 1; /* 1 = continuous mode */
rbdPtrGbl->l = 0; /* clear out */
rbdPtrGbl->ov = 0; /* clear out */
rbdPtrGbl->me = 0; /* clear out */
rbdPtrGbl->dataLen = 0; /* superfluous set by cp*/
rbdPtrGbl->dataPtr = &spmGbl.rf; /* assign ptr to buffer */

/* initialize transmit buffer descriptors */
tbdPtrGbl->r = 1; /* 1 = buffer ready to transmit */
tbdPtrGbl->w = 1; /* 1 = wrap this bd */
tbdPtrGbl->i = 0; /* 0 = don't enable interrupts of txb */
tbdPtrGbl->cm = 1; /* 1 = continuous mode */
tbdPtrGbl->l = 1; /* 1 = last */
tbdPtrGbl->un = 0; /* clear out */
tbdPtrGbl->me = 0; /* clear out */

```

```
tbdPtrGbl->dataLen = 2; /* set to buffer length should be 2bytes */
tbdPtrGbl->dataPtr = &spmGbl.tf; /* assign ptr to buffer */
```

```
*****
Initialize Globals Structure for Channel Access Algorithm
and Special Purpose Mode
*****
```

```
/* initialize receive frame buffers just to prevent garbage
   in case out of sync */
spmGbl.rf.setTxFlag = 0; /* frame status not transmitting */
spmGbl.rf.clrTxReqFlag = 0; /* don't clear */
spmGbl.rf.rxDataValid = 0; /* no valid data this frame */
spmGbl.rf.txDataCTS = 0; /* no clear to send */
spmGbl.rf.setCollDet = 0; /* no collision detected */
spmGbl.rf.rxFlag = 0; /* not receiving */
spmGbl.rf.rwAck = 0; /* not acknowledged */
spmGbl.rf.txOn = 0; /* not receiving */
spmGbl.rf.data = 0; /* */
```

```
/* initialize receive frame buffers just to prevent garbage in case */
/* out of sync */
spmGbl.tf.txFlag = 0; /* frame status not transmitting */
spmGbl.tf.txReqFlag = 0; /* don't req */
spmGbl.tf.txDataValid = 0; /* no valid data this frame */
spmGbl.tf.blank = 0; /* unused */
spmGbl.tf.txAddrRW = 0; /* write */
spmGbl.tf.txAddr = 0; /* default address */
spmGbl.tf.data = 0; /* */
```

```
/* Initialize spm global parameters */
```

```
spmGbl.mode = STOP; /* no errors yet */
spmGbl.state = IDLE; /* state machine start state */
macGbl.tpr = FALSE; /* packet not ready to transmit */
macGbl.tc = 0; /* transmit byte count 0 */
macGbl.tl = 0; /* last byte is 0 */
macGbl.rpr = FALSE; /* packet not yet received */
macGbl.rc = 0; /* receive byte count 0 */
macGbl.rl = 0; /* last byte is 0 */
spmGbl.crw = FALSE; /* don't write config register */
spmGbl.cra = 0; /* address zero nothing */
spmGbl.crData = 0; /* empty data */
spmGbl.srr = FALSE; /* don't read from status register */
spmGbl.sra = 0; /* empty address */
spmGbl.srData = 0; /* put nothing in */
spmGbl.resetCount = 0; /* zero to start */
spmGbl.collisionsThisPkt = 0; /* # of collisions this packet */
macGbl.priorityPkt = FALSE; /* FALSE = not a priority packet */
```

```
/* FALSE = channel access algo not complete */
spmGbl.accessApproved = FALSE;
/* TRUE means cycle timer to be reset and started */
spmGbl.cycleTimerRestart = TRUE;
```

```
spmGbl.backlog = 0; /* current channel backlog */
/* delta backlog on current transmit packet */
macGbl.deltaBLTx = 0;
macGbl.deltaBLRx = 0; /* delta backlog on last receive packet */
macGbl.altPathBit = 0; /* alternate path bit */
/* signal to write alternate path bit */
spmGbl.writeAltPathBit = FALSE;
/* alt path bit written state for this pkt */
spmGbl.altPathBitWritten = FALSE;
spmGbl.nodePriority = 0; /* node's priority slot number */
/* comm parameters for this node */
for ( i = 0; i < NUM_COMM_PARAMS; i++)
{
    spmGbl.configData[i] = 0;
}
spmGbl.phase = RANDOM_IDLE; /* Idle for a long time */
spmGbl.kind = POST_RX; /* beta1 time slot type */
```

```

spmGbl.nicstOTicks = 15;          /* conversion factor this specification's
                                   time base to 68 360 ticks */
spmGbl.bitClockRate = 156 250; /* in units of Hz */
spmGbl.beta2Ticks = 0;           /* length of beta2 in 68 360 ticks
                                   40ns each */
spmGbl.beta1Ticks = 0;           /* length of beta1 in 68 360 ticks
                                   40 ns each */
spmGbl.beta1PostTxTicks = 0;     /* length of beta1 in 68 360 ticks
                                   40 ns each */
spmGbl.beta1PostRxTicks = 0;     /* length of beta1 in 68 360 ticks
                                   40 ns each */
spmGbl.baseTicks = 0;            /* duration of wbase in 68 360 ticks
                                   40 ns each */
spmGbl.cycleTicks = 0;           /* duration of avg packet cycle in
                                   68 360 ticks 40 ns each */
spmGbl.priorityChPostTxTicks = 0; /* duration of channel priority
                                   slots */
spmGbl.priorityChPostRxTicks = 0; /* duration of channel priority
                                   slots */
spmGbl.priorityIdleTicks = 0;    /* duration of priority idle wait */
/* duration until node's priority slot */
spmGbl.priorityNodeTicks = 0;
spmGbl.randomTicks = 0;
/* timers for channel access algorithm */
spmGbl.idleTimerStart = 0;
spmGbl.baseTimerStart = 0;
spmGbl.cycleTimerStart = 0;
spmGbl.transmitTimerStart = 0;
spmGbl.elapsed = 0;
spmGbl.stopped = 0;
spmGbl.lastTime = 0;

/* initialize crcGbl for good form */
crcGbl.poly = 0;
crcGbl.crc = 0;
crcGbl.crcBit = 0;
crcGbl.dataBit = 0;
crcGbl.dataByte = 0;

/* initialize port B for SPI Master operation */
/* pin0 = spisel or chip select if single master */
/* pin1 = spiclk clock */
/* pin2 = spimosi master out slave in */
/* pin3 = spimiso master in slave out */
/* pin5 = ~ reset */

pbodrPtrGbl->od0 = 0; /* 0=active driven 1=open drain(3 state), if output */
pbodrPtrGbl->od1 = 0;
pbodrPtrGbl->od2 = 0;
pbodrPtrGbl->od3 = 0;
pbodrPtrGbl->od5 = 0; /* not open drain for reset? */

pbparPtrGbl->dd0 = 0; /* general purpose pin chip select*/
pbparPtrGbl->dd1 = 1; /* internal connect spiclk */
pbparPtrGbl->dd2 = 1; /* internal connect spimosi */
pbparPtrGbl->dd3 = 1; /* internal connect spimiso */
pbparPtrGbl->dd5 = 0; /* general purpose i/o */

pbdirPtrGbl->dr0 = 1; /* output */
pbdirPtrGbl->dr1 = 1; /* output */
pbdirPtrGbl->dr2 = 1; /* output */
/* although input must config as out else brgo4 */
pbdirPtrGbl->dr3 = 1;
pbdirPtrGbl->dr5 = 1; /* output */

/* initialize port B for IO pins : reset switch, manual service request,
ioswitch, and LEDs reset-service and IOLED
pb8 = led reset service
pb9 = general purpose out led
pb12 = reset switch
pb13 = manual service request
pb14 = general purpose in switch

```

*/

```

pbodrPtrGbl->od8 = 0; /* 0 = active driven not open drain */
pbodrPtrGbl->od9 = 0;
/* since input NA, however open drain for pull down */
pbodrPtrGbl->od12 = 1;
/* since input NA, however open drain for pull down */
pbodrPtrGbl->od13 = 1;
/* since input NA, however no pull down */
pbodrPtrGbl->od14 = 0;

```

```

pbparPtrGbl->dd8 = 0; /* general purpose pin chip select*/
pbparPtrGbl->dd9 = 0; /* general purpose pin chip select*/
pbparPtrGbl->dd12 = 0; /* general purpose pin chip select*/
pbparPtrGbl->dd13 = 0; /* general purpose pin chip select*/
pbparPtrGbl->dd14 = 0; /* general purpose pin chip select*/

```

```

pbdirPtrGbl->dr8 = 1; /* output */
pbdirPtrGbl->dr9 = 1; /* output */
pbdirPtrGbl->dr12 = 0; /* input */
pbdirPtrGbl->dr13 = 0; /* input */
pbdirPtrGbl->dr14 = 0; /* input */

```

```

/* set initial values */
pbdatPtrGbl->d8 = 0;
pbdatPtrGbl->d9 = 0;
pbdatPtrGbl->d12 = 1; /* input so NA */
pbdatPtrGbl->d13 = 1; /* input so NA */
pbdatPtrGbl->d14 = 0; /* input so NA */

```

```

/* reset xcvr */
/* driven low to reset hold in reset until change. */
pbdatPtrGbl->d5 = 0;

```

```

/* clear any previous spi interrupt events write 1 to clear */
spiemTemp.mme = 1;
spiemTemp.txr = 1;
spiemTemp.bsy = 1;
spiemTemp.txb = 1;
spiemTemp.rxb = 1;
*spiePtrGbl = spiemTemp; /* write it out to SPIE */

```

```

/* assign address of isr functions to vector table entry */
*spivPtrGbl = &SPMIsr; /* spi isr */
*cerrvPtrGbl = &CErrIsr; /* comm error isr */
*spurintvPtrGbl = &SpurIntIsr; /* spurious interrupt isr */
/* *buserrvPtrGbl = &BusErrIsr; */ /* spurious interrupt isr */

```

```

/* enable interrupts write 1 to enable */
spiemTemp.mme = 0;
spiemTemp.txr = 0;
spiemTemp.bsy = 0;
spiemTemp.txb = 0; /* isr will run after transmit */
spiemTemp.rxb = 1; /* isr will run after receive buffer filled */
*spimPtrGbl = spiemTemp; /* write it out to SPIM */

```

```

/* init CICR register */
cicrTemp.scdp = 3; /* scc4 has priority d */
cicrTemp.sccp = 2; /* scc3 has priority c */
cicrTemp.scbp = 1; /* scc2 has priority b */
cicrTemp.scap = 0; /* scc1 has priority a */
cicrTemp.irl = CPIR_LEVEL; /* level 4 interrupt request level */
cicrTemp.hpi = 31; /* default highest priority = 31 = 1F hex */
cicrTemp.vba = UIVN_MSB; /* user interrupt vector number offset */
cicrTemp.sps = 0; /* use grouped priority scheme */
*cicrPtrGbl = cicrTemp; /* write to cicr */

```

```

/* clear any old SPI interrupts from CISR */
c isrPtrGbl->spi = 1; /* clear by writing 1,
                    spi interrupt in service */
/* enable system interrupt for spi in CIMR */
c isrPtrGbl->spi = 1; /* enable by writing 1 */

```

```

/* init SPMODE register */
spmModeTemp.loop = 0; /* 1 = local loop back
                       0 = no local loop back */
spmModeTemp.ci = 0; /* don't invert clock */
spmModeTemp.cp = 1; /* toggle clock at begin of data transfer */
spmModeTemp.div16 = 0; /* don't divide brgclk by 16 */
spmModeTemp.rev = 1; /* use bigendian MSB first */
spmModeTemp.ms = 1; /* master mode */
spmModeTemp.len = 7; /* 8 bits per character = len + 1 */
spmModeTemp.pms = 4; /* prescale modulus select,
                       4 gives 1,25 Mbit/s */

spmModeTemp.en = 1; /* enable spi */
*spmModePtrGbl = spmModeTemp; /* write to spmode register */

```

```

/* initialize SPCOM (probably don't need to do */
spcomPtrGbl->res = 0; /* should never have to change */
spcomPtrGbl->str = 0; /* superfluous auto cleared one
                       clock cycle after set */

```

```

/*****
Enable interrupts by setting interrupt priority mask level
in Status Register to 0, must use in line assembly code
assumes CPU is in supervisor mode, Bits 10 9 8 are
interrupt priority mask level
*****/

```

```
asm(" ANDI #-0x0700,SR"); /* sets priority mask to level 000 */
```

```

/* Set up frame clock using scc2*/
/* put data into transmit buffer */
scc2tBufGbl[0][0] = 0x01U; /* first byte 7 bit delay
                           to sync frame to spi */
scc2tBufGbl[0][1] = 0x00U; /* second byte */
scc2tbdPtrGbl[0].dataLen = 2; /* send just two bytes */

```

```

/* enable frame clock */
gsmr12PtrGbl->enr = 1; /* receive */
gsmr12PtrGbl->ent = 1; /* transmit */

```

```

return(1);
}

```

```

/*****
Function: MACTimerInit
Returns: pointer to hardware timer counter register
Reference:
Purpose: initialize MAC hardware timer
Comments:
*****/

```

```

uint32 * MACTimerInit(void)
{
    tgcrPtrGbl->cas2 = 1; /* cascade 1 and 2 */
    tgcrPtrGbl->frz2 = 0; /* ignore freeze pin */
    tgcrPtrGbl->stp2 = 0; /* normal unstopped operation */
    tgcrPtrGbl->rst2 = 0; /* reset timer */

    tmr2PtrGbl->ps = 0; /* prescaler */
    tmr2PtrGbl->ce = 0; /* input capture disabled */
    tmr2PtrGbl->om = 0; /* output mode pulse */
    tmr2PtrGbl->ori = 0; /* disable output reference interrupt */
    tmr2PtrGbl->frr = 0; /* 0= free running counter */
    tmr2PtrGbl->iclk = 1; /* 1 = internal general system clk source */
    tmr2PtrGbl->ge = 0; /* tgate is ignored */

```

```

/* set reference to max all ones */
*trr12PtrGbl = (uint32) 0xFFFFFFFF;

```

```
/* writing a 1 resets the reference event bit */
```

```

ter2PtrGb1->ref = 1;
/* writing a 1 resets the capture event bit */
ter2PtrGb1->cap = 1;

*tcn12PtrGb1 = 0; /* start at zero */

tgcrPtrGb1->rst2 = 1; /* start timer running */

return(tcn12PtrGb1);
}

```

```

/*****
Function: DelayTicks
Returns: Boolean state of mac timer running = true stopped = false
Reference:
Purpose: Delay for a "delay" number of ticks
         Used during various startup routines
         to wait for xcvr hardware to respond
Comments:
*****/

```

```

Boolean DelayTicks(uint32 delay)
{
    uint32 start;

    if (tgcrPtrGb1->rst2 == 0)
    {
        /* timer not running so exit immediately with false */
        return (FALSE);
    }
    else
    {
        start = *tcn12PtrGb1;

        while ((*tcn12PtrGb1 - start) < delay)
        {
            ; /* keep waiting */
        }

        return (TRUE);
    }
}

```

```

/*****
Function: PHYSoftResetSPMXCVR
Returns:
Reference:
Purpose: Software reset Special Purpose Mode XCVR by reading
         from register zero
Comments:
*****/

```

```

void PHYSoftResetSPMXCVR(void)
{
    uint16 count;

    spmGb1.sra = 0;
    spmGb1.srr = TRUE;

    count = 0;
    while ((spmGb1.srr != FALSE) && (count < 0xFFFF))
    {
        count++;
    }
    spmGb1.srData = 0;


    return;
}

```

```

/*****
Function: PHYHardResetSPMXCVR

```



Returns:

Reference:

Purpose: hardware reset Special Purpose Mode XCVR by asserting reset pin. then configures xcvr this is used when xcvr hangs in tx_on mode e.g. spmGbl.resetCount times out

Comments:

```
void PHYHardResetSPMXCVR(void)
```

```
{
```

```
    unsigned long count;
```

```
    int i;
```

```
    Boolean good;
```

```
    pbdatPtrGbl->d5 = 0; /* drive xcvr into reset */
```

```
    /* wait for a while for everything to settle down */
    good = DelayTicks(RESTART_DELAY_TICKS);
```

```
    pbdatPtrGbl->d5 = 1; /* bring xcvr out of reset */
```

```
    /* initialize config registers on PLT-20 transceiver */
```

```
    /* load in reverse order */
```

```
    i = NUM_COMM_PARAMS - 1; /* should be 6 */
```

```
    while ( i >= 0)
```

```
    {
```

```
        spmGbl.crData = spmGbl.configData[i];
```

```
        /* config registers start at 7 down to 1 */
```

```
        spmGbl.cra = (Byte) i + 1;
```

```
        spmGbl.crw = TRUE;
```

```
        count = 0;
```

```
        /* wait for ack but time out so not infinite loop */
```

```
        while ((spmGbl.crw != FALSE) && (count < 0xFFFFF))
```

```
        {
```

```
            count++;
```

```
        }
```

```
        if (spmGbl.crw == TRUE) /* xcvr never acked try again */
```

```
        {
```

```
            pbdatPtrGbl->d5 = 0; /* reset xcvr */
```

```
            /* wait for a while for everything to settle down */
```

```
            good = DelayTicks(RESTART_DELAY_TICKS);
```

```
            pbdatPtrGbl->d5 = 1; /* bring xcvr out of reset */
```

```
            i = NUM_COMM_PARAMS - 1; /* start over again */
```

```
        } /* NOTE!!! if the xcvr never acks this code will hang */
```

```
    } else
```

```
    {
```

```
        i--;
```

```
    }
```

```
}
```

```
    spmGbl.crData = 0;
```

```
    spmGbl.cra = 0;
```

```
    return;
```

```
}
```

Function: PHYDisableSPMIsr

Returns:

Reference:

Purpose: To disable the isr temporarily on node reset. Must use PHYEnableIsr to reenble correctly.

Comments:

```
void PHYDisableSPMIsr(void)
```

```

{
  /* once the first line below is executed, the ISR will stop
  running. the next time it runs */
  spmGbl.mode = STOP;

  pbdDatPtrGbl->d5 = 0; /* drive xcvr into reset */

  spmGbl.state = DEBUG;

  macGbl.tpr = FALSE;
  macGbl.tc = 0;
  macGbl.tl = 0;
  macGbl.rpr = FALSE;
  macGbl.rc = 0;
  macGbl.rl = 0;
  spmGbl.crw = FALSE;
  spmGbl.srr = FALSE;
  spmGbl.sra = 0;

  return;
}

/*****
Function: PHYEnableSPMIsr
Returns:
Reference:
Purpose: To Enable the Isr after Being disabled on node reset
        Also to enable on powerup etc.
        Computes clock rates etc based on node comm parameters
Comments:
*****/

void PHYEnableSPMIsr(void)
{
  long i;
  uint32 inputClock;
  uint32 commClock;
  uint32 rxPad;
  uint32 txPad;
  uint32 beta2;
  Boolean good;

  /* compute conversion factor nics_To_Tick */
  /* converts from this specification's time base to 683 660 ticks */
  inputClock = (uint32) eep->configData.inputClock;
  commClock = (uint32) eep->configData.commClock;
  spmGbl.nicsToTicks = NICS_TICKS_BASE >> inputClock;

  /* compute channel access algorithm parameters */

  beta2 = (eep->configData.reserved[2] * 20) + 40;

  /* compute beta1 = postpacket + networkidlewait +
  interpacketpad + prepaket */

  if (eep->configData.reserved[4] < 128)
  {
    rxPad = eep->configData.reserved[4] * 41;
  }
  else
  {
    rxPad = (eep->configData.reserved[4] - 128) * 145;
  }

  if (eep->configData.reserved[3] < 128)
  {
    txPad = eep->configData.reserved[3] * 41;
  }
  else
  {
    txPad = (eep->configData.reserved[3] - 128) * 145;
  }
}

```

```

/* set beta1 time as per formula with implementation
specific adjustment BETA1_ADJUST_TICKS */
spmGbl.beta1PostRxTicks =
    (285 + beta2 + rxPad + 317) * spmGbl.nicsToTicks +
    BETA1_ADJUST_TICKS;
spmGbl.beta1PostTxTicks =
    (307 + beta2 + txPad + 317) * spmGbl.nicsToTicks +
    BETA1_ADJUST_TICKS;

/* set beta2 time as per formula with implementation
specific adjustment BETA2_ADJUST_TICKS */
spmGbl.beta2Ticks =
    beta2 * spmGbl.nicsToTicks + BETA2_ADJUST_TICKS;
spmGbl.baseTicks = spmGbl.beta2Ticks * W_BASE;
/* set cycle time as per formula with implementation
specific adjustment CYCLE_ADJUST_TICKS */
spmGbl.cycleTicks =
    eep->configData.reserved[1] * 1794 * spmGbl.nicsToTicks;

spmGbl.beta1Ticks = 0; /* this is set by isr to either post rx or
post tx beta1 as appropriate */

spmGbl.nodePriority =
    eep->configData.nodePriority; /* set node's priority slot # */

/* Add W Base slots to wait time for post tx access only when there
are non zero number of channel priority slots */
if (eep->configData.channelPriorities > 0)
{
    /* duration of channel priority slots */
    spmGbl.priorityChPostTxTicks = (eep->configData.channelPriorities +
        W_BASE) * spmGbl.beta2Ticks;
    /* duration of channel priority slots */
    spmGbl.priorityChPostRxTicks = eep->configData.channelPriorities
        * spmGbl.beta2Ticks;
}
else
{
    /* duration of channel priority slots */
    spmGbl.priorityChPostTxTicks = 0;
    spmGbl.priorityChPostRxTicks = 0;
}
/* duration of priority idle wait */
spmGbl.priorityIdleTicks = spmGbl.priorityChPostTxTicks;

/* set time of nodes priority slot. If eep->configData.nodePriority is 0,
then this field will be negative, but it is not used in this case. */
spmGbl.priorityNodeTicks =
    (eep->configData.nodePriority - 1) * spmGbl.beta2Ticks;
spmGbl.randomTicks = 0;
spmGbl.bitClockRate = (BIT_CLOCK_BASE << inputClock) >>
    (RATIO_BASE + commClock);

/* make local copy of xcvr parameters so can reset xcvr free of changes to eep
without following node reset. Needed in case xcvr locks up, See
PHYHardResetSPMXCVR(void)
*/
for (i = 0; i < NUM_COMM_PARAMS; i++)
{
    spmGbl.configData[i] = eep->configData.param.xcvrParams[i];
}

```

```

/* reinitialize remainder of spmGbl */
spmGbl.mode = RUN; /* get ready to go */
spmGbl.state = IDLE; /* state machine start state */
macGbl.tpr = FALSE; /* packet not ready to transmit */
macGbl.tc = 0; /* transmit byte count 0 */
macGbl.tl = 0; /* last byte is 0 */
macGbl.rpr = FALSE; /* packet not yet received */
macGbl.rc = 0; /* receive byte count 0 */
macGbl.rl = 0; /* last byte is 0 */
spmGbl.crw = FALSE; /* don't write config register */
spmGbl.cra = 0; /* address zero nothing */
spmGbl.crData = 0; /* empty data */
spmGbl.srr = FALSE; /* don't read from status register */
spmGbl.sra = 0; /* empty address */
spmGbl.srData = 0; /* put nothing in */
spmGbl.resetCount = 0; /* zero to start */
spmGbl.collisionsThisPkt = 0; /* # of collisions this packet */
macGbl.altPathBit = 0; /* alternate path bit */
spmGbl.writeAltPathBit = FALSE; /* signal to write
alternate path bit */
spmGbl.altPathBitWritten = FALSE; /* alt path bit written
state for this pkt */
macGbl.priorityPkt = FALSE; /* FALSE = not a priority packet */

spmGbl.accessApproved = FALSE; /* FALSE = channel access algo
not complete */
spmGbl.cycleTimerRestart = TRUE; /* indicates whether cycle
timer can be updated */

spmGbl.backlog = 0; /* current channel backlog */
macGbl.deltaBLTx = 0; /* delta backlog on curr transmit packet */
macGbl.deltaBLRx = 0; /* delta backlog on last receive packet */
spmGbl.phase = RANDOM_IDLE; /* Idle for a long time */

spmGbl.kind = POST_RX; /* beta1 time slot type */
spmGbl.idleTimerStart = 0;
spmGbl.baseTimerStart = 0;
spmGbl.transmitTimerStart = 0;
spmGbl.elapsed = 0;
/* spmGbl.clock is initialized in PHYInitSPM */
spmGbl.stopped = *(spmGbl.clock);
spmGbl.cycleTimerStart = spmGbl.stopped; /* start up 1st time */
spmGbl.lastTime = spmGbl.stopped;

/* configure bit clock */
/* div16 = 1 and pms = 4 gives 78,125 kHz */
/* div16 = 1 and pms = 3 gives 97,656 kHz */
/* div16 = 1 and pms = 2 gives 130,208 kHz */
/* div16 = 1 and pms = 1 gives 195,312 kHz */
/* div16 = 1 and pms = 0 gives 390,625 kHz */
/* div16 = 0 and pms = 9 gives 625,000 kHz */

```

```

/*****

```

Since this implementation runs in noncontinuous mode the effective frame period is the actual frame period plus the processing time for the ISR at the end of the frame. Therefore we need to run at a higher bit clock than specified by the network management so that the effective frame rate is the same or better than the network manager specifies. For a bit rate of 156,25 kHz the frame period is $16 * 6,4 \mu s = 102,4 \mu s$. Suppose the worst case time for ISR is 58 micro seconds then the time left over for the actual frame is $102,4 - 58 = 44,4 \mu s$. This corresponds to a bit rate of $16 * 1/(44,4 \mu s) = 360,36 \text{ kHz}$. The closest bit rate greater than this that the 360 supports is 390,625 kHz. The effective frame period becomes

58 μ s + (16 * (1/390,625 kHz)) = 98,96 μ s. This is faster so OK. Effective bit rate is 16 * 1/(98,96 μ s) = 161,68 kHz. Unless we can more than half the time for the ISR to run we can't run fast enough to make the next step that is the 312,5 kHz bit rate.

*****/

```

switch (spmGbl.bitClockRate)
{
  case 78125:
    /* run at 130 kHz to get same or faster effective rate */
    spmodePtrGbl->div16 = 1; /* divide by 16 */
    spmodePtrGbl->pms = 2; /* prescale modulus select */
    break;
  case 156250:
    /* run at 390 kHz to get same or faster effective rate */
    spmodePtrGbl->div16 = 1; /* divide by 16 */
    spmodePtrGbl->pms = 0; /* prescale modulus select */
    break;
  default:
    /* 156 250 */
    /* run at 390 kHz to get same or faster eff rate */
    spmodePtrGbl->div16 = 1; /* divide by 16 */
    spmodePtrGbl->pms = 0; /* prescale modulus select */
    break;
}

/* reinitialize receive frame buffers */
spmGbl.rf.setTxFlag = 0; /* frame status not transmitting */
spmGbl.rf.clrTxReqFlag = 0; /* don't clear */
spmGbl.rf.rxDataValid = 0; /* no valid data this frame */
spmGbl.rf.txDataCTS = 0; /* no clear to send */
spmGbl.rf.setCollDet = 0; /* no collision detected */
spmGbl.rf.rxFlag = 0; /* not receiving */
spmGbl.rf.rwAck = 0; /* not acknowledged */
spmGbl.rf.txOn = 0; /* not receiving */
spmGbl.rf.data = 0; /* */

/* reinitialize receive frame buffers */
spmGbl.tf.txFlag = 0; /* frame status not transmitting */
spmGbl.tf.txReqFlag = 0; /* don't req */
spmGbl.tf.txDataValid = 0; /* no valid data this frame */
spmGbl.tf.blank = 0; /* unused */
spmGbl.tf.txAddrRW = 0; /* write */
spmGbl.tf.txAddr = 0; /* default address */
spmGbl.tf.data = 0; /* */

/* initialize crcGbl for good form */
crcGbl.poly = 0;
crcGbl.crc = 0;
crcGbl.crcBit = 0;
crcGbl.dataBit = 0;
crcGbl.dataByte = 0;

/* Send First Frame ISR keeps it going */
tbdPtrGbl->r = 1; /* buffer ready to transmit */
spcomPtrGbl->str = 1;

/* wait for a while for everything to settle down */
good = DelayTicks(RESTART_DELAY_TICKS);

PHYHardResetSPMXCVR(); /* this also writes config registers */

return;
}

/*****
Function: PHYIOInit
Returns: None
Reference: None

```

Purpose: To Init variables related to PHYIO function.

Comments: None

void PHYIOInit(void)

```
{
    SetMsTimer(&phyIOTimer, (uint16)(PHYIO_CHECK_INTERVAL * 1 000));
    gp->resetPinPrevState = 1; /* Allow Reset Button Push */
    gp->manualServiceRequestPrevState = 1; /* Allow Manual Service Request Push */
    gp->ioInputPin0PrevState = 1;
}
```

Function: PHYIO

Returns: None

Reference: None

Purpose: To handle Input switches (reset service and IO) and to set value of output leds
Manual Service Request and Reset pin share same LED to indicate switch pushed

Comments: None

void PHYIO(void)

```
{
    /* Perform Pin related checks only on timer expiry
    to avoid bounce problem */
    if (MsTimerExpired(&phyIOTimer))
    {
        /* check reset switch */
        /* reset pulled low &&
        reset not enabled so need to enable &&
        have not yet set this pin push */
        if (( pbdPtrGbl->d12 == 0) &&
            !gp->resetNode &&
            (gp->resetPinPrevState != 0))
        {
            gp->resetNode = TRUE; /* signal scheduler there is reset */
            nmp->resetCause = EXTERNAL_RESET;
            /* NodeReset function will clear when reset is finished */
            /* prevents sending more than 1 reset until pin is toggled */
            gp->resetPinPrevState = 0;
        }

        /* reset pin high */
        if (pbdPtrGbl->d12 == 1)
        {
            gp->resetPinPrevState = 1;
        }

        if ((pbdPtrGbl->d13 == 0) && /* manual service request pulled low */
            !gp->manualServiceRequest && /* manualServiceRequest not enabled */
            (gp->manualServiceRequestPrevState != 0)) /* have not yet set
            this pin push */
        {
            gp->manualServiceRequestPrevState = 0;
            gp->manualServiceRequest = TRUE; /* notify stack that
            manual service request enabled */
        }

        if (pbdPtrGbl->d13 == 1) /* manual service request high */
        {
            gp->manualServiceRequestPrevState = 1; /* manual service request toggled
            so next press will allow push */
        }

        if(pbdPtrGbl->d14 == 1 &&
            (gp->ioInputPin0PrevState != 0)) /* debouncer, check
            gen purpose io input */
        {
            gp->ioInputPin0 = 1;
        }
        else
        {

```

```

    gp->ioInputPin0 = 0;
}

if (pbdatPtrGbl->d14 == 1) /* io pin high */
{
    gp->ioInputPin0PrevState = 1; /* io pin toggled so next
    press will allow push */
}

SetMSTimer(&phyIOTimer,
           (uint16)(PHYIO_CHECK_INTERVAL * 1 000));
}

if (gp->resetNode || gp->manualServiceRequest || gp->ioOutputPin0)
{
    pbdatPtrGbl->d8 = 1; /* turn on reset-service light */
}
else
{
    pbdatPtrGbl->d8 = 0; /* turn off reset-service light */
}

if(gp->ioOutputPin1 == 0) /* set io output pin */
{
    pbdatPtrGbl->d9 = 0;
}
else
{
    pbdatPtrGbl->d9 = 1;
}

return;
}

```

```

/*****
Function: IncrementBacklog
Returns:
Reference:
Purpose: increments backlog and handles backlog overflow
Comments:
*****/

```

```

static void IncrementBacklog(uint8 deltaBacklog)
{
    if (deltaBacklog > MAX_BACKLOG)
    {
        return; /* Erroneous deltaBacklog value */
    }
    /* spmGbl.backlog size must allow 2 * MAX_BACKLOG without
    wrap around */
    spmGbl.backlog += deltaBacklog;
    if (spmGbl.backlog > MAX_BACKLOG)
    {
        spmGbl.backlog = MAX_BACKLOG;
        INCR_STATS(nmp->stats.backlogOverflow);
    }
}

```

```

/*****
Function: DecrementBacklog
Returns:
Reference:
Purpose: decrements backlog and handles backlog underflow
Comments:

```

```

*****/
static void DecrementBacklog(uint8 deltaBacklog)
{
    if (deltaBacklog > MAX_BACKLOG)
    {
        return; /* Erroneous deltaBacklog value */
    }
    if (spmGbl.backlog <= deltaBacklog)
    {
        spmGbl.backlog = 0;
    }
    else
    {
        spmGbl.backlog -= deltaBacklog;
    }
}

```

```

/*****
Function: SPMIsr
Returns: none, no arguments allowed either
Reference:
Purpose:
    Interrupt Service Routine

```

This ISR serves two primary functions. the first is to execute the channel access algorithm. the second is to performs the special purpose mode transfers with the XCVR. For the channel access algorithm a single hardware timer is used as reference for a set of global values that are the expire times for the various channel access algorithm timers. The ISR polls the hardware timer each time the ISR runs and checks for expiration of the various timers. The ISR has two coupled state machines. the first indicated by spmGbl.phase controls the channel access algorithm and the second indicated by spmGbl.state controls the SPM transfers.

The ISR runs after each 16 SPI transfers or clock transitions. An Interrupt is generated by an rxb event when a receive buffer is full.

```

Comments: must use interrupt pragma
*****/
/* interrupt pragma informs compiler to make next function
   an interrupt handler with RTE and saved state of registers */

#pragma interrupt()

static void SPMIsr()
{
    SPIEventMaskReg spieTemp; /* local copy of event register */
    int j; /* for loop index */

    spieTemp = *spiePtrGbl; /* read SPIE into local copy */

    /* clear spie ASAP so as not to miss any events while in isr */
    /* write all ones to clear */
    *(uint8 *) spiePtrGbl = (uint8) 0xFFU;

    /* each event handled by this isr needs a separate if statement */
    if ( spieTemp.rxb == 1)
    {
        /* handle interrupt for receive buffer filled */
        /* transfer can be stopped by physical layer or for error */

```

```

if (spmGbl.mode == STOP) /* stop spm exchanges */
{
    spmGbl.state = DEBUG;
    macGbl.tc = 0;
    macGbl.tl = 0;
    macGbl.tpr = FALSE;
    macGbl.rc = 0;
    macGbl.rl = 0;
    macGbl.rpr = FALSE;
    spmGbl.crw = FALSE;
    spmGbl.srr = FALSE;
}
else /* State Machines for Transmit and Receive */
{
    /* debug */
    /* last received frame is in spmGbl.rf */
    /* update history for debugging purposes*/
#ifdef SPM_HISTORY
    hBufGbl.records[hBufGbl.index].rf = spmGbl.rf;
    hBufGbl.records[hBufGbl.index].state = spmGbl.state;
    hBufGbl.records[hBufGbl.index].rb = spiParamPtrGbl->rbptr;
    hBufGbl.records[hBufGbl.index].tb = spiParamPtrGbl->tbptr;

    hBufGbl.records[hBufGbl.index].start = *(spmGbl.clock);
#endif

    /* state machine for channel access algorithm */
    switch (spmGbl.phase)
    {
        case BUSY: /* some node is transmitting */
            /* waits here until channel is idle */

            if ((spmGbl.rf.rxFlag == 0) &&
                (spmGbl.rf.txOn == 0))
            {
                /* channel has become idle neither receive or transmit */
                /* start idle timer */
                spmGbl.idleTimerStart = *(spmGbl.clock);

                /* set betal duration based on last packet,
                either rx or tx */
                if (spmGbl.kind == POST_RX)
                {
                    spmGbl.betalTicks = spmGbl.betalPostRxTicks;
                    spmGbl.priorityIdleTicks = spmGbl.priorityChPostRxTicks;
                }
                else
                {
                    spmGbl.betalTicks = spmGbl.betalPostTxTicks;
                    spmGbl.priorityIdleTicks = spmGbl.priorityChPostTxTicks;
                }

                /* Previous Packet has ended so reset altPathBit flags.
                Once tpr goes true then we will know to write
                altPathBit once before tx */
                spmGbl.writeAltPathBit = FALSE;
                spmGbl.altPathBitWritten = FALSE;

                /* start waiting out betal time */
                spmGbl.phase = BETAL_IDLE;
            }
            else /* channel still busy */

```

```
{
    if (spmGbl.rf.rxFlag == 1)
    {
        /* busy receiving packet */
        spmGbl.kind = POST_RX;
    }
    else
    {
        /* busy transmitting packet */
        spmGbl.kind = POST_TX;
    }

    spmGbl.phase = BUSY;
}
break;
case BETA1_IDLE: /* waits out beta1 time */

    if ((spmGbl.rf.rxFlag == 1) ||
        (spmGbl.rf.txOn == 1))
    {
        /* channel is now busy */
        /* other node must have used channel or
           xcvr is in error with bad txOn*/

        spmGbl.phase = BUSY;
    }
    else if ((macGbl.tpr == TRUE) &&
             (spmGbl.writeAltPathBit == FALSE) &&
             (spmGbl.state == IDLE)) /*in case doing status register
                                       read*/
    {
        /* tx packet is ready */
        /* always do unconfirmed write
           of altPathBit before tx */
        spmGbl.writeAltPathBit = TRUE;

        /* wait until next frame before begin channel
           access */
        spmGbl.phase = BETA1_IDLE;
    }
    else
    {
        /* check idle timer to see if beta1 time expired */
        spmGbl.elapsed =
            *(spmGbl.clock) - spmGbl.idleTimerStart;

        if (spmGbl.elapsed >= spmGbl.beta1Ticks )
        {
            /* idle timer expired */
            /* check if transmit packet is still ready and
               set priority access type */
            /* conditions for priority access
               Packet marked as priority
               Collisions less than 2
               Node has a priority slot
               Only after received packet
               only after valid crc on last received pkt
            */
            if ( (macGbl.tpr == TRUE) &&
                (macGbl.priorityPkt == TRUE) &&
                (spmGbl.kind == POST_RX) && /* only after rx */
                (spmGbl.collisionsThisPkt <= 1) &&
                (spmGbl.nodePriority > 0) &&
```




```

        spmGbl.transmitTimerStart = spmGbl.idleTimerStart +
                                     spmGbl.beta1Ticks +
                                     spmGbl.priorityIdleTicks;
        /* start base timer */
        /* base timer runs when waiting for randomized */
        /* tx access */

        /* spmGbl.baseTimerStart = spmGbl.idleTimerStart +
                                     spmGbl.beta1Ticks +
                                     spmGbl.priorityIdleTicks; */

        spmGbl.baseTimerStart = spmGbl.transmitTimerStart;
        /* faster way */

        /* change seed */
        srand((unsigned int) spmGbl.transmitTimerStart);

        /* attempt random slot access */
        /* random slot between 0 and backlog * wbase - 1*/

        spmGbl.randomTicks = (rand() % ((spmGbl.backlog + 1) *
                                         W_BASE)) * spmGbl.beta2Ticks ;

        spmGbl.phase = RANDOM_WAIT_TX; /* go wait for slot */
    }
    else /* priority idle timer has expired but transmit */
        /* packet is not ready */
    {
        spmGbl.phase = RANDOM_IDLE; /* go wait */
    }
}
else /*timer not elapsed so keep waiting for end of priority
     slots*/
{
    spmGbl.phase = PRIORITY_IDLE;
}
}
break;
case RANDOM_IDLE:
    if ((spmGbl.fixFlag == 1) || (spmGbl.rf.txOn == 1)) /* busy */
    {
        /* other node must have used channel or
           xcvr is in error with bad txOn*/
        spmGbl.phase = BUSY;
    }
    else if ((macGbl.tpr == TRUE) && /* tx packet ready */
             (spmGbl.writeAltPathBit == FALSE) &&
             (spmGbl.state == IDLE)) /*in case doing status register
                                     read*/
    {
        /* always do unconfirmed write of altPathBit before tx */
        spmGbl.writeAltPathBit = TRUE;

        /* have to wait until next frame to start channel access */
        spmGbl.phase = RANDOM_IDLE;
    }
    else
    {
        /* check if transmit packet still ready */
        if ( (macGbl.tpr == TRUE) &&
             (spmGbl.state == IDLE) ) /* in case doing status register
                                     read /
        {
            spmGbl.transmitTimerStart = *(spmGbl.clock); /* start */

```



```

/* transmit */
/* timer */

/* base timer runs when waiting for randomized tx access */
/* start base timer */
spmGbl.baseTimerStart = spmGbl.transmitTimerStart;

srand((unsigned int) spmGbl.transmitTimerStart); /*change */
/* seed*/

/* attempt random slot access */
/* random slot between 0 and backlog * wbase - 1*/
spmGbl.randomTicks = (rand() % ((spmGbl.backlog + 1) *
W_BASE)) * spmGbl.beta2Ticks;

spmGbl.phase = RANDOM_WAIT_TX; /* go wait for slot */
}
else
{
spmGbl.phase = RANDOM_IDLE; /* nothing to send keeping */
/* waiting */
}
}
break;
case PRIORITY_WAIT_TX:
if ((spmGbl.rf.rxFlag == 1) || (spmGbl.rf.txOn == 1)) /* busy */
{
/* other node must have used channel or
xcvr is in error with bad txOn*/
spmGbl.phase = BUSY;
}
else
{
/* check tx timer wait for our priority slot to come up*/
spmGbl.elapsed = *(spmGbl.clock) - spmGbl.transmitTimerStart;
if (spmGbl.elapsed >= spmGbl.priorityNodeTicks)
{
/* approve transmission */
spmGbl.accessApproved = TRUE; /* enable spm state machine */
/* to begin tx */
spmGbl.phase = START_TX;
}
else
{
spmGbl.phase = PRIORITY_WAIT_TX;
}
}
break;
case RANDOM_WAIT_TX:
if ((spmGbl.rf.rxFlag == 1) || (spmGbl.rf.txOn == 1)) /* busy */
{
/* other node must have used channel or
xcvr is in error with bad txOn*/
spmGbl.phase = BUSY;
}
else
{
/* Get current time. Since used for two checks we want */
/* to be synchronized */
spmGbl.stopped = *(spmGbl.clock);

/* check tx timer wait for out random slot to come up */
spmGbl.elapsed = spmGbl.stopped - spmGbl.transmitTimerStart;

```

```

if (spmGbl.elapsed >= spmGbl.randomTicks)
{
/* approve transmission */
spmGbl.accessApproved = TRUE; /* enable spm state machine to
begin tx */
spmGbl.phase = START_TX;
}
else
{
spmGbl.phase = RANDOM_WAIT_TX;
}

/* check base timer, base timer running when we do random
slot access */
/* remember baseTimerStart is the same as transmitTimerStart */
/*only on the first iteration */
spmGbl.elapsed = spmGbl.stopped - spmGbl.baseTimerStart;
if (spmGbl.elapsed >= spmGbl.baseTicks)
{
spmGbl.baseTimerStart = spmGbl.stopped; /* restart base */
/* timer */
DecrementBacklog(1); /* decrement back log */
}
}
break;
case START_TX:
if ((spmGbl.rf.rxFlag == 1) || (spmGbl.rf.txOn == 1)) /* channel */
/* busy */
{
/* other node must have used channel or packet has started */
spmGbl.accessApproved = FALSE;
spmGbl.phase = BUSY;
}
else
if ( macGbl.tpr == FALSE) /* macGbl.tpr == FALSE packet */
/* cancelled */
{
spmGbl.accessApproved = FALSE; /* deny access */
spmGbl.phase = RANDOM_IDLE; /* back to idle */
}
else
spmGbl.phase = START_TX;
}

/* check base timer on more time in case expires while waiting
for txOn. only if non priority slot access */

spmGbl.stopped = *(spmGbl.clock);
spmGbl.elapsed = spmGbl.stopped - spmGbl.baseTimerStart;
if (spmGbl.elapsed >= spmGbl.baseTicks)
{
spmGbl.baseTimerStart = spmGbl.stopped; /* restart base */
/* timer */
DecrementBacklog(1); /* decrement back log */
}
}
break;

```

```

    default:
        spmGbl.phase = RANDOM_IDLE;
        break;
} /* End access algo switch */

/* Cycle Timer only runs when the Mac Layer is Idle that is when
the node is not transmitting or receiving or waiting to transmit
or counting down beta1 or counting down priority slots or counting
down the extra 16 beta2 slots after a transmission
This directly corresponds to the Phase RANDOM_IDLE

Anytime the MAC layer is busy ie in some phase other than RANDOM_IDLE
then the cycle timer stops. The cycle timer will then resume when the
mac layer returns to the RANDOM_IDLE phase. The cycle timer is reset
when spmGbl.cycleTimerRestart == TRUE. This is set to true
1) following a successful transmission
2) following a valid crc receive

We use a time difference between the current value of the hardware
timer and the stored value when we started the cycleTimer to determine
when the cycleTimer expires.
Since the hardware timer is free running and does not stop when
the cycle timer stops , we must keep shifting the
cycleTimerStart forward whenever the cycleTimer is stopped. This keeps
the relative time difference correct so that when it resumes
the expiration calculation will be valid.
*/

spmGbl.stopped = *(spmGbl.clock);
if ( (spmGbl.phase == RANDOM_IDLE) ) /* cycle timer is running */
{
    spmGbl.elapsed = spmGbl.stopped - spmGbl.cycleTimerStart;

    if (spmGbl.cycleTimerRestart) /* cycle timer needs to be restarted */
    {
        spmGbl.cycleTimerStart = spmGbl.stopped;
        spmGbl.cycleTimerRestart = FALSE;
    }
    else if (spmGbl.elapsed >= spmGbl.cycleTicks)
    {
        spmGbl.cycleTimerStart = spmGbl.stopped; /* restart */
        DecrementBacklog(1);
    }
}
else /* shift cycleTimerStart forward since cycle timer stopped */
{
    spmGbl.cycleTimerStart += spmGbl.stopped - spmGbl.lastTime;
}
spmGbl.lastTime = spmGbl.stopped; /* save last stopped value */

/*****
End Channel Access Algorithm State machine
*****/

/*****
Begin SPM Transfer State Machine
*****/
/* state machine for handshaking with xcvr*/
switch ( spmGbl.state)
{

    case IDLE:
        if ( spmGbl.rf.rxFlag == 1) /* XCVR has detected packet to */

```

```

        /* receive */
        {
            macGbl.rc = 0; /* init receive byte count */
            macGbl.rl = 0;
            if ( macGbl.rpr == TRUE ) /* last packet not copied out */
            {
                spmGbl.mode = OVERWRITE; /* stepped on last packet */
                macGbl.rpr = FALSE; /* what else to do ? */
            }
        }

        /* initialize crc stuff */
        crcGbl.poly = 0x1 021;
        crcGbl.crc = 0xffff;
        crcGbl.crcBit = 0;
        crcGbl.dataBit = 0;
        crcGbl.dataByte = 0;

        /*
            spmGbl.tf.txFlag = 0;
            spmGbl.tf.txReqFlag = 0;
            spmGbl.tf.txDataValid = 0;
            spmGbl.tf.blank = 0;
            spmGbl.tf.txAddrRW = 0;
            spmGbl.tf.txAddr = 0;
            spmGbl.tf.data = 0;
        */

        *((uint16 *)&(spmGbl.tf)) = (uint16) 0x0U; /* fast way */
        spmGbl.state = RECEIVE;
    }
    else if ( spmGbl.rf.txOn == 1 ) /* XCVR xmitting on network so */
    /* don't do anything */
    {
        /*
            spmGbl.tf.txFlag = 0;
            spmGbl.tf.txReqFlag = 0;
            spmGbl.tf.txDataValid = 0;
            spmGbl.tf.blank = 0;
            spmGbl.tf.txAddrRW = 0;
            spmGbl.tf.txAddr = 0;
            spmGbl.tf.data = 0;
        */

        *((uint16 *)&(spmGbl.tf)) = (uint16) 0x0U; /* fast way */

        /* increment reset count */
        spmGbl.resetCount ++;
        if (spmGbl.resetCount >= RESET_COUNT_LIMIT)
        {
            PHYHardResetSPMXCVR();
        }

        spmGbl.state = IDLE;
    }
    else if (( spmGbl.writeAltPathBit) && (!spmGbl.altPathBitWritten))
    {
        /* need to write alt path bit unacked write */
        /*
            spmGbl.tf.txFlag = 0;
            spmGbl.tf.txReqFlag = 0;
            spmGbl.tf.txDataValid = 0;
            spmGbl.tf.blank = 0;
            spmGbl.tf.txAddrRW = 0;
        */
    }

```

```

        spmGbl.tf.txAddr = 1;
        spmGbl.tf.data = spmGbl.configData[0];
        */

        *((uint8 *)&(spmGbl.tf)) = (uint8) 1; /* fast way */
        if (macGbl.altPathBit == 1)
        {
            *((uint8 *)&(spmGbl.tf.data)) =
                (uint8) ( 0x80 | spmGbl.configData[0]); /* fast way */
        }
        else
        {
            *((uint8 *)&(spmGbl.tf.data)) = (uint8) ( 0x7F &
                spmGbl.configData[0]);
        }
        spmGbl.altPathBitWritten = TRUE;
        spmGbl.state = IDLE;
    }
    else if ((macGbl.tpr == TRUE) && /* transmit packet ready */
        (spmGbl.accessApproved == TRUE)) /* channel access */
        /* approved */
    {
        /*
        spmGbl.tf.txFlag = 0;
        spmGbl.tf.txReqFlag = 1;
        spmGbl.tf.txDataValid = 0;
        spmGbl.tf.blank = 0;
        spmGbl.tf.txAddrRW = 0;
        spmGbl.tf.txAddr = 0;
        spmGbl.tf.data = 0;
        */

        *((uint16 *)&(spmGbl.tf)) = (uint16) 0x4 000U; /* fast way */

        macGbl.tc = 0;
        spmGbl.state = REQ_TX;
    }

    else if ( (spmGbl.crw == TRUE) && /* config register write */
        (spmGbl.cra > 0) && /* 0 < config reg address <= 7 */
        (spmGbl.cra <= 7) )
    {
        /*
        spmGbl.tf.txFlag = 0;
        spmGbl.tf.txReqFlag = 0;
        spmGbl.tf.txDataValid = 0;
        spmGbl.tf.blank = 0;
        spmGbl.tf.txAddrRW = 0;
        spmGbl.tf.txAddr = spmGbl.cra;
        spmGbl.tf.data = spmGbl.crData;
        */

        *((uint8 *)&(spmGbl.tf)) = (uint8) spmGbl.cra; /* fast way */
        *((uint8 *)&(spmGbl.tf.data)) = (uint8) spmGbl.crData; /*fast */
        /* way */

        spmGbl.state = WRITE;
    }
    else if ( (spmGbl.srr == TRUE) && /* status register read */
        (spmGbl.sra >= 0) && /* 0 < status reg address <= 7 */
        (spmGbl.sra <= 7) )
    {
        spmGbl.tf.txFlag = 0;
    }

```

```

        spmGbl.tf.txReqFlag = 0;
        spmGbl.tf.txDataValid = 0;
        spmGbl.tf.blank = 0;
        spmGbl.tf.txAddrRW = 1;
        spmGbl.tf.txAddr = spmGbl.sra;
        spmGbl.tf.data = 0;

        spmGbl.state = READ;
    }
    else /* Nothing can be done just wait */
    {
        /*
        spmGbl.tf.txFlag = 0;
        spmGbl.tf.txReqFlag = 0;
        spmGbl.tf.txDataValid = 0;
        spmGbl.tf.blank = 0;
        spmGbl.tf.txAddrRW = 0;
        spmGbl.tf.txAddr = 0;
        spmGbl.tf.data = 0;
        */
    }

    *((uint16 *)&(spmGbl.tf)) = (uint16) 0x00; /* fast way */
    spmGbl.state = IDLE;
}
break;
case RECEIVE:
/*
spmGbl.tf.txFlag = 0;
spmGbl.tf.txReqFlag = 0;
spmGbl.tf.txDataValid = 0;
spmGbl.tf.blank = 0;
spmGbl.tf.txAddrRW = 0;
spmGbl.tf.txAddr = 0;
spmGbl.tf.data = 0;
*/

*((uint16 *)&(spmGbl.tf)) = (uint16) 0x00; /* fast way */

if (spmGbl.rf.rxFlag == 0) /* packed ended */
{
    macGbl.rl = macGbl.rc; /* set last byte count */
    /* is packet of valid length */
    if ((macGbl.rl >= 8) && /* minimum valid packet is 8 bytes */
        (macGbl.rl < PKT_BUF_LEN) ) /* must be less than buffer */
    {
        /* do last step of crc */
        crcGbl.crc = crcGbl.crc ^ 0xffff;

        /* is crc valid */
        if ( crcGbl.crc == (*((uint16 *) &macGbl.rPkt[macGbl.rl -
2])) )
        {
            /* copy out backlog */
            macGbl.deltaBLRx = macGbl.rPkt[0] & 0x3F;

            /* update cycle timer and set flag */
            if (macGbl.deltaBLRx <= 0)
            {
                DecrementBacklog(1);
            }
            else
            {
                IncrementBacklog(macGbl.deltaBLRx);
            }
        }
    }
}

```

```

}
/* Cycle Timer needs to be restarted after valid crc rx */
spmGbl.cycleTimerRestart = TRUE;

/* Attempt to copy packet into Link Layer receive Queue */
if ( (*gp->lkInQTailPtr == 0) && /* == 0 means free */
      /* buffer big enough for packet */
      (gp->lkInBufSize >= macGbl.rl + 3) )
{
  /* Copy the packet to link layer input queue */
  *(uint16 *) (gp->lkInQTailPtr + 1) = (uint16) macGbl.rl;
  /* copy length */
  memcpy(gp->lkInQTailPtr + 3, macGbl.rPkt, macGbl.rl);
  /* Update Link Layer Input Queue Fields */
  *gp->lkInQTailPtr = 1; /*lets link layer know packet */
  /* is ready to process */
  gp->lkInQTailPtr += gp->lkInBufSize;
  if (gp->lkInQTailPtr ==
      gp->lkInQ + gp->lkInBufSize * gp->lkInQCnt)
  { /* past end of queue */
    gp->lkInQTailPtr = gp->lkInQ; /* wrap to */
    /* beginning */
  }
}
else /* packet discarded */
{
  /* Discard packet as either there is no buffer */
  /* available or it is too big for buffer */
  INCR_STATS(nmp->stats.missedMessages); /* update */
  /*stats */
}
}
else /* invalid crc */
{
  /* update stats for bad crc packet */
  INCR_STATS(nmp->stats.transmissionErrors);
}
}
else /* update stats invalid packet length */
{
  INCR_STATS(nmp->stats.transmissionErrors);
}
}

/* Reset macGbl's receive packet fields */
macGbl.rc = 0; /* reinit to be safe */
macGbl.rl = 0;
macGbl.rpr = FALSE; /* ready to receive another packet */

spmGbl.state = IDLE; /* all done */
}
else if (spmGbl.rf.rxDataValid == 1) /* valid byte this frame */
{
  if (macGbl.rc < PKT_BUF_LEN) /* don't go past end of buffer */
  {
    macGbl.rPkt[macGbl.rc] = spmGbl.rf.data; /* copy out byte */
    macGbl.rc++; /* increment counter */

    /* do 1 byte of crc. Delay by two bytes so we do not computer
    crc on the two crc bytes in the packet itself */
    if (macGbl.rc >= 3)
    {
      /* make copy of byte */
      crcGbl.dataByte = macGbl.rPkt[macGbl.rc - 3];
      for (j = 0; j < 8; j++)

```

```

    {
        crcGbl.crcBit = (crcGbl.crc & 0x8 000) ? 1 : 0;
        crcGbl.dataBit = (crcGbl.dataByte & 0x80) ? 1 : 0;
        crcGbl.dataByte = crcGbl.dataByte << 1;
        crcGbl.crc = crcGbl.crc << 1;
        if ( crcGbl.crcBit != crcGbl.dataBit)
        {
            crcGbl.crc = crcGbl.crc ^ crcGbl.poly;
        }
    }
}
}

    spmGbl.state = RECEIVE; /* look for more */
}
else /* no valid data but still receiving */
{
    spmGbl.state = RECEIVE; /* keep looking */
}
break;
case WRITE:
    if ( spmGbl.rf.rxFlag == 1) /* XCVR has detected packet to */
        /* receive */
    {
        macGbl.rc = 0; /* init receive byte count */
        macGbl.rl = 0;
        if ( macGbl.rpr == TRUE ) /* last packet not copied out */
        {
            spmGbl.mode = OVERWRITE; /* stepped on last packet */
            macGbl.rpr = FALSE; /* what else to do ? */
        }
    }

    /* initialize crc stuff */
    crcGbl.poly = 0x1 021;
    crcGbl.crc = 0xffff;
    crcGbl.crcBit = 0;
    crcGbl.dataBit = 0;
    crcGbl.dataByte = 0;

    /*
    spmGbl.tf.txFlag = 0;
    spmGbl.tf.txReqFlag = 0;
    spmGbl.tf.txDataValid = 0;
    spmGbl.tf.blank = 0;
    spmGbl.tf.txAddrRW = 0;
    spmGbl.tf.txAddr = 0;
    spmGbl.tf.data = 0;
    */

    *((uint16 *)&(spmGbl.tf)) = (uint16) 0x0U; /* fast way */

    spmGbl.state = RECEIVE;
}
else if ((spmGbl.rf.rwAck == 0) && /* still not written */
        (spmGbl.crw == TRUE) &&
        (spmGbl.cra > 0) && /* 0< config reg address */
        /* <=7 */
        (spmGbl.cra <= 7) )
{
    /*
    spmGbl.tf.txFlag = 0;
    spmGbl.tf.txReqFlag = 0;

```

```

        spmGbl.tf.txDataValid = 0;
        spmGbl.tf.blank = 0;
        spmGbl.tf.txAddrRW = 0;
        spmGbl.tf.txAddr = spmGbl.cra;
        spmGbl.tf.data = spmGbl.crData;
        */

        *((uint8 *)&(spmGbl.tf)) = (uint8) spmGbl.cra; /* fast way */
        *((uint8 *)&(spmGbl.tf.data)) = (uint8) spmGbl.crData; /*fast */
                                                /* way */

        spmGbl.state = WRITE; /* try again */
    }
    else /* write successful or recalled */
    {
        spmGbl.crw = FALSE;

        /*
        spmGbl.tf.txFlag = 0;
        spmGbl.tf.txReqFlag = 0;
        spmGbl.tf.txDataValid = 0;
        spmGbl.tf.blank = 0;
        spmGbl.tf.txAddrRW = 0;
        spmGbl.tf.txAddr = 0;
        spmGbl.tf.data = 0;
        */

        *((uint16 *)&(spmGbl.tf)) = (uint16) 0x0U; /* fast way */

        spmGbl.state = IDLE;
    }
    break;
case READ:
    if ( spmGbl.rf.rxFlag == 1) /* XCVR has detected packet to */
        /* receive */
    {
        macGbl.rc = 0; /* init receive byte count */
        macGbl.rl = 0;
        if ( macGbl.rpr == TRUE ) /* last packet not copied out */
        {
            spmGbl.mode = OVERWRITE; /* stepped on last packet */
            macGbl.rpr = FALSE; /* what else to do ? */
        }

        /* initialize crc stuff */
        crcGbl.poly = 0x1 021;
        crcGbl.crc = 0xffff;
        crcGbl.crcBit = 0;
        crcGbl.dataBit = 0;
        crcGbl.dataByte = 0;

        /*
        spmGbl.tf.txFlag = 0;
        spmGbl.tf.txReqFlag = 0;
        spmGbl.tf.txDataValid = 0;
        spmGbl.tf.blank = 0;
        spmGbl.tf.txAddrRW = 0;
        spmGbl.tf.txAddr = 0;
        spmGbl.tf.data = 0;
        */

        *((uint16 *)&(spmGbl.tf)) = (uint16) 0x0U; /* fast way */
    }

```

```
        spmGbl.state = RECEIVE;
    }
    else if ((spmGbl.rf.rwAck == 0) && /* still not read */
            (spmGbl.srr == TRUE) &&
            (spmGbl.sra >= 0) && /* 0< config reg address */
            /* <=7 */
            (spmGbl.sra <= 7) )
    {

        spmGbl.tf.txFlag = 0;
        spmGbl.tf.txReqFlag = 0;
        spmGbl.tf.txDataValid = 0;
        spmGbl.tf.blank = 0;
        spmGbl.tf.txAddrRW = 1;
        spmGbl.tf.txAddr = spmGbl.sra;
        spmGbl.tf.data = 0;

        spmGbl.state = READ; /* keep trying */
    }
    else if ( spmGbl.rf.rwAck == 1)
    {
        spmGbl.srData = spmGbl.rf.data;
        spmGbl.srr = FALSE;

        /*
        spmGbl.tf.txFlag = 0;
        spmGbl.tf.txReqFlag = 0;
        spmGbl.tf.txDataValid = 0;
        spmGbl.tf.blank = 0;
        spmGbl.tf.txAddrRW = 0;
        spmGbl.tf.txAddr = 0;
        spmGbl.tf.data = 0;
        */

        *((uint16 *)&(spmGbl.tf)) = (uint16) 0x0U; /* fast way */
        spmGbl.state = IDLE;
    }
    else
    {
        /*
        spmGbl.tf.txFlag = 0;
        spmGbl.tf.txReqFlag = 0;
        spmGbl.tf.txDataValid = 0;
        spmGbl.tf.blank = 0;
        spmGbl.tf.txAddrRW = 0;
        spmGbl.tf.txAddr = 0;
        spmGbl.tf.data = 0;
        */

        *((uint16 *)&(spmGbl.tf)) = (uint16) 0x0U; /* fast way */
        spmGbl.state = IDLE;
    }
    break;
case REQ_TX:
    if ( spmGbl.rf.rxFlag == 1 /* XCVR has detected packet to */
        /* receive */
        )
    {
        macGbl.rc = 0; /* init receive byte count */
        macGbl.rl = 0;
        if ( macGbl.rpr == TRUE ) /* last packet not copied out */
        {
            spmGbl.mode = OVERWRITE; /* stepped on last packet */
            macGbl.rpr = FALSE; /* what else to do ? */
        }
    }
}
```

IECNORM.COM Click to view the full PDF of ISO/IEC 14908-1:2012

```

/* initialize crc stuff */
crcGbl.poly = 0x1021;
crcGbl.crc = 0xffff;
crcGbl.crcBit = 0;
crcGbl.dataBit = 0;
crcGbl.dataByte = 0;

```

```

/*
spmGbl.tf.txFlag = 0;
spmGbl.tf.txReqFlag = 0;
spmGbl.tf.txDataValid = 0;
spmGbl.tf.blank = 0;
spmGbl.tf.txAddrRW = 0;
spmGbl.tf.txAddr = 0;
spmGbl.tf.data = 0;
*/

```

```

*((uint16 *)&(spmGbl.tf)) = (uint16) 0x0U; /* fast way */

```

```

spmGbl.state = RECEIVE;
}
else if (spmGbl.rf.clrTxReqFlag == 1) /* either accept or deny */
{
if ( (spmGbl.rf.setTxFlag == 1) && /* request accepted */
(spmGbl.rf.txDataCTS == 1) )
{
/*
spmGbl.tf.txFlag = 1;
spmGbl.tf.txReqFlag = 0;
spmGbl.tf.txDataValid = 1;
spmGbl.tf.blank = 0;
spmGbl.tf.txAddrRW = 0;
spmGbl.tf.txAddr = 0;
spmGbl.tf.data = macGbl.tPkt[macGbl.tc];
*/

```

```

*((uint8 *)&(spmGbl.tf)) = (uint8) 0xA0; /* fast way */
*((uint8 *)&(spmGbl.tf.data)) = (uint8)
macGbl.tPkt[macGbl.tc];

```

```

macGbl.tc++; /* increment count */

```

```

spmGbl.state = TRANSMIT; /* accepted */
}
else /* request denied */
{
/*
spmGbl.tf.txFlag = 0;
spmGbl.tf.txReqFlag = 0;
spmGbl.tf.txDataValid = 0;
spmGbl.tf.blank = 0;
spmGbl.tf.txAddrRW = 0;
spmGbl.tf.txAddr = 0;
spmGbl.tf.data = 0;
*/

```

```

*((uint16 *)&(spmGbl.tf)) = (uint16) 0x0U; /* fast way */

```

```

spmGbl.state = IDLE; /* dont want to tx anymore */

```

```

}
}
else /* wait for xcvr to respond to request */

```

```
{
    /* typically there is one blank frame from xcvr
    after REQ_TX bit is set but before CTS or ClrTxReqFlag
*/
}

/*
spmGbl.tf.txFlag = 0;
spmGbl.tf.txReqFlag = 0;
spmGbl.tf.txDataValid = 0;
spmGbl.tf.blank = 0;
spmGbl.tf.txAddrRW = 0;
spmGbl.tf.txAddr = 0;
spmGbl.tf.data = 0;
*/

*((uint16 *)&(spmGbl.tf)) = (uint16) 0x00; /* fast way */

spmGbl.state = REQ_TX; /* Wait for response */
}
break;
case TRANSMIT:
if ( spmGbl.rf.setCollDet == 1) /* collision so start over */
{
    /*
    spmGbl.tf.txFlag = 0;
    spmGbl.tf.txReqFlag = 0;
    spmGbl.tf.txDataValid = 0;
    spmGbl.tf.blank = 0;
    spmGbl.tf.txAddrRW = 0;
    spmGbl.tf.txAddr = 0;
    spmGbl.tf.data = 0;
    */

    *((uint16 *)&(spmGbl.tf)) = (uint16) 0x00; /* fast way */

    macGbl.tc = 0;

    IncrementBacklog(1); /* collision so increment backlog */

    spmGbl.collisionsThisPkt++; /*increment collison count this */
    /* packet*/

    INCR_STATS(nmp->stats.collisions);/* increment collision */
    /* stats */

    if (spmGbl.collisionsThisPkt >= 255)
    {
        /* throw away packet */
        macGbl.tc = 0;
        spmGbl.resetCount = 0; /* reset count for txOn */
        spmGbl.collisionsThisPkt = 0;
        macGbl.tpr = FALSE;
    }

    spmGbl.state = IDLE; /* start over */
}
else if (spmGbl.rf.txDataCTS == 1)
{
    /*
    spmGbl.tf.txFlag = 1;
    spmGbl.tf.txReqFlag = 0;
    spmGbl.tf.txDataValid = 1;
    spmGbl.tf.blank = 0;
    spmGbl.tf.txAddrRW = 0;
    */
}
```

IECNORM.COM: Click to view the full PDF of ISO/IEC 14908-1:2012

```

    spmGbl.tf.txAddr = 0;
    spmGbl.tf.data = macGbl.tPkt[macGbl.tc];
    */

```

```

    *((uint8 *)&(spmGbl.tf)) = (uint8) 0xA0; /* fast way */
    *((uint8 *)&(spmGbl.tf.data)) = (uint8) macGbl.tPkt[macGbl.tc];
    /* fast way */

```

```

    macGbl.tc++; /* increment count */

```

```

    if( macGbl.tc >= macGbl.tl) /* last byte sent this frame */
    {
        spmGbl.state = DONE_TX; /* dont want to tx anymore */
    }
    else
    {
        spmGbl.state = TRANSMIT;
    }
}
else if ((spmGbl.rf.txOn == 1) &&
        (macGbl.tpr == TRUE) &&
        (macGbl.tc < macGbl.tl) ) /* wait for cts */
{

```

```

    /*
    spmGbl.tf.txFlag = 1;
    spmGbl.tf.txReqFlag = 0;
    spmGbl.tf.txDataValid = 0;
    spmGbl.tf.blank = 0;
    spmGbl.tf.txAddrRW = 0;
    spmGbl.tf.txAddr = 0;
    spmGbl.tf.data = 0;
    */

```

```

    *((uint8 *)&(spmGbl.tf)) = (uint8) 0x80; /* fast way */
    *((uint8 *)&(spmGbl.tf.data)) = (uint8) 0; /* fast way */

```

```

    spmGbl.resetCount++;
    if (spmGbl.resetCount >= RESET_COUNT_LIMIT)
    {
        PHYHardResetSPMXCVR();
        spmGbl.state = IDLE;
    }
    else
    {
        spmGbl.state = TRANSMIT;
    }

```

```

    else /* something wrong here throw away packet and get out */
    {

```

```

    /*
    spmGbl.tf.txFlag = 0;
    spmGbl.tf.txReqFlag = 0;
    spmGbl.tf.txDataValid = 0;
    spmGbl.tf.blank = 0;
    spmGbl.tf.txAddrRW = 0;
    spmGbl.tf.txAddr = 0;
    spmGbl.tf.data = 0;
    */

```

```

    *((uint16 *)&(spmGbl.tf)) = (uint16) 0x00; /* fast way */

```

```

    macGbl.tc = 0;
    spmGbl.resetCount = 0; /* reset count for txOn */
    spmGbl.collisionsThisPkt = 0;

```

```

        macGbl.tpr = FALSE;
        spmGbl.state = IDLE;
    }
    break;
case DONE_TX: /* wait for tx on to go off */
    if ( spmGbl.rf.setCollDet == 1) /* collision so start over */
    {
        /*
        spmGbl.tf.txFlag = 0;
        spmGbl.tf.txReqFlag = 0;
        spmGbl.tf.txDataValid = 0;
        spmGbl.tf.blank = 0;
        spmGbl.tf.txAddrRW = 0;
        spmGbl.tf.txAddr = 0;
        spmGbl.tf.data = 0;
        */

        *((uint16 *)&(spmGbl.tf)) = (uint16) 0x0U; /* fast way */

        macGbl.tc = 0;

        IncrementBacklog(1); /* collision so increment backlog */

        spmGbl.collisionsThisPkt++; /* increment collision count */
        /* this packet */

        INCR_STATS(nmp->stats.collisions); /* increment collision */
        /* stats */

        if (spmGbl.collisionsThisPkt >= 255)
        {
            /* throw away packet */
            macGbl.tc = 0;
            spmGbl.resetCount = 0; /* reset count for txOn */
            spmGbl.collisionsThisPkt = 0;
            macGbl.tpr = FALSE;
        }

        spmGbl.state = IDLE; /* start over */
    }
    else if (spmGbl.rf.txOn == 1) /* still sending last byte(s) */
    {
        /*
        spmGbl.tf.txFlag = 0;
        spmGbl.tf.txReqFlag = 0;
        spmGbl.tf.txDataValid = 0;
        spmGbl.tf.blank = 0;
        spmGbl.tf.txAddrRW = 0;
        spmGbl.tf.txAddr = 0;
        spmGbl.tf.data = 0;
        */

        *((uint16 *)&(spmGbl.tf)) = (uint16) 0x0; /* fast way */

        spmGbl.resetCount++;
        if (spmGbl.resetCount >= RESET_COUNT_LIMIT)
        {
            PHYHardResetSPMXCVR();
            spmGbl.state = IDLE;
        }
        else
        {
            spmGbl.state = DONE_TX;
        }
    }
}

```

```

    }
    else /* (spmGbl.rf.txOn == 0) done sending */
    {
        /*
        spmGbl.tf.txFlag = 0;
        spmGbl.tf.txReqFlag = 0;
        spmGbl.tf.txDataValid = 0;
        spmGbl.tf.blank = 0;
        spmGbl.tf.txAddrRW = 0;
        spmGbl.tf.txAddr = 0;
        spmGbl.tf.data = 0;
        */

        *((uint16 *)&(spmGbl.tf)) = (uint16) 0x0; /* fast way */

        /* successful transmission so update backlog */
        if (macGbl.deltaBLTx <= 0)
        {
            DecrementBacklog(1);
        }
        else
        {
            IncrementBacklog(macGbl.deltaBLTx);
        }

        /* Cycle Timer needs to be restarted after valid tx */
        spmGbl.cycleTimerRestart = TRUE;

        /* clean up */
        macGbl.tc = 0;
        spmGbl.resetCount = 0; /* reset count for txOn */
        spmGbl.collisionsThisPkt = 0;
        macGbl.tpr = FALSE;
        spmGbl.state = IDLE; /* dont want to tx anymore */
    }
    break;
case DEBUG:
default:
    /*
    spmGbl.tf.txFlag = 0;
    spmGbl.tf.txReqFlag = 0;
    spmGbl.tf.txDataValid = 0;
    spmGbl.tf.blank = 0;
    spmGbl.tf.txAddrRW = 0;
    spmGbl.tf.txAddr = 0;
    spmGbl.tf.data = 0;
    */

    *((uint16 *)&(spmGbl.tf)) = (uint16) 0x0U; /* fast way */

    spmGbl.state = DEBUG;
} /* end switch spm state machine */

#ifdef SPM_HISTORY
hBufGbl.records[hBufGbl.index].tf = spmGbl.tf;
/* time period of isr */
/* C unsigned math is congruent mod 2^n so negatives wrap around OK */
hBufGbl.records[hBufGbl.index].duration = *(spmGbl.clock) -
    hBufGbl.records[hBufGbl.index].start;

```

```

        hBufGbl.index = (hBufGbl.index + 1) % NUM_HIST;
#endif
        /* Send Frame */
        tbdPtrGbl->r = 1; /* buffer ready to transmit */
        spcomPtrGbl->str = 1;
    } /* end if spmGbl.mode == STOP */
} /* endif rxb event */

    cisrPtrGbl->spi = 1; /* clear spi bit in CISR by writing a 1 */
    return;
}

/*****
Function: CErrIsr
Returns: none, no arguments allowed either
Reference:
Purpose: interrupt service routine for CPM Int. Error
Comments: must use interrupt pragma
*****/
/* interrupt pragma informs compiler to make next function
   an interrupt handler with RTE and saved state of registers */
#pragma interrupt()

static void CErrIsr(void)
{

    return;
}

/*****
Function: SpurIntIsr
Returns: none, no arguments allowed either
Reference:
Purpose: interrupt service routine for spurious interrupt Error
Comments: must use interrupt pragma
*****/
/* interrupt pragma informs compiler to make next function
   an interrupt handler with RTE and saved state of registers */
#pragma interrupt()

static void SpurIntIsr(void)
{
    exceptions++;

    return;
}

/*****
Function: BusErrIsr
Returns: none, no arguments allowed either
Reference:
Purpose: interrupt service routine for Bus errors
Comments: must use interrupt pragma
*****/
/* interrupt pragma informs compiler to make next function
   an interrupt handler with RTE and saved state of registers */
#pragma interrupt()

static void BusErrIsr(void)
{
    exceptions++;

    return;
}

/*****
Function: GetTransceiverStatus
Returns: none
Purpose: To determine the status of transceiver registers.
        The status registers are different from config registers.
*****/

```

```

Comments: The array should have space for all the register values.
*****
void GetTransceiverStatus(Byte transceiverStatusOut[])
{
    int i;
    unsigned long count;
    Boolean good;

    /* read config registers on PLT-20 transceiver */

    /* read in reverse order */
    i = NUM_COMM_PARAMS - 1; /* should be 6 */
    while ( i >= 0)
    {
        /* read status registers starting at 7 down to 1 */
        spmGbl.sra = (Byte) i + 1;
        spmGbl.srr = TRUE;
        count = 0;
        /* wait for ack but time out so not infinite loop */
        while ((spmGbl.srr != FALSE) && (count < 0xFFFFF))
        {
            count++;
        }
        if (spmGbl.srr == TRUE) /* xcvr never acked try again */
        {
            pbdPtrGbl->d5 = 0; /* first reset xcvr */

            /* wait for a while for everything to settle down */
            good = DelayTicks(RESTART_DELAY_TICKS);

            pbdPtrGbl->d5 = 1; /* bring xcvr out of reset */
            i = NUM_COMM_PARAMS - 1; /* start over again */
        } /* NOTE!!! if the xcvr never acks this code will hang */
        else
        {
            transceiverStatusOut[i] = spmGbl.srData;
            i--;
        }
    }

    spmGbl.srData = 0;
    spmGbl.sra = 0;

    return;
}

/*****End of spm.c*****/

```

IECNORM.COM : Click to view the full PDF of ISO/IEC 14908-1:2012

A.3 LPDU transmit algorithm

```

/*****
Function: LKSend
Returns: None
Reference: None
Purpose: To take the NPDU from link layer's output queue and put it
         in the queue for the physical layer.
Comments: We assume that there will be sufficient space as we
         allocated the extra bytes based on header size etc.
*****/
void LKSend(void)
{
    LKSendParam    *lkSendParamPtr;
    Queue          *lkSendQueuePtr;
    Byte           *npduPtr;
    Byte           *phyQItemPtr, *phyQPtr, *tempPtr;
    Byte           **phyQTailPtrPtr;
    uint16         queueCnt, itemSize;
    uint16         *pduSizePtr;
    LPDUHeader     *lpduHeaderPtr;
    Boolean         priority;

    /* First, make variables point to the right queue. */
    if (!QueueEmpty(&gp->lkOutPriQ))
    {
        priority      = TRUE;
        lkSendQueuePtr = &gp->lkOutPriQ;
        phyQPtr       = gp->phyOutPriQ;
        phyQItemPtr   = gp->phyOutPriQTailPtr;
        phyQTailPtrPtr = &gp->phyOutPriQTailPtr;
        queueCnt      = gp->phyOutPriQCnt;
        itemSize      = gp->phyOutPriBufSize;
    }
    else if (!QueueEmpty(&gp->lkOutQ))
    {
        priority      = FALSE;
        lkSendQueuePtr = &gp->lkOutQ;
        phyQPtr       = gp->phyOutQ;
        phyQItemPtr   = gp->phyOutQTailPtr;
        phyQTailPtrPtr = &gp->phyOutQTailPtr;
        queueCnt      = gp->phyOutQCnt;
        itemSize      = gp->phyOutBufSize;
    }
    else
    {
        return; /* Nothing to send. */
    }

    lkSendParamPtr = QueueHead(lkSendQueuePtr);
    npduPtr         = (Byte *) (lkSendParamPtr + 1);

    /* Check if there is space in the physical layer's queue. */
    if (*phyQItemPtr == 1)
    {
        return; /* No space in the physical layer queue. */
    }

    /* Fill the PDU size so that the physical layer knows about it. */
    pduSizePtr = (uint16 *) ((char *)phyQItemPtr + 1);
    *pduSizePtr = lkSendParamPtr->pduSize + 3;
}

```

```

/* First fill the data. */
tempPtr = phyQItemPtr + 3;

/* Form the header. */
lpduHeaderPtr = (LPDUHeader *)tempPtr;
lpduHeaderPtr->priority = priority;
lpduHeaderPtr->altPath = lkSendParamPtr->altPath;
lpduHeaderPtr->deltaBL = lkSendParamPtr->deltaBL;
tempPtr++;

/* Copy the NPDU. */
if (lkSendParamPtr->pduSize <= itemSize)
{
    memcpy(tempPtr, npduPtr, lkSendParamPtr->pduSize);
}
else
{
    ErrorMsg("LKSend: NPDU seems too large to fit.\n");
}

/* Compute the CRC value. */
CRC16(phyQItemPtr+3, lkSendParamPtr->pduSize + 1);

/* Turn the flag on so that physical layer can send it. */
*phyQItemPtr = 1;

/* Increment tail pointer taking care of wraparound. */
*phyQTailPtrPtr = *phyQTailPtrPtr + itemSize;
if (*phyQTailPtrPtr == (phyQPtr + queueCnt * itemSize))
{
    *phyQTailPtrPtr = phyQPtr; /* wrap around. */
}

DeQueue(lkSendQueuePtr);

return;
}

/*****
Function: CRC16
Returns: 16 bit CRC computed.
Purpose: To compute the 16 bit CRC for a given buffer.
Comments: None.
*****/
void CRC16(Byte bufInOut[], uint16 sizeIn)
{
    uint16 poly = 0x1021; /* Generator Polynomial. */
    uint16 crc = 0xffff;
    uint16 i, j;
    unsigned char byte, crcbit, databit;

    for (i = 0; i < sizeIn; i++)
    {
        byte = bufInOut[i];
        for (j = 0; j < 8; j++)
        {
            crcbit = crc & 0x8000 ? 1 : 0;
            databit = byte & 0x80 ? 1 : 0;
            crc = crc << 1;
            if (crcbit != databit)
            {
                crc = crc ^ poly;
            }
            byte = byte << 1;
        }
    }
}

```

```

    }
}
crc = crc ^ 0xffff;
bufInOut[sizeIn] = (crc >> 8);
bufInOut[sizeIn + 1] = (crc & 0x00FF);

return;
}

```

A.4 LPDU receive algorithm

```

/*****
Function: LKReceive
Returns: None
Reference: None
Purpose: To receive the incoming LPDUs and process them.
Comments: Each item of the queue gp->lkInQ has the following form:
          flag pduSize LPDU
          flag is 1 byte long.
          pduSize is 2 bytes long.
          LPDU has header followed by the rest of the LPDU and then CRC.
          The LPDU header is 1 byte long. CRC uses 2 bytes.
          If a packet is in lkInQ then it should fit into nwInQ.
*****/
void LKReceive(void)
{
    NWReceiveParam *nwReceiveParamPtr;
    Byte *npduPtr;
    LPDUHeader *lpduHeaderPtr;
    Byte *tempPtr;
    uint16 lpduSize;

    if (*(gp->lkInQHeadPtr) == 0)
    {
        /* There is nothing to receive. */
        return;
    }
    lpduSize = *(uint16 *) (gp->lkInQHeadPtr + 1);
    lpduHeaderPtr = (LPDUHeader *) (gp->lkInQHeadPtr + 3);

    /* Throw away packets that are smaller than 8 bytes long. */
    /* this check is now made in the mac sublayer */
    /* Do CRC check. */
    /* this check is now made in the mac sublayer */
    /* Only packets with valid CRC and >= 8 bytes are placed
       in the lkInQ by mac sublayer. */

    INCR_STATS(nmp->stats.layer2Received); /* Got a good packet. */

    /* We need to receive this message. */
    if (QueueFull(&gp->nwInQ))
    {
        /* We are losing this packet. */
        INCR_STATS(nmp->stats.missedMessages);
    }
    else
    {
        nwReceiveParamPtr = QueueTail(&gp->nwInQ);
        npduPtr = (Byte *) (nwReceiveParamPtr + 1);
    }
}

```

```

nwReceiveParamPtr->priority = lpduHeaderPtr->priority;
nwReceiveParamPtr->altPath = lpduHeaderPtr->altPath;
tempPtr = (Byte *) ((char *) lpduHeaderPtr + 1);
nwReceiveParamPtr->pduSize = lpduSize - 3;

/* Copy the NPDU. */
/* if it was in link layer's queue, then the size should be
sufficient in network layer's queue as they differ by 3.
However, let us play safe by checking the size first. */
if (nwReceiveParamPtr->pduSize <= gp->nwInBufSize)
{
    memcpy(npduPtr, tempPtr, nwReceiveParamPtr->pduSize);
}
else
{
    ErrorMessage("LKReceive: NPDU size seems too large.\n");
}
EnQueue (&gp->nwInQ);
}
* (gp->lkInQHeadPtr) = 0;
gp->lkInQHeadPtr = gp->lkInQHeadPtr + gp->lkInBufSize;
if (gp->lkInQHeadPtr ==
    (gp->lkInQ + gp->lkInBufSize * gp->lkInQCnt))
{
    gp->lkInQHeadPtr = gp->lkInQ; /* wrap around. */
}

return;
}

```

A.5 Routing algorithm

Input:
 NPDU the NPDU to be routed

Output:
 Decision one of (Forward, Drop)

Uses:

- My_Domain the domain this router is assigned to
- My_Subnet the subnet within the domain that this side of the router is assigned to
- ROUTE_{uc} () routing table
- ROUTE_{mc} () routing table
- ROUTE_{pc} () routing table
- RouterType one of: Configured, Learning, Bridge, Repeater

```

Begin { routingalgorithm }

If RouterType = Repeater Then Begin
    Decision := Forward;
    Return;
end;

If RouterType = Learning Then
    Execute ROUTING_EVENT of learning algorithm;

If NPDU.Domain <> My_Domain Then
    If RouterType = Bridge or RouterType = Learning Then Begin
        Decision := Drop;
        Return;
    end;

```

```

    If NPDU.Domain <> Null Domain Then Begin
        Decision := Drop;
        Return;
    end;
Else If RouterType = Bridge Then Begin
    Decision := Forward;
    Return;
end;

Case NPDU.DestAddrFmt Of
    Subnet/Node:      Decision := ROUTEuc (NPDU.DestSubnet);
    Group:           Decision := ROUTEmc (NPDU.DestGroup);
    Broadcast:       Decision := ROUTEbc (NPDU.DestSubnet);
end case;

Return;
end { routing algorithm};

```

A.6 Learning algorithm

Inputs:

INIT EVENT
 always occurs on system reboot; may also occur periodically, allowing the router to adapt to changes in network topology

ROUTING EVENT
 NPDU the NPDU to be routed
 MySubnet the subnet the router is configured on for this side of the router

Output:
 Defines routing function ROUTE_{uc} ()

```

begin { learning algorithm }
  case event of
    INIT EVENT:
      Set ROUTEuc () := Forward for all subnet addresses;
      Set ROUTEuc (MySubnet) := Drop;
      Set ROUTEmc () := Forward for all group addresses;
    ROUTING EVENT:
      ROUTEuc (NPDU.SrcSubnet) := Drop;
  end case;
end { learning algorithm };

```

A.7 Transaction control algorithm

Reference: Section 9.5, Transaction Control Algorithm

File: tcs.c

Version: 1.7

Purpose: Interface file for transaction control sublayer.
 Outgoing sequencing.
 Incoming sequencing and duplicate detection.

Note: For assigning TIDs, a table is used. We

remember the last TID for each unique destination address. When a new TID is requested for a destination, this table is searched for that destination. If found, we make sure that we don't assign the same TID used for that destination. If the destination is not found, we make a new entry in the table.

We have an entry in the table for each subnet/node, group, broadcast, subnet broadcast, unique node id. When a table entry is assigned, we remember the time stamp too. If the table does not have space for a new destination address, we get rid of one that has remained more than 24 seconds. If there is no such entry, then we fail to allocate the new transaction ID. The table size is configurable.

To Do: None

```

/* *** START INFORMATIVE - Transaction ID Allocation *** */
/* These functions represent an example means of allocating transaction IDs.
 * There are in fact several valid mechanisms for allocating transaction IDs.
 * In addition to the mechanism below, there are at least two other accepted means
 * for allocating transaction IDs.
 * 1. Allocate a transaction ID per unique destination address. This method
 * should not be used if acknowledged or request/response using unique ID or
 * broadcast addressing are using in time proximity with the other addressing.
 * modes
 * Note that such combinations can be accomplished in this scheme if guardbands
 * are placed around expected arrivals of acks/responses per transaction ID.
 * 2. Allocate all transaction IDs from a single transaction ID space without
 * conflict checking. If this simple scheme is used, it is recommended that
 * conflict checking be performed by the application. */

```

```

/*-----
Section: Includes
-----*/

```

```

#include <stdio.h>
#include <string.h>
#include <cnp_1.h>
#include <node.h>
#include <tcs.h>

```

```

/*-----
Section: Constant Definitions
-----*/

```

```

/* Minimum amount of time in seconds a record in the priTbl or
 * non-priTbl should stay before it can be replaced with a new
 * entry. i.e., if the table is full and a new entry is needed,
 * we look for an entry that has remained in the table for
 * at least MIN_TABLE_TIME seconds. */

```

```

#define MIN_TABLE_TIME 24

```

```

/*-----
Section: Type Definitions
-----*/

```

```

/* None */

```

```

/*-----
Section: Globals
-----*/

```

```

/* None */

```

```

/*-----
Section: Function Prototypes
-----*/
/*****
Function: TCSReset
Returns: None
Reference: Section 9, Transaction control sublayer.
Purpose: To initialize all globals to proper values.
Comments: None.
*****/
void TCSReset(void)
{
    gp->priTransID = 0; /* On node reset, transaction id 0 is used. */
    gp->nonpriTransID = 0;
    gp->priTransCtrlRec.inProgress = FALSE;
    gp->nonpriTransCtrlRec.inProgress = FALSE;
    /* Reset the tables that keep track of (destination address
    transaction id) pairs only during powerup or external reset.
    When resetCause is software reset or cleared, we keep this
    table to ensure that we don't send a message to a destination
    with tid same as the one used last time for that destination.
    For power-up or external reset, we also need to ensure that
    using some other technique. We will delay transport or session
    layer sends by a small amount so that no messages are pending in
    target nodes. If we don't follow these guidelines, the target
    node may throw away messages sent after a reset as duplicates. */
    if (nmp->resetCause == POWER_UP_RESET || nmp->resetCause == EXTERNAL_RESET)
    {
        gp->priTblSize = 0;
        gp->nonpriTblSize = 0;
    }
}

/*****
Function: NewTrans
Returns: SUCCESS if a transaction id can be assigned.
        FAILURE if it is not possible to assign an id.
Purpose: To get a new transaction id.
Comments: This function implements a new algorithm to assign the
transaction id. It does not use the one in protocol specification.
Alg Idea: For each of the following categories, we have an
entry in the table.
1. Subnet/Node
2. group
3. broadcast (domainwide or subnet)
4. unique node id
When a new id is requested, we increment the tid from
the single space. We then search the table for this
entry. If a matching entry is found, then we check
if that tid was used last time for the same destination.
If so, we bump it up by one. If not we use it. In
either case, we record this tid in the table.
If there was no such entry, we create a new one.
If there is no space for the new entry, we release one
that has remained more than MIN_TABLE_TIME seconds.
If no such entry, then we fail to assign a tid.
*****/
Status NewTrans(Boolean priorityIn, DestinationAddress addrIn,
                TransNum *transNumOut)
{
    uint16 i;
    TransCtrlRecord *transRecPtr;
    TransNum *transNumPtr;
}

```



```

TIDTableEntry *tbl;
uint16 *tblSize;
Boolean found;

```

```

/* Point to the appropriate control record & table. */
if (priorityIn)

```

```

{
    transRecPtr = &gp->priTransCtrlRec;
    transNumPtr = &gp->priTransID;
    tbl = gp->priTbl;
    tblSize = &gp->priTblSize;
}

```

```

else

```

```

{
    transRecPtr = &gp->nonpriTransCtrlRec;
    transNumPtr = &gp->nonpriTransID;
    tbl = gp->nonpriTbl;
    tblSize = &gp->nonpriTblSize;
}

```

```

/* Check if transaction already in progress. */

```

```

if (transRecPtr->inProgress)

```

```

{
    /* We can't allow a new transaction. Return failure. */
    return(FAILURE);
}

```

```

/* We can allow the transaction. Allocate a new TID. */

```

```

transRecPtr->transNum = *transNumPtr;

```

```

/* Make sure that this dest did not use this TID last time.

```

```

If it did, increment the TID. */
/* Note: addrIn.addressMode can never be MULTICAST ACK
for transactions initiated by a node. */

```

```

found = FALSE;
for (i = 0; i < *tblSize; i++)

```

```

{
    /* Update timer for this i whether match or not. */
    UpdateMsTimer(&tbl[i].timer);

```

```

/* If domainId does not match, skip entry. */

```

```

if (addrIn.domainIndex != FLEX_DOMAIN &&
    (eep->domainTable[addrIn.domainIndex].len == 0xFF ||
     tbl[i].len != eep->domainTable[addrIn.domainIndex].len ||
     memcmp(eep->domainTable[addrIn.domainIndex].domainId,
            tbl[i].domainId,
            eep->domainTable[addrIn.domainIndex].len) != 0)

```

```

{
    continue; /* Not flex domain but domain mismatch. */
}

```

```

if (addrIn.domainIndex == FLEX_DOMAIN &&
    (tbl[i].len != addrIn.flexDomainLen ||
     memcmp(addrIn.flexDomainId,
            tbl[i].domainId,
            addrIn.flexDomainLen) != 0)

```

```

{
    continue; /* Flex domain but domain mismatch. */
}

```

```

switch(addrIn.addressMode)

```

```

{

```

```

case SUBNET_NODE:
    if (tbl[i].addressMode == SUBNET_NODE &&
        memcmp(&tbl[i].addr.subnetNode, &addrIn.addr.addr2a,
            sizeof(SubnetAddress)) == 0)
    {
        found = TRUE;
    }
    break;
case UNIQUE_NODE_ID:
    if (tbl[i].addressMode == UNIQUE_NODE_ID &&
        memcmp(tbl[i].addr.uniqueNodeId,
            addrIn.addr.addr3.uniqueId,
            UNIQUE_NODE_ID_LEN) == 0)
    {
        found = TRUE;
    }
    break;
case MULTICAST:
    if (tbl[i].addressMode == MULTICAST &&
        tbl[i].addr.group == addrIn.addr.addr1)
    {
        found = TRUE;
    }
    break;
case BROADCAST:
    if (tbl[i].addressMode == BROADCAST &&
        tbl[i].addr.subnet == addrIn.addr.addr0)
    {
        found = TRUE;
    }
    break;
default:
    ErrorMessage("NewTrans: Unexpected addressMode.\n");
    /* Should not come here. */
}
if (found)
{
    break; /* Need to leave for loop with matched i value. */
}
}

if (found)
{
    /* Found a match. Check if last TID is same or not. */
    /* We can reuse this entry and reinitialize timer. */
    if (tbl[i].tid == *transNumPtr)
    {
        /* Increment TID. */
        (*transNumPtr)++;
        if (*transNumPtr == 16)
        {
            *transNumPtr = 1; /* Wrap around. */
        }
        transRecPtr->transNum = *transNumPtr;
    }
    tbl[i].tid = *transNumPtr;
    SetMsTimer(&tbl[i].timer,
        (uint16)(MIN_TABLE_TIME * 1000));
    *transNumOut = *transNumPtr;
    transRecPtr->inProgress = TRUE;
    return(SUCCESS);
}

/* No match. Make a new entry. If no space. get a space. */

```

```

/* All the timers must have been updated in the for loop above. */
if (*tblSize == TID_TABLE_SIZE)
{
    /* Table is full. See if any entry can be replaced. */
    found = FALSE;
    for (i = 0; i < *tblSize; i++)
    {
        if (tbl[i].timer.curTimerValue == 0) /* Expired */
        {
            found = TRUE;
            break;
        }
    }
    if (found)
    {
        /* Replace this entry with last entry of table. */
        (*tblSize)--;
        tbl[i] = tbl[*tblSize];

        /* Fall through to code below. */
    }
    else
    {
        /* Unable to find an entry. */
        return(FAILURE);
    }
}

```

```

/* Now we have space for an entry. Add new entry. */
/* Store the domain len and domain id in table */
if (addrIn.domainIndex == FLEX_DOMAIN)
{
    memcpy(tbl[*tblSize].domainId,
           addrIn.flexDomainId,
           addrIn.flexDomainLen);
    tbl[i].len = addrIn.flexDomainLen;
}
else
{
    memcpy(tbl[*tblSize].domainId,
           eep->domainTable[addrIn.domainIndex].domainId,
           eep->domainTable[addrIn.domainIndex].len);
    tbl[i].len = eep->domainTable[addrIn.domainIndex].len;
}

```

```

tbl[*tblSize].addressMode = addrIn.addressMode;
if (addrIn.addressMode == MULTICAST)
{
    tbl[*tblSize].addr.group = addrIn.addr.addr1;
}
else if (addrIn.addressMode == SUBNET_NODE)
{
    tbl[*tblSize].addr.subnetNode = addrIn.addr.addr2a;
}
else if (addrIn.addressMode == UNIQUE_NODE_ID)
{
    memcpy(tbl[*tblSize].addr.uniqueNodeId,
           addrIn.addr.addr3.uniqueId,
           UNIQUE_NODE_ID_LEN);
}
else if (addrIn.addressMode == BROADCAST)
{
    tbl[*tblSize].addr.subnet = addrIn.addr.addr0;
}

```

```
else
{
    /* Should not come here as addressMode was checked before too. */
    ErrorMsg("NewTrans: Invalid addressMode at unexpected place\n");
}
SetMsTimer(&tbl[*tblSize].timer, (uint16)(MIN_TABLE_TIME * 1000));
tbl[*tblSize].tid = *transNumPtr;
*transNumOut = *transNumPtr;
(*tblSize)++;
transRecPtr->inProgress = TRUE;
return(SUCCESS);
}
```

```
*****
Function: TransDone
Returns: None
Reference: Section 9, Transaction control sublayer
Purpose: To release the transaction record for future assignments.
Comments: None
*****
```

```
void TransDone(Boolean priorityIn)
{
    TransCtrlRecord *transRecPtr;
    TransNum *transNumPtr;
```

```
    /* Point to the appropriate control record & table. */
    if (priorityIn)
    {
        transRecPtr = &gp->priTransCtrlRec;
        transNumPtr = &gp->priTransID;
    }
    else
    {
        transRecPtr = &gp->nonpriTransCtrlRec;
        transNumPtr = &gp->nonpriTransID;
    }
}
```

```
    /* Mark transaction as available. */
    transRecPtr->inProgress = FALSE;
```

```
    /* Increment the corresponding transaction id. */
    (*transNumPtr)++;
    if (*transNumPtr == 16)
    {
        *transNumPtr = 1; /* Wrap Around to 1. */
    }
}
```

```
*****
Function: ValidateTrans
Returns: TRANS_CURRENT if the transNumIn matches transaction
        in progress.
        TRANS_NOT_CURRENT otherwise.
Reference: Section 9, Transaction control sublayer.
Purpose: To check if a given transNumIn is current or not.
Comments: None
*****
```

```
TransStatus ValidateTrans(Boolean priorityIn,
                          TransNum transNumIn)
{
```

```
    TransCtrlRecord *transRecPtr;

    /* Point to the appropriate control record & table. */
    if (priorityIn)
```



```

    {
        transRecPtr = &gp->priTransCtrlRec;
    }
    else
    {
        transRecPtr = &gp->nonpriTransCtrlRec;
    }

    if (transRecPtr->inProgress &&
        transRecPtr->transNum == transNumIn)
    {
        return(TRANS_CURRENT);
    }
    else
    {
        return(TRANS_NOT_CURRENT);
    }
}

/* *** END INFORMATIVE - Transaction ID Allocation *** */

/*-----End of tcs.c-----*/

```

A.8 Network layer algorithm

```

/*****
Reference:      Section 8, Network layer
File:          network.c
Version:       1.7
Purpose:       To implement network layer functions.
Note:          Reference implementation does not support
               special nodes such as routers and bridges.
               Extra code is needed to implement these.
To Do:         None
*****/
/*-----*/
Section: Includes
-----*/
#include <stdio.h>
#include <string.h>

#include <cmp_1.h>
#include <node.h>
#include <queue.h>
#include <network.h>

/*-----*/
Section: Constants
-----*/
/* #define DEBUG */

/*-----*/
Section: Type Definitions
-----*/
/*****
Byte data[1] is used so that variable data has address assigned by
the compiler. Once we know the size of the record, we will use
data[0], data[1], etc.
*****/

```

```
data[0] is source subnet.
data[1] is source node.
Based on the addrFmt field and 1st bit of data[1], the rest of
the data array is used appropriately.
*****/
#pragma maxalign(1)
typedef struct
{
  Bits    protocolVersion    :2;
  Bits    pduType            :2;
  Bits    addrFmt            :2;
  Bits    domainLength       :2;
  Byte    data[1];          /* Variable part */
} NPDU;
#pragma maxalign()

/*-----
Section: Globals
-----*/
/* None */

/*-----
Section: Local Function Prototypes
-----*/
static Byte DecodeDomainLength(Byte lengthCode);
static Byte EncodeDomainLength(Byte length);

/*-----
Section: Function Definitions
-----*/
/*****
Function: NWReset
Returns:  None
Reference: None
Purpose:  To initialize the queues used by the network layer.
Comments: None.
*****/
void NWReset(void)
{
  uint16 queueItemSize;

  /* Allocate and initialize the input queue. */
  gp->nwInBufSize =
    DecodeBufferSize((uint8)eep->readOnlyData.nwInBufSize);
  gp->nwInQCnt = DecodeBufferCnt((uint8)eep->readOnlyData.nwInBufCnt);
  queueItemSize = gp->nwInBufSize + sizeof(NWReceiveParam);

  if (QueueInit(&gp->nwInQ, queueItemSize, gp->nwInQCnt) != SUCCESS)
  {
    ErrorMessage("NWReset: Unable to init the input queue.\n");
    gp->resetOk = FALSE;
    return;
  }

  /* Allocate and initialize the output queue. */
  gp->nwOutBufSize =
    DecodeBufferSize((uint8)eep->readOnlyData.nwOutBufSize);
  gp->nwOutQCnt = DecodeBufferCnt((uint8)eep->readOnlyData.nwOutBufCnt);
  queueItemSize = gp->nwOutBufSize + sizeof(NWSendParam);

  if (gp->nwOutQCnt < 2)
  {
```



```

    ErrorMessage("NWReset: Network non-pri buffers count should be >= 2.\n");
    gp->resetOk = FALSE;
    return;
}

if (QueueInit(&gp->nwOutQ, queueItemSize, gp->nwOutQCnt)
    != SUCCESS)
{
    ErrorMessage("NWReset: Unable to init the output queue.\n");
    gp->resetOk = FALSE;
    return;
}

/* Allocate and initialize the priority output queue. */
gp->nwOutPriBufSize = gp->nwOutBufSize;
gp->nwOutPriQCnt =
    DecodeBufferCnt((uint8)eep->readOnlyData.nwOutBufPriCnt);
queueItemSize = gp->nwOutPriBufSize + sizeof(NWSendParam);

if (gp->nwOutPriQCnt < 2)
{
    ErrorMessage("NWReset: Network pri buffers count should be >= 2.\n");
    gp->resetOk = FALSE;
    return;
}

if (QueueInit(&gp->nwOutPriQ, queueItemSize, gp->nwOutPriQCnt)
    != SUCCESS)
{
    ErrorMessage("NWReset: Unable to init the priority output queue.\n");
    gp->resetOk = FALSE;
    return;
}

return;
}

```

```

/*****
Function: NWSend
Returns: None
Reference: None. No algorithms in protocol specification.
Purpose: To send outgoing PDUS (APDU or SPDU or TPDU or AuthPDU)
         waiting on the queue (pri or nonpri) for network layer.
         Network layer forms the NPDU and the parameters for
         sending the NPDU and writes to the queue for the
         link/mac layer.
Comments: Network buffer size is guaranteed to be at least
         20 bytes long as the encoding table's minimum value is 20.
         The NPDU's header's worst case size is 16. So, we are
         OK. No need to check for space when writing headers.
*****/
void NWSend(void)
{
    NWSendParam *nwSendParamPtr; /* Param in nwOutQ or nwPriOutQ. */
    LKSendParam *lkSendParamPtr; /* Param in lkOutQ or lkPriOutQ. */
    APPReceiveParam *appReceiveParamPtr;
    NPDU *npduPtr; /* Pointer to NPDU being formed. */
    Byte *pduPtr; /* Pointer to PDU etc being sent. */
    Boolean priority; /* TRUE if processing pri msg. */
    Byte selfField; /* 0 or 1. Used to form NPDU. */
    uint8 j; /* For temporary use. */
    uint16 npduSize; /* Size of NPDU formed. */
    uint8 numDomains; /* Number of domains for this node. */
    Boolean flexDomain; /* True if sending in flex domain. */

```

```

uint8      domainLength; /* Length of domain value sent. */
Byte       domainId[DOMAIN_ID_LEN]; /* Value of domain. */

/* Check if there is work to do and set pointers */
if ( !QueueEmpty(&gp->nwOutPriQ) && !QueueFull(&gp->lkOutPriQ) )
{
    /* Process priority message if there is one and it can be processed. */
    priority      = TRUE;
    nwSendParamPtr = QueueHead(&gp->nwOutPriQ);
    lkSendParamPtr = QueueTail(&gp->lkOutPriQ);
}
else if ( !QueueEmpty(&gp->nwOutQ) && !QueueFull(&gp->lkOutQ) )
{
    /* Process non-priority message if there is one and can be processed */
    priority      = FALSE;
    nwSendParamPtr = QueueHead(&gp->nwOutQ);
    lkSendParamPtr = QueueTail(&gp->lkOutQ);
}
else
{
    /* Either there is nothing to send or there is no space in link layer */
    return;
}

/* For application layer messages, we need to give completion event
using the tag given. This is for consistency with transport/session
layers. Thus completion events are streamlined in one place in
application layer rather than lots of places. */
if (nwSendParamPtr->pduType == APDU_TYPE && QueueFull(&gp->appInQ))
{
    /* Can't deliver the indication. Wait until we can send indication */
    return;
}

/* Process the waiting PDU, form the NPDU and send it */

/* ptr to APDU or TPDU or SPDU or AuthPDU. */
pduPtr = (Byte *) (nwSendParamPtr + 1);

/* ptr to NPDU constructed. */
npduPtr = (NPDU *) (lkSendParamPtr + 1);

/* Write the NPDU header. */
npduPtr->protocolVersion = PROTOCOL_VERSION; /* See cnp_1.h */
npduPtr->pduType         = nwSendParamPtr->pduType;
switch (nwSendParamPtr->destAddr.addressMode)
{
    case BROADCAST:
        npduPtr->addrFmt = 0;
        break;
    case MULTICAST:
        npduPtr->addrFmt = 1;
        break;
    case SUBNET_NODE:
    case MULTICAST_ACK:
        npduPtr->addrFmt = 2;
        break;
    case UNIQUE_NODE_ID:
        npduPtr->addrFmt = 3;
        break;
    default:
        ErrorMessage("NWSend: Unknown address mode.\n");
        /* Discard the packet as addrmode is wrong */
        nmp->errorLog = BAD_ADDRESS_TYPE;
}

```

```

/* Send completion event if it was an APDU */
if (nwSendParamPtr->pduType == APDU_TYPE)
{
    appReceiveParamPtr = QueueTail(&gp->appInQ);
    appReceiveParamPtr->indication = COMPLETION;
    appReceiveParamPtr->success = FALSE;
    appReceiveParamPtr->tag = nwSendParamPtr->tag;
    EnQueue (&gp->appInQ);
}
if (priority)
{
    DeQueue (&gp->nwOutPriQ);
}
else
{
    DeQueue (&gp->nwOutQ);
}
return;
}

/* Write the domain length. */
/* First determine the number of domains for this node */
if (eep->readOnlyData.twoDomains == 1)
{
    numDomains = 2;
}
else
{
    numDomains = 1;
}

/* if a node is in in unconfigured state and the message is not in flex
domain, then we discard the message. We should not use the domain table
in unconfigured state, irrespective of whether they are valid or not.
However, we allow acks, response, challenge and reply. The field
dropIfUnconfigured indicates whether this check is done or not. */
if (nwSendParamPtr->dropIfUnconfigured &&
    nwSendParamPtr->destAddr.domainIndex != FLEX_DOMAIN &&
    NodeUnConfigured())
{
    /* drop this packet. */
    /* Send completion event if it was an APDU */
    if (nwSendParamPtr->pduType == APDU_TYPE)
    {
        appReceiveParamPtr = QueueTail(&gp->appInQ);
        appReceiveParamPtr->indication = COMPLETION;
        appReceiveParamPtr->success = FALSE;
        appReceiveParamPtr->tag = nwSendParamPtr->tag;
        EnQueue (&gp->appInQ);
    }
    if (priority)
    {
        DeQueue (&gp->nwOutPriQ);
    }
    else
    {
        DeQueue (&gp->nwOutQ);
    }
    return;
}

/* If the domain used is not in use, it cannot send any packet */
if (nwSendParamPtr->destAddr.domainIndex < numDomains &&
    eep->domainTable[nwSendParamPtr->destAddr.domainIndex].len

```

```
        == 0xFF)
    {
        if (!nwSendParamPtr->dropIfUnconfigured)
        {
            /* It is not ACK, RESP etc. Don't log domain error in this case.
             * LNS might use join domain to leave a domain with ACKD. So, the
             * ACK send by the transport layer will be in an invalid domain
             * but should be ignored. */

            /* Discard the packet as the domain table entry is not in use */
            nmp->errorLog = INVALID_DOMAIN;
        }
        /* Send completion event if it was an APDU */
        if (nwSendParamPtr->pduType == APDU_TYPE)
        {
            appReceiveParamPtr = QueueTail(&gp->appInQ);
            appReceiveParamPtr->indication = COMPLETION;
            appReceiveParamPtr->success = FALSE;
            appReceiveParamPtr->tag = nwSendParamPtr->tag;
            EnQueue(&gp->appInQ);
        }
        if (priority)
        {
            DeQueue(&gp->nwOutPriQ);
        }
        else
        {
            DeQueue(&gp->nwOutQ);
        }
        return;
    }

    /* Use destAddr to determine the domain and write it,
     * compute and store domainLength and domainId for later use. */
    if (nwSendParamPtr->destAddr.domainIndex < numDomains)
    {
        /* One of this node's domains. */
        domainLength =
            eep->domainTable[nwSendParamPtr->destAddr.domainIndex].len;
        npduPtr->domainLength =
            EncodeDomainLength(
                eep->domainTable[nwSendParamPtr->destAddr.domainIndex].len
            );
        if (domainLength <= DOMAIN_ID_LEN)
        {
            memcpy(domainId,
                eep->domainTable[
                    nwSendParamPtr->destAddr.domainIndex].domainId,
                domainLength); /* Save id for now */
        }
        flexDomain = FALSE;
    }
    else if (nwSendParamPtr->destAddr.domainIndex == FLEX_DOMAIN)
    {
        /* Flex domain message. */
        domainLength = nwSendParamPtr->destAddr.flexDomainLen;
        npduPtr->domainLength =
            EncodeDomainLength(
                nwSendParamPtr->destAddr.flexDomainLen
            );
        if (domainLength <= DOMAIN_ID_LEN)
        {
            memcpy(domainId,
                nwSendParamPtr->destAddr.flexDomainId,
```

ECNORP.COM - Do not view the full PDF of ISO/IEC 14908-1:2012

```

        domainLength); /* Save the id for now */
    }
    flexDomain = TRUE;
}
else
{
    ErrorMsg("NWSend: Domain index is not valid.\n");
    nmp->errorLog = INVALID_DOMAIN;
    /* Send completion event if it was an APDU */
    if (nwSendParamPtr->pduType == APDU_TYPE)
    {
        appReceiveParamPtr = QueueTail(&gp->appInQ);
        appReceiveParamPtr->indication = COMPLETION;
        appReceiveParamPtr->success = FALSE;
        appReceiveParamPtr->tag = nwSendParamPtr->tag;
        EnQueue(&gp->appInQ);
    }
    /* Discard the packet as the domain index is invalid. */
    if (priority)
    {
        DeQueue(&gp->nwOutPriQ);
    }
    else
    {
        DeQueue(&gp->nwOutQ);
    }
    return;
}
}

if (domainLength != 0 && domainLength != 1 &&
    domainLength != 3 && domainLength != 6)
{
    /* Protocol specification indicates that domainLength has to be
       one of the above values. If not, it is a bad value. */
    ErrorMsg("NWSend: Domain length is not valid.\n");
    nmp->errorLog = INVALID_DOMAIN;
    /* Send completion event if it was an APDU */
    if (nwSendParamPtr->pduType == APDU_TYPE)
    {
        appReceiveParamPtr = QueueTail(&gp->appInQ);
        appReceiveParamPtr->indication = COMPLETION;
        appReceiveParamPtr->success = FALSE;
        appReceiveParamPtr->tag = nwSendParamPtr->tag;
        EnQueue(&gp->appInQ);
    }
    /* Discard the packet as the domain length is invalid. */
    if (priority)
    {
        DeQueue(&gp->nwOutPriQ);
    }
    else
    {
        DeQueue(&gp->nwOutQ);
    }
    return;
}
}

/* Write the address. It goes into data[0] onwards. */

/* First, write source subnet. */
if (flexDomain)
{
    npduPtr->data[0] = 0; /* It is 0 for flex domain response. */
}
}

```

```

else
{
    npduPtr->data[0] =
        eep->domainTable[nwSendParamPtr->destAddr.domainIndex].subnet;
}

/* Determine the selField value. */
/* Only MULTICAST_ACK has selector field as 0. For all others, it is 1. */
if (nwSendParamPtr->destAddr.addressMode == MULTICAST_ACK)
{
    selField = 0;
}
else
{
    selField = 1;
}

/* Write the source node. */
/* Node value is only 7 bits. The high order bit is selField. */
if (flexDomain)
{
    npduPtr->data[1] = selField << 7; /* SrcNode is 0. */
}
else
{
    npduPtr->data[1] = selField << 7 |
        eep->domainTable[nwSendParamPtr->destAddr.domainIndex].node;
}

/* Write the destination address. */
/* Set j to the index for writing the domain field. */
switch (nwSendParamPtr->destAddr.addressMode)
{
    case BROADCAST:
        npduPtr->data[2] = nwSendParamPtr->destAddr.addr.addr0;
        j = 3;
        break;
    case MULTICAST:
        npduPtr->data[2] = nwSendParamPtr->destAddr.addr.addr1;
        j = 3;
        break;
    case SUBNET_NODE:
        nwSendParamPtr->destAddr.addr.addr2a.selField = 1;
        memcpy(&npduPtr->data[2],
            &nwSendParamPtr->destAddr.addr.addr2a,
            2);
        j = 4;
        break;
    case MULTICAST_ACK:
        nwSendParamPtr->destAddr.addr.addr2b.subnetAddr.selField = 1;
        memcpy(&npduPtr->data[2],
            &nwSendParamPtr->destAddr.addr.addr2b,
            4);
        j = 6;
        break;
    case UNIQUE_NODE_ID:
        memcpy(&npduPtr->data[2],
            &nwSendParamPtr->destAddr.addr.addr3,
            7);
        j = 9;
        break;
    default:
        ErrorMessage("NWSend: Unknown address format.\n");
        /* Discard the packet as the address Mode is wrong. */
}

```

```

nmp->errorLog = BAD_ADDRESS_TYPE;
/* Send completion event if it was an APDU */
if (nwSendParamPtr->pduType == APDU_TYPE)
{
    appReceiveParamPtr = QueueTail(&gp->appInQ);
    appReceiveParamPtr->indication = COMPLETION;
    appReceiveParamPtr->success = FALSE;
    appReceiveParamPtr->tag = nwSendParamPtr->tag;
    EnQueue (&gp->appInQ);
}
if (priority)
{
    DeQueue (&gp->nwOutPriQ);
}
else
{
    DeQueue (&gp->nwOutQ);
}
return;
}

```

```

/* Now, j has the index of data field in which domain goes. */
/* Write the domain. We saved this information earlier. */
memcpy(&npduPtr->data[j], domainId, domainLength);
j += domainLength;

```

```

/* Write the enclosed PDU. */
if (1 + j + nwSendParamPtr->pduSize > gp->nwOutBufSize)
{
    /* Discard the packet as it is too long. */
    nmp->errorLog = WRITE_PAST_END_OF_NET_BUFFER;
    /* Send completion event if it was an APDU */
    if (nwSendParamPtr->pduType == APDU_TYPE)
    {
        appReceiveParamPtr = QueueTail(&gp->appInQ);
        appReceiveParamPtr->indication = COMPLETION;
        appReceiveParamPtr->success = FALSE;
        appReceiveParamPtr->tag = nwSendParamPtr->tag;
        EnQueue (&gp->appInQ);
    }
    if (priority)
    {
        DeQueue (&gp->nwOutPriQ);
    }
    else
    {
        DeQueue (&gp->nwOutQ);
    }
    return;
}

```

```

memcpy(&npduPtr->data[j], pduPtr, nwSendParamPtr->pduSize);
/* NPDU size is header_size + enclosed PDU size. */
npduSize = 1 + j + nwSendParamPtr->pduSize;

```

```

/* Write the parameters for the link layer. */
lkSendParamPtr->deltaBL = nwSendParamPtr->deltaBL;
lkSendParamPtr->altPath = nwSendParamPtr->altPath;
lkSendParamPtr->pduSize = npduSize;

```

```

/* Update both queues. */
if (priority)
{
    DeQueue (&gp->nwOutPriQ);
}

```

```

        EnQueue (&gp->lkOutPriQ);
#ifdef DEBUG
        DebugMsg("NWSend: Sending a priority packet.");
#endif
    }
    else
    {
        DeQueue (&gp->nwOutQ);
        EnQueue (&gp->lkOutQ);
#ifdef DEBUG
        DebugMsg("NWSend: Sending a non-priority packet.");
#endif
    }
}

```

```

    INCR_STATS (nmp->stats.layer3Transmitted);

```

```

/* Send completion event if it was an APDU */
if (nwSendParamPtr->pduType == APDU_TYPE)
{
    appReceiveParamPtr = QueueTail (&gp->appInQ);
    appReceiveParamPtr->indication = COMPLETION;
    appReceiveParamPtr->success = TRUE;
    appReceiveParamPtr->tag = nwSendParamPtr->tag;
    EnQueue (&gp->appInQ);
}

```

```

    return;
}

```

```

/*****
Function:  NWReceive
Returns:  None
Reference: None. No receive algorithms in protocol specification.
Purpose:  To receive packets waiting for the network layer
          from the link layer. The NPDU is retrieved, processed
          and the enclosed PDU is sent to the proper destination queue.
          If the NPDU is not for this node, it is discarded.
Comments: Discard packets originated from this node itself.
          It might receive such packets in the presence of repeaters.
*****/

```

Discard packets in which version field is not correct.

Discard packets that match a domain but not subnet or group.

When a node is not in configured state and not in hard-offline state, it can only receive broadcast or matching Unique Node ID messages. In such a case, the domain on which it is received need not match its own domain. If it does not match, then the message is said to be received in a flex domain.

```

*****/

```

```

void  NWReceive(void)
{
    NWReceiveParam    *nwReceiveParamPtr; /* Param in gp->nwInQ. */
    APPReceiveParam   *appReceiveParamPtr;
    TSAResponseParam  *tsaResponseParamPtr;
    SourceAddress      srcAddr;           /* Address of source node. */
    NPDU               *npduPtr;         /* ptr to NPDU being received. */
    Byte               *pduPtr;          /* ptr to item in target queue. */
    uint16             pduSize;          /* Size of enclosed PDU. */
    Boolean            flexDomain;        /* TRUE => NPDU in flexdomain. */
    uint8              numDomains;       /* # of domains of this node. */
    uint8              domainLength;     /* Domain length */
}

```

```

Byte          domainId[DOMAIN_ID_LEN]; /* Temp. */
Byte          uniqueNodeId[UNIQUE_NODE_ID_LEN]; /* Temp. */
SubnetAddress destAddr; /* Temp. */
uint8         j; /* Temp. */

/* First, check if we have any packets to process. */
if (QueueEmpty(&gp->nwInQ))
{
    return; /* Nothing to process. */
}

/* Until we determine what type of PDU we have, we cannot
check for space availability in destination queue.
Also, it is possible that the NPDU may very well be
discarded. */

/* Set the pointer to NPDU in nwInQ. */
nwReceiveParamPtr = QueueHead(&gp->nwInQ);
npduPtr           = (NPDU *) (nwReceiveParamPtr + 1);

/* Discard NPDU if version is not PROTOCOL_VERSION */
if (npduPtr->protocolVersion != PROTOCOL_VERSION)
{
    DeQueue(&gp->nwInQ);
#ifdef DEBUG
    DebugMsg(" NWReceive: Discard packet. Wrong version.\n");
#endif
    return;
}

/* Determine the source address. */
memcpy(&srcAddr.subnetAddr, npduPtr->data, 2);

/* Determine the destination address used and set srcAddr properly. */
/* For MULTICAST and MULTICAST_ACK address modes, the
group and/or member values are copied into srcAddr.group
or srcAddr.ackNode. For BROADCAST and SUBNET_NODE address
modes, destAddr is used to store subnet and/or node
values. For UNIQUE_NODE_ID, uniqueNodeId is used & subnet is ignored */
/* Also, set j to domain field's index. */
switch (npduPtr->addrFmt)
{
    case 0:
        srcAddr.addressMode = BROADCAST;
        destAddr.subnet     = npduPtr->data[2];
        j = 3;
        break;
    case 1:
        srcAddr.addressMode = MULTICAST;
        srcAddr.group       = npduPtr->data[2];
        j = 3;
        break;
    case 2:
        if (srcAddr.subnetAddr.selField == 1)
        {
            srcAddr.addressMode = SUBNET_NODE;
            memcpy(&destAddr, &npduPtr->data[2], 2);
            j = 4;
        }
        else
        {
            srcAddr.addressMode = MULTICAST_ACK;
            memcpy(&destAddr, &npduPtr->data[2], 2);
            memcpy(&srcAddr.ackNode.subnetAddr, &destAddr, 2);
        }
}

```

```

        memcpy(&srcAddr.ackNode.groupAddr, &npduPtr->data[4], 2);
        j = 6;
    }
    break;
case 3:
    srcAddr.addressMode = UNIQUE_NODE_ID;
    destAddr.subnet = npduPtr->data[2]; /* Routing Purpose */
    memcpy(uniqueNodeId, &npduPtr->data[3], UNIQUE_NODE_ID_LEN);
    j = 3 + UNIQUE_NODE_ID_LEN;
    break;
default:
    /* Discard it as the address format is wrong. */
    ErrorMessage("NWReceive: Unknown addFmt.\n");
    nmp->errorLog = BAD_ADDRESS_TYPE;
    DeQueue(&gp->nwInQ);
    return;
}

/* Determine the domain. */
domainLength = DecodeDomainLength(npduPtr->domainLength);
if (domainLength != 0 && domainLength != 1 &&
    domainLength != 3 && domainLength != 6)
{
    ErrorMessage("NWReceive: Domain length is not valid.\n");
    nmp->errorLog = INVALID_DOMAIN;
    /* Discard the packet as the domain length is invalid. */
    DeQueue(&gp->nwInQ);
    return;
}

/* domainLength is good. Safe to use memcpy now. */
memcpy(domainId, &npduPtr->data[j], domainLength);

j += domainLength; /* Now j points to enclosed PDU. */

/* Determine the number of domains for this node. */
if (eep->readOnlyData.twoDomains)
{
    numDomains = 2;
}
else
{
    numDomains = 1;
}

/* Check if the NPDU is received in flexDomain.
   If domainId does not match any of this node's domains,
   then the msg is said to have been received in flex domain. */

flexDomain = FALSE; /* Assume it is not flex domain. */
if (NodeConfigured() && eep->domainTable[0].len != 0xFF &&
    domainLength == eep->domainTable[0].len &&
    memcmp(domainId, eep->domainTable[0].domainId,
           domainLength) == 0)
{
    /* Matches domainId in index 0 */
    srcAddr.domainIndex = 0;
}
else if (NodeConfigured() && numDomains == 2 &&
         eep->domainTable[1].len != 0xFF &&
         domainLength == eep->domainTable[1].len &&
         memcmp(domainId, eep->domainTable[1].domainId,
                domainLength) == 0)
{

```

```

    /* Matches domainId in index 1 */
    srcAddr.domainIndex = 1;
}
else
{
    /* Must be a flex domain. */
    srcAddr.domainIndex = FLEX_DOMAIN;
    srcAddr.flexDomainLen = domainLength;
    memcpy(srcAddr.flexDomainId, domainId, domainLength);
    flexDomain = TRUE;
}

/* Determine if the packet was sent by myself. If so, drop. */
/* We can do this check only in non-flexdomain as
src subnet and node are 0 in flex domain. */
if (! flexDomain &&
    memcmp(&srcAddr.subnetAddr,
        &eep->domainTable[srcAddr.domainIndex].subnet, 2)
    == 0)
{
    /* Not flex domain and source addr matches. */
    DeQueue(&gp->nwInQ); /* Discard packet. */
#ifdef DEBUG
    DebugMsg("NWReceive. Discarding Self Pck\n");
#endif
    return;
}

/* Drop packet in various address modes if not for us. */
switch(srcAddr.addressMode)
{
    case BROADCAST:
        if (!flexDomain &&
            destAddr.subnet != 0 && /* subnet broadcast. */
            memcmp(&destAddr.subnet,
                &eep->domainTable[srcAddr.domainIndex].subnet,
                1) != 0)
        {
            /* Domain matches but destAddr does not. Not for us. */
            DeQueue(&gp->nwInQ);
#ifdef DEBUG
            DebugMsg("NWReceive: Discard BC pck. Not my subnet.\n");
#endif
            return;
        }
        srcAddr.broadcastSubnet = destAddr.subnet;
        break;
    case MULTICAST:
        if (!flexDomain &&
            !IsGroupMember(srcAddr.domainIndex,
                srcAddr.group, NULL) )
        {
            /* Domain matches but group does not. Not for us. */
            DeQueue(&gp->nwInQ);
#ifdef DEBUG
            DebugMsg("NWReceive: Discard MC pck. Not my group.\n");
#endif
            return;
        }
        break;
    case SUBNET_NODE:
        if (!flexDomain &&
            memcmp(&destAddr,
                &eep->domainTable[srcAddr.domainIndex].subnet,

```

```

        2) != 0)
    {
        DeQueue(&gp->nwInQ);
#ifdef DEBUG
        DebugMsg("NWReceive: Discard unicast logical packet. "
                "Not my subnet (or subnode).\n");
#endif
        return;
    }
    break;
case MULTICAST_ACK:
    /* Make sure the destination subnet/node matches. */
    if (!flexDomain &&
        memcmp(&destAddr,
                &eep->domainTable[srcAddr.domainIndex].subnet,
                2) != 0)
    {
        DeQueue(&gp->nwInQ);
#ifdef DEBUG
        DebugMsg("NWReceive: Discard multicast ack packet. "
                "Not my subnet (or subnode).\n");
#endif
        return;
    }
    /* Also make sure that group matches. */
    if (!flexDomain &&
        !IsGroupMember(srcAddr.domainIndex,
                        srcAddr.ackNode.groupAddr.group,
                        NULL) )
    {
        DeQueue(&gp->nwInQ);
#ifdef DEBUG
        DebugMsg("NWReceive: Discard multicast ack packet. "
                "Not my group.\n");
#endif
        return;
    }
    break;
case UNIQUE_NODE_ID:
    if (memcmp(uniqueNodeId,
                eep->readOnlyData.uniqueNodeId,
                UNIQUE_NODE_ID_LEN) != 0)
    {
        /* Unique Node Id message but not for our id. */
        DeQueue(&gp->nwInQ);
#ifdef DEBUG
        DebugMsg("NWReceive: Discard Unique Node ID packet. Not my Id.\n");
#endif
        return;
    }
    break;
default:
    ; /* Null statement. */
    /* Error message has been already printed in the previous switch. */
    /* Control should not come here. But, let us play safe. */
    DeQueue(&gp->nwInQ);
    return;
}

/* If a node is in unconfigured state,
   only broadcast and Unique Node ID messages can be received. */
if (NodeUnConfigured() &&
    srcAddr.addressMode != BROADCAST &&

```

```

        srcAddr.addressMode != UNIQUE_NODE_ID)
    {
        /* Drop the packet. */
        DeQueue(&gp->nwInQ);
#ifdef DEBUG
        DebugMsg("NWReceive: Discard packet. We are not online.\n");
#endif
        return;
    }

    /* Drop packets received on flexDomain if the state
       is not unconfigured and it is not Unique Node ID addressed. */
    /* Unique Node ID addressed packets are always received. */
    /* i.e if node is configured, flexdomain is not possible
       unless it is Unique Node ID addressed. */
    if (flexDomain &&
        NodeConfigured() &&
        srcAddr.addressMode != UNIQUE_NODE_ID)
    {
        /* Drop the packet. */
        DeQueue(&gp->nwInQ);
#ifdef DEBUG
        DebugMsg("NWReceive: Discard packet. Flex domain & not Neu. Id.\n");
#endif
        return;
    }

    /* We now got a packet that must be received. */
    INCR_STATS(nmp->stats.layer3Received);

    /* pduSize = npduSize - npduHeaderSize. */
    /* j is length of the variable part header of NPDU. */
    /* The fixed portion of NPDU header is always 1 byte. */
    pduSize = nwReceiveParamPtr->pduSize - j - 1;

    /* Set the pdu pointer properly. */
    switch (npduPtr->pduType)
    {
        case APDU_TYPE:
            if (QueueFull(&gp->appInQ) ||
                pduSize > gp->appInBufSize)
            {
                /* No space or insufficient space. Discard packet. */
                if (pduSize > gp->appInBufSize)
                {
                    nmp->errorLog = WRITE_PAST_END_OF_APPL_BUFFER;
                }
                INCR_STATS(nmp->stats.lostMessages);
                DeQueue(&gp->nwInQ);
#ifdef DEBUG
                DebugMsg("NWReceive: Discard packet. Insufficient space.\n");
#endif
                return;
            }
            /* Queue is not full and buffer has sufficient space. */
            appReceiveParamPtr = QueueTail(&gp->appInQ);
            pduPtr = (Byte *) appReceiveParamPtr +
                sizeof(APPRceiveParam);

            appReceiveParamPtr->indication = MESSAGE;
            appReceiveParamPtr->srcAddr = srcAddr;
            appReceiveParamPtr->priority = nwReceiveParamPtr->priority;
            appReceiveParamPtr->altPath = nwReceiveParamPtr->altPath;
            appReceiveParamPtr->pduSize = pduSize;

```

```

appReceiveParamPtr->auth      = FALSE;
appReceiveParamPtr->service    = UNACKD;
memcpy(pduPtr, &npduPtr->data[j], pduSize);
EnQueue(&gp->appInQ);
INCR_STATS(nmp->stats.layer6_7MsgsRcvd);
DeQueue(&gp->nwInQ);
return;
case TPDU_TYPE: /* Fall through. */
case SPDU_TYPE: /* Fall through. */
case AUTHPDU_TYPE:
    if (QueueFull(&gp->tsaInQ) ||
        pduSize > gp->tsaInBufSize)
    {
        /* No space or insufficient space. Discard packet. */
        if (pduSize > gp->tsaInBufSize)
        {
            /* Buffer sizes are based on app buf sizes. See
               TSAReset function. */
            nmp->errorLog = WRITE_PAST_END_OF_APPL_BUFFER;
        }
        INCR_STATS(nmp->stats.lostMessages);
        DeQueue(&gp->nwInQ);
#ifdef DEBUG
        DebugMsg("NWReceive: Discard packet. Insufficient space.\n");
#endif
        return;
    }
    /* Queue is not full and buffer has sufficient space. */
    tsaReceiveParamPtr = QueueTail(&gp->tsaInQ);
    pduPtr = (Byte *) tsaReceiveParamPtr +
        sizeof(TSAReceiveParam);
    tsaReceiveParamPtr->pduType = npduPtr->pduType;
    tsaReceiveParamPtr->srcAddr = srcAddr;
    tsaReceiveParamPtr->priority = nwReceiveParamPtr->priority;
    tsaReceiveParamPtr->altPath = nwReceiveParamPtr->altPath;
    tsaReceiveParamPtr->pduSize = pduSize;
    memcpy(pduPtr, &npduPtr->data[j], pduSize);
    EnQueue(&gp->tsaInQ);
    DeQueue(&gp->nwInQ);
    return;
default:
    ErrorMessage("NWReceive: Unknown PDU was received.\n");
    nmp->errorLog = UNKNOWN_PDU;
    DeQueue(&gp->nwInQ);
    return;
}

/* Should not come here. */
}

/*****
Function: DecodeDomainLength
Returns:  Decoded value of domain length code.
Reference: None.
Purpose:  To compute the actual domain length from code.
Comments: None.
*****/
static Byte DecodeDomainLength(Byte lengthCodeIn)
{
    switch(lengthCodeIn)
    {
        case 0:
            return(0);
        case 1:

```

```

        return(1);
    case 2:
        return(3);
    case 3:
        return(6);
    default:
        /* Impossible to come here as lengthCode is 2 bits. */
        ;
    }
    return(0); /* To silence the compiler from complaining. */
}

/*****
Function:  EncodeDomainLength
Returns:  Encode value of domain length.
Reference: None
Purpose:  To compute the encoded value of domain length given.
Comments:
*****/
static Byte EncodeDomainLength(Byte lengthIn)
{
    switch(lengthIn)
    {
        case 0:
            return(0);
        case 1:
            return(1);
        case 3:
            return(2);
        case 6:
            return(3);
        default:
            return(0); /* should not come here. But has to return
                       something. Chose 0 arbitrarily */
    }
}

/*-----End of network.c-----*/

```

A.9 TPDU and SPDU send algorithm with authentication

```

/*****
Reference:  Sections 9 and 10
File:      tsa.c (Transport Session Authentication)
Version:   1.7
Purpose:   Transport, Session and Authentication Layers.
Note:     None.
To Do:    None.
*****/
/*-----
Section: Includes
-----*/
#include <stdio.h>
#include <stdlib.h>
#include <string.h>

```

```

#include <cnp_1.h>
#include <node.h>
#include <queue.h>
#include <tcs.h>
#include <tsa.h>
#include <app.h> /* For TAG related macros and constants */

/*-----
Section: Constant Definitions.
-----*/
/* #define DEBUG */
/* The last few tries for a message are sent using alternate path.
The following constant determines how many are sent like this.
A message is sent on alternate path if retries_left <= ALT_PATH_COUNT.
Thus actual # of messages sent on alternate path is ALT_PATH_COUNT + 1 */
#define ALT_PATH_COUNT 1

/*-----
Section: Type Definitions.
-----*/
typedef enum
{
    TRANSPORT,
    SESSION
} Layer;

typedef enum
{
    ACKD_MSG      = 0, /* for Transport */
    REQUEST_MSG   = 0, /* for Session */
    CHALLENGE_MSG = 0, /* for Authentication */
    UNACK_RPT_MSG = 1, /* for Transport */
    ACK_MSG       = 2, /* for Transport */
    RESPONSE_MSG  = 2, /* for Session */
    REPLY_MSG     = 2, /* for Authentication */
    REMINDER_MSG  = 4, /* for Transport and Session */
    REM MSG MSG   = 5  /* for Transport and Session */
} PDUMsgType; /* Type of msg sent in the PDU
              (TPDU or SPDU or AuthPDU) */

#pragma maxalign(1)
typedef struct
{
    Bits    auth      :1; /* Needs authentication? */
    Bits    pduMsgType :3; /* See PDUMsgType above */
    Bits    transNum  :4;
    Byte    data[1]; /* Variable length field */
} TSPDU; /* Transport or Session PDU */

typedef TSPDU *TSPDUPtr;

typedef struct
{
    Bits    fmt      :2; /* Same as addrfmt. */
    Bits    pduMsgType :2; /* Type of AuthPDU. See PDUMsgType. */
    Bits    transNum  :4; /* Transaction number. */
    union {
        Byte    randomBytes[8]; /* Random number for challenge. */
        Byte    cryptoBytes[8]; /* Encrypted value in response. */
    } value;
    Byte    group; /* Present only if fmt = 1. */
} AuthPDU;
#pragma maxalign()

```

```

typedef AuthPDU *AuthPDUPtr;

/*-----
Section: Globals.
-----*/
/* None */

/* Array to convert address format to address mode. If format is 2,
we convert to SUBNET_NODE instead of MULTICAST_ACK */
static Byte addrFmtToMode[4] =
{
    BROADCAST,      /* 0 */
    MULTICAST,      /* 1 */
    SUBNET_NODE,    /* 2 */
    UNIQUE_NODE_ID /* 3 */
};

/* Array to convert address mode to format. For example,
BROADCAST to 0 MULTICAST to 1 etc. */
static Byte addrModeToFmt[6] =
{
    0,
    2, /* SUBNET_NODE */
    3, /* UNIQUE_NODE_ID */
    0, /* BROADCAST */
    1, /* MULTICAST */
    2 /* MULTICAST_ACK */
};

/*-----
Section: Local Function Prototypes.
-----*/
/* Authentication related functions. */
static void InitiateChallenge(uint16 rrIndexIn);
static void SendReplyToChallenge(void);
static void ProcessReply(void);

/* Transport layer related functions. */
static void TPSendAck(uint16 rrIndexIn);
static void TPReceiveAck(void);

/* Session layer related functions. */
static void SNSendResponse(uint16 rrIndexIn, Boolean nullResponse);
static void SNReceiveResponse(void);

/* Functions that are common to both transport and session layers. */
static void XmitTimerExpiration(Layer layerIn, Boolean priorityIn);
static void TerminateTrans(Boolean priorityIn);
static void SendNewMsg(Layer layerIn, Boolean priorityIn);
static void ReceiveNewMsg(Layer layerIn);
static void ReceiveRem(Layer layerIn);
static void Deliver(uint16 rrIndexIn);

static int16 AllocateRR(void);
static int16 RetrieveRR(SourceAddress srcAddrIn, Boolean priorityIn);

static uint16 ComputeRecvTimerValue(AddrMode addrModeIn,
                                     MulticastAddress group);
static void Encrypt(Byte rand[], APDU *apdu, uint16 apduSize,
                   Byte domainIndex, Byte encryptValue[]);

/*-----
Section: Function Definitions.
-----*/

```

```

-----*/
/*****
Function: TSAReset
Returns: None
Reference: None
Purpose: To initialize the queues used by the transport and session
         layers and to initialize transmit and receive records.
Comments: Sets gp->resetOk to FALSE if unable to reset properly.
*****/
void TSAReset(void)
{
    uint16 queueItemSize;
    uint16 i;

    /* Allocate and initialize the input queue. */

    /* Some TSPDUs have APDU attached and others do not.
       The max # bytes for TSPDU with no APDU is 10 (REMINDER).
       The max header size for those with APDU is 4 (REM/MSG). */
    gp->tsaInBufSize =
        DecodeBufferSize((uint8)eep->readOnlyData.appInBufSize) + 4;
    gp->tsaInBufSize = MAX(gp->tsaInBufSize, 10);
    gp->tsaInQCnt = DecodeBufferCnt((uint8)eep->readOnlyData.appInBufCnt);
    queueItemSize = gp->tsaInBufSize + sizeof(TSAReceiveParam);

    if (QueueInit(&gp->tsaInQ, queueItemSize, gp->tsaInQCnt)
        != SUCCESS)
    {
        ErrorMsg("TSAReset: Unable to initialize the input queue.");
        gp->resetOk = FALSE;
        return;
    }

    /* Allocate and initialize the output queue. */
    gp->tsaOutBufSize =
        DecodeBufferSize((uint8)eep->readOnlyData.appOutBufSize) + 4;
    gp->tsaOutBufSize = MAX(gp->tsaOutBufSize, 10);
    gp->tsaOutQCnt =
        DecodeBufferCnt((uint8)eep->readOnlyData.appOutBufCnt);
    queueItemSize = gp->tsaOutBufSize + sizeof(TSASendParam);

    if (QueueInit(&gp->tsaOutQ, queueItemSize, gp->tsaOutQCnt)
        != SUCCESS)
    {
        ErrorMsg("TSAReset: Unable to initialize the output queue.");
        gp->resetOk = FALSE;
        return;
    }

    /* Allocate and initialize the priority output queue. */
    gp->tsaOutPriBufSize = gp->tsaOutBufSize;
    gp->tsaOutPriQCnt =
        DecodeBufferCnt((uint8)eep->readOnlyData.appOutBufPriCnt);
    queueItemSize = gp->tsaOutPriBufSize + sizeof(TSASendParam);

    if (QueueInit(&gp->tsaOutPriQ, queueItemSize, gp->tsaOutPriQCnt)
        != SUCCESS)
    {
        ErrorMsg("TSAReset: Unable to initialize the priority output queue.");
        gp->resetOk = FALSE;
        return;
    }

    /* Allocate and initialize the responses queue. */

```

```

gp->tsaRespBufSize = gp->tsaOutBufSize;
gp->tsaRespQCnt    = gp->tsaOutQCnt;
queueItemSize     = gp->tsaRespBufSize + sizeof(TSASendParam);

if (QueueInit(&gp->tsaRespQ, queueItemSize, gp->tsaRespQCnt)
    != SUCCESS)
{
    ErrorMsg("TSAReset: Unable to initialize the responses queue.");
    gp->resetOk = FALSE;
    return;
}

/* Initialize the transmit records. */
gp->xmitRec.status    = UNUSED_TX;
gp->priXmitRec.status = UNUSED_TX;

/* Initialize the receive records. */
gp->recvRecCnt = RECEIVE_TRANS_COUNT;
gp->recvRec    = AllocateStorage((uint16) (gp->recvRecCnt *
                                         sizeof(ReceiveRecord)));
if (gp->recvRec == NULL)
{
    ErrorMsg("TSAReset: Insufficient space for allocating receive records.");
    gp->resetOk = FALSE;
    return;
}

for (i = 0; i < gp->recvRecCnt; i++)
{
    gp->recvRec[i].response =
        AllocateStorage(DecodeBufferSize((uint8) eep-
>readOnlyData.appOutBufSize));
    gp->recvRec[i].apdu =
        AllocateStorage(DecodeBufferSize((uint8) eep-
>readOnlyData.appInBufSize));
    if (gp->recvRec[i].response == NULL ||
        gp->recvRec[i].apdu == NULL)
    {
        ErrorMsg("TSAReset: Insufficient space for response or apdu.");
        gp->resetOk = FALSE;
        return;
    }
    gp->recvRec[i].status = UNUSED_RR;
}

/* Initialize the running count for request id assignment. */
gp->reqId = 0;

return;
}

/*****
Function:  TPSend
Returns:   None
Reference: Section 10, Transport layer.
Purpose:   To implement send algorithm for transport layer.
           If there is anything to be sent by transport layer,
           it processes that message and calls the right function
           that sends it.
Comments:  Update the priority transaction timer, if it exists.
           Update the non-priority transaction timer, if it exists.
           If the priority transaction timer expired then
           process this event.
           else if there is a priority message to be sent and there is space

```

```
        in priority queue of the network layer then
        process the priority message.
    else if non-priority transaction timer expired then
        process that event.
    else if there is a non-priority message to be sent and there
        is space in the non-priority queue of the network layer then
        process the non-priority message.
    else
        there is nothing to do. return.
```

Note:

```
*****
```

```
void TPSend(void)
```

```
{
```

```
    /* Delay TPSend after power-up or external reset. */
```

```
    if ( gp->tsDelayTimer.curTimerValue > 0 &&
        (nmp->resetCause == POWER_UP_RESET ||
         nmp->resetCause == EXTERNAL_RESET)
    )
```

```
    {
        UpdateMsTimer(&gp->tsDelayTimer);
        return; /* Do nothing */
    }
```

```
    /* Update transmit timers, if they do exist. */
```

```
    if (gp->priXmitRec.status == TRANSPORT_TX &&
        gp->priXmitRec.xmitTimer.curTimerValue > 0)
```

```
    {
        UpdateMsTimer(&gp->priXmitRec.xmitTimer);
    }
```

```
    if (gp->xmitRec.status == TRANSPORT_TX &&
        gp->xmitRec.xmitTimer.curTimerValue > 0)
```

```
    {
        UpdateMsTimer(&gp->xmitRec.xmitTimer);
    }
```

```
    /******
```

```
    Priority transaction timer expired event.
    *****
```

```
    if (gp->priXmitRec.status == TRANSPORT_TX &&
        gp->priXmitRec.xmitTimer.curTimerValue == 0)
```

```
    {
        XmitTimerExpiration(TRANSPORT, TRUE);
        return;
    }
```

```
    /******
```

```
    Send a new priority message event.
    *****
```

```
    else if (gp->priXmitRec.status == UNUSED_TX &&
        ! QueueEmpty(&gp->tsaOutPriQ) &&
        ! QueueFull(&gp->nwOutPriQ) )
```

```
    {
        SendNewMsg(TRANSPORT, TRUE);
        return;
    }
```

```
    /******
```

```
    Non-priority transaction timer expired event.
    *****
```

```
    else if (gp->xmitRec.status == TRANSPORT_TX &&
        gp->xmitRec.xmitTimer.curTimerValue == 0)
```

```
    {
        XmitTimerExpiration(TRANSPORT, FALSE);
    }
```

```
    /******
```



```

    Send a new non-priority message.
    *****/
    else if (gp->xmitRec.status == UNUSED_TX &&
            ! QueueEmpty(&gp->tsaOutQ) &&
            ! QueueFull(&gp->nwOutQ) )
    {
        SendNewMsg(TRANSPORT, FALSE);
    }
    else
    {
        /* Either there is no work or there is no space. */
        return;
    }

return;

}

/*****
Function: TerminateTrans
Returns:  None
Reference: None
Purpose:  To terminate a transaction for transport or session
          layer and send the completion indication to application
          layer. If the application layer's input queue is full,
          we don't terminate the transaction.
Comments: layerIn is not passed as it is not needed.
*****/
static void TerminateTrans(Boolean priorityIn)
{
    Queue          *tsaQPtr; /* Pointer to source queue */
    TSASendParam  *tsaSendParamPtr;
    APPReceiveParam *appReceiveParamPtr;
    TransmitRecord *xmitRecPtr; /* Ptr to xmit rec (pri or nonpri)*/
    Boolean        success;

    if (QueueFull(&gp->appInQ))
    {
        return; /* Can't send the indication. Come back later. */
    }

    if (priorityIn)
    {
        tsaQPtr = &gp->tsaOutPriQ;
        tsaSendParamPtr = QueueHead(tsaQPtr);
        xmitRecPtr = &gp->priXmitRec;
    }
    else
    {
        tsaQPtr = &gp->tsaOutQ;
        tsaSendParamPtr = QueueHead(tsaQPtr);
        xmitRecPtr = &gp->xmitRec;
    }

    appReceiveParamPtr = QueueTail(&gp->appInQ);

    if (tsaSendParamPtr->service == UNACK_RPT ||
        xmitRecPtr->destCount == xmitRecPtr->ackCount ||
        (xmitRecPtr->nwDestAddr.addressMode == BROADCAST &&
         xmitRecPtr->ackCount >= 1)
        )
    {
        /* UNACK_RPT or ACK and got all acks(or resp). */
        success = TRUE;
    }
}

```

```

    }
    else
    {
        INCR_STATS(nmp->stats.transmitTXFailures);
        success = FALSE; /* REQUEST or ACK and did not get all acks. */
    }
    appReceiveParamPtr->indication = COMPLETION;
    appReceiveParamPtr->success = success;
    appReceiveParamPtr->tag = tsaSendParamPtr->tag;
    EnQueue(&gp->appInQ);

    TransDone(priorityIn); /* Call to TCS. */
    xmitRecPtr->status = UNUSED_TX;
#ifdef DEBUG
    if (success)
    {
        DebugMsg("Debug: TermTran: Terminated the transaction. Success.");
    }
    else
    {
        DebugMsg("Debug: TermTran: Terminated the transaction. Fail.");
    }
#endif
    /* Remove the transaction from the queue. */
    DeQueue(tsaQPtr);
    return;
}

/*****
Function: XmitTimerExpiration
Returns: None
Reference: None
Purpose: To process the XmitTimer expiration event (pri or nonpri).
Retransmission and termination of transaction are
handled. Retransmission might be reply to already
initiated challenge or it might be the APDU itself.
If there is no space for retransmission, the retry is
lost.
Comments: None
*****/
static void XmitTimerExpiration(Layer layerIn, Boolean priorityIn)
{
    TSASendParam *tsaSendParamPtr; /* Param in tsaQ (Pri or nonPri). */
    NWSendParam *nwSendParamPtr; /* Param in nwQ (Pri or nonPri). */
    TransmitRecord *xmitRecPtr; /* Ptr to xmit rec (pri or nonpri). */
    Queue *tsaQPtr; /* Pointer to source queue. */
    Queue *nwQPtr; /* Pointer to target queue. */
    TSPDUPtr pduPtr; /* Pointer to TSPDU being formed. */
    uint8 deltaBL;
    uint16 pduSize;
    int8 i;
    uint8 length; /* For length of reminder in bytes. */
    uint16 queueSpace;

    if (priorityIn)
    {
        tsaQPtr = &gp->tsaOutPriQ;
        tsaSendParamPtr = QueueHead(tsaQPtr);
        nwQPtr = &gp->nwOutPriQ;
        nwSendParamPtr = QueueTail(nwQPtr);
        xmitRecPtr = &gp->priXmitRec;
    }
    else
    {

```

```

    tsaQPtr      = &gp->tsaOutQ;
    tsaSendParamPtr = QueueHead(tsaQPtr);
    nwQPtr      = &gp->nwOutQ;
    nwSendParamPtr = QueueTail(nwQPtr);
    xmitRecPtr   = &gp->xmitRec;
}

/* First, check if we really need to retry the message. */
if (xmitRecPtr->retriesLeft == 0 ||
    xmitRecPtr->destCount == xmitRecPtr->ackCount ||
    (xmitRecPtr->nwDestAddr.addressMode == BROADCAST &&
     xmitRecPtr->ackCount >= 1)
)
{
    /* No More retries left or all acks have been received.
       Terminate the transaction. Send indication to the application
       layer. */
    TerminateTrans(priorityIn);
    return;
}

/* Check if there is space in the network buffer for retransmission */
if (QueueFull(nwQPtr))
{
    /* We are losing a retry chance locally due to lack of space
       in network queue. If we don't want to lose the retry, we
       simply delete the next two lines of code */
    xmitRecPtr->retriesLeft--;
    /* Start the transmit timer */
    SetMsTimer(&xmitRecPtr->xmitTimer, xmitRecPtr->xmitTimerValue);
#ifdef DEBUG
    DebugMsg("XmitTimerExp: Retry failure due to no space in net");
#endif
    return;
}

/* Now, we need to retransmit the message again. */
/* Form the PDU to be sent directly in the target queue. */
pduPtr      = (TSPDUPtr) (nwSendParamPtr + 1);
pduPtr->auth = tsaSendParamPtr->auth;
pduPtr->transNum = xmitRecPtr->transNum;

if (tsaSendParamPtr->service == UNACK_RPT)
{
    pduPtr->pduMsgType = UNACK_RPT_MSG;
    memcpy(pduPtr->data, xmitRecPtr->apdu,
           xmitRecPtr->apduSize);
    pduSize = xmitRecPtr->apduSize + 1;
#ifdef DEBUG
    DebugMsg("XmitTimerExp: Resending UNACK_RPT packet.");
#endif
}
else if (xmitRecPtr->nwDestAddr.addressMode != MULTICAST)
{
    if (layerIn == TRANSPORT)
    {
        pduPtr->pduMsgType = ACKD_MSG;
#ifdef DEBUG
        DebugMsg("XmitTimerExp: Resending ACKD packet.");
#endif
    }
    else if (tsaSendParamPtr->service == REQUEST)
    {
        pduPtr->pduMsgType = REQUEST_MSG;
    }
}

```

```
#ifndef DEBUG
    DebugMsg("XmitTimerExp: Resending REQUEST packet.");
#endif
}
else
{
    /* Response Messages are retried. Something is wrong. */
    /* Force retriesLeft to 0 so that next time we will
       terminate the transaction. */
    xmitRecPtr->retriesLeft = 0;
#ifdef DEBUG
    DebugMsg("XmitTimerExp: Response Message??. What is wrong?");
#endif
    return;
}
memcpy(pduPtr->data, xmitRecPtr->apdu,
        xmitRecPtr->apduSize);
pduSize = xmitRecPtr->apduSize + 1;
}
else
{
    /* Multicast Retry */
    /* Compute the highest numbered group member that has
       acknowledged and form the M_LIST up to that. Since the
       rest of the nodes have not acknowledged, they will
       respond when they see that their bit is missing.
       However, the last byte of M_LIST should be padded with
       0 as those members need to acknowledge. Note that a node
       will respond if its member number is not even present
       in the M_List. */
    /* Group members are 0..MAX_GROUP_NUMBER */
    if (xmitRecPtr->ackCount == 0)
    {
        length = 0;
    }
    else
    {
        /* ackCount > 0, So, we have at least one ack.
           Find the highest member who have responded. */
        for (i = MAX_GROUP_NUMBER; i >= 0; i--)
        {
            if (xmitRecPtr->ackReceived[i])
            {
                break;
            }
        }
        if (i == -1)
        {
            /* There should have been at least one ack. */
            ErrorMsg("XmitTimerExpiration: Something is wrong."
                    " Check code. Atleast one ack member expected.");
            xmitRecPtr->retriesLeft = 0;
            return;
        }
        length = i / 8 + 1; /* Number of bytes in M List. */
    }
}

if (length <= 2)
{
    pduPtr->pduMsgType = REM_MSG_MSG;
    pduPtr->data[0] = length; /* # of bytes in M List. */
    /* Copy the M_LIST. See Fig 8.2 in Protocol Specification. */
    /* We use the fact that ackReceived[i] is 0 or 1. */
    /* The padding of 0's of last byte is automatic as
```



```

        ackReceived[i] for those are anyway 0. */
        pduPtr->data[1] = 0; /* Init anyway even if not used. */
        pduPtr->data[2] = 0; /* Init anyway even if not used. */
        for (i = 0; i < 8*length; i++)
        {
            pduPtr->data[1 + i / 8] |=
                (xmitRecPtr->ackReceived[i] << (i % 8));
        }
        /* Copy APDU. */
        memcpy(&pduPtr->data[1+length],
            xmitRecPtr->apdu,
            xmitRecPtr->apduSize);
        /* TSPDU = 1 byte header + 1 byte for length + M_LIST. */
        pduSize = xmitRecPtr->apduSize + 2 + length;
#ifdef DEBUG
        DebugMsg("XmitTimerExp: Resending REMINDER packet.");
#endif
    }
    else
    {
        /* Length > 2 */
        /* A Pair is sent in this case. First, send the REMINDER
           and then send the ACKD or REQUEST message. */
        /* In this case, we are going to send two msgs.
           So, we need to make sure that the queue has space
           for 2 msgs. If not, return and come back later to
           do this case. */
        queueSpace = QueueCnt(nwQPtr) - QueueSize(nwQPtr);
        if (queueSpace < 2)
        {
            /* We are losing a retry chance locally due to lack
               of space in network queue. */
            xmitRecPtr->retriesLeft--;
            /* Start the transmit timer. */
            SetMsTimer(&xmitRecPtr->xmitTimer,
                xmitRecPtr->xmitTimerValue);
#ifdef DEBUG
            DebugMsg("XmitTimerExp: Retry failure due to no"
                " space in network buffer.");
#endif
            return; /* Not enough space in the queue. Come back. */
        }
        /* Send the REMINDER message. */
        if (tsaSendParamPtr->service == ACKD ||
            tsaSendParamPtr->service == REQUEST)
        {
            nwSendParamPtr = QueueTail(nwQPtr);
            nwSendParamPtr->dropIfUnconfigured = TRUE;
            pduPtr = (TSPDUPtr)
                ((char *)nwSendParamPtr + sizeof(NWSendParam));

            pduPtr->auth        = tsaSendParamPtr->auth;
            pduPtr->pduMsgType  = REMINDER_MSG;
            pduPtr->transNum    = xmitRecPtr->transNum;
            pduPtr->data[0]     = length;

            /* Copy the M_LIST. See Fig 8.2 in Protocol Specification. */
            /* First, initialize all the M_LIST fields to 0. */
            for (i = 1; i <= length; i++)
            {
                pduPtr->data[i] = 0;
            }
            /* Set the bits for M_LIST field based on received acks. */
            for (i = 0; i < 8*length; i++)

```

```
{
    pduPtr->data[1 + i / 8] |=
        (xmitRecPtr->ackReceived[i] << (i % 8));
}

pduSize = 2 + length; /* REMINDER has no APDU. */

/* Fill in the NWSendParam structure. */
nwSendParamPtr->destAddr = xmitRecPtr->nwDestAddr;
if (layerIn == TRANSPORT)
{
    nwSendParamPtr->pduType = TPDU_TYPE;
}
else
{
    nwSendParamPtr->pduType = SPDU_TYPE;
}
nwSendParamPtr->deltaBL = 0; /* REMINDER has deltaBL 0. */
nwSendParamPtr->pduSize = pduSize;

/* UnAck_rpt packets do not use alt path. */
if (tsaSendParamPtr->service != UNACK_RPT)
{
    nwSendParamPtr->altPath =
        (xmitRecPtr->retriesLeft <= (ALT_PATH_COUNT + 1));
}
else
{
    nwSendParamPtr->altPath = FALSE;
}

/* if altPath has override, use it */
if (tsaSendParamPtr->altPathOverride)
{
    nwSendParamPtr->altPath = tsaSendParamPtr->altPath;
}

/* Add TSPDU into the queue. */
EnQueue(nwQPtr);
}

/* Send the ACKD or REQUEST. */
nwSendParamPtr = QueueTail(nwQPtr);
nwSendParamPtr->dropIfUnconfigured = TRUE;
pduPtr = (TSPDUPtr)
    ((char *)nwSendParamPtr + sizeof(NWSendParam));
pduPtr->auth = tsaSendParamPtr->auth;
pduPtr->transNum = xmitRecPtr->transNum;
if (tsaSendParamPtr->service == ACKD)
{
    pduPtr->pduMsgType = ACKD_MSG;
}
else
{
    pduPtr->pduMsgType = REQUEST_MSG;
}
memcpy(pduPtr->data,
        xmitRecPtr->apdu,
        xmitRecPtr->apduSize);
pduSize = xmitRecPtr->apduSize + 1;

#ifdef DEBUG
    DebugMsg("XmitTimerExp: Resending REM/MSG pair.");
#endif
#endif
```



```

    }
}

if (tsaSendParamPtr->service != UNACK_RPT)
{
    INCR_STATS(nmp->stats.transmitTXRetries);
}

/* Compute the delta backlog value. */
deltaBL = 1; /* for subnet and unique id messages. */
if (tsaSendParamPtr->service == UNACK_RPT)
{
    deltaBL = 0; /* Only on first attempt, deltaBL is retries left. */
}
else if (xmitRecPtr->nwDestAddr.addressMode == BROADCAST)
{
    /* Domainwide or subnet BROADCAST. */
    /* If there is no override value for deltaBL, then it is 15. */
    if (tsaSendParamPtr->destAddr.bcast.backlog)
    {
        deltaBL = tsaSendParamPtr->destAddr.bcast.backlog;
    }
    else
    {
        deltaBL = 15;
    }
}
else if (xmitRecPtr->nwDestAddr.addressMode == MULTICAST)
{
    /* deltaBL is outstanding responses or acknowledgements. */
    deltaBL = xmitRecPtr->destCount - xmitRecPtr->ackCount;
}

/* Fill in the NWSendParam structure */
nwSendParamPtr->destAddr = xmitRecPtr->nwDestAddr;
if (layerIn == TRANSPORT)
{
    nwSendParamPtr->pduType = TPDU_TYPE;
}
else
{
    nwSendParamPtr->pduType = SPDU_TYPE;
}
nwSendParamPtr->deltaBL = deltaBL;

/* UnAck rpt packets do not use alt path. */
if (tsaSendParamPtr->service != UNACK_RPT)
{
    nwSendParamPtr->altPath =
        (xmitRecPtr->retriesLeft <= (ALT_PATH_COUNT + 1));
}
else
{
    nwSendParamPtr->altPath = FALSE;
}
/* if altPath has override, use it */
if (tsaSendParamPtr->altPathOverride)
{
    nwSendParamPtr->altPath = tsaSendParamPtr->altPath;
}

nwSendParamPtr->pduSize = pduSize;

```

```

xmitRecPtr->retriesLeft--;

/* Add TSPDU into the queue. */
EnQueue(nwQPtr);

/* Start the transmit timer. */
SetMsTimer(&xmitRecPtr->xmitTimer, xmitRecPtr->xmitTimerValue);

return;
}

/*****
Function: SendNewMsg
Returns: None
Reference: None
Purpose: To process a new request from the application layer that
is in the tsa output queue (pri or nonpri). Request or ACKD.
Comments: This fn is called only if there is space in the
corresponding queue of the network layer.
*****/
static void SendNewMsg(Layer layerIn, Boolean priorityIn)
{
    Queue *tsaQPtr; /* Pointer to the source queue. */
    TSASendParam *tsaSendParamPtr; /* Param in tsaQ (Pri or non-pri). */
    Queue *nwQPtr; /* Pointer to target queue. */
    NWSendParam *nwSendParamPtr; /* Param in nwQ (Pri or non-pri). */
    TransmitRecord *xmitRecPtr; /* Ptr to xmit rec. */
    DestinationAddress nwDestAddr; /* Destination address. */
    TSPDUPtr pduPtr; /* Pointer to TSPDU being formed. */
    APPReceiveParam *appReceiveParamPtr;
    Status status;
    uint16 rptTimer;
    uint8 retryCount;
    uint16 txTimer;
    uint8 deltaBL;
    uint16 nwBufSize;
    int8 i;

    if (priorityIn)
    {
        tsaQPtr = &gp->tsaOutPriQ;
        tsaSendParamPtr = QueueHead(tsaQPtr);
        nwQPtr = &gp->nwOutPriQ;
        nwSendParamPtr = QueueTail(nwQPtr);
        nwBufSize = gp->nwOutPriBufSize;
        xmitRecPtr = &gp->priXmitRec;
    }
    else
    {
        tsaQPtr = &gp->tsaOutQ;
        tsaSendParamPtr = QueueHead(tsaQPtr);
        nwQPtr = &gp->nwOutQ;
        nwSendParamPtr = QueueTail(nwQPtr);
        nwBufSize = gp->nwOutBufSize;
        xmitRecPtr = &gp->xmitRec;
    }

    /* If processing a new message, make sure that it is for this
layer. If not, we are done. */

    if (layerIn == TRANSPORT &&
        tsaSendParamPtr->service != ACKD &&
        tsaSendParamPtr->service != UNACK_RPT)

```

```

{
    return;
}

if (layerIn == TRANSPORT && NV_LAST_TAG(tsaSendParamPtr->tag))
{
    if (QueueFull(&gp->appInQ))
    {
        return;
    }
    /* Special tag used by application layer for synchronization.
       Send completion indication right away. */
    appReceiveParamPtr = QueueTail(&gp->appInQ);
    appReceiveParamPtr->indication = COMPLETION;
    appReceiveParamPtr->success = TRUE;
    appReceiveParamPtr->tag = tsaSendParamPtr->tag;
    EnQueue(&gp->appInQ);
    DeQueue(tsaQPtr);
    return;
}

if (layerIn == SESSION && tsaSendParamPtr->service != REQUEST)
{
    /* Responses are placed in the response queue. */
    return;
}

/* Make sure that large group size is not used for ack
   or request service. */
if (tsaSendParamPtr->destAddr.group.groupFlag &&
    tsaSendParamPtr->destAddr.group.groupSize == 0 &&
    tsaSendParamPtr->service != UNACK_RPT)
{
    /* Large groups can only use unack or unack_rpt services. */
    /* Indicate failure of this message to application layer. */
    if (!QueueFull(&gp->appInQ))
    {
        appReceiveParamPtr = QueueTail(&gp->appInQ);
        appReceiveParamPtr->indication = COMPLETION;
        appReceiveParamPtr->success = FALSE;
        appReceiveParamPtr->tag = tsaSendParamPtr->tag;
        EnQueue(&gp->appInQ);
        DeQueue(tsaQPtr);
    }
    else
    {
        /* We wait until appInQ has space for the indication. */
    }
    return;
}
/* Make sure that groupSize is in the proper range. */
/* *** START INFORMATIVE - Group Size *** */
/* See "START INFORMATIVE - Group Size" below. */
#ifdef GROUP_SIZE_COMPATIBILITY
    if (tsaSendParamPtr->destAddr.group.groupFlag &&
        (tsaSendParamPtr->destAddr.group.groupSize == 1 ||
         tsaSendParamPtr->destAddr.group.groupSize > MAX_GROUP_NUMBER+1) )
#else
    if (tsaSendParamPtr->destAddr.group.groupFlag &&
        tsaSendParamPtr->destAddr.group.groupSize > MAX_GROUP_NUMBER)
#endif
/* *** END INFORMATIVE - Group Size *** */
{
    /* Indicate failure of this message to application layer. */
}

```

```

    if (!QueueFull(&gp->appInQ))
    {
        appReceiveParamPtr = QueueTail(&gp->appInQ);
        appReceiveParamPtr->indication = COMPLETION;
        appReceiveParamPtr->success = FALSE;
        appReceiveParamPtr->tag = tsaSendParamPtr->tag;
        EnQueue(&gp->appInQ);
        DeQueue(tsaQPtr);
    }
    else
    {
        /* We wait until appInQ has space for indication. */
    }
    return;
}

```

```

/* Make sure there is space in network buffer. If not, we fail. */
/* apdu + (tran or session header of 1 byte) should fit. */
if ((tsaSendParamPtr->apduSize + 1) > nwBufSize)
{
    /* We can't send this message as it is too big for
       the network layer's buffer. */
    /* Right now, we haven't allocated any transmit record. */
    /* So, we directly give the indication to application. */
    if (!QueueFull(&gp->appInQ))
    {
        appReceiveParamPtr = QueueTail(&gp->appInQ);
        appReceiveParamPtr->indication = COMPLETION;
        appReceiveParamPtr->success = FALSE;
        appReceiveParamPtr->tag = tsaSendParamPtr->tag;
        EnQueue(&gp->appInQ);
        DeQueue(tsaQPtr);
    }
    else
    {
        /* We wait until appInQ has space for indication. */
    }
    return;
}

```

```

/* First, compute nwDestAddr from destAddr. */
/* First, initialize domainIndex. Only if it is COMPUTE_DOMAIN_INDEX,
   we need to recompute it based on destAddr field value. */
nwDestAddr.domainIndex = tsaSendParamPtr->domainIndex;
switch (tsaSendParamPtr->destAddr.noAddress)
{
    case UNBOUND:
        /* Not in use or turnaround format. */
        if (!QueueFull(&gp->appInQ))
        {
            ErrorMessage("SendNewMsg: UNBOUND destination address is invalid.");
            appReceiveParamPtr = QueueTail(&gp->appInQ);
            appReceiveParamPtr->indication = COMPLETION;
            appReceiveParamPtr->success = FALSE;
            appReceiveParamPtr->tag = tsaSendParamPtr->tag;
            EnQueue(&gp->appInQ);
            DeQueue(tsaQPtr);
        }
        else
        {
            /* We wait until appInQ has space for indication. */
        }
        return;
    case SUBNET_NODE:

```

```

nwDestAddr.addressMode = SUBNET_NODE;
if (tsaSendParamPtr->domainIndex == COMPUTE_DOMAIN_INDEX)
{
    /* Use the domainIndex from destAddr. */
    nwDestAddr.domainIndex =
        tsaSendParamPtr->destAddr.snode.domainIndex;
}
nwDestAddr.addr.addr2a.subnet =
    tsaSendParamPtr->destAddr.snode.subnetID;
nwDestAddr.addr.addr2a.selField = 1; /* always 1 */
nwDestAddr.addr.addr2a.node =
    tsaSendParamPtr->destAddr.snode.node;
txTimer =
    DecodeTxTimer((uint8) tsaSendParamPtr->destAddr.snode.txTimer);
rptTimer =
    DecodeRptTimer((uint8) tsaSendParamPtr->destAddr.snode.rptTimer);
retryCount =
    tsaSendParamPtr->destAddr.snode.retryCount;
break;
case UNIQUE_NODE_ID:
nwDestAddr.addressMode = UNIQUE_NODE_ID;
if (tsaSendParamPtr->domainIndex == COMPUTE_DOMAIN_INDEX)
{
    nwDestAddr.domainIndex =
        tsaSendParamPtr->destAddr.uniqueNodeId.domainIndex;
}
nwDestAddr.addr.addr3.subnet =
    tsaSendParamPtr->destAddr.uniqueNodeId.subnetID;
memcpy(nwDestAddr.addr.addr3.uniqueId,
        tsaSendParamPtr->destAddr.uniqueNodeId.uniqueId,
        UNIQUE_NODE_ID_LEN);
txTimer =
    DecodeTxTimer((uint8) tsaSendParamPtr->destAddr.uniqueNodeId.txTimer);
rptTimer =
    DecodeRptTimer((uint8) tsaSendParamPtr->
>destAddr.uniqueNodeId.rptTimer);
retryCount =
    tsaSendParamPtr->destAddr.uniqueNodeId.retryCount;
break;
case BROADCAST:
/* The following field is not used in this mode by
application. It is however used in BROADCAST_GROUP. */
tsaSendParamPtr->destAddr.bcast.maxResponses = 1;
/* Fall Through */
/* *** START INFORMATIVE - Broadcast Group */
/* Broadcast group addressing is optional. It can not be assumed that all
devices
* support this form of addressing. */
case BROADCAST_GROUP:
nwDestAddr.addressMode = BROADCAST;
if (tsaSendParamPtr->domainIndex == COMPUTE_DOMAIN_INDEX)
{
    nwDestAddr.domainIndex =
        tsaSendParamPtr->destAddr.bcast.domainIndex;
}
nwDestAddr.addr.addr0 =
    tsaSendParamPtr->destAddr.bcast.subnetID;
txTimer =
    DecodeTxTimer((uint8) tsaSendParamPtr->destAddr.bcast.txTimer);
rptTimer =
    DecodeRptTimer((uint8) tsaSendParamPtr->destAddr.bcast.rptTimer);
retryCount =
    tsaSendParamPtr->destAddr.bcast.retryCount;
break;

```

```
/* *** END INFORMATIVE - Broadcast Group */
default:
/* Must be group format unless it is an invalid value. */
if (tsaSendParamPtr->destAddr.group.groupFlag != 1)
{
/* It must be some invalid value. Let us fail. */
nmp->errorLog = BAD_ADDRESS_TYPE;
if (!QueueFull(&gp->appInQ))
{
ErrorMsg("SendNewMsg: Invalid group format addr.");
appReceiveParamPtr = QueueTail(&gp->appInQ);
appReceiveParamPtr->indication = COMPLETION;
appReceiveParamPtr->success = FALSE;
appReceiveParamPtr->tag = tsaSendParamPtr->tag;
EnQueue(&gp->appInQ);
DeQueue(tsaQPtr);
}
else
{
/* We wait until appInQ has space for indication. */
}
return;
}
nwDestAddr.addressMode = MULTICAST;
if (tsaSendParamPtr->domainIndex == COMPUTE_DOMAIN_INDEX)
{
nwDestAddr.domainIndex =
tsaSendParamPtr->destAddr.group.domainIndex;
}
nwDestAddr.addr.addr1 =
tsaSendParamPtr->destAddr.group.groupID;
txTimer =
DecodeTxTimer((uint8) tsaSendParamPtr->destAddr.group.txTimer);
rptTimer =
DecodeRptTimer((uint8) tsaSendParamPtr->destAddr.group.rptTimer);
retryCount =
tsaSendParamPtr->destAddr.group.retryCount;
} /* switch */

if (nwDestAddr.domainIndex == FLEX_DOMAIN)
{
/* flex domain. Copy the domain id. */
nwDestAddr.flexDomainLen = tsaSendParamPtr->flexDomainLen;
if (tsaSendParamPtr->flexDomainLen <= DOMAIN_ID_LEN)
{
memcpy(nwDestAddr.flexDomainId,
tsaSendParamPtr->flexDomainId,
tsaSendParamPtr->flexDomainLen);
}
}
/* Get transaction number using nwDestAddr. */
status = NewTrans(priorityIn, nwDestAddr, &xmitRecPtr->transNum);
if (status == FAILURE)
{
/* Unable to get the transaction number. Give up. Try later. */
return;
}

/* Initialize the xmit record. */
if (layerIn == TRANSPORT)
{
xmitRecPtr->status = TRANSPORT_TX;
}
else
```



```

    xmitRecPtr->status = SESSION_TX;
}
xmitRecPtr->nwDestAddr = nwDestAddr; /* Save it for future use. */
for (i = 0; i <= MAX_GROUP_NUMBER; i++)
{
    xmitRecPtr->ackReceived[i] = FALSE;
}

if (nwDestAddr.addressMode == MULTICAST)
{
    /* If the node is a member of the group, then group size
       field is set to 1 more than actual group size
       by in app layer or app pgm.
       However, provide an option to set this to the
       true group size and transport and session layers
       will take care of this. */
    xmitRecPtr->destCount =
        tsaSendParamPtr->destAddr.group.groupSize - 1;
    /* *** START INFORMATIVE - Group Size *** */
    /* To be fully compatible with all applications, you must use the
       GROUP_SIZE_COMPATIBILITY option. This behavior only affects explicitly
       addressed messages originated by the application. */
#ifdef GROUP_SIZE_COMPATIBILITY
    if (!IsGroupMember(tsaSendParamPtr->destAddr.group.domainIndex,
                      tsaSendParamPtr->destAddr.group.group,
                      &groupMember))
    {
        /* node is not a member & group size is true size */
        xmitRecPtr->destCount =
            tsaSendParamPtr->destAddr.group.groupSize;
    }
#endif
    /* *** END INFORMATIVE - Group Size *** */
    if (xmitRecPtr->destCount == 0)
    {
        /* If the value is incorrect, set it to 1. We need at least
           one acknowledgement or response. */
#ifdef DEBUG
        DebugMsg("SendNewMsg: groupSize incorrect. Default assumed.");
#endif
        xmitRecPtr->destCount = 1;
    }
}
else
{
    xmitRecPtr->destCount = 1;
}

xmitRecPtr->retriesLeft = retryCount;
xmitRecPtr->ackCount = 0;
xmitRecPtr->apdu = (APDU *) (tsaSendParamPtr + 1);
xmitRecPtr->apduSize = tsaSendParamPtr->apduSize;
if (tsaSendParamPtr->service == UNACK_RPT)
{
    xmitRecPtr->xmitTimerValue = rptTimer;
}
else
{
    xmitRecPtr->xmitTimerValue = txTimer;
}

/* Form the TSPDU to be sent directly in queue. */
pduPtr = (TSPDUPtr)

```

```

    ((char *)nwSendParamPtr + sizeof(NWSendParam));
    pduPtr->auth = tsaSendParamPtr->auth;
    /* Save auth status so that if a challenge comes later on
       we can at least verify that it was legitimate challenge */
    xmitRecPtr->auth = tsaSendParamPtr->auth;
    if (tsaSendParamPtr->service == UNACK_RPT)
    {
        pduPtr->pduMsgType = UNACK_RPT_MSG;
#ifdef DEBUG
        DebugMsg("SendNewMsg: Sending a new UNACK_RPT packet.");
#endif
    }
    else if (layerIn == TRANSPORT)
    {
        pduPtr->pduMsgType = ACKD_MSG;
#ifdef DEBUG
        DebugMsg("SendNewMsg: Sending a new ACKD packet.");
#endif
    }
    else if (tsaSendParamPtr->service == REQUEST)
    {
        pduPtr->pduMsgType = REQUEST_MSG;
#ifdef DEBUG
        DebugMsg("SendNewMsg: Sending a new REQ packet.");
#endif
    }
    else
    {
#ifdef DEBUG
        DebugMsg("SendNewMsg: Something is wrong. Unknown service.");
#endif
    }
    pduPtr->transNum = xmitRecPtr->transNum;
    memcpy(pduPtr->data, xmitRecPtr->apdu,
           xmitRecPtr->apduSize);

    /* Compute the delta backlog value. */
    deltaBL = 1; /* For subnet and unique node id messages. */
    if (tsaSendParamPtr->service == UNACK_RPT_MSG)
    {
        deltaBL = xmitRecPtr->retriesLeft;
    }
    else if (nwDestAddr.addressMode == BROADCAST)
    {
        if (tsaSendParamPtr->destAddr.bcast.backlog)
        {
            deltaBL = tsaSendParamPtr->destAddr.bcast.backlog;
        }
        else
        {
            deltaBL = 15;
        }
    }
    else if (nwDestAddr.addressMode == MULTICAST)
    {
        deltaBL = xmitRecPtr->destCount;
    }

    /* Fill in the NWSendParam structure. */
    nwSendParamPtr->dropIfUnconfigured = TRUE;
    nwSendParamPtr->destAddr = nwDestAddr;
    if (layerIn == TRANSPORT)
    {
        nwSendParamPtr->pduType = TPDU_TYPE;
    }

```

```

    }
    else
    {
        nwSendParamPtr->pduType = SPDU_TYPE;
    }
    nwSendParamPtr->deltaBL = deltaBL;

    /* UnAck_rpt packets do not use alternate path. */
    if (tsaSendParamPtr->service != UNACK_RPT)
    {
        nwSendParamPtr->altPath = (retryCount <= ALT_PATH_COUNT);
    }
    else
    {
        nwSendParamPtr->altPath = FALSE;
    }

    /* if altPath has override, use it */
    if (tsaSendParamPtr->altPathOverride)
    {
        nwSendParamPtr->altPath = tsaSendParamPtr->altPath;
    }

    nwSendParamPtr->pduSize = xmitRecPtr->apduSize + 1;

    /* Add the TSPDU into the queue. */
    EnQueue(nwQPtr);

    /* Start the transmit timer. */
    SetMsTimer(&xmitRecPtr->xmitTimer, xmitRecPtr->xmitTimerValue);

    return;
}

/*****
Function: TPReceive
Returns: None
Reference: None
Purpose: To receive and process incoming TPDU's by calling
         appropriate functions. Also handle receive timers.
Comments: None
*****/
void TPReceive(void)
{
    TSAReceiveParam *tsaReceiveParamPtr; /* Param in tsaQ. */
    TSPDUPtr      pduInPtr;             /* Pointer to TPDU received. */
    int16         i;

    /* Update all the receive timers, if they do exist */
    for (i = 0; i < gp->recvRecCnt; i++)
    {
        if (gp->recvRec[i].status == TRANSPORT_RR)
        {
            if (gp->recvRec[i].recvTimer.curTimerValue > 0)
            {
                UpdateMsTimer(&gp->recvRec[i].recvTimer);
            }
            if (gp->recvRec[i].recvTimer.curTimerValue == 0)
            {
                /* Timer expired. See if RR can be released. */
#ifdef DEBUG
                DebugMsg("TPReceive: Receive timer expired.");
#endif
            }
        }
    }
}

```

```

/* Deliver the message if it has not been delivered. */
/* Deliver fn checks for authentication */
if (gp->rcvRec[i].transState == DELIVERED ||
    gp->rcvRec[i].transState == DONE)
{
    gp->rcvRec[i].status = UNUSED_RR; /* Release the RR */
}
else
{
    Deliver(i);
    if (gp->rcvRec[i].serviceType == ACKD &&
        gp->rcvRec[i].transState == DELIVERED)
    {
        TPSendAck(i); /* may get lost due to no space. */
    }
}
}
else if ((gp->rcvRec[i].transState == JUST_RECEIVED &&
        !gp->rcvRec[i].needAuth) ||
        gp->rcvRec[i].transState == AUTHENTICATED )
{
    /* The request does not need authentication and just received
    or it has been authenticated */
    Deliver(i);
    if (gp->rcvRec[i].serviceType == ACKD &&
        gp->rcvRec[i].transState == DELIVERED)
    {
        TPSendAck(i); /* may get lost due to no space. */
    }
    /* We can't release RR as it is not expired yet. */
}
}
}

/* Check if there is TPDU to be processed. */
if (QueueEmpty(&gp->tsaInQ))
{
    /* There is nothing to process. */
    return;
}

tsaReceiveParamPtr = QueueHead(&gp->tsaInQ);
pduInPtr = (TSPDUPtr) (tsaReceiveParamPtr + 1);

/* Check if the PDU is for transport layer. If not, we are done. */
if (tsaReceiveParamPtr->pduType != TPDU_TYPE)
{
    return;
}

/* We have a TPDU to be processed. Check the type and
process accordingly. */
switch (pduInPtr->pduMsgType)
{
    case ACK_MSG:
        TPReceiveAck();
        return;
    case ACKD_MSG:
        /* Fall through. */
    case UNACK_RPT_MSG:
        ReceiveNewMsg(TRANSPORT);
        return;
    case REMINDER_MSG:

```

```

        /* Fall through. */
        case REM_MSG_MSG:
            ReceiveRem(TRANSPORT);
            return;
        default:
            ErrorMessage("TPReceive: Unknown TPDU type received.");
            DeQueue(&gp->tsaInQ);
            nmp->errorLog = UNKNOWN_PDU;
    }

    return;
}

/*****
Function:  TPReceiveAck
Returns:   None
Reference: None
Purpose:   To process ACK message received by the transport layer.
Comments:  ACK might correspond to a transmit record or it may be
           stale, in which case we ignore it.
*****/
static void TPReceiveAck(void)
{
    TSAReceiveParam *tsaReceiveParamPtr;
    TSPDUPtr        pduPtr;
    TransmitRecord *xmitRecPtr; /* Ptr to xmit rec (pri or nonpri). */

    tsaReceiveParamPtr = QueueHead(&gp->tsaInQ);
    pduPtr              = (TSPDUPtr) (tsaReceiveParamPtr + 1);

    /* Set the corresponding transmit pointer. */
    if (tsaReceiveParamPtr->priority)
    {
        xmitRecPtr = &gp->priXmitRec;
    }
    else
    {
        xmitRecPtr = &gp->xmitRec;
    }

    if (ValidateTrans(tsaReceiveParamPtr->priority, pduPtr->transNum)
        == TRANS_NOT_CURRENT)
    {
        /* Stale ACK. Ignore it. */
        DeQueue(&gp->tsaInQ);
#ifdef DEBUG
        DebugMsg("Debug: TPReceiveAck: Stale Ack Discarded");
#endif
        INCR_STATS(nmp->stats.lateAcknowledgements);
        return;
    }

    /* Check if the ACK really corresponds to the transaction in progress. */
    if (xmitRecPtr->status != TRANSPORT_TX ||
        xmitRecPtr->nwDestAddr.domainIndex !=
        tsaReceiveParamPtr->srcAddr.domainIndex)
    {
        /* Transmit record is not ours or the domain index for Ack
           and the transaction do not match. */
        DeQueue(&gp->tsaInQ);
#ifdef DEBUG
        DebugMsg("Debug: TPReceiveAck: Stale ack discarded.");
#endif
        INCR_STATS(nmp->stats.lateAcknowledgements);
    }
}

```

```

    return;
}

if (xmitRecPtr->nwDestAddr.addressMode == SUBNET_NODE &&
    (xmitRecPtr->nwDestAddr.addr.addr2a.subnet !=
    tsaReceiveParamPtr->srcAddr.subnetAddr.subnet ||
    xmitRecPtr->nwDestAddr.addr.addr2a.node !=
    tsaReceiveParamPtr->srcAddr.subnetAddr.node))
{
    /* Source address of ACK does not match destination address of
    transmit record. */
    /* ACK does not seem to correspond to what we are expecting. */
    DeQueue(&gp->tsaInQ);
#ifdef DEBUG
    DebugMsg("Debug: TPReceiveAck: Stale Ack discarded.");
#endif
    INCR_STATS(nmp->stats.lateAcknowledgements);
    return;
}

if (xmitRecPtr->nwDestAddr.addressMode == MULTICAST &&
    (tsaReceiveParamPtr->srcAddr.addressMode != MULTICAST_ACK ||
    xmitRecPtr->nwDestAddr.addr.addr1 !=
    tsaReceiveParamPtr->srcAddr.ackNode.groupAddr.group))
{
    /* MULTICAST message but not MULTICAST_ACK or the ack's group
    # does not match that of xmitRecord. */
    /* ACK does not seem to correspond to what we are expecting. */
    DeQueue(&gp->tsaInQ);
#ifdef DEBUG
    DebugMsg("Debug: TPReceiveAck: Stale ack discarded.");
#endif
    INCR_STATS(nmp->stats.lateAcknowledgements);
    return;
}

/* For broadcast messages, ACK can come back with subnet value of 0
from unconfigured nodes. We should accept these acks too. */
if (xmitRecPtr->nwDestAddr.addressMode == BROADCAST &&
    tsaReceiveParamPtr->srcAddr.subnetAddr.subnet != 0 &&
    xmitRecPtr->nwDestAddr.addr.addr0 != 0 &&
    xmitRecPtr->nwDestAddr.addr.addr0 !=
    tsaReceiveParamPtr->srcAddr.subnetAddr.subnet)
{
    /* Subnet broadcast but the ACK's subnet does not match. */
    /* ACK does not seem to correspond to what we are expecting. */
    DeQueue(&gp->tsaInQ);
#ifdef DEBUG
    DebugMsg("Debug: TPReceiveAck: Stale ack discarded.");
#endif
    INCR_STATS(nmp->stats.lateAcknowledgements);
    return;
}

switch (xmitRecPtr->nwDestAddr.addressMode)
{
    case BROADCAST: /* Fall Through. */
    case SUBNET_NODE: /* Fall Through. */
    case UNIQUE_NODE_ID:
        /* Normally the first ack should have terminated the transaction.
        If it did not, we can try to terminate again. There is no
        harm in doing this. Also, there is no harm in increment
        ackCount as XmitTimerExpiration checks for ackCount >= 1. */
        xmitRecPtr->ackCount++; /* Got one more ack. */
}

```

```

        TerminateTrans(tsaReceiveParamPtr->priority);
        break;
    case MULTICAST:
        /* Group acknowledgement. */
        if (tsaReceiveParamPtr->srcAddr.ackNode.groupAddr.member
            > MAX_GROUP_NUMBER)
        {
            ErrorMsg("TPReceiveAck: Invalid group number.");
            break;
        }
        if (!xmitRecPtr->ackReceived[
            tsaReceiveParamPtr->srcAddr.ackNode.groupAddr.member])
        {
            /* We did not receive this ack in past. */
            xmitRecPtr->ackReceived[
                tsaReceiveParamPtr->srcAddr.ackNode.groupAddr.member]
                = TRUE;
            xmitRecPtr->ackCount++;
#ifdef DEBUG
            DebugMsg("TPReceiveAck: A new multicast ACK recvd.");
#endif
        }
        else
        {
            /* Else, it is a duplicate Ack. Ignore it. */
#ifdef DEBUG
            DebugMsg("TPReceiveAck: A Duplicate Mul. ACK ignored");
#endif
        }
        if (xmitRecPtr->destCount == xmitRecPtr->ackCount)
        {
            TerminateTrans(tsaReceiveParamPtr->priority);
        }
        break;
    default:
        nmp->errorLog = BAD_ADDRESS_TYPE;
        ErrorMsg("TPReceiveAck: Invalid address mode");
    }

#ifdef DEBUG
    DebugMsg("TPReceiveAck: Ack was received.");
#endif

    DeQueue(&gp->tsaInQ);

    /* Restart the Xmit Timer if the Xmit record is still active. */
    if (xmitRecPtr->status != UNUSED_TX)
    {
        SetMSTimer(&xmitRecPtr->xmitTimer, xmitRecPtr->xmitTimerValue);
    }

    return;
}

/*****
Function: SNReceiveResponse
Returns: None
Reference: None
Purpose: To process response message received by the session layer.
Comments: Response should correspond to current transaction in
          progress Or else it is thrown away.
*****/
static void SNReceiveResponse(void)

```

```

{
    TSAReceiveParam *tsaReceiveParamPtr;
    TSASendParam *tsaSendParamPtr;
    TSPDUPtr pduPtr;
    TransmitRecord *xmitRecPtr; /* Ptr to xmit rec (pri or nonpri). */
    APPReceiveParam *appReceiveParamPtr;
    APDU *apduPtr;

    tsaReceiveParamPtr = QueueHead(&gp->tsaInQ);
    pduPtr = (TSPDUPtr) (tsaReceiveParamPtr + 1);

    /* Set the corresponding transmit pointer. */
    if (tsaReceiveParamPtr->priority)
    {
        xmitRecPtr = &gp->priXmitRec;
        tsaSendParamPtr = QueueHead(&gp->tsaOutPriQ);
    }
    else
    {
        xmitRecPtr = &gp->xmitRec;
        tsaSendParamPtr = QueueHead(&gp->tsaOutQ);
    }

    if (ValidateTrans(tsaReceiveParamPtr->priority, pduPtr->transNum)
        == TRANS_NOT_CURRENT)
    {
        /* Unsolicited response. Ignore it. */
#ifdef DEBUG
        DebugMsg("SNReceiveResponse: Unsolicited response ignored.");
#endif
        DeQueue(&gp->tsaInQ);
        INCR_STATS(nmp->stats.lateAcknowledgements);
        return;
    }

    /* Check if possible if the Response really corresponds to the
    transaction in progress. */
    if (xmitRecPtr->status != SESSION_TX ||
        xmitRecPtr->nwDestAddr.domainIndex !=
        tsaReceiveParamPtr->srcAddr.domainIndex)
    {
        /* Transmit record is not ours or the domain indices for
        the response and the transaction record do not match. */
        DeQueue(&gp->tsaInQ);
#ifdef DEBUG
        DebugMsg("Debug: SNReceiveResponse: Stale response discarded.");
#endif
        INCR_STATS(nmp->stats.lateAcknowledgements);
        return;
    }

    if (xmitRecPtr->nwDestAddr.addressMode == SUBNET_NODE &&
        (xmitRecPtr->nwDestAddr.addr.addr2a.subnet !=
         tsaReceiveParamPtr->srcAddr.subnetAddr.subnet ||
         xmitRecPtr->nwDestAddr.addr.addr2a.node !=
         tsaReceiveParamPtr->srcAddr.subnetAddr.node))
    {
        /* Source address of response does not match dest addr of
        transmit record. */
        /* Response does not seem to correspond to what we are expecting. */
        DeQueue(&gp->tsaInQ);
#ifdef DEBUG
        DebugMsg("Debug: SNReceiveResponse: Stale response discarded.");
#endif
    }
}

```

```

        INCR_STATS(nmp->stats.lateAcknowledgements);
        return;
    }

    if (xmitRecPtr->nwDestAddr.addressMode == MULTICAST &&
        (tsaReceiveParamPtr->srcAddr.addressMode != MULTICAST_ACK ||
         xmitRecPtr->nwDestAddr.addr.addr1 !=
         tsaReceiveParamPtr->srcAddr.ackNode.groupAddr.group))
    {
        /* MULTICAST message but not MULTICAST_ACK or the response's group
         # does not match that of xmitRecord. */
        /* Response does not seem to correspond to what we are expecting. */
        DeQueue(&gp->tsaInQ);
#ifdef DEBUG
        DebugMsg("Debug: SNReceiveResponse: Stale response discarded.");
#endif
        INCR_STATS(nmp->stats.lateAcknowledgements);
        return;
    }

    /* For broadcast messages, the subnet in the response can be 0 from
    unconfigured nodes. Another possibility is that the response might
    come through a router in a scenario where the router replaces the
    subnet with its own. Thus the response can be valid even if the
    subnet does not match. So, we should skip this test. */

    /* Check if there is space in application layer's input queue. */
    if (QueueFull(&gp->appInQ))
    {
        return; /* Can't give the response yet. Come back later. */
    }

    appReceiveParamPtr = QueueTail(&gp->appInQ);
    apduPtr = (APDU *) (appReceiveParamPtr + 1);

    /* Deliver the partial response to application layer. */
    appReceiveParamPtr->indication = MESSAGE;
    appReceiveParamPtr->srcAddr = tsaReceiveParamPtr->srcAddr;
    appReceiveParamPtr->service = RESPONSE;
    appReceiveParamPtr->priority = tsaReceiveParamPtr->priority;
    appReceiveParamPtr->pduSize = tsaReceiveParamPtr->pduSize - 1;
    appReceiveParamPtr->auth = FALSE;
    appReceiveParamPtr->tag = tsaSendParamPtr->tag;
    memcpy(apduPtr, pduPtr->data, tsaReceiveParamPtr->pduSize - 1);
    /* Don't deliver the response to application yet. It could be
    a duplicate. */
    switch (xmitRecPtr->nwDestAddr.addressMode)
    {
        case BROADCAST:
            /* We deliver up to N responses to app layer where N =
            tsaSendParamPtr->destAddr.bcast.maxResponses.
            But we succeed if at least one resp is received. */
            if (xmitRecPtr->ackCount <
                tsaSendParamPtr->destAddr.bcast.maxResponses)
            {
                EnQueue(&gp->appInQ);
                INCR_STATS(nmp->stats.layer6_7RespRcvd);
                xmitRecPtr->ackCount++;
                if (xmitRecPtr->ackCount ==
                    tsaSendParamPtr->destAddr.bcast.maxResponses)
                {
                    TerminateTrans(tsaReceiveParamPtr->priority);
                }
            }
        }
    }

```

```

    }
    /* else, we don't want this response. Ignore it. */
    break;
case SUBNET_NODE: /* Fall through. */
case UNIQUE_NODE_ID:
    if (xmitRecPtr->ackCount == 0)
    {
        EnQueue(&gp->appInQ);
        INCR_STATS(nmp->stats.layer6_7RespRcvd);
        xmitRecPtr->ackCount++; /* First response. */
        TerminateTrans(tsaReceiveParamPtr->priority);
    }
    /* else, it is a duplicate response. Ignore it. */
    break;
case MULTICAST:
    /* Group request message. Check response address mode. */
    if (tsaReceiveParamPtr->srcAddr.addressMode
        != MULTICAST_ACK)
    {
        ErrorMsg("SNReceiveResponse: RESPONSE should be "
            "MULTICAST_ACK.");
        break;
    }
    if (tsaReceiveParamPtr->srcAddr.ackNode.groupAddr.member
        > MAX_GROUP_NUMBER)
    {
        ErrorMsg("SNReceiveResponse: Invalid group number.");
        break;
    }
    if (!xmitRecPtr->ackReceived[
        tsaReceiveParamPtr->srcAddr.ackNode.groupAddr.member])
    {
#ifdef DEBUG
        DebugMsg("SNReceiveResp: A multicast resp delivered.");
#endif
        EnQueue(&gp->appInQ);
        INCR_STATS(nmp->stats.layer6_7RespRcvd);
        xmitRecPtr->ackReceived[
            tsaReceiveParamPtr->srcAddr.ackNode.groupAddr.member]
            = TRUE;
        xmitRecPtr->ackCount++;
    }
    else
    {
        /* Else, it is a duplicate response. Ignore it */
#ifdef DEBUG
        DebugMsg("SNReceiveResp: A duplicate multicast response ignored.");
#endif
    }
    if (xmitRecPtr->destCount == xmitRecPtr->ackCount)
    {
        TerminateTrans(tsaReceiveParamPtr->priority);
    }
    break;
default:
    nmp->errorLog = BAD_ADDRESS_TYPE;
    ErrorMsg("SNReceiveResponse: Invalid address mode.");
}

DeQueue(&gp->tsaInQ);

/* Restart the timer if the xmit rec is still active. */
if(xmitRecPtr->status != UNUSED_TX)
{

```

```

        SetMsTimer(&xmitRecPtr->xmitTimer, xmitRecPtr->xmitTimerValue);
    }

    return;
}

/*****
Function: ReceiveNewMsg
Returns:  None
Reference: None
Purpose:  To process either a new message received by transport
          (ACKD or UNACK RPT) or session layer (REQUEST).
Comments: The message could be new or a duplicate. If new, we
          need to allocate a RR. If not, we use the existing RR.
*****/
static void ReceiveNewMsg(Layer layerIn)
{
    TSAReceiveParam *tsaReceiveParamPtr;
    TSPDUPtr        pduPtr;
    uint16          recvTimerValue;
    int16           i;
    Boolean          initRR; /* Used to check if RR needs to init. */

    /* We have a new msg in TSA In queue. */

    tsaReceiveParamPtr = QueueHead(&gp->tsaInQ);
    pduPtr              = (TSPDUPtr) (tsaReceiveParamPtr + 1);

    /* First retrieve associated RR, if it exists. */
    /* Since we can receive at most one message from a node
       (one for priority & one for non-priority), we can reuse
       receive records if the sender determines that a message
       transmission is over by transmitting a new message with a
       new transaction number or different service (i.e layer) or
       a new APDU. */

    i = RetrieveRR(tsaReceiveParamPtr->srcAddr,
                  tsaReceiveParamPtr->priority);
    if (i == -1)
    {
        /* No Associated RR found. We need to allocate a new one. */
        i = AllocateRR();
        if (i == -1)
        {
            /* Unable to allocate a new RR. */
            INCR_STATS(nmp->stats.receiveTXFull);
#ifdef DEBUG
            DebugMsg("ReceiveNewMsg: Unable to allocate RR. Msg is lost.");
#endif
            DeQueue(&gp->tsaInQ); /* Remove item from queue. */
            return;
        }
        /* We did allocate a new RR. We need to init this RR. */
        initRR = TRUE;
    }
    else if (gp->recvRec[i].transNum != pduPtr->transNum ||
             gp->recvRec[i].status  != (layerIn ==
TRANSPORT?TRANSPORT_RR:SESSION_RR)
             || tsaReceiveParamPtr->pduSize - 1 !=
             gp->recvRec[i].apduSize ||
             /* *** START INFORMATIVE - APDU Contents and Duplicate Detection *** */
             /* This check causes the contents of the APDU to always be factored I
              * the duplicate detection algorithm.
              * It is considered a requirement that the APDU contents be

```

```

    * factored into the duplicate detection algorithm only in the case where
the
    * message is authenticated and the request is idempotent (because retries
    * are not re-authenticated). Whether this is done by storing the entire
    * APDU for comparison or storing only the APDU length and a checksum of
the
    * APDU data is implementation dependent. If a checksum method is used,
the
    * checksum should be at least 24 bits in length. In the case where a
    * non-matching APDU vectors into an existing authenticated transaction,
two
    * choices are possible:
    * a. Treat the message as if it were not a duplicate (as is done here).
    * b. Treat the message as a duplicate but mark it as not authenticated
    * (if it is necessary to deliver the retry to the application see
    * "START INFORMATIVE - Saved Response Length" below). */
    memcmp(pduPtr->data, gp->recvRec[i].apdu,
           gp->recvRec[i].apduSize) != 0)
    /* *** END INFORMATIVE - APDU Contents and Duplicate Detection *** */
{
    /* Something does not match. Must be a new message from
    the sender. Let us reuse this RR, even if it is a
    request. If it is a request and response comes later,
    it won't match this record anyway due to reqid. */
    initRR = TRUE;
    /* If the old message was not delivered, increment lost msg stat */
    if (gp->recvRec[i].transState != DELIVERED &&
        gp->recvRec[i].transState != DONE &&
        gp->recvRec[i].transState != RESPONDED)
    {
        INCR_STATS(nmp->stats.lostMessages);
    }
}
else
{
    /* It is an existing RR with everything matching. */
    /* Nothing to do. We use the information in existing RR. */
    /* Set the alternate path bit based on new message so that
    acks, challenge etc will use the same path. Change only if
    it is not already using alternate path. */
    if (! gp->recvRec[i].altPath)
    {
        gp->recvRec[i].altPath = tsaReceiveParamPtr->altPath;
    }
    initRR = FALSE;
}

if (initRR)
{
    if (layerIn == TRANSPORT)
    {
        gp->recvRec[i].status = TRANSPORT_RR;
    }
    else
    {
        gp->recvRec[i].status = SESSION_RR;
    }
    gp->recvRec[i].srcAddr = tsaReceiveParamPtr->srcAddr;
    gp->recvRec[i].transNum = pduPtr->transNum;
    gp->recvRec[i].transState = JUST_RECEIVED;
    gp->recvRec[i].priority = tsaReceiveParamPtr->priority;
    gp->recvRec[i].altPath = tsaReceiveParamPtr->altPath;
    gp->recvRec[i].auth = FALSE;
    gp->recvRec[i].reqId = 0; /* Init to invalid reqid. */
}

```

```

    if (layerIn == TRANSPORT)
    {
        gp->recvRec[i].serviceType =
            pduPtr->pduMsgType == ACKD_MSG? ACKD: UNACK_RPT;
    }
    else
    {
        gp->recvRec[i].serviceType = REQUEST;
        /* reqId can wrap around. Never use 0 as reqId so that
           a valid reqId will never match a receive record that
           does not correspond to corresponding request. */
        if (gp->reqId == 0)
        {
            gp->reqId++;
        }
        gp->recvRec[i].reqId = gp->reqId++;
    }
    gp->recvRec[i].apduSize = tsaReceiveParamPtr->pduSize - 1;
    memcpy(gp->recvRec[i].apdu,
        pduPtr->data,
        gp->recvRec[i].apduSize); /* Store the APDU. */
    /* Compute the recvTimer value to be used. */
    recvTimerValue = ComputeRecvTimerValue(
        tsaReceiveParamPtr->srcAddr.addressMode,
        tsaReceiveParamPtr->srcAddr.group);
    SetMsTimer(&gp->recvRec[i].recvTimer, recvTimerValue);
}

DeQueue(&gp->tsaInQ); /* Remove item from queue. */

/* Now, we have a RR for this message. */
/* Determine if the msg needs authentication and store. */
/* Allow authentication for UnAck_Rpt. */
/* flexDomain messages cannot be authenticated. Force it. */

if (pduPtr->auth && tsaReceiveParamPtr->srcAddr.domainIndex != FLEX_DOMAIN)
{
    gp->recvRec[i].needAuth = TRUE;
}
else
{
    gp->recvRec[i].needAuth = FALSE;
}

/* Authentication is performed if it is a new message or
   in the process of authenticating and it needs to be
   authenticated. */
if ((gp->recvRec[i].transState == JUST_RECEIVED ||
    gp->recvRec[i].transState == AUTHENTICATING) &&
    gp->recvRec[i].needAuth)
{
    /* The message needs authentication. Initiate Challenge. */
    /* Or ReInitiate Challenge as the prev one is probably lost. */
#ifdef DEBUG
    DebugMsg("ReceiveNewMsg: Initiating Challenge.");
#endif
    InitiateChallenge(i);
    return;
}

if (gp->recvRec[i].transState != DELIVERED &&
    gp->recvRec[i].transState != RESPONDED &&
    gp->recvRec[i].transState != DONE)
{

```

```

        /* Deliver the message to the application layer. */
        Deliver(i);
    }
    else
    {
#ifdef DEBUG
        DebugMsg("ReceiveNewMsg: Msg received was already delivered.");
#endif
    }
}

if (layerIn == TRANSPORT)
{
    if (gp->recvRec[i].transState == DELIVERED &&
        gp->recvRec[i].serviceType == ACKD)
    {
        /* Compose and send the acknowledgement. */
        TPSendAck(i);
    }
}
else if (gp->recvRec[i].transState == RESPONDED)
{
    /* Must be a request that was already responded. */
    /* We already have a resp. Simply send it. */
    SNSendResponse(i, FALSE); /* It can't be a null response. */
}
else if (gp->recvRec[i].transState == DONE)
{
#ifdef DEBUG
    DebugMsg("ReceiveNewMsg: Nothing to do.");
#endif
}
return;
}

/*****
Function: ReceiveRem
Returns: None
Reference: None
Purpose: To process REMINDER and REM/MSG messages.
         We either do nothing or send an ack (for Transport)
         or a response (for Session) if possible.
Comments: None
*****/
static void ReceiveRem(Layer layerIn)
{
    TSAReceiveParam *tsaReceiveParamPtr;
    TSPDUPtr        pduPtr;
    int16           i;
    APDU            *apduPtr;
    uint16          apduSize;
    uint8           length;
    uint8           member;
    uint8           mlistIndex, mlistOffset;
    Byte            *mlistPtr;
    uint16          recvTimerValue;

    /* We have a REMINDER or REM/MSG in TSA input queue. */

    tsaReceiveParamPtr = QueueHead(&gp->tsaInQ);
    pduPtr              = (TSPDUPtr) (tsaReceiveParamPtr + 1);
    length              = pduPtr->data[0];

    if (pduPtr->pduMsgType == REMINDER_MSG)
    {

```

```

    apduSize = 0;
    apduPtr = NULL;
}
else
{
    /* Must be REM_MSG_MSG. */
    /* TSPDU header size before APDU is actual 1 byte header,
       1 byte length field and the length of M_List field. */
    apduSize = tsaReceiveParamPtr->pduSize - 2 - length;
    apduPtr = (APDU *)&pduPtr->data[1 + length];
}

/* First retrieve the associated RR, if it exists. */
i = RetrieveRR(tsaReceiveParamPtr->srcAddr,
               tsaReceiveParamPtr->priority);

/* Check if the REMINDER msg has an associated RR. */
if (i == -1 && pduPtr->pduMsgType == REMINDER_MSG)
{
    /* No associated RR. Discard this REMINDER msg. */
#ifdef DEBUG
    DebugMsg("ReceiveRem: REMINDER msg has no associated RR");
#endif
    DeQueue(&gp->tsaInQ);
    return;
}

if (i != -1 &&
    (gp->recvRec[i].srcAddr.addressMode != MULTICAST ||
     gp->recvRec[i].transNum != pduPtr->transNum ||
     gp->recvRec[i].status != (layerIn == TRANSPORT?TRANSPORT_RR:SESSION_RR) ||
     (apduPtr && apduSize != gp->recvRec[i].apduSize) ||
     (apduPtr &&
      /* *** START INFORMATIVE - APDU Contents and Duplicate Detection *** */
      /* See "START INFORMATIVE - APDU Contents and Duplicate Detection". */
      memcmp(apduPtr, gp->recvRec[i].apdu, apduSize) != 0)
      /* *** END INFORMATIVE - APDU Contents and Duplicate Detection *** */
    )
)
{
    /* Associate RR does not match properly. Either it is not
       a multicast message or transNum does not match or
       APDU does not match. This is not OK for REMINDER_MSG.
       If it is however REM_MSG_MSG, we want to treat it as a
       new message. */
    if (pduPtr->pduMsgType == REMINDER_MSG)
    {
#ifdef DEBUG
        DebugMsg("ReceiveRem: Associated RR does not match.");
#endif
        DeQueue(&gp->tsaInQ);
        return;
    }
    if (gp->recvRec[i].transState == DELIVERED ||
        gp->recvRec[i].transState == DONE)
    {
        /* Reuse this receive record. We will free this record and allocate
           a new one. */
        gp->recvRec[i].status = UNUSED_RR;
        i = -1;
    }
}
else
{

```

```
        i = -1; /* Allocate new one. */
    }
}

if (i != -1 && gp->recvRec[i].serviceType == UNACK_RPT)
{
    if (pduPtr->pduMsgType == REMINDER_MSG)
    {
        /* We should not have gotten this REMINDER as the original
        message was UNACK_RPT. So, ignore this message. */
#ifdef DEBUG
        DebugMsg("ReceiveRem: Original msg is UNACK_RPT.");
#endif
        DeQueue(&gp->tsaInQ);
        return;
    }
    /* Treat REM_MSG MSG as new one. Fack this by setting i to -1. */
    i = -1;
}

if (i != -1)
{
    /* We have already received the corresponding APDU. */
    /* Probably the ack or response sent earlier was lost. */
    /* Sent the ack or response again. */
    if (!IsGroupMember(gp->recvRec[i].srcAddr.domainIndex,
        gp->recvRec[i].srcAddr.group,
        &member))
    {
        /* We are not member of the group used for this msg.
        Strange! Ignore this msg too!
        Network layer should not have delivered such msg
        to upper layers. */
#ifdef DEBUG
        DebugMsg("ReceiveRem: Strange! Not a group member!!.");
#endif
        DeQueue(&gp->tsaInQ);
        return;
    }
    mlistIndex = member % 8;
    mlistOffset = member % 8;
    mlistPtr = &pduPtr->data[1];
    if (
        length == 0
        ||
        mlistIndex >= length
        ||
        (mlistPtr[mlistIndex] & (1 << mlistOffset)) == 0
    )
    {
        /* We are asked to respond. Server did not get our ack or response. */

        /* If it is a REMINDER_MSG, it will be followed by the retry.
        So, we simply ignore it. */
        if (pduPtr->pduMsgType == REMINDER_MSG)
        {
            DeQueue(&gp->tsaInQ);
            return;
        }

        if (gp->recvRec[i].needAuth &&
            (gp->recvRec[i].transState == JUST_RECEIVED ||
            gp->recvRec[i].transState == AUTHENTICATING)
        )
    }
}
```



```

        DeQueue (&gp->tsaInQ);
    }
    return;
}

/* Now we must have a REM_MSG_MSG with no associated RR. */
/* REMINDER msg with no associated record was taken care of
   earlier. */
i = AllocateRR();
if (i == -1)
{
    /* Unable to allocate a new RR. Give up. */
    return;
}
if (layerIn == TRANSPORT)
{
    gp->recvRec[i].status = TRANSPORT_RR;
}
else
{
    gp->recvRec[i].status = SESSION_RR;
}
gp->recvRec[i].srcAddr = tsaReceiveParamPtr->srcAddr;
gp->recvRec[i].transNum = pduPtr->transNum;
gp->recvRec[i].transState = JUST_RECEIVED;
gp->recvRec[i].priority = tsaReceiveParamPtr->priority;
gp->recvRec[i].altPath = tsaReceiveParamPtr->altPath;
gp->recvRec[i].auth = FALSE; /* Not authenticated yet. */
if (layerIn == TRANSPORT)
{
    /* We have REM/MSG. So service type must be ACKD. */
    gp->recvRec[i].serviceType = ACKD;
}
else
{
    gp->recvRec[i].serviceType = REQUEST;
    /* reqId can wrap around. Never use 0 as reqId so that
       a valid reqId will never match a receive record that
       does not correspond to corresponding request. */
    if (gp->reqId == 0)
    {
        gp->reqId++;
    }
    gp->recvRec[i].reqId = gp->reqId++;
}
gp->recvRec[i].apduSize = apduSize;
memcpy(gp->recvRec[i].apdu, apduPtr, apduSize);
/* Compute the recvTimer value to be used. */
recvTimerValue =
    ComputeRecvTimerValue(
        tsaReceiveParamPtr->srcAddr.addressMode,
        tsaReceiveParamPtr->srcAddr.group
    );
DeQueue (&gp->tsaInQ); /* Remove the item from queue. */

SetMsTimer (&gp->recvRec[i].recvTimer, recvTimerValue);

/* Flex domain messages cannot be authenticated. */
if (pduPtr->auth &&
    tsaReceiveParamPtr->srcAddr.domainIndex != FLEX_DOMAIN)
{
    gp->recvRec[i].needAuth = TRUE; /* Remember that we need auth. */
}
else

```

```

{
    gp->recvRec[i].needAuth = FALSE;
}

/* Now, we have a RR for this message. */
if (gp->recvRec[i].needAuth)
{
    /* The message needs authentication. Initiate Challenge. */
#ifdef DEBUG
    DebugMsg("ReceiveRem: Initiating Challenge.");
#endif
    InitiateChallenge(i);
    return;
}

/* Deliver the message to the application layer. */
Deliver(i);

if (layerIn == TRANSPORT)
{
    if (gp->recvRec[i].transState == DELIVERED)
    {
        /* Compose and send the acknowledgement. */
        TPSendAck(i);
    }
}
else
{
    /* We just delivered. Can't have a response yet. */
}
return;
}

/*****
Function: TPSendAck
Returns: None
Reference: None
Purpose: To Send an ACK message for ACKD msg received by the
transport layer. If there is no space in network
output queue, then nothing is sent.
Comments: None.
*****/
static void TPSendAck(uint16 rrIndexIn)
{
    NWSendParam *nwSendParamPtr; /* Ptr to NW Send Param. */
    TSPDUPtr pduPtr; /* Ptr to TPDU sent. */
    Queue *nwQueuePtr;
    DestinationAddress destAddr;

    if (gp->recvRec[rrIndexIn].priority)
    {
        nwQueuePtr = &gp->nwOutPriQ;
    }
    else
    {
        nwQueuePtr = &gp->nwOutQ;
    }

    if (QueueFull(nwQueuePtr))
    {
        return; /* Can't send the acknowledgement now. */
    }

    nwSendParamPtr = QueueTail(nwQueuePtr);

```

www.icsnm.com

To view the full PDF of ISO/IEC 14908-1:2012

```

pduPtr      = (TSPDUPtr) (nwSendParamPtr + 1);

/* Form the TPDU directly in the network layer's queue. */
pduPtr->auth      = FALSE; /* Acks are not authenticated. */
pduPtr->pduMsgType = ACK_MSG;
pduPtr->transNum  = gp->recvRec[rrIndexIn].transNum;

/* Fill in the details for the network layer. */

/* First, form sender's (i.e our) address. */
destAddr.domainIndex = gp->recvRec[rrIndexIn].srcAddr.domainIndex;
if (destAddr.domainIndex == FLEX_DOMAIN)
{
    /* Flex domain was used. Copy flex domain information. */
    destAddr.flexDomainLen =
        gp->recvRec[rrIndexIn].srcAddr.flexDomainLen;
    /* Make sure we have a good length field. */
    if (destAddr.flexDomainLen <= DOMAIN_ID_LEN)
    {
        memcpy(destAddr.flexDomainId,
            gp->recvRec[rrIndexIn].srcAddr.flexDomainId,
            destAddr.flexDomainLen);
    }
}

/* We send unicast ACK or multicast ACK depending on msg recvd. */
if (gp->recvRec[rrIndexIn].srcAddr.addressMode == MULTICAST)
{
    /* Send ACK in address format 2b. */
    destAddr.addressMode = MULTICAST_ACK;
    destAddr.addr.addr2b.subnetAddr =
        gp->recvRec[rrIndexIn].srcAddr.subnetAddr;
    destAddr.addr.addr2b.groupAddr.group =
        gp->recvRec[rrIndexIn].srcAddr.group;
    if (!IsGroupMember(destAddr.domainIndex,
destAddr.addr.addr2b.groupAddr.group,
                        &destAddr.addr.addr2b.groupAddr.member))
    {
        ErrorMessage("SendACKTPDU: Ack msg for a non-existing group.");
        return;
    }
}
else
{
    /* Send Ack in address format 2a. */
    destAddr.addressMode = SUBNET_NODE;
    destAddr.addr.addr2a =
        gp->recvRec[rrIndexIn].srcAddr.subnetAddr;
}

nwSendParamPtr->dropIfUnconfigured = FALSE; /* acks are not dropped */
nwSendParamPtr->destAddr = destAddr;
nwSendParamPtr->pduType  = TPDU_TYPE;
nwSendParamPtr->deltaBL  = 0;
nwSendParamPtr->altPath  = gp->recvRec[rrIndexIn].altPath;
nwSendParamPtr->pduSize  = 1;

#ifdef DEBUG
    DebugMsg("Debug: TPSendAck. Sending an ACK.");
#endif
    EnQueue(nwQueuePtr);
}

/*****

```

```

Function: SNSendResponse
Returns: None
Reference: None
Purpose: To send a response message for REQUEST msg received by the
         session layer. If there is no space in network
         output queue, then nothing is sent.
         If it is a null response, then the receive record is freed
         and no response goes out.
Comments: This function is called only when the application layer
         has already given the response. (Or else how can this
         function know about how to respond anyway?)
*****
static void SNSendResponse(uint16 rrIndexIn, Boolean nullResponse)
{
    NWSendParam    *nwSendParamPtr; /* Ptr to NW Send Param. */
    TSPDUPtr       pduPtr;          /* Ptr to TPDU sent. */
    Queue          *nwQueuePtr;
    DestinationAddr destAddr;

    if (gp->recvRec[rrIndexIn].priority)
    {
        nwQueuePtr = &gp->nwOutPriQ;
    }
    else
    {
        nwQueuePtr = &gp->nwOutQ;
    }

    if (QueueFull(nwQueuePtr) && !nullResponse)
    {
        return; /* Can't sent the response now.
    }

    if (gp->recvRec[rrIndexIn].transState != RESPONDED &&
        gp->recvRec[rrIndexIn].transState != DONE)
    {
        ErrorMessage("SNSendResponse: How can I be called without "
                     "atleast one resp?");
        return;
    }

    if (nullResponse)
    {
        /* Set state to DONE and do not send the response. */
#ifdef DEBUG
        DebugMsg("SendResponse: Null response. Nothing goes out.");
#endif
        gp->recvRec[rrIndexIn].transState = DONE;
        return;
    }

    nwSendParamPtr = QueueTail(nwQueuePtr);
    pduPtr         = (TSPDUPtr) (nwSendParamPtr + 1);

    if (gp->nwOutBufSize < gp->recvRec[rrIndexIn].rspSize + 1)
    {
        ErrorMessage("SNSendResponse: Network buf too small for response.");
        return;
    }

    pduPtr->auth      = FALSE; /* Responses are not authenticated. */
    pduPtr->pduMsgType = RESPONSE_MSG;
    pduPtr->transNum  = gp->recvRec[rrIndexIn].transNum;
    /* Copy the existing response from RR */
    if (gp->recvRec[rrIndexIn].rspSize <=

```

```

        DecodeBufferSize((uint8) eep->readOnlyData.appOutBufSize))
    {
        /* *** START INFORMATIVE - Saved Response Length *** */
/* This implementation saves the entire response in the receive transaction record.
 * Thus, if and when a retry of the request is received, the response can be
 * re-transmitted without re-delivering the request to the application for
 * construction of a response. It is acceptable to save only responses of certain
 * length (e.g., as little as 1 byte) in order to minimize RAM use.
 * Under these conditions, a retry of a request that illicited a response of
 * length greater than that minimum length is considered to be idempotent (can be
 * safely executed again) and may be re-delivered to the application for
 * reformulation of the response. It is also required that under these conditions
 * that the application be informed of the duplicate nature of the request in case
 * the application chooses to treat the request as non-idempotent by saving the
 * response for retransmission without recomputation. In this case a key must
 * also be provided for the application to use to map the request to a saved
 * response. */
        memcpy(pduPtr->data, gp->recvRec[rrIndexIn].response,
            gp->recvRec[rrIndexIn].rspSize);
        /* *** END INFORMATIVE - Saved Response Length *** */
    }
    else
    {
#ifdef DEBUG
        DebugMsg("SNSendResponse: Discarding a long response.");
#endif
        return;
    }
    /* Fill in the details for the network layer */

    destAddr.domainIndex = gp->recvRec[rrIndexIn].srcAddr.domainIndex;
    if (destAddr.domainIndex == FLEX_DOMAIN)
    {
        /* Flex domain was used. Copy flex domain information. */
        destAddr.flexDomainLen =
            gp->recvRec[rrIndexIn].srcAddr.flexDomainLen;
        if (destAddr.flexDomainLen <= DOMAIN_ID_LEN)
        {
            memcpy(destAddr.flexDomainId,
                gp->recvRec[rrIndexIn].srcAddr.flexDomainId,
                destAddr.flexDomainLen);
        }
    }

    /* We send unicast response or multicast response depending on
    the request received. */
    if (gp->recvRec[rrIndexIn].srcAddr.addressMode == MULTICAST)
    {
        /* Send the response in address format 2b. */
        destAddr.addressMode = MULTICAST_ACK;
        destAddr.addr.addr2b.subnetAddr =
            gp->recvRec[rrIndexIn].srcAddr.subnetAddr;
        destAddr.addr.addr2b.groupAddr.group =
            gp->recvRec[rrIndexIn].srcAddr.group;
        if (!IsGroupMember(destAddr.domainIndex,
            destAddr.addr.addr2b.groupAddr.group,
                &destAddr.addr.addr2b.groupAddr.member))
        {
            ErrorMsg("SNSendResponse: Response for a non-existing group.");
            return;
        }
    }
    else
    {

```

```

    /* Send response in address format 2a. */
    destAddr.addressMode = SUBNET_NODE;
    destAddr.addr.addr2a =
        gp->recvRec[rrIndexIn].srcAddr.subnetAddr;
}

nwSendParamPtr->dropIfUnconfigured = FALSE; /* responses are not dropped */
nwSendParamPtr->destAddr = destAddr;
nwSendParamPtr->pduType = SPDU_TYPE;
nwSendParamPtr->deltaBL = 0;
nwSendParamPtr->altPath = gp->recvRec[rrIndexIn].altPath;
nwSendParamPtr->pduSize = gp->recvRec[rrIndexIn].rspSize + 1;

#ifdef DEBUG
    DebugMsg("SNSendResponse: Sending a response.");
#endif
    EnQueue(nwQueuePtr);
}

/*****
Function: Deliver
Returns: None
Reference: None
Purpose: To deliver a message received by transport or session layer
to the application layer.
Comments: layerIn is not needed as it is not used.
*****/
static void Deliver(uint16 rrIndexIn)
{
    APPReceiveParam *appReceiveParamPtr;
    char *apduInPtr;
    uint16 i = rrIndexIn; /* Use i instead of rrIndexIn. */

    if (gp->recvRec[i].needAuth && gp->recvRec[i].transState != AUTHENTICATED)
    {
        /* The message needs authentication but was not authenticated. */
        gp->recvRec[i].transState = DONE;
        return;
    }

    if (QueueFull(&gp->appInQ))
    {
        /* We can wait, but then we may not be able to guarantee delivery in
        sequence from a given source node. So, it is better to drop the
        message and let the retry mechanism take care of redelivery. */
        INCR_STATS(nmp->stats.lostMessages);
        gp->recvRec[i].transState = DONE; /* indicate that this one is done */
        return;
    }

    appReceiveParamPtr = QueueTail(&gp->appInQ);
    apduInPtr = (char *) (appReceiveParamPtr + 1);

    appReceiveParamPtr->indication = MESSAGE;
    appReceiveParamPtr->srcAddr = gp->recvRec[i].srcAddr;
    appReceiveParamPtr->service = gp->recvRec[i].serviceType;
    appReceiveParamPtr->priority = gp->recvRec[i].priority;
    appReceiveParamPtr->altPath = gp->recvRec[i].altPath;
    appReceiveParamPtr->auth = gp->recvRec[i].auth;
    appReceiveParamPtr->pduSize = gp->recvRec[i].apduSize;
    appReceiveParamPtr->reqId = gp->recvRec[i].reqId;

    if (gp->appInBufSize < gp->recvRec[i].apduSize)
    {

```

```

    ErrorMessage("Deliver: APDU size too big");
    /* We can never deliver this APDU. So, make it look like
       it was delivered so that it can be discarded. We don't
       want to send any ACK or response for this message. */
    gp->recvRec[i].transState = DONE;
    nmp->errorLog = WRITE_PAST_END_OF_APPL_BUFFER;
    return;
}
/* Now it should be safe to do memcpy. */
memcpy(apduInPtr, gp->recvRec[i].apdu, gp->recvRec[i].apduSize);
EnQueue(&gp->appInQ);
INCR_STATS(nmp->stats.layer6_7MsgsRcvd);
gp->recvRec[i].transState = DELIVERED;
#ifdef DEBUG
    DebugMsg("Debug: Deliver: Packet has been delivered"
             " to the application layer.");
#endif
}

/*****
Function: RetrieveRR
Returns:  Index of RR Table that matches given input parameters.
         -1 if none exists.
Reference: None
Purpose:  To retrieve the receive record from the RR table
         that corresponds to a message received. For matching,
         we use priority, domainIndex, addressMode, and source address.
         We also match subnet if the message is broadcast
         or group if the message is multicast.
Comments: None
*****/
static int16 RetrieveRR(SourceAddress srcAddrIn,
                       Boolean priorityIn)
{
    int16 i;

    /* Search through all the receive records for a match. */

    for (i = 0; i < gp->recvRecCnt; i++)
    {
        if (
            priorityIn == gp->recvRec[i].priority
            &&
            /* Destination subnet/node match is based on domainIndex. */
            srcAddrIn.domainIndex == gp->recvRec[i].srcAddr.domainIndex
            &&
            (srcAddrIn.addressMode == gp->recvRec[i].srcAddr.addressMode)
            &&
            /* Source node address should always match. */
            (memcmp(&srcAddrIn.subnetAddr,
                   &gp->recvRec[i].srcAddr.subnetAddr,
                   sizeof(SubnetAddress)) == 0)
            &&
            /* Make sure BROADCAST address matches for broadcast messages. */
            ( srcAddrIn.addressMode != BROADCAST ||
              srcAddrIn.broadcastSubnet == gp->recvRec[i].srcAddr.broadcastSubnet )
            &&
            /* Make sure MULTICAST address matches for multicast messages. */
            ( srcAddrIn.addressMode != MULTICAST ||
              srcAddrIn.group == gp->recvRec[i].srcAddr.group )
        )
    {
        break;
    }
}

```

```

    }
}

    if (i == gp->recvRecCnt)
    {
        return(-1); /* Matching RR was not found. */
    }

    return(i); /* Found matching RR. */
}

/*****
Function: AllocateRR
Returns:  Index of RR table that can be used for a new msg.
Reference: None
Purpose:  To find an index in the RR table that is UNUSED.
Comments: None
*****/
static int16 AllocateRR(void)
{
    int16 i;

    /* First search for one that is unused. */
    for (i = 0; i < gp->recvRecCnt; i++)
    {
        if (gp->recvRec[i].status == UNUSED_RR)
        {
            return(i); /* Found one that is unused. */
        }
    }

    return(-1);
}

/*****
Function: ComputeRecvTimerValue
Returns:  Receive Timer value in milli seconds.
Reference: None
Purpose:  To compute the value to be used for receive timer
          based on the address format of the received message
          and group id.
Comments: None
*****/
static uint16 ComputeRecvTimerValue(AddrMode      addrModeIn,
                                     MulticastAddress groupIdIn)
{
    uint16 i, max = 0, temp;

    if (addrModeIn == UNIQUE_NODE_ID)
    {
        return((uint16)(NGTIMER_SPCL_VAL * 1 000,0));
    }
    if (addrModeIn == MULTICAST)
    {
        /* Search through the address table to find the receiver timer val. */
        /* If there is more than one entry with the same group,
           use the one with the max rcv timer value */
        for (i = 0; i < NUM_ADDR_TBL_ENTRIES; i++)
        {
            if (eep->addrTable[i].addrFormat >= 128 &&
                eep->addrTable[i].groupEntry.groupID == groupIdIn)
            {
                /* Group format match */
            }
        }
    }
}

```

```

temp = DecodeRcvTimer((uint8)
    eep->addrTable[i].groupEntry.rcvTimer);
/* *** START INFORMATIVE - Multicast Receive Timer *** */
/* Using the maximum receive timer for the group is not required. It
 * is acceptable to use the receive timer for the first group entry
 * found in the table. */
if (temp > max)
{
    max = temp;
}
/* *** END INFORMATIVE - Multicast Receive Timer *** */
}
}
return(max);
}
/* All other messages use non-group timer value. */
return(DecodeRcvTimer((uint8) eep->configData.nonGroupTimer));
}

```

Function: SNSend
Returns: None
Reference: Section 10, Transport layer
Purpose: To implement Send algorithm for the session layer.
If there is anything to be sent by the session layer, this function will process that message and sends it. If there is any ongoing message, it might need some processing such as retry, timer expiry etc. This function will process such events too.
Comments: Update the priority transmit timer, if it exists. Update the non-priority transmit timer, if it exists. If the priority transmit timer expired then process this event. else if there is priority message to be sent and there is space in priority queue of the network layer then process the priority message. else if the non-priority transmit timer expired then process that event. else if there is non-priority message to be sent and there is space in non-priority queue of network layer then process the non-priority message. else nothing to do. return.

Note: *****

```

void SNSend(void)
{
    TSASendParam *tsaSendParamPtr;
    uint16 i;

    /* Delay SNSend after power-up or external reset. */
    if ( gp->tsDelayTimer.curTimerValue > 0 &&
        (nmp->resetCause == POWER_UP_RESET ||
         nmp->resetCause == EXTERNAL_RESET)
        )
    {
        UpdateMsTimer(&gp->tsDelayTimer);
        return; /* Do nothing */
    }

    /* *****
     * Send response, if any, first. Responses are not like transactions
     * and hence it is better to send it first.
     * ***** */

```

```

if (!QueueEmpty(&gp->tsaRespQ) &&
    !QueueFull(&gp->nwOutQ))
{
    /* We have a response to be sent out.
       Make sure the response is not stale.
       Response should have a reqId.
       If there is no RR for this reqId, then it is stale.
       Throw the response away, if it is stale. */
    tsaSendParamPtr = QueueHead(&gp->tsaRespQ);

    if (tsaSendParamPtr->service != RESPONSE)
    {
        /* Throw away this message. Only responses are
           allowed in this queue. */
#ifdef DEBUG
        DebugMsg("SNSend: Response queue is only for responses.");
#endif
        DeQueue(&gp->tsaRespQ);
        return;
    }

    /* Search for the associated RR for this response. */
    for (i = 0; i < gp->recvRecCnt; i++)
    {
        if (gp->recvRec[i].status == SESSION_RR &&
            gp->recvRec[i].reqId == tsaSendParamPtr->reqId)
        {
            break;
        }
    }
    if (i == gp->recvRecCnt ||
        gp->recvRec[i].serviceType != REQUEST ||
        gp->recvRec[i].transState != DELIVERED)
    {
        /* Stale or duplicate response. Ignore it. */
        DeQueue(&gp->tsaRespQ);
#ifdef DEBUG
        DebugMsg("SNSend: Discarding stale or duplicate response.");
#endif
        INCR_STATS(nmp->stats.lateResponses);
        return;
    }
    /* Copy the response to the receive record and send response. */
    gp->recvRec[i].rspSize = tsaSendParamPtr->apduSize;
    /* Resp should fit in response field as it was found to be
       fit in the TSA queue. */
    memcpy(gp->recvRec[i].response,
        (char *) (tsaSendParamPtr + 1),
        gp->recvRec[i].rspSize);
    gp->recvRec[i].transState = RESPONDED;
    SNSendResponse(i, tsaSendParamPtr->nullResponse);
    INCR_STATS(nmp->stats.layer6_7RespSent);
    DeQueue(&gp->tsaRespQ);
    return;
}

/* Update transmit timers, if they do exist */
if (gp->priXmitRec.status == SESSION_TX &&
    gp->priXmitRec.xmitTimer.curTimerValue > 0)
{
    UpdateMsTimer(&gp->priXmitRec.xmitTimer);
}
if (gp->xmitRec.status == SESSION_TX &&
    gp->xmitRec.xmitTimer.curTimerValue > 0)

```

```
{
    UpdateMsTimer (&gp->xmitRec.xmitTimer);
}

/*****
Priority transmit timer expired event.
*****/
if (gp->priXmitRec.status == SESSION_TX &&
    gp->priXmitRec.xmitTimer.curTimerValue == 0)
{
    XmitTimerExpiration(SESSION, TRUE);
    return;
}
/*****
Send a new priority message event.
*****/
else if (gp->priXmitRec.status == UNUSED_TX &&
    ! QueueEmpty(&gp->tsaOutPriQ) &&
    ! QueueFull(&gp->nwOutPriQ) )
{
    SendNewMsg(SESSION, TRUE);
    return;
}
/*****
Non-priority timer expired event.
*****/
else if (gp->xmitRec.status == SESSION_TX &&
    gp->xmitRec.xmitTimer.curTimerValue == 0)
{
    XmitTimerExpiration(SESSION, FALSE);
}
/*****
Send a new non-priority message.
*****/
else if (gp->xmitRec.status == UNUSED_TX &&
    ! QueueEmpty(&gp->tsaOutQ) &&
    ! QueueFull(&gp->nwOutQ) )
{
    SendNewMsg(SESSION, FALSE);
}
else
{
    /* Either there is no work or there is no space. */
    return;
}

return;
}

/*****
Function: SNReceive
Returns: None
Reference: None
Purpose: To receive and process incoming SPDU's.
Comments: None
*****/
void SNReceive(void)
{
    TSAReceiveParam *tsaReceiveParamPtr; /* Param in tsa input queue. */
    TSPDUPtr        spduInPtr;          /* Pointer to SPDU received. */
    int16           i;

    /* Update Receive Timers, if they do exist */

```

TECNORM.COM: Click to view the full PDF of ISO/IEC 14908-1:2012

```

for (i = 0; i < gp->recvRecCnt; i++)
{
    if (gp->recvRec[i].status == SESSION_RR)
    {
        if (gp->recvRec[i].recvTimer.curTimerValue > 0)
        {
            UpdateMsTimer(&gp->recvRec[i].recvTimer);
        }
        if (gp->recvRec[i].recvTimer.curTimerValue == 0)
        {
            /* Timer expired. Release the receive record. */
#ifdef DEBUG
            DebugMsg("SNReceive: Receive timer expired.");
#endif
            /* Deliver the request if it has not been delivered.
            Deliver fn checks for authentication. */
            if (gp->recvRec[i].transState == DELIVERED ||
                gp->recvRec[i].transState == DONE ||
                gp->recvRec[i].transState == RESPONDED)
            {
                gp->recvRec[i].status = UNUSED_RR; /* Release the RR */
            }
            else
            {
                Deliver(i);
            }
        }
        else if ((gp->recvRec[i].transState == JUST_RECEIVED &&
            !gp->recvRec[i].needAuth) ||
            gp->recvRec[i].transState == AUTHENTICATED )
        {
            /* The request does not need authentication and was just received
            or it has been authenticated. */
            Deliver(i);
        }
    }
}

/* Check if there is SPDU to be processed. */
if (QueueEmpty(&gp->tsaInQ))
{
    /* There is nothing to process. */
    return;
}

tsaReceiveParamPtr = QueueHead(&gp->tsaInQ);
spduInPtr = (TSPDUPtr) ((char *)tsaReceiveParamPtr
    + sizeof(TSAReceiveParam));

/* Check if the PDU is for session layer. If not, we are done. */
if (tsaReceiveParamPtr->pduType != SPDU_TYPE)
{
    return;
}

/* We have a SPDU to be processed. Check the type and
process accordingly. */
switch (spduInPtr->pduMsgType)
{
    case RESPONSE_MSG:
        SNReceiveResponse();
        return;
    case REQUEST_MSG:
        ReceiveNewMsg(SESSION);
}

```

```
        return;
    case REMINDER_MSG:
        /* Fall through. */
    case REM_MSG_MSG:
        ReceiveRem(SESSION);
        return;
    default:
        nmp->errorLog = UNKNOWN_PDU;
        ErrorMsg("SNReceive: Unknown SPDU type received.");
        DeQueue(&gp->tsaInQ);
    }

    return;
}

/*****
Function: AuthSend
Returns: None
Reference: None
Purpose: To send challenges that are pending in receive records.
        These are challenges that could not be sent earlier due
        to unavailable space in network queue.
Comments: None
*****/
void AuthSend(void)
{
    int16 i;

    /* Only thing the authentication layer can do here is to check if any
       challenges need to be sent. */
    for (i = 0; i < gp->recvRecCnt; i++)
    {
        if (gp->recvRec[i].status != UNUSED_RR &&
            gp->recvRec[i].needAuth &&
            gp->recvRec[i].transState == JUST_RECEIVED)
        {
            InitiateChallenge(i);
        }
    }

    return;
}

/*****
Function: AuthReceive
Returns: None
Reference: None
Purpose: To receive an incoming AUTH_PDU packet and process.
Comments: None
*****/
void AuthReceive(void)
{
    TSAReceiveParam *tsaReceiveParamPtr; /* Parameter in tsa input queue. */
    AuthPDUPtr      pduInPtr;           /* Ptr to PDU received. */

    /* Check if there is AuthPDU to be processed. */
    if (QueueEmpty(&gp->tsaInQ))
    {
        /* There is nothing to process. */
        return;
    }

    tsaReceiveParamPtr = QueueHead(&gp->tsaInQ);
```



```

pduInPtr      = (AuthPDUPtr) (tsaReceiveParamPtr + 1);

/* Check if the PDU is for session layer. If not, we are done. */
if (tsaReceiveParamPtr->pduType != AUTHPDU_TYPE)
{
    return;
}

/* We have a AuthPDU to be processed. Check the type and
   process accordingly. */
if (pduInPtr->pduMsgType == CHALLENGE_MSG)
{
    SendReplyToChallenge();
}
else if (pduInPtr->pduMsgType == REPLY_MSG)
{
    ProcessReply();
}
else
{
    ErrorMsg("AuthReceive: Unknown pdu type received.");
    nmp->errorLog = UNKNOWN_PDU;
    DeQueue(&gp->tsaInQ);
    return;
}
}

/*****
Function:  InitiateChallenge
Returns:  None
Reference: None
Purpose:  To send a challenge message for a message received.
Comments: None
*****/
static void InitiateChallenge(uint16 rrIndexIn)
{
    AuthPDUPtr      pduOutPtr; /* Ptr to PDU sent. */
    NWSendParam     *nwSendParamPtr;
    Queue           *nwQueuePtr;
    Byte            randomValue[8];
    uint8           i;

    /* Since authentication is not allowed in flex domain, if
       this fn is called when a message received in flex domain,
       let us force the authentication to be a failure */
    if (gp->recvRec[rrIndexIn].srcAddr.domainIndex == FLEX_DOMAIN)
    {
        gp->recvRec[rrIndexIn].auth = FALSE;
        gp->recvRec[rrIndexIn].transState = AUTHENTICATED;
        return;
    }

    if (gp->recvRec[rrIndexIn].priority)
    {
        nwQueuePtr = &gp->nwOutPriQ;
    }
    else
    {
        nwQueuePtr = &gp->nwOutQ;
    }

    if (QueueFull(nwQueuePtr))
    {

```

```
/* No space to send challenge anyway. Come back later. */
return;
}

nwSendParamPtr = QueueTail(nwQueuePtr);
pduOutPtr      = (AuthPDU *) (nwSendParamPtr + 1);

/* First compute the random bytes to be sent */
if (gp->recvRec[rrIndexIn].transState != AUTHENTICATING)
{
    /* Generate random number only the first time we are called
    for this message. subsequent calls use the same rand. */
    for (i = 0; i < 8; i++)
    {
        randomValue[i] = (Byte)((gp->prevChallenge[i] + rand() % 256 +
                                GetCurrentTime() % 256) % 256);
        gp->prevChallenge[i] = randomValue[i];
    }
    memcpy(gp->recvRec[rrIndexIn].rand, randomValue, 8); /* Save */
}

/* Form the challenge AuthPDU. */
pduOutPtr->fmt = addrModeToFmt[gp->recvRec[rrIndexIn].srcAddr.addressMode];
if (gp->recvRec[rrIndexIn].srcAddr.addressMode == MULTICAST)
{
    /* For Multicast message, send the group info with AuthPDU. */
    nwSendParamPtr->pduSize = 10;
    pduOutPtr->group      = gp->recvRec[rrIndexIn].srcAddr.group;
}
else
{
    nwSendParamPtr->pduSize = 9;
}
pduOutPtr->pduMsgType = CHALLENGE_MSG;
pduOutPtr->transNum = gp->recvRec[rrIndexIn].transNum;
memcpy(pduOutPtr->value.randomBytes,
        gp->recvRec[rrIndexIn].rand,
        8);

/* Now fill in the NWSendParam structure. */
nwSendParamPtr->dropIfUnconfigured = FALSE; /* Challenges are not dropped */
/* Challenge must have come from a particular node.
Use format 2b for multicast and format 2a for others. */
nwSendParamPtr->destAddr.domainIndex =
gp->recvRec[rrIndexIn].srcAddr.domainIndex;
if (gp->recvRec[rrIndexIn].srcAddr.addressMode == MULTICAST)
{
    nwSendParamPtr->destAddr.addressMode = MULTICAST_ACK;
    nwSendParamPtr->destAddr.addr.addr2b.subnetAddr =
gp->recvRec[rrIndexIn].srcAddr.subnetAddr;
    nwSendParamPtr->destAddr.addr.addr2b.groupAddr.group =
gp->recvRec[rrIndexIn].srcAddr.group;
    if (!IsGroupMember(gp->recvRec[rrIndexIn].srcAddr.domainIndex,
                       gp->recvRec[rrIndexIn].srcAddr.group,
                       &nwSendParamPtr->destAddr.addr.addr2b.groupAddr.member))
    {
        ErrorMsg("InitiateChallenge: Strange: We are not member of group???.");
        return; /* Don't challenge. This case should not happen. */
    }
}
else
{
    nwSendParamPtr->destAddr.addressMode = SUBNET_NODE;
    nwSendParamPtr->destAddr.addr.addr2a =
```

```

        gp->recvRec[rrIndexIn].srcAddr.subnetAddr;
    )

    nwSendParamPtr->pduType = AUTHPDU_TYPE;
    nwSendParamPtr->deltaBL = 0;
    nwSendParamPtr->altPath = gp->recvRec[rrIndexIn].altPath;
    gp->recvRec[rrIndexIn].transState = AUTHENTICATING;
    EnQueue(nwQueuePtr);
#ifdef DEBUG
    DebugMsg("InitiateChallenge: Sending a challenge.");
#endif
    return;
}

/*****
Function:  SendReplyToChallenge
Returns:  None
Reference: None
Purpose:  To send a reply to a challenge just received.
Comments: None
*****/
static void SendReplyToChallenge(void)
{
    TSAReceiveParam *tsaReceiveParamPtr; /* Parameter in tsa input queue. */
    AuthPDUPtr      pduInPtr;           /* Ptr to PDU received. */
    AuthPDUPtr      pduOutPtr;          /* Ptr to PDU sent. */
    NWSendParam     *nwSendParamPtr;
    Queue           *nwQueuePtr;
    TransmitRecord  *xmitRecPtr;
    Byte            encryptValue[8];

    tsaReceiveParamPtr = QueueHead(&gp->tsaInQ);
    pduInPtr            = (AuthPDUPtr) (tsaReceiveParamPtr + 1);

    if (tsaReceiveParamPtr->srcAddr.domainIndex == FLEX_DOMAIN)
    {
        /* Challenge was received in flex domain that is not
           possible. We don't initiate challenge in flex domain.
           Ignore the challenge. */
        DeQueue(&gp->tsaInQ);
        return;
    }

    if (tsaReceiveParamPtr->priority)
    {
        nwQueuePtr = &gp->nwOutPriQ;
        xmitRecPtr = &gp->priXmitRec;
    }
    else
    {
        nwQueuePtr = &gp->nwOutQ;
        xmitRecPtr = &gp->xmitRec;
    }

    /* Make sure that this challenge for current transaction
       in progress. If not, it is stale. Ignore it. */
    /* Also do not reply if we did not set auth bit or
       the group value in challenge msg, if present,
       does not match the one in transmit record. */
    if (
        xmitRecPtr->status == UNUSED_TX ||

```

```

    ! xmitRecPtr->auth ||
    pduInPtr->transNum != xmitRecPtr->transNum ||
    addrFmtToMode[pduInPtr->fmt] != xmitRecPtr->nwDestAddr.addressMode ||
    (pduInPtr->fmt == 1 &&
     xmitRecPtr->nwDestAddr.addr.addr1 != pduInPtr->group)
)
{
    DeQueue(&gp->tsaInQ);
    INCR_STATS(nmp->stats.lateChallenges);
    return;
}

if (QueueFull(nwQueuePtr))
{
    /* No Space to send reply anyway. Come back later. */
    return;
}
nwSendParamPtr = QueueTail(nwQueuePtr);
pduOutPtr      = (AuthPDU *) (nwSendParamPtr + 1);

/* First compute the cryptoBytes to be sent. */
Encrypt(pduInPtr->value.randomBytes,
        xmitRecPtr->apdu, xmitRecPtr->apduSize,
        tsaReceiveParamPtr->srcAddr.domainIndex,
        encryptValue);

/* Form the reply AuthPDU. */
pduOutPtr->fmt = pduInPtr->fmt;
if (pduInPtr->fmt == 1)
{
    pduOutPtr->group = pduInPtr->group;
    nwSendParamPtr->pduSize = 10;
}
else
{
    nwSendParamPtr->pduSize = 9;
}
pduOutPtr->pduMsgType = REPLY_MSG;
pduOutPtr->transNum = xmitRecPtr->transNum;
memcpy(pduOutPtr->value.cryptoBytes, encryptValue, 8);

/* Now fill in the NWSendParam structure */
nwSendParamPtr->dropIfUnconfigured = FALSE; /* Replies are not dropped */
/* Challenge must have come from a particular node.
   Use subnet addressing to send to that node. */
nwSendParamPtr->destAddr.domainIndex =
    tsaReceiveParamPtr->srcAddr.domainIndex;
nwSendParamPtr->destAddr.addressMode = SUBNET_NODE;
nwSendParamPtr->destAddr.addr.addr2a =
    tsaReceiveParamPtr->srcAddr.subnetAddr;
nwSendParamPtr->pduType = AUTHPDU_TYPE;
nwSendParamPtr->deltaBL = 0;
nwSendParamPtr->altPath = tsaReceiveParamPtr->altPath;
EnQueue(nwQueuePtr);
DeQueue(&gp->tsaInQ);
#ifdef DEBUG
    DebugMsg("SendReply: Sending a reply msg.");
#endif
/* Restart the transmit timer. */
SetMsTimer(&xmitRecPtr->xmitTimer, xmitRecPtr->xmitTimerValue);
return;
}

/*****

```

```

Function: ProcessReply
Returns: None
Reference: None
Purpose: To process a reply msg received to see if it meets the
        challenge sent earlier.
Comments: None
*****/
static void ProcessReply(void)
{
    TSAReceiveParam *tsaReceiveParamPtr; /* Parameter in tsa input queue. */
    AuthPDUPtr      pduInPtr;           /* Ptr to PDU received. */
    int16           i;
    Byte            encryptValue[8];
    Byte            domainIndex;

    tsaReceiveParamPtr = QueueHead(&gp->tsaInQ);
    pduInPtr           = (AuthPDUPtr) (tsaReceiveParamPtr + 1);

    if (tsaReceiveParamPtr->srcAddr.domainIndex == FLEX_DOMAIN)
    {
        /* Reply received in flex domain. Ignore it. */
        DeQueue(&gp->tsaInQ);
        return;
    }

    /* If the reply indicates that the original address format is
       multicast, then make sure that the receive record matches
       this group number. Force it so that RetrieveRR will do the
       match. */
    tsaReceiveParamPtr->srcAddr.group = pduInPtr->group;

    /* The address format of the reply will be different from the address
       format of the original message. The original address format is in
       the Reply PDU. Change the address mode in source address before
       calling RetrieveRR. */
    tsaReceiveParamPtr->srcAddr.addressMode = addrFmtToMode[pduInPtr->fmt];

    /* Retrieve the associated record.

       If the original address format is broadcast, we don't have
       the subnet number in the current reply (as the reply itself does
       not use broadcast address mode) and hence we can't match
       subnet number. So, we don't support authentication in
       broadcast mode. */

    i = RetrieveRR(tsaReceiveParamPtr->srcAddr,
                  tsaReceiveParamPtr->priority);

    if (i == -1)
    {
        /* We did not find an associated RR. Ignore reply. */
        DeQueue(&gp->tsaInQ);
        INCR_STATS(nmp->stats.lateReplies);
        return;
    }

    /* We have a RR. */

    /* Check if we have already authenticated. */
    if (gp->recvRec[i].transState != AUTHENTICATING)
    {
        /* Ignore this reply as it is probably a duplicate. */
        DeQueue(&gp->tsaInQ);
        return;
    }
}

```

```

)

/* Check if other things match to make sure that we are
   authenticating the right RR. */
if (pduInPtr->fmt == 1 &&
    pduInPtr->group != gp->recvRec[i].srcAddr.group)
{
    /* Group in AuthPDU does not match one in RR. */
#ifdef DEBUG
    DebugMsg("ProcessReply: Group does not match. Ignore reply.");
#endif
    DeQueue(&gp->tsaInQ);
    return;
}

if (pduInPtr->transNum != gp->recvRec[i].transNum)
{
    /* Transaction Number does not match. Ignore reply. */
#ifdef DEBUG
    DebugMsg("ProcessReply: TID does not match. Ignore reply.");
#endif
    DeQueue(&gp->tsaInQ);
    return;
}

/* Now check if the reply matches our encryption. */
/* First compute the value of E(range, apdu) */

domainIndex = gp->recvRec[i].srcAddr.domainIndex;
if (domainIndex == FLEX_DOMAIN)
{
    /* We should not have initiated challenge in flexDomain. */
    /* Somthing is wrong. Ignore this reply. */
#ifdef DEBUG
    DebugMsg("ProcessReply: Oops! Challenge was unnecessary.");
#endif
    gp->recvRec[i].auth = FALSE; /* Flex Domain? Force it */
    DeQueue(&gp->tsaInQ);
    return;
}

Encrypt(gp->recvRec[i].rand,
        gp->recvRec[i].apdu, gp->recvRec[i].apduSize,
        domainIndex, encryptValue);

if (memcmp(encryptValue, pduInPtr->value.cryptoBytes, 8) == 0)
{
    /* Matches */
#ifdef DEBUG
    DebugMsg("ProcessReply: Reply matches.");
#endif
    gp->recvRec[i].auth = TRUE;
}
else
{
#ifdef DEBUG
    DebugMsg("ProcessReply: Reply Does not match");
#endif
    nmp->errorLog = AUTHENTICATION_MISMATCH;
    gp->recvRec[i].auth = FALSE;
}
gp->recvRec[i].transState = AUTHENTICATED;

/* Deliver the message now to the application layer. */
```

Click to view the full PDF of ISO/IEC 14908-1:2012

```

    Deliver(i);

    /* Send ack message if it is for transport layer and ackd msg. */
    if (gp->rcvRec[i].status == TRANSPORT_RR &&
        gp->rcvRec[i].serviceType == ACKD &&
        gp->rcvRec[i].transState == DELIVERED)
    {
        TPSendAck(i);
    }

    DeQueue(&gp->tsaInQ);
    return;
}

/*****
Function: Encrypt
Returns: None
Reference: 11.12 of this International Standard
Purpose: To compute the encryption key based on authentication
         key in the domain table, the APDU, and the random
         number given.
Comments: None
*****/
static void Encrypt(Byte randIn[], APDU *apduIn, uint16 apduSizeIn,
                  Byte domainIndexIn, Byte encryptValueOut[])
{
    int8 i, j, k;
    Byte m, n;
    Byte *apduBytes = (Byte *)apduIn;
    uint16 apduSize = apduSizeIn;

    for (i = 0; i < 8; i++)
    {
        encryptValueOut[i] = randIn[i];
    }

    do
    {
        for (i = 0; i <= 5; i++)
        {
            for (j = 7; j >= 0; j--)
            {
                {
                    k = (j + 1) % 8;
                    if (apduSize > 0)
                    {
                        m = apduBytes[--apduSize];
                    }
                    else
                    {
                        m = 0;
                    }
                    n = ~(encryptValueOut[j] + j);
                    if (eep->domainTable[domainIndexIn].key[i] &
                        (1 << (7 - j)))
                    {
                        encryptValueOut[j] =
                            encryptValueOut[k] + m + ((n << 1) + (n >> 7));
                    }
                    else
                    {
                        encryptValueOut[j] =
                            encryptValueOut[k] + m - ((n >> 1) + (n << 7));
                    }
                }
            }
        }
    }
}

```

```

    }
  } while (apduSize > 0);
}
/*-----End of tsa.c-----*/

```

A.10 Application Layer

```

/*****
Reference:      Section 12, Presentation/Application layer

File:          app.c

Version:       1.7

Purpose:       To implement session/application layer.

Note:         None

To Do:        None
*****/

```

```

/*****

```

Overview:

All messages coming into the application layer are handled by the APPReceive() function, that dispatches messages to the appropriate "Handle" function. Some of the functions explained here are local to the application layer and are not available to the application program. See "Local Function Prototypes" section below.

HandleNormal(): Handles normal messages bound to the application program. These are messages from other nodes that are bound to the application program.

HandleResponse(): Handles normal responses bound to the application program. These are responses due to requests generated by the application program.

ProcessNV(): Handles incoming NV update and poll messages. These are messages from other nodes or responses for requests generated by the application layer.

SendVar(): Takes care of network variable updates waiting to be sent, i.e implicit messages generated due to output network variable updates in the application program.

PollVar(): Takes care of network variable polls waiting to be dispatched. These are messages explicitly generated by the application program by calling various forms of poll functions. The corresponding variables are input network variables.

HandleNM(): Processes network management messages. Defn is in netmgmt.c.

HandleND(): Processes network diagnostic messages. Defn is in netmgmt.c.

HandleProxyResponse(): Handles responses from proxy messages. Defn is in netmgmt.c. i.e responses received from the target node are relayed back to the original node.

HandleMsgCompletion(): Handles transaction completion indications from

transport, session, and network layers. Some of them are for transactions originated by the application layer itself. Others are for transactions originated by the application program. In that case, the application program is notified of these completion events by a call to `MsgCompletes` or `NVUpdateCompletes` function.

`TryMsgSend()`: Helper function that moves messages in the application queue to lower layer queues as appropriate.

All messages generated by the application program (implicit or explicit) are buffered and then sent to lower layers by the `APPSend()` function.

`APPReset()`: Takes care of the application layer reset operations. Allocates memory for all queue structures used by the application. Also, performs some initialization that are done after each reset.

`APPInit()`: Takes care of initializations that are done only during power up.

`AddNV()`: Takes care of network variable declarations in the application program. This function is normally called during power up to register all network variables in application program. This is done using the function `AppInit()`. Note that `APPInit()` is application layer function whereas `AppInit()` is application program function.

`RefImpToAlt()`, `AltToRefImp()`: Functions to transform data between a format often used by CNP applications (such as `msg_in`, `msg_out`, `resp_in` etc) and the corresponding structures for reference implementation (`msgIn`, `msgOut`, etc).

The functions in this file also support the API interface used by application programs. e.g. `msg_send`, `resp_send`, `propagate()` etc.

There is no implicit way of sending network variable updates in the reference implementation. The application program should call `Propagate` or one of its variants to actually propagate network variable updates.

```

*****
/*-----*/
Section: Includes
-----*/
#include <stdio.h>
#include <string.h>

#include <cnp_1.h>
#include <node.h>
#include <queue.h>
#include <app.h>
#include <api.h>
#include <netmgmt.h>

/*-----*/
Section: Constant and Macro Definitions
-----*/
#define MAX_NV_SELF_DOC_LENGTH 1 023

/* Depending on whether ALTERNATE_STRUCTURES are used in application
   program or not, define the macros REF_IMP_TO_ALT and ALT_TO_REF_IMP
   accordingly. */
#if defined(ALTERNATE_STRUCTURES_NEEDED)
#define REF_IMP_TO_ALT(a,b) RefImpToAlt(a,b)
#define ALT_TO_REF_IMP(a,b) AltToRefImp(a,b)
#else

```

```
#define REF_IMP TO ALT(a,b)
#define ALT TO REF_IMP(a,b)
#endif

/*-----
Section: Type Definitions
-----*/
/* None */

/*-----
Section: Globals
-----*/
/* None */

/*-----
Section: Local Function Prototypes
-----*/
static void ProcessNV (APPReceiveParam *appReceiveParamPtr,
                      APDU *apduPtr);
static void ProcessNVUpdate (APPReceiveParam *appReceiveParamPtr,
                             APDU *apduPtr);
static void ProcessNVPoll (APPReceiveParam *appReceiveParamPtr,
                          APDU *apduPtr);

static void HandleMsgCompletion (APPReceiveParam *appReceiveParamPtr,
                                APDU *apduPtr);
static void HandleResponse (APPReceiveParam *appReceiveParamPtr,
                             APDU *apduPtr);
static void HandleNormal (APPReceiveParam *appReceiveParamPtr,
                          APDU *apduPtr);

static Status TryMsgSend (APPSendParam *appSendParamPtr,
                         APDU *apduPtr,
                         Queue *tsaOutQPtr,
                         Queue *nwOutQPtr);

static void ReinitMsgOut ();
static void ReinitRespOut ();

static Status PropagateThisIndex (int16 nvIndexIn, int16 primaryIndex);
static void PropagateThisPrimary (int16 nvIndexIn);
static void SendVar (void);

static Status PollThisIndex (int16 nvIndexIn);
static void PollThisPrimary (int16 nvIndexIn);
static void PollVar (void);

static Boolean IsArrayNV (int16 nvIndexIn,
                         uint16 *dimOut, int16 *indexOut);

static void ReinitMsgOut (void);
static void ReinitRespOut (void);
/*-----
Section: Function Definitions
-----*/

/*****
Function: APPInit
Returns: None
Reference: None
Purpose: To perform initializations that should be done only
         once when the node is powered on. These are not
         done during node reset.
Comments: None.
*****/
```

```

*****
void APPInit(void)
{
    uint16 len;

    gp->unboundSelector = 0x3FFF; /* Countdown as we assign */
    gp->nvArrayTblSize = 0;
    gp->nextBindableMsgTag = 0;
    gp->nextNonbindableMsgTag = NUM_ADDR_TBL_ENTRIES;

    /*****
    The SNVT area has the following layout (as expected by Network
    management tools):

    Header:
    uint16 length;
    uint8 numNetvars;
    uint8 version;
    uint8 msbNumNetvars;
    uint8 mtagCount;

    SNVT Desc:
    SNVTdescStruct[]; One struct (2 bytes) per var

    Node Self Doc String:
    char[]; Null terminated; just "\0" if empty

    SNVT Extension Records:
    one byte + various lengths

    Alias Field
    three bytes

    In the reference implementation, the SNVT information is
    stored in nmp->snvt, of type SNVTstruct. It can be
    stored in EEPROM too.

    In SNVTstruct the header fields are stored in explicit
    structure members, but the remaining information is stored
    in the 'sb' member that is simply a buffer of type char.

    When a network variable is added via AddNV():
    1. The Alias Field is saved.
    2. Room is made for the new SNVT Desc by moving all data
    past the last SNVT Desc forward by sizeof(SNVTdesc).
    The descPtr pointer indicates where the move starts.
    3. The new SNVT Desc is added (and descPtr is incremented).
    4. The new extension records are appended after the
    existing extension records.
    5. The Alias Field is restored (placed after the last
    extension record, and pointed to by aliasPtr).

    *****/

    /* Initialize SNVT area */
    nmp->snvt.version = 1;
    nmp->snvt.numNetvars = 0;
    nmp->snvt.msbNumNetvars = 0;
    nmp->snvt.mtagCount = 0;

    /* Copy NODE DOC info if there is sufficient space */
    /* If not, init to null string. */
    len = strlen(NODE_DOC) + 1;
    if (len <= SNVT_SIZE - sizeof(AliasField))

```

```

    strcpy((char *)&nmp->snvt.sb[0], NODE_DOC);
}
else
{
    nmp->snvt.sb[0] = '\0';
    len = 1;
}

/* Initially, there is no network var related info */
nmp->snvt.length = 6 + len + sizeof(AliasField);
nmp->snvt.descPtr = (SNVTdescStruct *)&nmp->snvt.sb[0];
nmp->snvt.aliasPtr = (AliasField *)&nmp->snvt.sb[len];
nmp->snvt.aliasPtr->bindingII = TRUE;
nmp->snvt.aliasPtr->queryStats = TRUE;
nmp->snvt.aliasPtr->aliasCount = 0x3F;
nmp->snvt.aliasPtr->hostAlias = NV_ALIAS_TABLE_SIZE;

nmp->nvTableSize = 0;
}

/*****
Function: APPReset
Returns: None
Reference: None
Purpose: To initialize the Queues used by the application layer.
        May be some more.
Comments: None.
*****/
void APPReset(void)
{
    uint16 queueItemSize;

    /* Allocate and Initialize Input Queue */
    gp->appInBufSize =
        DecodeBufferSize((uint8)eep->readOnlyData.appInBufSize);
    gp->appInQCnt = DecodeBufferCnt((uint8)eep->readOnlyData.appInBufCnt);
    queueItemSize = gp->appInBufSize + sizeof(APPReceiveParam);

    if (QueueInit(&gp->appInQ, queueItemSize, gp->appInQCnt)
        != SUCCESS)
    {
        ErrorMsg("APPReset: Unable to init Input Queue.\n");
        gp->resetOk = FALSE;
        return;
    }

    /* Allocate and Initialize Output Queue */
    gp->appOutBufSize =
        DecodeBufferSize((uint8)eep->readOnlyData.appOutBufSize);
    gp->appOutQCnt =
        DecodeBufferCnt((uint8)eep->readOnlyData.appOutBufCnt);
    queueItemSize = gp->appOutBufSize + sizeof(APPSendParam);

    if (QueueInit(&gp->appOutQ, queueItemSize, gp->appOutQCnt)
        != SUCCESS)
    {
        ErrorMsg("APPReset: Unable to init Output Queue.\n");
        gp->resetOk = FALSE;
        return;
    }

    /* Allocate and Initialize Pri Output Queue */
    gp->appOutPriBufSize = gp->appOutBufSize;
}

```

```

gp->appOutPriQCnt =
    DecodeBufferCnt((uint8)eep->readOnlyData.appOutBufPriCnt);
queueItemSize    = gp->appOutPriBufSize + sizeof(APPParam);

if (QueueInit(&gp->appOutPriQ, queueItemSize, gp->appOutPriQCnt)
    != SUCCESS)
{
    ErrorMsg("APPReset: Unable to init Priority Output Queue.\n");
    gp->resetOk = FALSE;
    return;
}

/* Allocate Queue for NV output variable scheduling */
gp->nvOutIndexQCnt    = MAX_NV_OUT;
gp->nvOutIndexBufSize = 2 + MAX_NV_LENGTH;
if (QueueInit(&gp->nvOutIndexQ, gp->nvOutIndexBufSize,
             gp->nvOutIndexQCnt) != SUCCESS)
{
    ErrorMsg("APPReset: Unable to init NV Out Index Queue.\n");
    gp->resetOk = FALSE;
    return;
}
gp->nvOutStatus      = SUCCESS; /* Propagate succeeds if all the scheduled
                                transactions complete successfully. */
gp->nvOutCanSchedule = TRUE;
gp->nvOutIndex       = 0; /* Not relevant initially */

/* Allocate Queue for NV input variable scheduling */
gp->nvInIndexQCnt = MAX_NV_IN;
if (QueueInit(&gp->nvInIndexQ, 2, gp->nvInIndexQCnt)
    != SUCCESS)
{
    ErrorMsg("APPReset: Unable to init NV In Index Queue.\n");
    gp->resetOk = FALSE;
    return;
}
gp->nvInDataStatus  = FAILURE; /* See node.h for usage */
gp->nvInTranStatus  = SUCCESS; /* See node.h for usage */
gp->nvInCanSchedule = TRUE;
gp->nvInIndex       = 0; /* Not relevant initially */

/* Set flags to correct state */
gp->msgReceive      = FALSE; /* TRUE if data is in gp->msgIn */
gp->respReceive     = FALSE; /* TRUE if data is in gp->respIn */
gp->callMsgFree     = FALSE;
gp->callRespFree    = FALSE;
gp->selectQueryFlag = FALSE; /* FALSE until selected */

/* Init msg and resp */
memset(&gp->msgIn, 0, sizeof(gp->msgIn));
memset(&gp->msgOut, 0, sizeof(gp->msgOut));
memset(&gp->respIn, 0, sizeof(gp->respIn));
memset(&gp->respOut, 0, sizeof(gp->respOut));
memset(&gp->nvInAddr, 0, sizeof(gp->nvInAddr));
gp->nvArrayIndex = 0;
#if defined(ALTERNATE_STRUCTURES_NEEDED)
memset(&msg_in, 0, sizeof(msg_in));
memset(&msg_out, 0, sizeof(msg_out));
memset(&resp_in, 0, sizeof(resp_in));
memset(&resp_out, 0, sizeof(resp_out));
memset(&nv_in_addr, 0, sizeof(nv_in_addr));
nv_array_index = 0;
#endif
}

```

```

/*****
Function: HandleMsgCompletion
Returns: None
Reference: None
Purpose: Pass a message completion event to the application
Comments: None.
*****/
static void HandleMsgCompletion (APPReceiveParam *appReceiveParamPtr,
                                APDU *apduPtr)
{
    Status stat;
    int16 primaryIndex, baseIndex;
    uint16 dim;
    Boolean pollCompletion = TRUE;

    if (appReceiveParamPtr->success)
    {
        stat = SUCCESS;
    }
    else
    {
        stat = FAILURE;
    }

    /* Since App Layer sends messages for NV update
       we may also get completion indication for these.
       See app.h for tag usage. */
    if (appReceiveParamPtr->tag < 0)
    {
        /* Negative tags belong to application layer. */
        /* See app.h for explanation on how the tag is used. */
        if (PROXY_TAG(appReceiveParamPtr->tag))
        {
            /* Proxy Completion. Release the proxy command structure */
            nmp->pxyData.pxyType = -1;
        }
        else if (MANUAL_SERVICE_REQUEST_TAG(appReceiveParamPtr->tag))
        {
            ; /* Ignore. Nothing to do. */
        }
        else
        {
            /* Must be a tag for NV message generated by application layer. */
            if (NV_POLL_TAG(appReceiveParamPtr->tag))
            {
                /* A network variable poll for an input variable will
                   succeed if both gp->nvInDataStatus and gp->nvInTranStatus succeed.
                   The gp->nvInDataStatus flag is updated by ProcessNVUpdate
                   function. */
                if (NV_LAST_TAG(appReceiveParamPtr->tag))
                {
                    primaryIndex = gp->nvInIndex;
                    IsArrayNV(primaryIndex, &dim, &baseIndex);
                    gp->nvArrayIndex = primaryIndex - baseIndex;
                    REF_IMP_TO_ALT(NV_ARRAY_INDEX, &nv_array_index);
                    /* Set poll completion status */
                    if ( (gp->nvInDataStatus == SUCCESS) &&
                        (gp->nvInTranStatus == SUCCESS)
                    )
                    {
                        stat = SUCCESS;
                    }
                }
            }
            else
            {
                stat = FAILURE;
            }
        }
    }
}

```



```

    {
        stat = FAILURE;
    } /* poll completion status */
    gp->nvInDataStatus = FAILURE; /* Reinit */
    gp->nvInTranStatus = SUCCESS;
    if (AppPgmRuns())
    {
        NVUpdateCompletes(stat, baseIndex, gp->nvArrayIndex);
    }
}
else
{
    /* Update the index. Since the last tag does not have the
       index, we need to save it. */
    gp->nvInIndex = NV_INDEX_OF_TAG(appReceiveParamPtr->tag);
    if (stat == FAILURE)
    {
        /* Set the flag to FAILURE as this transaction failed. */
        gp->nvInTranStatus = FAILURE;
    }
}
gp->nvInCanSchedule = TRUE; /* Resume scheduling */
}
else
{
    /* NV_UPDATE_TAG */
    /* A network variable update for an output variable will
       succeed if all the transactions scheduled for that
       variable succeed. So, we need to update status flag. */
    if (NV_LAST_TAG(appReceiveParamPtr->tag))
    {
        primaryIndex = gp->nvOutIndex;
        lsArrayNV(primaryIndex, &dim, &baseIndex);
        gp->nvArrayIndex = primaryIndex - baseIndex;
        REF_IMP_TO_ALT(NV_ARRAY_INDEX, &nv_array_index);
        stat = gp->nvOutStatus;
        gp->nvOutStatus = SUCCESS; /* Reinit */
        if (AppPgmRuns())
        {
            NVUpdateCompletes(stat, baseIndex, gp->nvArrayIndex);
        }
    }
    else
    {
        /* Set index. Update gp->nvOutStatus */
        gp->nvOutIndex = NV_INDEX_OF_TAG(appReceiveParamPtr->tag);
        if (stat == FAILURE)
        {
            gp->nvOutStatus = FAILURE;
        }
    }
    gp->nvOutCanSchedule = TRUE; /* Resume scheduling */
}
}
}
else
{
    /* Non-negative tags belong to application. */
    MsgCompletes(stat, appReceiveParamPtr->tag);
}

/* Message processing completed - remove it from queue */
DeQueue(&gp->appInQ);
}

```

```

/*****
Function:  HandleResponse
Returns:  None
Reference: None
Purpose:  Handle incoming response message, passing it to the
          application via the gp->respIn global.
Comments: None.
*****/
static void HandleResponse(APPReceiveParam *appReceiveParamPtr,
                          APDU             *apduPtr)
{
    /* Discard responses received when the node is not CNFG_ONLINE.
       In CNFG_ONLINE, the application can be either running (online)
       or not running (soft-offline). In either of these cases,
       we receive the response and store it in resp_in. Note that
       one reponse can be received at a time from resp_in. If the
       application is offline, then at most one response can be
       stored in resp_in */
    if(eep->readOnlyData.nodeState != CNFG_ONLINE)
    {
        DeQueue(&gp->appInQ); /* Discard response, nothing to do */
        return;
    }

    /* If the application has not processed the previous
       * response, then do nothing, we'll try again next time
       */
    if(gp->respReceive)
    {
        return;
    }

    /* Pass response to application */

    /* Setup gp->respIn */
    gp->respIn.tag = appReceiveParamPtr->tag;
    gp->respIn.code = apduPtr->code.allBits;
    gp->respIn.len = appReceiveParamPtr->pduSize - 1;

    /* Copy domainIndex even if it is 2. respIn.domainIndex is
       only one bit anyway, so the result is 0 or 1 */
    gp->respIn.addr.domain = appReceiveParamPtr->srcAddr.domainIndex;
    gp->respIn.addr.flexDomain =
        (appReceiveParamPtr->srcAddr.domainIndex == 2);
    memcpy(&gp->respIn.addr.srcAddr,
          &appReceiveParamPtr->srcAddr.subnetAddr,
          sizeof(appReceiveParamPtr->srcAddr.subnetAddr));
    gp->respIn.addr.srcAddr.snodeFlag =
        appReceiveParamPtr->srcAddr.addressMode != MULTICAST_ACK;
    if (gp->respIn.addr.srcAddr.snodeFlag == 0)
    {
        memcpy(&gp->respIn.addr.destAddr.group,
              &appReceiveParamPtr->srcAddr.ackNode,
              sizeof(appReceiveParamPtr->srcAddr.ackNode));
    }
    else if (!gp->respIn.addr.flexDomain)
    {
        /* Fill snode entry only for non-flex domain response */
        gp->respIn.addr.destAddr.snode.subnet =
            eep->domainTable[appReceiveParamPtr->
                            srcAddr.domainIndex].subnet;
        gp->respIn.addr.destAddr.snode.node =
            eep->domainTable[appReceiveParamPtr->

```

```

        srcAddr.domainIndex].node;
    }
    if (gp->respIn.len <= gp->appInBufSize)
    {
        memcpy(gp->respIn.data, &apduPtr->data, gp->respIn.len);
        gp->respReceive = TRUE;
#ifdef ALTERNATE_STRUCTURES_NEEDED
        REF_IMP TO ALT(Resp_In, &resp_in);
#endif
    }
    else
    {
        nmp->errorLog = WRITE_PAST_END_OF_APPL_BUFFER;
    }
    /* Message processing completed - remove it from queue */
    DeQueue (&gp->appInQ);
}

```

```

/*****
Function:  HandleNormal
Returns:   None
Reference: None
Purpose:   Handle incoming normal message
Comments:  If the application program is not running and a request message
           for the application program is received, we send a offline
           message. Note that the node state could be unconfigured or
           soft off-line.
*****/
static void HandleNormal (APPReceiveParam *appReceiveParamPtr,
                          APDU           *apduPtr)
{
    Queue          *tsaOutQPtr;
    TSASendParam   *tsaSendParamPtr;
    APDU           *apduRespPtr;

    if (!AppPgmRuns ())
    {
        if (appReceiveParamPtr->service == REQUEST)
        {
            /* If not online, send offline response */
            tsaOutQPtr = &gp->tsaRespQ;
            if (QueueFull (tsaOutQPtr))
            {
                /* Can't send response yet - try later */
                return;
            }
            tsaSendParamPtr = QueueTail (tsaOutQPtr);
            tsaSendParamPtr->altPathOverride = FALSE;
            tsaSendParamPtr->service = RESPONSE;
            tsaSendParamPtr->reqId = appReceiveParamPtr->reqId;
            tsaSendParamPtr->nullResponse = FALSE;
            tsaSendParamPtr->apduSize = 1; /* Just the code */
            apduRespPtr = (APDU *) (tsaSendParamPtr + 1);
            if (apduPtr->code.ff.ffFlag == 0x4)
            {
                apduRespPtr->code.allBits = FOREIGN_FRAME_OFFLINE;
            }
            else
            {
                apduRespPtr->code.allBits = APPL_MSG_OFFLINE;
            }
            EnQueue (tsaOutQPtr);
        }
        DeQueue (&gp->appInQ); /* Discard msg, nothing to do */
    }
}

```

```

    return;
}

/* If the application has not processed the previous
 * message, then do nothing, we'll try again next time */
if(gp->msgReceive)
{
    return;
}

/* Pass message to application */

/* Setup gp->msgIn */
gp->msgIn.code = apduPtr->code.allBits;
gp->msgIn.len = appReceiveParamPtr->pduSize - 1;
if (gp->msgIn.len <= gp->appInBufSize)
{
    memcpy(gp->msgIn.data, &apduPtr->data, gp->msgIn.len);
}
else
{
    nmp->errorLog = WRITE_PAST_END_OF_APPL_BUFFER;
    DeQueue(&gp->appInQ);
    return;
}

gp->msgIn.authenticated = appReceiveParamPtr->auth;
gp->msgIn.service = appReceiveParamPtr->service;
gp->msgIn.reqId = appReceiveParamPtr->reqId;
/* Fill in addr structure */
gp->msgIn.addr.domain = appReceiveParamPtr->srcAddr.domainIndex;
gp->msgIn.addr.flexDomain =
    (appReceiveParamPtr->srcAddr.domainIndex == 2);
/* Copy Source Address */
memcpy(&gp->msgIn.addr.srcAddr,
    &appReceiveParamPtr->srcAddr.subnetAddr,
    sizeof(gp->msgIn.addr.srcAddr));
switch(appReceiveParamPtr->srcAddr.addressMode)
{
    case BROADCAST:
        gp->msgIn.addr.format = 0;
        gp->msgIn.addr.destAddr.bcastSubnet =
            appReceiveParamPtr->srcAddr.broadcastSubnet;
        break;
    case MULTICAST:
        gp->msgIn.addr.format = 1;
        gp->msgIn.addr.destAddr.group =
            appReceiveParamPtr->srcAddr.group;
        break;
    case SUBNET_NODE:
        gp->msgIn.addr.format = 2;
        if (!gp->msgIn.addr.flexDomain)
        {
            gp->msgIn.addr.destAddr.snode.subnet =
                eep->domainTable[gp->msgIn.addr.domain].subnet;
            gp->msgIn.addr.destAddr.snode.node =
                eep->domainTable[gp->msgIn.addr.domain].node;
        }
        break;
    case UNIQUE_NODE_ID:
        gp->msgIn.addr.format = 3;
        gp->msgIn.addr.destAddr.uniqueNodeId.subnet = 0; /* Not stored */
        memcpy(gp->msgIn.addr.destAddr.uniqueNodeId.uniqueId,

```

```

        eep->readOnlyData.uniqueNodeId,
        UNIQUE_NODE_ID_LEN);
    break;
default:
    /* should not come here */
    gp->msgIn.addr.format = 5; /* unknown. arbitrary 5 */
}

gp->msgReceive = TRUE;
REF_IMP_TO_ALT(MSG_IN, &msg_in);
/* Message processing completed - remove it from queue */
DeQueue(&gp->appInQ);
}

/*****
Function: APPSend
Returns: None
Reference: None
Purpose: Process send side of the application layer
        Send one message of each of the following types if there is space.
        pri msg, nv update message, nv poll message, non-pri msg.
Comments: Called by scheduler loop.
*****/
void APPSend(void)
{
    Queue      *appOutQPtr;
    Queue      *tsaOutQPtr;
    Queue      *nwOutQPtr;
    APPSendParam *appSendParamPtr;
    APDU       *apduPtr;
    Status      status;

    if(gp->>manualServiceRequest)
    {
        ManualServiceRequestMessage();
        gp->>manualServiceRequest = FALSE;
    }

    /* Call MsgFree or RespFree implicitly if needed. */
    if (gp->callMsgFree)
    {
        MsgFree();
    }
    if (gp->callRespFree)
    {
        RespFree();
    }

    /* Send a priority message if we can */
    if (!QueueEmpty(&gp->appOutPriQ))
    {
        appOutQPtr = &gp->appOutPriQ;
        tsaOutQPtr = &gp->tsaOutPriQ;
        nwOutQPtr = &gp->nwOutPriQ;
        appSendParamPtr = QueueHead(appOutQPtr);
        apduPtr = (APDU *) (appSendParamPtr + 1);
        status = TryMsgSend(appSendParamPtr, apduPtr,
                           tsaOutQPtr, nwOutQPtr);
        if (status == SUCCESS)
        {
            /* We have moved this message. Discard it */
            DeQueue(appOutQPtr);
        }
    }
}

```

```

}

/* Process one NV output variable scheduled, if any. */
SendVar();

/* Process one NV input variable (Poll) scheduled, if any. */
PollVar();

/* Send a non-priority message if we can */
if (!QueueEmpty(&gp->appOutQ))
{
    appOutQPtr = &gp->appOutQ;
    tsaOutQPtr = &gp->tsaOutQ;
    nwOutQPtr = &gp->nwOutQ;
    appSendParamPtr = QueueHead(appOutQPtr);
    apduPtr = (APDU *) (appSendParamPtr + 1);
    status = TryMsgSend(appSendParamPtr, apduPtr,
                       tsaOutQPtr, nwOutQPtr);

    if (status == SUCCESS)
    {
        /* We have moved this message. Discard it */
        DeQueue(appOutQPtr);
    }
}
}
}

```

```

/*****
Function: APPReceive
Returns: None
Reference: None
Purpose: Process receive side of the application layer.
Comments: Called by scheduler loop.
*****/
void APPReceive(void)
{
    APPReceiveParam *appReceiveParamPtr;
    APDU *apduPtr; /* ptr to APDU being received */

    /* Check if anything to process */
    if(QueueEmpty(&gp->appInQ))
    {
        return; /* Nothing to process */
    }

    /* Set the pointer to APDU in appInQ */
    appReceiveParamPtr = QueueHead(&gp->appInQ);
    apduPtr = (APDU *) (appReceiveParamPtr + 1);

    if(appReceiveParamPtr->indication == COMPLETION)
    {
        HandleMsgCompletion(appReceiveParamPtr, apduPtr);
    }
    else if(appReceiveParamPtr->service == RESPONSE &&
            appReceiveParamPtr->tag >= 0)
    {
        /* The response belongs to the application program.
        Deliver it to the application irrespective of
        what type of message it is. If the application
        sends network management/diagnostic messages,
        it is its responsibility to handle them */
        HandleResponse(appReceiveParamPtr, apduPtr);
    }
}

```

```

/* Handle Response from a Network Diagnostic Proxy Command */
/* pxyType is initialized to -1. If a proxy command has been
   received, it is set to the command requested (0 or 1 or 2).
   The command is forwarded using a tag value of PROXY_TAG.
   So, check if this message is a response and is a response
   to a previously forwarded proxy command.
   The response should match (success or failure) of
   original the request */
else if(nmp->pxyData.pxyType != -1 &&
        PROXY_TAG(appReceiveParamPtr->tag) &&
        appReceiveParamPtr->service == RESPONSE &&
        (apduPtr->code.allBits == 0x32 ||
         apduPtr->code.allBits == 0x12)
       )
{
    /* Indeed we have a good proxy response. Forward to source */
    HandleProxyResponse(appReceiveParamPtr, apduPtr);
}
else if (appReceiveParamPtr->service == RESPONSE &&
        PROXY_TAG(appReceiveParamPtr->tag))
{
    /* ill-formed proxy response. Ignore. */
    DeQueue (&gp->appInQ);
}
else if (apduPtr->code.nm.nmFlag == 0x3)
{
    /* Network management messages */
    HandleNM(appReceiveParamPtr, apduPtr);
}
else if (apduPtr->code.nd.ndFlag == 0x5)
{
    /* Network diagnostic messages */
    HandleND(appReceiveParamPtr, apduPtr);
}
else if (apduPtr->code.nv.nvFlag == 0x1)
{
    /* Network variable update/poll messages */
    ProcessNV(appReceiveParamPtr, apduPtr);
}
else if (apduPtr->code.ap.apFlag == 0x0 || apduPtr->code.ff.ffFlag == 0x4)
{
    /* Messages bound to the application program. App Msg or Foreign Frames. */
    HandleNormal(appReceiveParamPtr, apduPtr);
}
else
{
    /* Not supported - just discard */
    DeQueue (&gp->appInQ);
}
}

/*****
Function: TryMsgSend
Returns: SUCCESS if message sent, FAILURE otherwise
Reference: None
Purpose: If room is available, move message from app queue to
         to tsa or nw output queue.
Comments: None.
*****/
static Status TryMsgSend(APPParam *appSendParamPtr,
                        APDU *apduPtr,
                        Queue *tsaOutQPtr,
                        Queue *nwOutQPtr)

```

```
{
    TSASendParam *tsaSendParamPtr;
    NWSendParam *nwSendParamPtr;
    APDU *apduSendPtr;

    /* If the address is bad, don't even bother sending it */
    if(appSendParamPtr->addr.noAddress == UNBOUND)
    {
        /* TurnAround is not possible with MsgOutAddr */
        MsgCompletes(SUCCESS, appSendParamPtr->tag);
        return(SUCCESS);
    }

    /* Simple unacknowledged messages go to network layer */
    if(appSendParamPtr->service == UNACKD)
    {
        if(QueueFull(nwOutQPtr))
        {
            return(FAILURE); /* Can't send message yet - try later */
        }

        nwSendParamPtr = QueueTail(nwOutQPtr);

        nwSendParamPtr->dropIfUnconfigured = TRUE;

        switch(appSendParamPtr->addr.noAddress)
        {
            case UNBOUND:
                /* Can't happen. We took care above */
                return(SUCCESS); /* doesn't matter what we return */
            case SUBNET_NODE:
                nwSendParamPtr->destAddr.addressMode = SUBNET_NODE;
                nwSendParamPtr->destAddr.domainIndex =
                    appSendParamPtr->addr.snode.domainIndex;
                nwSendParamPtr->destAddr.addr.addr2a.subnet =
                    appSendParamPtr->addr.snode.subnetID;
                nwSendParamPtr->destAddr.addr.addr2a.node =
                    appSendParamPtr->addr.snode.node;
                break;

            case UNIQUE_NODE_ID:
                nwSendParamPtr->destAddr.addressMode = UNIQUE_NODE_ID;
                nwSendParamPtr->destAddr.domainIndex =
                    appSendParamPtr->addr.uniqueNodeId.domainIndex;
                nwSendParamPtr->destAddr.addr.addr3.subnet =
                    appSendParamPtr->addr.uniqueNodeId.subnetID;
                memcpy(nwSendParamPtr->destAddr.addr.addr3.uniqueId,
                    appSendParamPtr->addr.uniqueNodeId.uniqueId,
                    UNIQUE_NODE_ID_LEN);
                break;

            case BROADCAST:
                nwSendParamPtr->destAddr.addressMode = BROADCAST;
                nwSendParamPtr->destAddr.domainIndex =
                    appSendParamPtr->addr.bcast.domainIndex;
                nwSendParamPtr->destAddr.addr.addr0 =
                    appSendParamPtr->addr.bcast.subnetID;
                break;

            default: /* MUST BE GROUP FORMAT */
                nwSendParamPtr->destAddr.addressMode = MULTICAST;
                nwSendParamPtr->destAddr.domainIndex =
                    appSendParamPtr->addr.group.domainIndex;
                nwSendParamPtr->destAddr.addr.addr1 =
```



```

        appSendParamPtr->addr.group.groupID;
        break;
    } /* switch */

    nwSendParamPtr->tag = appSendParamPtr->tag;
    nwSendParamPtr->pduType = APDU_TYPE;
    nwSendParamPtr->deltaBL = 0;
    /* unacknowledged messages do not use alternate path */
    nwSendParamPtr->altPath = FALSE;
    nwSendParamPtr->pduSize = appSendParamPtr->len + 1;

    apduSendPtr = (APDU *) (nwSendParamPtr + 1);
    if (nwSendParamPtr->pduSize <= gp->nwOutBufSize)
    {
        memcpy(apduSendPtr, apduPtr, appSendParamPtr->len + 1);
        EnQueue(nwOutQPtr);
        /* Don't give completion yet. The network layer will send the
           completion indication in gp->appInQ */
    }
    else
    {
        /* Losing this packet as it is too large */
        MsgCompletes(FAILURE, appSendParamPtr->tag);
    }

    return(SUCCESS);
}

if (QueueFull(tsaOutQPtr))
{
    return(FAILURE); /* Can't send message yet - try later */
}

/* All other service types go to TSA layers */
tsaSendParamPtr = QueueTail(tsaOutQPtr);

tsaSendParamPtr->domainIndex = 3;
memcpy(&tsaSendParamPtr->destAddr,
        &appSendParamPtr->addr,
        sizeof(appSendParamPtr->addr));
tsaSendParamPtr->service = appSendParamPtr->service;
tsaSendParamPtr->auth = appSendParamPtr->authenticated;
tsaSendParamPtr->reqId = appSendParamPtr->reqId;
tsaSendParamPtr->tag = appSendParamPtr->tag;
tsaSendParamPtr->apduSize = appSendParamPtr->len + 1;
tsaSendParamPtr->altPathOverride = FALSE;

apduSendPtr = (APDU *) (tsaSendParamPtr + 1);
if (tsaSendParamPtr->apduSize <= gp->tsaOutBufSize)
{
    memcpy(apduSendPtr, apduPtr, tsaSendParamPtr->apduSize);
    EnQueue(tsaOutQPtr);
}
else
{
    /* Losing this message */
    MsgCompletes(FAILURE, appSendParamPtr->tag);
}

return(SUCCESS);
}

static void ReinitMsgOut(void)
{

```

```
/* Reinit whatever fields need to be reinitialized after each msg_send */
memset(&gp->msgOut, 0, sizeof(gp->msgOut));
#if defined(ALTERNATE_STRUCTURES_NEEDED)
memset(&msg_out, 0, sizeof(msg_out));
#endif
}

static void ReinitRespOut(void)
{
/* Reinit whatever fields need to be reinitialized after each resp_send */
memset(&gp->respOut, 0, sizeof(gp->respOut));
#if defined(ALTERNATE_STRUCTURES_NEEDED)
memset(&resp_out, 0, sizeof(resp_out));
#endif
}


/*****
Function: MsgAlloc
Returns: None
Reference: None
Purpose: Determines if there is room for a message to be sent.
Comments: None.
*****/
Boolean MsgAlloc(void)
{
return(!QueueFull(&gp->appOutQ));
}

/* For nc compatibility */
Boolean msg_alloc(void)
{
return(!QueueFull(&gp->appOutQ));
}

/*****
Function: MsgAllocPriority
Returns: None
Reference: None
Purpose: Determines if there is room for a pri message to be sent.
Comments: None.
*****/
Boolean MsgAllocPriority(void)
{
return(!QueueFull(&gp->appOutPriQ));
}

/* For nc compatibility */
Boolean msg_alloc_priority(void)
{
return(!QueueFull(&gp->appOutPriQ));
}

/*****
Function: MsgSend
Returns: None
Reference: None
Purpose: The application calls this function to send a message.
The message is placed in the application queue for
processing by APPSend.
Comments: None.
*****/
void MsgSend(void)
{
Queue *outQptr;
```



```

APPSendParam    *appSendParamPtr;
APDU            *apduPtr;
AddrTableEntry  *ap;
uint16          addrIndex;

```

```

ALT_TO_REF_IMP(MSG_OUT, &msg_out);

```

```

if(gp->msgOut.priorityOn)
{
    outQptr = &gp->appOutPriQ;
}
else
{
    outQptr = &gp->appOutQ;
}

```

```

/* Negative tags are reserved for application layer.
   Applications are not allowed to use negative tags */
if(QueueFull(outQptr) || gp->msgOut.tag < 0 ||
   (gp->msgOut.service >= RESPONSE))
{
    /* Bad Tag OR
       Bad Service OR
       No place to put the message - discard it. This should
       not happen if application called MsgAlloc or
       MsgPriorityAlloc before forming the message */
    MsgCompletes(FAILURE, gp->msgOut.tag);
    ReinitMsgOut();
    return;
}

```

```

appSendParamPtr = QueueTail(outQptr);
appSendParamPtr->tag = gp->msgOut.tag;
appSendParamPtr->len = gp->msgOut.len;
appSendParamPtr->authenticated = gp->msgOut.authenticated;
appSendParamPtr->service = gp->msgOut.service;
appSendParamPtr->addr = gp->msgOut.addr;
apduPtr = (APDU *) (appSendParamPtr + 1);
apduPtr->code.allBits = gp->msgOut.code;
if (appSendParamPtr->len + 1 <= gp->appOutBufSize)
{
    /* There is space in the queue item to copy data */
    memcpy((char *)apduPtr+1,
           gp->msgOut.data,
           appSendParamPtr->len);
}
else
{
    /* We are losing this message as it is too big. */
    MsgCompletes(FAILURE, appSendParamPtr->tag);
    ReinitMsgOut();
    return;
}

```

```

/* Use implicit addressing if the tag value corresponds to an address
   table entry and the explicit address is unbound or turnaround.
   Thus explicit address can be used to override implicit addressing.
   Note that turnaround is not allowed with explicit messages. */
if(appSendParamPtr->tag < NUM_ADDR_TBL_ENTRIES &&
   gp->msgOut.addr.noAddress == UNBOUND)
{
    addrIndex = appSendParamPtr->tag;
    ap = AccessAddress(addrIndex); /* ap cannot be NULL */
}

```

```
    if (ap == NULL || ap->addrFormat == UNBOUND)
    {
        /* ap cannot be NULL, but we can be safe in checking it anyway.
           We lose this message as the address table entry is unbound
           or turnaround. */
        MsgCompletes(FAILURE, appSendParamPtr->tag);
        ReinitMsgOut();
        return;
    }
    memcpy(&appSendParamPtr->addr,
           ap,
           sizeof(MsgOutAddr));
}
EnQueue(outQptr);
ReinitMsgOut();
}

/* For nc compatibility */
void msg_send(void)
{
    MsgSend();
}

/*****
Function:  MsgCancel
Returns:   None
Reference: None
Purpose:   The application calls this function to cancel a
           previous message allocation.
Comments:  None.
*****/
void MsgCancel(void)
{
    /* Nothing to do */
}

/* For nc compatibility */
void msg_cancel()
{
}

/*****
Function:  MsgFree
Returns:   None
Reference: None
Purpose:   Releases gp->msgIn (by cleaning gp->msgReceive) so that the
           next message can be copied to gp->msgIn.
Comments:  None.
*****/
void MsgFree(void)
{
    gp->msgReceive = FALSE; /* TRUE when data is in gp->msgIn */
    gp->callMsgFree = FALSE;
}

/* For nc compatibility */
void msg_free(void)
{
    gp->msgReceive = FALSE;
    gp->callMsgFree = FALSE;
}

/* TRUE if there is msg to be received */
Boolean msgReceive(void)
```

Click to view the full PDF of ISO/IEC 14908-1:2012

```

{
    if (gp->msgReceive)
    {
        /* There is a message to be received. Need to call msg_free() */
        gp->callMsgFree = TRUE;
    }
    return(gp->msgReceive);
}

/* For nc compatibility */
Boolean msg_receive(void)
{
    if (gp->msgReceive)
    {
        /* There is a message to be received. Need to call msg_free() */
        gp->callMsgFree = TRUE;
    }
    return(gp->msgReceive);
}

/*****
Function: RespAlloc
Returns: None
Reference: None
Purpose: Check if there is space for sending a response.
Comments: None.
*****/
Boolean RespAlloc(void)
{
    if (!QueueFull(&gp->tsaRespQ))
    {
        return(TRUE);
    }
    return(FALSE);
}

/* For nc compatibility */
Boolean resp_alloc(void)
{
    return(RespAlloc());
}

/*****
Function: RespSend
Returns: None
Reference: None
Purpose: Reads gp->respOut, sends the response message
Comments: None.
*****/
void RespSend(void)
{
    TSASendParam *tsaSendParamPtr;
    APDU *apduRespPtr;

    ALT_TO_REF_IMP(RESP_OUT, &resp_out);

    if (gp->respOut.reqId == 0)
    {
        /* Application did not initialize it. Let us use as default
        the reqId of message currently in gp->msgIn */
        gp->respOut.reqId = gp->msgIn.reqId;
    }

    /* Place the response in tsaRespQ. If it is full, discard the

```

```
response. There should be space if application called
RespAlloc before forming the response */
if (!QueueFull(&gp->tsaRespQ))
{
    tsaSendParamPtr      = QueueTail(&gp->tsaRespQ);
    apduRespPtr          = (APDU *) (tsaSendParamPtr + 1);
    tsaSendParamPtr->altPathOverride = FALSE;
    tsaSendParamPtr->service      = RESPONSE;
    tsaSendParamPtr->reqId       = gp->respOut.reqId;
    tsaSendParamPtr->apduSize    = gp->respOut.len + 1;
    tsaSendParamPtr->nullResponse = gp->respOut.nullResponse;
    apduRespPtr->code.allBits    = gp->respOut.code;
    if (tsaSendParamPtr->apduSize <= gp->tsaRespBufSize)
    {
        memcpy((char *)apduRespPtr + 1,
              gp->respOut.data,
              gp->respOut.len);
        EnQueue(&gp->tsaRespQ);
    }
    else
    {
        /* Lose this response as it is too big to fit */
        /* There is no errorLog or stat to record this */
        ;
    }
}
else
{
    /* Sorry! Application is sending a response without checking
    for space first */
    ;
}
ReinitRespOut();
}
```

```
/* For nc compatibility */
void resp_send(void)
{
    RespSend();
}
```

```
*****
Function: RespCancel
Returns: None
Reference: None
Purpose: The application calls this function to cancel a
previous response allocation.
Comments: None.
*****
```

```
void RespCancel(void)
{
    /* Nothing to do */
}
```

```
/* For nc compatibility */
void resp_cancel(void)
{
}
```

```
*****
Function: RespFree
Returns: None
Reference: None
*****
```



Purpose: Sets gp->respReceive to FALSE, which will allow a new response to be received.

Comments: None.

```
void RespFree(void)
```

```
{
    gp->respReceive = FALSE; /* TRUE when data is in gp->respIn */
    gp->callRespFree = FALSE;
}
```

```
/* For nc compatibility */
```

```
void resp_free(void)
```

```
{
    gp->respReceive = FALSE;
    gp->callRespFree = FALSE;
}
```

```
/* Returns TRUE if there is resp to be received */
```

```
Boolean RespReceive(void)
```

```
{
    if (gp->respReceive)
    {
        /* There is a response to be received. Need to call resp_free() */
        gp->callRespFree = TRUE;
    }
    return(gp->respReceive);
}
```

```
/* For nc comptability */
```

```
Boolean resp_receive(void)
```

```
{
    if (gp->respReceive)
    {
        /* There is a response to be received. Need to call resp_free() */
        gp->callRespFree = TRUE;
    }
    return(gp->respReceive);
}
```

```
void RefImpToAlt(RefImpAltStruct whatIn, void *destAddr)
```

```
{
    switch(whatIn)
    {
        case MSG_IN:
            memcpy(destAddr, &gp->msgIn, sizeof(gp->msgIn));
            break;
        case MSG_OUT:
            memcpy(destAddr, &gp->msgOut, sizeof(gp->msgOut));
            break;
        case RESP_IN:
            memcpy(destAddr, &gp->respIn, sizeof(gp->respIn));
            break;
        case RESP_OUT:
            memcpy(destAddr, &gp->respOut, sizeof(gp->respOut));
            break;
        case NV_IN_ADDR:
            memcpy(destAddr, &gp->nvInAddr, sizeof(gp->nvInAddr));
            break;
        case NV_ARRAY_INDEX:
            memcpy(destAddr, &gp->nvArrayIndex, sizeof(gp->nvArrayIndex));
            break;
        default:
            /* Do nothing */
            ;
    }
}
```

```

}
}
void AltToRefImp(RefImpAltStruct whatIn, void *srcAddr)
{
    switch(whatIn)
    {
        case MSG_IN:
            memcpy(&gp->msgIn, srcAddr, sizeof(gp->msgIn));
            break;
        case MSG_OUT:
            memcpy(&gp->msgOut, srcAddr, sizeof(gp->msgOut));
            break;
        case RESP_IN:
            memcpy(&gp->respIn, srcAddr, sizeof(gp->respIn));
            break;
        case RESP_OUT:
            memcpy(&gp->respOut, srcAddr, sizeof(gp->respOut));
            break;
        case NV_IN_ADDR:
            memcpy(&gp->nvInAddr, srcAddr, sizeof(gp->nvInAddr));
            break;
        case NV_ARRAY_INDEX:
            memcpy(&gp->nvArrayIndex, srcAddr, sizeof(gp->nvArrayIndex));
            break;
        default:
            /* Do nothing */
            ;
    }
}

/*****
Function: AddNV
Returns: Network variable index. For arrays, the base index is returned.
Reference: None
Purpose: Adds a new network variable. This involves
         adding an entry into nvConfigTable, nvFixedTable,
         SNVT information, if present etc.
         The return value is the index assigned to the variable.
         For arrays, each element is like a separate network
         variable. So, multiple entries are added to the
         tables. However, only the base index is returned.
Comments: Format of the snvt.sb space is as follows:
         Self-Id for each network variable (SNVTdescStruct)
         (For arrays, one entry for each element)
         Node Self-Doc string.
         Self-Doc for each network variable
         (SNVTExtension & variable part)
         Self-Id for binding and status (AliasField)
*****/
int16 AddNV(NVDefinition *dp)
{
    uint16 i, nvSelfIdCnt;
    uint16 nvNameLen; /* Length for name of network variable. */
    uint16 docLen; /* Length for self-doc for network var. */
    uint16 selectorVal;
    uint16 sizeNeeded;
    uint16 dim;
    uint16 jumpBy; /* Number of bytes by that we shift sb array. */
    uint8 remainder, quotient;
    SNVTExtension *se;
    SNVTdescStruct *sd;
    AliasField saveAlias; /* To save old alias field. */
    char *p;
    char *extPtr; /* Points to where the new ext rec can be stored.*/

```

```

char      *endOfSb; /* Points to end of sb array. */

/* Initialize local pointers for structure information in dp so that
we can use field names in these structures instead of explicit
bit operations */
se = (SNVTextension *) &dp->snvtExt;
/* snvtType info is not part of the snvtDesc. We only want to access the
first byte of the structure, anyway. */
sd = (SNVTdescStruct *) &dp->snvtDesc;

/* First determine the number of entries to be added to nvConfigTable */
if (dp->arrayCnt > 0)
{
    dim = dp->arrayCnt; /* Array Variable. dim can still be 1. */
}
else
{
    dim = 1; /* Simple variable */
}

if (dp->nvName == NULL || dp->varAddr == NULL)
{
    return(-1); /* Network variable name and address is a must. */
}

if (nmp->nvTableSize + dim > NV_TABLE_SIZE)
{
    /* Not enough space in network variable table. */
    return(-1);
}

/* Save the original alias field. */
saveAlias = *nmp->snvt.aliasPtr;

/* Make endOfSb point to last element of sb array. We never want to go
past this element */
endOfSb = (char *)&nmp->snvt.sb[SNVT_SIZE - 1];

/* Compute the size needed for this variable in SNVT structure. */
if (dp->arrayCnt > 0 && dp->explodeArray)
{
    /* We need one entry for each network variable. */
    nvSelfIdCnt = dim;
}
else
{
    nvSelfIdCnt = 1;
}

sizeNeeded = sizeof(SNVTdescStruct) * nvSelfIdCnt;

/* Fixed extRec. One for each entry in self id desc part. */
if (sd->extRec) /* Check ext_rec bit */
{
    /* Need space for fixed extension record too */
    sizeNeeded = sizeNeeded + sizeof(SNVTextension) * nvSelfIdCnt;
}

/* Variable Part of Extension Record. */
/* One for each entry in self id desc part. */
if (sd->extRec && se->mre)
{
    sizeNeeded += nvSelfIdCnt; /* One byte for maximum rate */
}

```

```
if (sd->extRec && se->re)
{
    sizeNeeded += nvSelfIdCnt; /* One byte for average rate */
}
if (sd->extRec && se->nm)
{
    nvNameLen = strlen(dp->nvName) + 1;
    if (dp->arrayCnt > 0 && dp->explodeArray)
    {
        /* Need space for [ ] and up to 3 bytes for index */
        nvNameLen += 5;
        if (nvNameLen > 22)
        {
            return(-1);
        }
    }
    else if (nvNameLen > 17)
    {
        return(-1); /* Only up to 17 bytes supported */
    }

    sizeNeeded += (nvNameLen * nvSelfIdCnt);
}
if (sd->extRec && se->sd)
{
    if (dp->nvSdoc)
    {
        docLen = strlen(dp->nvSdoc) + 1;
    }
    else
    {
        docLen = 1; /* For null character */
    }
    if (docLen > MAX_NV_SELF_DOC_LENGTH)
    {
        return(-1);
    }
    sizeNeeded += (docLen * nvSelfIdCnt);
}

if (sd->extRec & se->nc)
{
    /* 16 bit count for # of network variables of this type. dim? */
    /* Reference implementation uses ver 1. */
    sizeNeeded += (2 * nvSelfIdCnt);
}

if ((char *)nmp->snvt.aliasPtr + sizeof(AliasField) + sizeNeeded
    > endOfSb)
{
    /* No Space for the new snvt_desc_struct and extension rec. */
    return(-1);
}

/* For arrays, we need space in gp->nvArrayTblSize */
if (dp->arrayCnt > 0 && gp->nvArrayTblSize == MAX_NV_ARRAYS)
{
    /* No more space to save array information */
    return(-1);
}

/*****
    dp->bind = TRUE ==> the network variable is bindable. Bindable
    variables are automatically given selector numbers in the range
```

0x3000-0x3FFF (unbound network variables). Bindable means they are currently unbound.

dp->bind = FALSE ==> the network variable is non-bindable. i.e. the application program assigns selector numbers and these variables are cannot be bound by the binder tools. In this case, it is the responsibility of the application program to assign these selector numbers in a reasonable way. For array variables, the application program indicates the selector for the first element and the other elements automatically get the previous selector numbers. The selector numbers count down.

```

/* We need dim many selectors. dim can be 1. */
/* bindable variables use unboundSelectors */
selectorVal = gp->unboundSelector; /* initialize */
if (dp->bind && gp->unboundSelector - dim + 1 < 0x3000)
{
    /* Not enough selector numbers available for assigning */
    return(-1);
}
else if (!dp->bind)
{
    /* selectors are specified by the application program.
    For arrays, only the selector for first element is
    given. Application program has the responsibility to
    assign unique selectors for all variables */

    selectorVal = dp->selectorHi;
    selectorVal = (selectorVal << 8) + dp->selectorLo;
    /* We are using dim selectors. Make sure that all are in range */
    if (selectorVal + dim - 1 > 0x2FFF)
    {
        /* Nonbindable variables should have value in 0-0x2FFF */
        return(-1);
    }
}

/* Now selectorVal has the selector number to be assigned */

/* Everything is fine. We are now ready to add this variable */

/* Make extPtr point to where the new extension rec would go */
/* aliasPtr points to the byte following the last byte of ext records */
extPtr = (char *)nmp->snvt.aliasPtr + sizeof(SNVTdescStruct) * nvSelfIdCnt;

/* Add entry or entries into the nvConfigTable and Fixed Table */
/* Add one entry for each array element irrespective of whether it
is exploded or not. */
for (i = nmp->nvTableSize; i < nmp->nvTableSize + dim; i++)
{
    /* nv config table */
    nmp->nvConfigTable[i].nvPriority = dp->priority;
    nmp->nvConfigTable[i].nvDirection = dp->direction;
    nmp->nvConfigTable[i].nvSelectorHi = selectorVal >> 8;
    nmp->nvConfigTable[i].nvSelectorLo = selectorVal & 0xFF;
    selectorVal--; /* automatic countdown - for both bind & non-bind */
    if (dp->bind)
    {
        gp->unboundSelector--; /* Update this as we just used up one */
    }
    nmp->nvConfigTable[i].nvTurnaround = dp->turnaround;
    nmp->nvConfigTable[i].nvService = dp->service;
    nmp->nvConfigTable[i].nvAuth = dp->auth;
}

```

```

    nmp->nvConfigTable[i].nvAddrIndex = 0xF;

    /* nv fixed table */
    nmp->nvFixedTable[i].nvSync = sd->nvSync;
    nmp->nvFixedTable[i].nvLength = dp->nvLength;
    /* For arrays, make sure we compute the address of each item. */
    nmp->nvFixedTable[i].nvAddress = (char *) dp->varAddr +
        (i - nmp->nvTableSize) * dp->nvLength;
}

/* If we are adding an array, save this info in gp->nvArrayTbl */
/* Array with dim 1 is considered like an array */
if (dp->arrayCnt > 0)
{
    gp->nvArrayTbl[gp->nvArrayTblSize].nvIndex = nmp->nvTableSize;
    gp->nvArrayTbl[gp->nvArrayTblSize++].dim = dim;
}

/*****
Format of the SNVT structure: (See APPReset for more info).
snvtheaderv nv-self-id-desc node-self-doc nv-self-doc alias-field

snvtheaderv is part of the nmp->snvt structure, its initial members.
nmp->snvt.sb array is used for [nv-self-id-desc ... alias-field]
alias-fields has binding and status information.
nmp->snvt.descPtr points to beginning address of node-self-doc.
i.e the address where the nv-self-id-desc for new network
variable should be placed.
*****/

/* Add data to snvt structure */

/* Update snvt descriptor count in snvt structure.
nmp->snvt.msbNumNetvars is the most significant byte.
nmp->snvt.numNetvars is the least significant byte.
We want to add the value of dim to this number */
quotient = (nmp->snvt.numNetvars + nvSelfIdCnt) / 256;
remainder = (nmp->snvt.numNetvars + nvSelfIdCnt) % 256;
nmp->snvt.numNetvars = remainder;
nmp->snvt.msbNumNetvars += quotient;

/* Now we need to move nv-self-doc and node-self-doc to make
for self-id-desc for the network variable being added. */

/* Make p point the last byte of nv-self-doc */
p = (char *)nmp->snvt.aliasPtr - 1;
/* Determine how many bytes everything moves by. */
jumpBy = sizeof(SNVTdescStruct) * nvSelfIdCnt;
while(p >= (char *) (nmp->snvt.descPtr))
{
    *(p + jumpBy) = *p;
    p--;
}

/* Copy dp->snvtDesc information. One for each array item. */
/* All array items have the same information. i.e homogeneous. */
sd = nmp->snvt.descPtr; /* Initialize */
for (i = 0; i < nvSelfIdCnt; i++)
{
    memcpy(sd, &dp->snvtDesc, 1); /* can't assign without casting. */
    sd->snvtTypeIndex = dp->snvtType;
    sd++;
}
nmp->snvt.descPtr = sd;

```

```

sd = (SNVTdescStruct *)&dp->snvtDesc; /* Reinitialize */
/* We are now ready to add the extension information */
if(sd->extRec)
{
    /* This variable has extension record following node-self-doc */
    /* Add one for each entry in the self id desc part. */
    for (i = 0; i < nvSelfIdCnt; i++)
    {
        /* extPtr has already been set to point to the right place */
        /* se has already been set to point to dp->snvtExt */
        /* extPtr is of type (Byte *) */
        *extPtr = dp->snvtExt;
        extPtr += sizeof(SNVTextension);
        if(se->mre)
        {
            *extPtr = dp->maxrEst;
            extPtr++;
        }

        if(se->re)
        {
            *extPtr = dp->rateEst;
            extPtr++;
        }

        if(se->nm)
        {
            /* We need to store the name of the variable. null terminated. */
            nvNameLen = strlen(dp->nvName) + 1;
            if (dp->arrayCnt > 0 && dp->explodeArray)
            {
                int index = i + 1;
                /* We support maximum of 999 array items */
                /* 999 is the maximum index we can represent with 3 digits */
                sprintf(extPtr, "%s ", dp->nvName);
                extPtr += nvNameLen; /* Should now point to null character */
                if (index < 10)
                {
                    sprintf(extPtr, "%1d", index); /* Single digit index */
                    extPtr++;
                }
                else if (index < 100)
                {
                    sprintf(extPtr, "%2d", index); /* Double digit index */
                    extPtr += 2;
                }
                else
                {
                    sprintf(extPtr, "%3d", index); /* Triple digit index */
                    extPtr += 3;
                }
                *extPtr = '\0';
                extPtr++;
            } /* for j loop */
            else
            {
                /* Simple variable. or Array with one entry. */
                strcpy(extPtr, dp->nvName); /* Adds Null ch too */
                extPtr += nvNameLen;
            } /* else */
        } /* if (se->nm) */
    }
}

```

```

    if(se->sd)
    {
        if (dp->nvSdoc == NULL)
        {
            *extPtr = '\0'; /* nvSdoc is missing */
            extPtr++;
        }
        else
        {
            docLen = strlen(dp->nvSdoc) + 1;
            strcpy(extPtr, dp->nvSdoc);
            extPtr += docLen;
        }
    }

    if(se->nc)
    {
        /* Store the dimension of the variable. Useful only for array
           entered in SNVT that are not exploded. */
        *extPtr = dp->arrayCnt >> 8; /* High order byte. */
        extPtr++;
        *extPtr = dp->arrayCnt & 0xFF; /* Low order byte */
        extPtr++;
    }
    } /* for */
} /* if (sd->extRec) */

/* Restore Alias */
nmp->snvt.aliasPtr = (AliasField *)extPtr;
*nmp->snvt.aliasPtr = saveAlias;
extPtr = extPtr + sizeof(AliasField);

/* Now extPtr points to the byte following the alias field */

/* Update nmp->snvt.length */
/* 6 below refers to the size of the header in snvt structure */
nmp->snvt.length = (extPtr - (char *)&nmp->snvt.sb[0]) + 6;

nmp->nvTableSize += dim;

return(nmp->nvTableSize - dim); /* Base index for arrays. */
}

/*****
Function: ProcessNV
Returns: None
Purpose: To process an incoming network variable message.
         The message can be
         1. NV Update Message (ACKD, UNACKD, UNACKD_RPT)
         2. NV Poll Message. (REQUEST)
Comments: In either case, the msg should have at least 2 bytes.
*****/
static void ProcessNV(APPReceiveParam *appReceiveParamPtr,
                    APDU *apduPtr)
{
    if (appReceiveParamPtr->service == REQUEST)
    {
        ProcessNVPoll(appReceiveParamPtr, apduPtr);
    }
    else
    {
        ProcessNVUpdate(appReceiveParamPtr, apduPtr);
    }
}

```

```

/*****
Function: ProcessNVPoll
Returns: None
Purpose: To process an incoming network variable poll message.
         The service should be a request.
Comments: The message should have 2 bytes.
         The network variable poll message is normally addressed
         to an output variable. However, we will allow either
         input or output variable to be polled. We simply respond
         with the data value of the matching variable.
         The application layer in reference implementation
         never sends network variable poll messages addressed
         to input variables. A network variable monitor tool
         might do this to get the value of input variables.
         (NVFetch is another way).

         If we are offline, send a response with no data.
         Else
             If we have one matching network variable (primary
             or alias), then send the response with the data.

             If we have two matching primary network variables
             then we ignore this message.

             If we don't have a matching network variable,
             then send a response with no data.

         The response is network variable update message
         with the direction flipped from what was received.

         If we have more than one primary variable with matching
         selector, then we have a problem. The sender is expecting
         only one response from each node receiving the poll message.
         So, it is not clear which one to send. If we have this
         situation, we will ignore this message and not respond
         at all. Note that it is not meaningful to have a primary
         and an alias of that primary to have the same selector.
         If the incoming variable is connected to two different primary
         variables on this node, then the incoming variable
         should not have been polled.
*****/
static void ProcessNVPoll(APDReceiveParam *appReceiveParamPtr,
                        APDU *apduPtr)
{
    int16 i;
    uint8 nvDirection;
    uint16 selector, thisSelector;
    int16 matchingIndex;
    uint16 matchingPrimaryIndex;
    Queue *tsaOutQPtr;
    TSASendParam *tsaSendParamPtr;
    APDU *apduRespPtr;
    NVStruct *thisNVStrPtr, *matchingNVStrPtr;
    Boolean authOK;
    int16 nvAliasTableSize;
    Boolean noData; /* Should data go out? */

    nvAliasTableSize = nmp->snvt.aliasPtr->hostAlias;

    if(appReceiveParamPtr->pduSize != 2)
    {
        /* The message does not have correct size */
        nmp->errorLog = NV_MSG_TOO_SHORT;
    }

```

```

    DeQueue (&gp->appInQ);
    return;
}

tsaOutQPtr = &gp->tsaRespQ;

if (QueueFull (tsaOutQPtr))
{
    /* Can't send response yet - try later. */
    return;
}

if (NodeUnConfigured ())
{
    /* Ignore this message in this state.
    tsaSendParamPtr = QueueTail (tsaOutQPtr);
    tsaSendParamPtr->altPathOverride = FALSE;
    tsaSendParamPtr->service = RESPONSE;
    tsaSendParamPtr->>nullResponse = TRUE;
    tsaSendParamPtr->reqId = appReceiveParamPtr->reqId;
    EnQueue (tsaOutQPtr);
    DeQueue (&gp->appInQ);
    return;
}

/* Determine selector and nvDirection for variable in the poll message. */
selector = (apduPtr->code.nv.nvCode << 8) | apduPtr->data[0];
nvDirection = apduPtr->code.nv.nvDir;

noData = TRUE; /* Assume that we will respond with no data */
matchingIndex = -1; /* Initialize to indicate that no match yet. */

/* If application is not running, then we should return with no data */
/* We know that the node is configured at this point */
if (AppPgmRuns ())
{
    /* Search for matching network variable. Search both primary
    and alias entries */
    for (i = 0; i < nmp->nvTableSize+nvAliasTableSize; i++)
    {
        thisNVStrPtr = GetNVStructPtr (i);
        thisSelector =
            (thisNVStrPtr->nvSelectorHi << 8) | thisNVStrPtr->nvSelectorLo;
        if (thisNVStrPtr->nvDirection == nvDirection &&
            thisSelector == selector)
        {
            if (matchingIndex == -1)
            {
                matchingIndex = i; /* First match. */
            }
            else if (GetPrimaryIndex (matchingIndex) ==
                GetPrimaryIndex (i))
            {
                /* We have two distinct primary variables with same
                selector. Ignore this message. */
                tsaSendParamPtr = QueueTail (tsaOutQPtr);
                tsaSendParamPtr->altPathOverride = FALSE;
                tsaSendParamPtr->service = RESPONSE;
                tsaSendParamPtr->>nullResponse = TRUE;
                tsaSendParamPtr->reqId = appReceiveParamPtr->reqId;
                EnQueue (tsaOutQPtr);
                DeQueue (&gp->appInQ);
                return;
            }
        }
    }
}

```

```

    }
    else
    {
        continue; /* Skip this entry. Does not match. */
    }
}

/* Send the response with either data or no data. */
tsaSendParamPtr = QueueTail(tsaOutQPtr);
tsaSendParamPtr->altPathOverride = FALSE;
tsaSendParamPtr->service = RESPONSE;
tsaSendParamPtr->nullResponse = FALSE;
tsaSendParamPtr->reqId = appReceiveParamPtr->reqId;
apduRespPtr = (APDU *) (tsaSendParamPtr + 1);
apduRespPtr->code.nv.nvFlag = 0x1;
apduRespPtr->code.nv.nvDir = 1 - nvDirection; /* Opposite */
/* Keep the same selector as the one received */
apduRespPtr->code.nv.nvCode = apduPtr->code.nv.nvCode;
apduRespPtr->data[0] = apduPtr->data[0];

if (matchingIndex != -1)
{
    noData = FALSE;
    matchingPrimaryIndex = GetPrimaryIndex(matchingIndex);
    matchingNVStrPtr = GetNVStructPtr(matchingIndex);
}

if (appReceiveParamPtr->auth ||
    matchingIndex == -1 ||
    !matchingNVStrPtr->nvAuth)
{
    authOK = TRUE;
}
else
{
    authOK = FALSE;
}

if (noData || matchingIndex == -1 || authOK == FALSE)
{
    /* Send a response with no data */
    tsaSendParamPtr->apduSize = 2;
}
else
{
    /* Send a response with data */
    if (NV_LENGTH(matchingPrimaryIndex) + 2 <= gp->tsaRespBufSize)
    {
        memcpy(&apduRespPtr->data[1],
            NV_ADDRESS(matchingPrimaryIndex),
            NV_LENGTH(matchingPrimaryIndex));
        tsaSendParamPtr->apduSize = 2 + NV_LENGTH(matchingPrimaryIndex);
    }
    else
    {
        tsaSendParamPtr->apduSize = 2;
    }
}
EnQueue(tsaOutQPtr);

/* Message processing completed - remove it from queue */
DeQueue(&gp->appInQ);
return;

```

}

/******

Function: ProcessNVUpdate

Returns: None

Purpose: To process an incoming network variable update message.

The service can be ACKD, UNACKD, UNACKD_RPT.

The service can be RESPONSE too for poll responses.

Comments: The message should have > 2 bytes.

The network variable update message is addressed

to an input variable.

If we are unconfigured then discard the message.

There can be only one variable (primary or alias) with

matching selector. Once a match is found, break.

If we update one ore more network variables and we are

not soft-offline then we don't give NVUpdateOccurs event.

Otherwise, we do give NVUpdateOccurs to the application program.

The prefix 'this' is used for local variables of this function

related to information regarding network variables searched.

static void ProcessNVUpdate(APPReceiveParam *appReceiveParamPtr,

APDU *apduPtr)

{

int16 i;

uint16 dataLength, matchingDataLength;

uint8 nvDirection;

uint16 selector, thisSelector;

int16 matchingIndex;

uint16 matchingPrimaryIndex;

NVStruct *thisNVStrPtr, *matchingNVStrPtr;

Boolean authOK;

int16 nvAliasTableSize;

uint16 thisDim;

int16 thisBaseIndex;

nvAliasTableSize = nmp->snvt.aliasPtr->hostAlias;

if (appReceiveParamPtr->pduSize <= 2)

{

/* The message does not have any correct size or data field. */

nmp->errorLog = NV_MSG_TOO_SHORT;

DeQueue(&gp->appInQ);

return;

}

if (eep->readOnlyData.nodeState == APPL_UNCNFG)

{

/* Ignore this message in this state.*/

DeQueue(&gp->appInQ);

return;

}

/* Determine selector and nvDirection for variable in the update message. */

selector = (apduPtr->code.nv.nvCode << 8) | apduPtr->data[0];

nvDirection = apduPtr->code.nv.nvDir;

if (nvDirection == NV_OUTPUT)

{

/* Ignore this message */

nmp->errorLog = NV_UPDATE_ON_OUTPUT_NV;

DeQueue(&gp->appInQ);

}

}

/******

*/

*/

*/

*/

*/

*/

*/

*/

```

    return;
}

dataLength = appReceiveParamPtr->pduSize - 2; /* data length in message */

/* Go through network input variables looking for a match. Once
   a match is found, update it and break. */
matchingIndex = -1;
for(i = 0; i < nmp->nvTableSize + nvAliasTableSize; i++)
{
    thisNVStrPtr = GetNVStructPtr(i);
    thisSelector =
        (thisNVStrPtr->nvSelectorHi << 8) | thisNVStrPtr->nvSelectorLo;
    if (thisNVStrPtr->nvDirection == NV_OUTPUT)
    {
        continue; /* Skip network output variables */
    }
    if (thisSelector == selector)
    {
        matchingIndex = i;
        break;
    }
}

if (matchingIndex != -1)
{
    /* Need to update the network input variable
     /* matchingIndex can be primary or alias index */
    matchingPrimaryIndex = GetPrimaryIndex(matchingIndex);
    matchingDataLength = NV_LENGTH(matchingPrimaryIndex);
    matchingNVStrPtr = GetNVStructPtr(matchingPrimaryIndex);

    /* If the data size does not match, don't update. ignore. */
    if (dataLength != matchingDataLength)
    {
        nmp->errorLog = NV_LENGTH_MISMATCH;
        DeQueue(&gp->appInQ);
        return;
    }

    if(appReceiveParamPtr->auth || !matchingNVStrPtr->nvAuth)
    {
        authOK = TRUE;
    }
    else
    {
        authOK = FALSE;
    }

    if (!authOK)
    {
        DeQueue(&gp->appInQ);
        return; /* Skip the update as authentication did not succeed. */
    }

    /* Update the variable */
    if (dataLength > 0 && appReceiveParamPtr->service == RESPONSE)
    {
        /* We have a response to poll message. Update gp->nvInDataStatus flag. */
        gp->nvInDataStatus = SUCCESS;
    }
    memcpy(NV_ADDRESS(matchingPrimaryIndex),
           &apduPtr->data[1],
           dataLength);
}

```

```

if (AppPgmRuns ())
{
    /* Notify application program only if it is running. */
    gp->nvInAddr.domain = appReceiveParamPtr->srcAddr.domainIndex;
    gp->nvInAddr.flexDomain =
        (appReceiveParamPtr->srcAddr.domainIndex == FLEX_DOMAIN);
    memcpy (&gp->nvInAddr.srcAddr,
            &appReceiveParamPtr->srcAddr.subnetAddr,
            sizeof (gp->nvInAddr.srcAddr));

    switch (appReceiveParamPtr->srcAddr.addressMode)
    {
        case BROADCAST:
            gp->nvInAddr.format = 0;
            break;
        case MULTICAST:
            gp->nvInAddr.format = 1;
            gp->nvInAddr.destAddr.group =
                appReceiveParamPtr->srcAddr.group;
            break;
        case SUBNET_NODE:
            gp->nvInAddr.format = 2;
            break;
        case UNIQUE_NODE_ID:
            gp->nvInAddr.format = 3;
            break;
        default:
            /* should not come here */
            gp->nvInAddr.format = 5; /* unknown */
    }
    IsArrayNV (matchingPrimaryIndex, &thisDim, &thisBaseIndex);
    gp->nvArrayIndex = matchingPrimaryIndex - thisBaseIndex;
    REF_IMP_TO_ALT (NV_IN_ADDR, &nv_in_addr);
    REF_IMP_TO_ALT (NV_ARRAY_INDEX, &nv_array_index);
    NVUpdateOccurs (thisBaseIndex, gp->nvArrayIndex);
}
}

DeQueue (&gp->appInQ);
return;
}

```

```

/*****
Function: PropagateThisIndex
Returns: SUCCESS if the index is scheduled.
        FAILURE if the queue is full and hence not scheduled
           or for sync network output variables, the queue
           buffer size is not sufficient for this variable.
        INVALID if the index does not correspond to NV_OUTPUT
Purpose: To schedule a specific index of a network variable
        (primary or alias), polled or not.
Comment: This function is local to this file and used by API functions
        Propagate, PropagateNV, and PropagateArrayNV.
        The address table entry for NV_OUTPUT can be turnaround.
        So, if it is UNBOUND, then we check for turnaround field too.

```

```

    primaryIndex is passed for efficiency to avoid recomputation.
    nvIndexIn is always valid.
*****/
static Status PropagateThisIndex (int16 nvIndexIn, int16 primaryIndex)
{
    int16 *indexPtr;

```

```

Queue    *indexQPtr;
uint16   addrIndex;
NVStruct *nvStructPtr;
uint16   nvAliasTableSize;
char     *valPtr;
uint16   bufSize;

nvAliasTableSize = nmp->snvt.aliasPtr->hostAlias;
nvStructPtr      = GetNVStructPtr(nvIndexIn);
addrIndex        = nvStructPtr->nvAddrIndex;

/* If the variable is not output, then we can't propagate. */
if (nvStructPtr->nvDirection != NV_OUTPUT)
{
    return(INVALID);
}

indexQPtr = &gp->nvOutIndexQ;
bufSize   = gp->nvOutIndexBufSize;

if (QueueFull(indexQPtr))
{
    return(FAILURE); /* Could not schedule all. */
}

indexPtr = QueueTail(indexQPtr);
*indexPtr = nvIndexIn;
if (NV_SYNC(primaryIndex))
{
    /* Copy current value for synchronous variables */
    /* In the queue, the 2 byte index should follow the value */
    valPtr = (char *) (indexPtr + 1);
    if (NV_LENGTH(primaryIndex) <= bufSize - 2)
    {
        memcpy(valPtr, NV_ADDRESS(primaryIndex), NV_LENGTH(primaryIndex));
        EnQueue(indexQPtr);
    }
    else
    {
        return(FAILURE);
    }
}
else
{
    EnQueue(indexQPtr);
}

return(SUCCESS);
}

/*****
Function: PropagateThisPrimary
Returns: None
Purpose: To schedule a specific primary network variable.
        If the variable is bound
        then
            this schedules the primary and any alias entries for this
            primary using PropagateThisIndex.
        If nothing was scheduled
        then
            generate failure completion event.
        else
            generate success completion event.
Comment: After scheduling the primary and all related alias entries,

```

```

        this function will add -1 to the queue to indicate end.
        *****/
void PropagateThisPrimary(int16 nvIndexIn)
{
    int16 *indexPtr;
    Queue *indexQPtr;
    NVStruct *nvStructPtr;
    uint16 nvAliasTableSize;
    uint16 count, dim;
    int16 baseIndex;
    int16 j;
    uint16 queueSpace;

    nvAliasTableSize = nmp->snvt.aliasPtr->hostAlias;
    nvStructPtr = GetNVStructPtr(nvIndexIn);

    indexQPtr = &gp->nvOutIndexQ;

    queueSpace = QueueCnt(indexQPtr) - QueueSize(indexQPtr);

    /* Schedule primary network output variables for NVUpdate. */
    if (IsNVBound(nvIndexIn))
    {
        /* We need space for at least 2 entries to schedule.
           i.e we need to reserve one space for -1 at the end. */

        count = 0;
        if (queueSpace > 1 && PropagateThisIndex(nvIndexIn, nvIndexIn) == SUCCESS)
        {
            count++;
            queueSpace--;
        }
        /* Schedule all alias entries that map to this primary entry.
           If queue does not have much space, stop scheduling rest. */
        for (j = nmp->nvTableSize;
             j < nmp->nvTableSize + nvAliasTableSize && queueSpace > 1;
             j++)
        {
            if (GetPrimaryIndex(j) != nvIndexIn)
            {
                continue;
            }
            if (PropagateThisIndex(j, nvIndexIn) == SUCCESS)
            {
                count++;
                queueSpace--;
            }
        }
        if (count == 0)
        {
            IsArrayNV(nvIndexIn, &dim, &baseIndex);
            gp->nvArrayIndex = nvIndexIn - baseIndex;
            REF_IMP_TO_ALT(NV_ARRAY_INDEX, &nv_array_index);
            NVUpdateCompletes(FAILURE, baseIndex, gp->nvArrayIndex);
        }
        else
        {
            /* Schedule a -1 to indicate end of indices for this primary. */
            /* There should be at least one space left in queue */
            indexPtr = QueueTail(indexQPtr);
            *indexPtr = -1;
            EnQueue(indexQPtr);
        }
    }
}

```

```

else
{
    IsArrayNV(nvIndexIn, &dim, &baseIndex);
    gp->nvArrayIndex = nvIndexIn - baseIndex;
    REF_IMP TO ALT(NV_ARRAY_INDEX, &nv_array_index);
    NVUpdateCompletes(SUCCESS, baseIndex, gp->nvArrayIndex); /* Not bound. */
}
}

```

```

/*****
Function: Propagate
Returns: None
Purpose: To propagate all output network variables.
Comment: This function is called by the application program to propagate
all output network variables (declared as polled or not).

```

Schedule all NV OUTPUT indices with a valid address table entry regardless of whether it is primary or alias.

This function only schedules these variables by placing them in a queue for later processing by APPSend function. APPSend will call SendVar function to actually send out NV Updates messages. If a network output variable is not bound, then there is no need to schedule it.

The addressing information is implicit. If the network output variables does not correspond to an address table entry, then it can't be scheduled as we don't know how to generate the destination address.

It is possible that not all variables can be scheduled due to space limitation in the queues. For guranteed scheduling of all possible network ouput variables, the nv output queue should be large enough.

```

*****/
void Propagate(void)
{
    int16 i;

    /* Schedule primary network output variables. */
    for (i = 0; i < nmp->nvTableSize; i++)
    {
        PropagateThisPrimary(i);
    }
}

```

```

/*****
Function: PropagateNV
Returns: None
Purpose: To propagate a specific output network variable (simple or array)
Comment: This function is called by the application program to propagate
a specific network output variable (declared as polled or not).
If the index corresponds to the first item of an array,
then all items of the array are propagated.

```

If the index does not correspond to first item of an array, only that index is propagated.

The variable must be a primary variable. Alias entries that map to this primary (for array, any of the entries), that are bound to some valid address table entry, are also scheduled.

This function only schedules these variables by placing them in a queue for later processing by APPSend function. APPSend will call SendVar function to actually send out NV Update messages.

There is no gurantee that all possible variables are scheduled due to space limitation in the schedule queue. To ensure that this does not happen, the queue size for the scheduling should be made larger.

The addressing information is implicit. If the network output variables does not correspond to an address table entry, then it can't be scheduled as we don't know how to generate the destination address.

```

*****
void PropagateNV(int16 nvIndexIn)
{
    uint16    dim;
    int16     baseIndex;
    int16     i;

    if (nvIndexIn < 0 || nvIndexIn >= nmp->nvTableSize )
    {
        return; /* Must be a valid primary index. */
    }

    IsArrayNV(nvIndexIn, &dim, &baseIndex);
    if (nvIndexIn != baseIndex)
    {
        dim = 1; /* nvIndexIn is not the first item of array */
    }

    /* Scheduled one or more (for array) primary indices. */
    /* For array, nvIndexIn = baseIndex */
    for (i = nvIndexIn; i < nvIndexIn + dim; i++)
    {
        PropagateThisPrimary(i);
    }
}

```

```

/*****
Function:    PropagateArrayNV
Returns:    None
Purpose:    To propagate a specific element of an array output network
            variable or any other network variable (i.e non-array nv).
Comment:    This function is called by the application program to propagate
            a specific item of an array network output variable
            (declared as polled or not) or a simple network variable.

```

Once the primary is scheduled, we also schedule alias entries that map to this primary to make sure that we reach all possible input connections.

This function only schedules these variables by placing them in a queue for later processing by APPSend function. APPSend will call SendVar function to actually send out NV Update messages.

The addressing information is implicit. If the network input variables does not correspond to an address table entry, then it can be scheduled as we don't know how to generate the destination address.



```

        If arrayNVIndexIn corresponds to the baseindex of an array
        network variable then indexIn is used to compute the specific
        item of the array. Otherwise indexIn is set to 0 so that this
        function will propagate the given index only (a specific array
        item or a simple network variable).
    *****/
void PropagateArrayNV(int16 arrayNVIndexIn, int16 indexIn)
{
    uint16    dim;
    int16     baseIndex;
    int16     nvIndex;

    if (arrayNVIndexIn < 0 || arrayNVIndexIn >= nmp->nvTableSize)
    {
        return; /* Invalid index. */
    }

    /* if arrayNVIndexIn is not an array variable, then dim is set to
       and baseIndex is set to arrayNVIndexIn by IsArrayNV function */
    if (!IsArrayNV(arrayNVIndexIn, &dim, &baseIndex) )
    {
        indexIn = 0; /* Simple network variable */
    }
    else if (baseIndex != arrayNVIndexIn)
    {
        indexIn = 0; /* Any other array item. don't use indexIn passed. */
    }

    if (indexIn < 0 || indexIn >= dim)
    {
        return; /* Invalid index */
    }

    nvIndex = arrayNVIndexIn + indexIn;
    PropagateThisPrimary(nvIndex);
}

/*****
Function:  SendVar
Returns:  None.
Purpose:  Generates NV Update message for the given index.
          The given index can be either primary or alias.
          For sync network output variables, we are also
          given the corresponding value. For nonsync variables,
          valPtr is null and current value is used.

          If the network output variable has nvTurnaround on,
          then we need to search for a network input variable with
          matching selector number. Once found, we update it, and
          send NVUpdateOccurs event to the application program.
          Note that we search through both primary and alias
          entries for the turnaround. If a primary is connected to this
          output variables, we will find it eventually either directly
          or indirectly (via alias).

Comments:
          We need to handle only the given index. Propagate functions
          take care of scheduling all needed alias indices properly.
          Implicit NV Updates are handled through Propagate.

          It is possible that variables are scheduled, but by the time
          they are processed in this function, the application is
          offline or the node is unconfigured. So, check for this

```

too before updating network variables for turnaround.

Also, it is possible that some attributes of the variable has been changed by a network management tool after the index was scheduled.

If the index is -1, then it represents the end of scheduling for a primary. Generate a message to transport layer with a special tag that will be recognized and sent back immediately in the indication to application layer.

```

*****
static void SendVar()
{
    Queue      *indexQPtr;
    int16      i; /* For loop. */
    uint16     bufSize; /* bufSize for the target queue */
    int16      nvIndex;
    int16      primaryIndex; /* For nvIndex. */
    uint16     nvLength; /* For nvIndex. */
    uint16     selector; /* For nvIndex. */
    Byte       *nvPtr; /* For nvIndex. Points to storage. */
    uint16     dimIn; /* For input network variable */
    int16      primaryIndexIn; /* For input network variable */
    int16      baseIndexIn; /* For input network variable */
    uint16     nvLengthIn; /* For input network variable */
    Byte       *nvPtrIn; /* For input network variable */
    uint16     selectorIn; /* For input network variable */
    Queue      *nwOutQPtr, *tsaOutQPtr;
    TSASendParam *tsaSendParamPtr;
    NWSendParam *nwSendParamPtr;
    APDU       *apduPtr;
    uint16     nvAliasTableSize;
    NVStruct   *nvStrPtr, *nvStrPtrIn;
    uint16     addrIndex;
    AddrTableEntry *ap;
    Boolean     turnaroundOnly; /* does not mean turnaround for sure. Means
                                that the variable does not have addr table
                                entry or the address table entry is unbound
                                or it is turnaround entry. */

    Boolean     foundMatchingInputVar;
    int16      *indexPtr;
    char       *valPtr;

    indexQPtr = &gp->nvOutIndexQ;

    if (!gp->nvOutCanSchedule || QueueEmpty(indexQPtr))
    {
        return; /* Nothing to do. */
    }
    indexPtr = QueueHead(indexQPtr);
    nvIndex = *indexPtr;
    valPtr = (char *) (indexPtr + 1);

    /* If the node enters unconfigured state before processing this nv update
       we do not want to schedule these indices. We simply do nothing and wait
       for the node to go configured. */
    if (eep->readOnlyData.nodeState == APPL_UNCNFG)
    {
        return;
    }

    nvAliasTableSize = nmp->snvt.aliasPtr->hostAlias;

    /* nvIndexIn > 0 => nv variable. nvIndex == -1 => end of scheduling */

```

```

if (nvIndex >= 0)
{
    /* Make nvStrPtr point to the right NVStruct for nvIndexIn */
    nvStrPtr = GetNVStructPtr(nvIndex);
    primaryIndex = GetPrimaryIndex(nvIndex);
    nvPtr = NV_ADDRESS(primaryIndex);
    nvLength = NV_LENGTH(primaryIndex);
    selector = (nvStrPtr->nvSelectorHi << 8) | nvStrPtr->nvSelectorLo;
    addrIndex = nvStrPtr->nvAddrIndex;
    /* The variable is turnaround only if addrIndex is 0xF or the address
    table entry is unbound (turnaround or not). */
    /* *** START INFORMATIVE - Unbound Network Variable */
    /* It is acceptable to require that turnaround NVs have an address table
    * entry assigned. This entry may be used for determining retry counts
    * and tx timer values for retrying in the event of resource problems such
    * as input buffer inavailability. Network management tools are expected
    * to assign an address table entry even if using unackd service. */
    /* *** END INFORMATIVE - Unbound Network Variable */
    turnaroundOnly = addrIndex == 0xF ||
        eep->addrTable[addrIndex].addrFormat == UNBOUND;

    if(nvStrPtr->nvPriority)
    {
        tsaOutQPtr = &gp->tsaOutPriQ;
        nwOutQPtr = &gp->nwOutPriQ;
        if (nvStrPtr->nvService == UNACKD)
        {
            bufSize = gp->nwOutPriBufSize;
        }
        else
        {
            bufSize = gp->tsaOutPriBufSize;
        }
    }
    else
    {
        tsaOutQPtr = &gp->tsaOutQ;
        nwOutQPtr = &gp->nwOutQ;
        if (nvStrPtr->nvService == UNACKD)
        {
            bufSize = gp->nwOutBufSize;
        }
        else
        {
            bufSize = gp->tsaOutBufSize;
        }
    }
}
else
{
    /* Let us use tsaOutQ for the special message */
    tsaOutQPtr = &gp->tsaOutQ;
}

if (nvIndex == -1 || !turnaroundOnly)
{
    /* We need to make sure that we have space in transport or network
    layer. If there is no space, we should return without doing any
    processing.
    NV variable messages can be ACK, UNACK, UNACKD RPT */
    if (nvIndex == -1)
    {
        if (QueueFull(tsaOutQPtr))
        {

```

```

        return;
    }
}
else if (nvStrPtr->nvService == UNACKD && QueueFull(nwOutQPtr))
{
    return;
}
else if (nvStrPtr->nvService != UNACKD && QueueFull(tsaOutQPtr))
{
    return;
}
}
}

if (nvIndex == -1)
{
    /* Form a message with a special tag to transport layer. */
    tsaSendParamPtr = QueueTail(tsaOutQPtr);
    tsaSendParamPtr->altPathOverride = FALSE;
    tsaSendParamPtr->service = ACKD;
    tsaSendParamPtr->tag = NV_UPDATE_LAST_TAG_VALUE;
    tsaSendParamPtr->apduSize = 0;
    EnQueue(tsaOutQPtr);
    gp->nvOutCanSchedule = FALSE; /* Only one at a time. */
    DeQueue(indexQPtr);
    return;
}

/* If the variable is flagged as turnaround, then we look for first
network input variable with matching selector number. Once found,
we update that input variable, and then send NVUpdateOccurs event
to the application program. We break as soon as first match is found. */
if (nvStrPtr->nvTurnaround)
{
    foundMatchingInputVar = FALSE;
    for (i = 0; i < nmp->nvTableSize+nvAliasTableSize; i++)
    {
        nvStrPtrIn = GetNVStructPtr(i);
        selectorIn =
            (nvStrPtrIn->nvSelectorHi << 8) | nvStrPtrIn->nvSelectorLo;
        /* If this variable is not input or does not have matching selector,
then skip this entry */
        if (nvStrPtrIn->nvDirection != NV_INPUT ||
            selectorIn != selector)
        {
            continue; /* Not a matching entry */
        }
        /* Found a matching turnaround entry for nvIndexIn */
        primaryIndexIn = GetPrimaryIndex(i);
        nvPtrIn = NV_ADDRESS(primaryIndexIn);
        nvLengthIn = NV_LENGTH(primaryIndexIn);
        if (nvLength != nvLengthIn)
        {
            break; /* selector matches but length does not */
        }
        memcpy(nvPtrIn, nvPtr, nvLength);
        foundMatchingInputVar = TRUE;
        /* Notify application if it is running */
        if (AppPgmRuns())
        {
            IsArrayNV(primaryIndexIn, &dimIn, &baseIndexIn);

            gp->nvInAddr.format = 4; /* TURNAROUND */
            memset(&gp->nvInAddr.srcAddr, 0, sizeof(SubnetAddress));

```

```

        gp->nvInAddr.domain = 0; /* Not relevant */
        gp->nvArrayIndex    = primaryIndexIn - baseIndexIn;
        REF_IMP_TO_ALT(NV_IN_ADDR, &nv_in_addr);
        REF_IMP_TO_ALT(NV_ARRAY_INDEX, &nv_array_index);
        NVUpdateOccurs(baseIndexIn, gp->nvArrayIndex);
    }

    break; /* break after first match */
} /* for */
} /* if */

if (turnAroundOnly)
{
    /* Completion event is given in HandleMsgCompletion function */
    /* Since there is nothing actually scheduled, no need to clear
    gp->nvOutCanSchedule flag. */
    /* Since this index does not go through HandleMsgCompletion, we need
    to set gp->nvOutIndex here. This is to take care of the case when
    a variable is turndaround only with no alias. In this case this index
    is followed by -1 in the queue. Hence, the gp->nvOutIndex would never
    be initialized when HandleMsgCompletion gets NV_UPDATE_LAST_TAG_VALUE.
    Explicit initialization here will fix the problem. */
    gp->nvOutIndex = GetPrimaryIndex(nvIndex);
    DeQueue(indexQPtr);
    return;
}

gp->nvOutCanSchedule = FALSE; /* Only one index at a time */
DeQueue(indexQPtr);

/* Build and send network variable update message. */
ap = AccessAddress(addrIndex); /* ap can't be null. */
/* Fail if we don't have sufficient space in the target queue. */
if (2 + nvLength > bufSize)
{
    /* Discard this index as the space is not sufficient */
    return;
}

if (nvStrPtr->nvService == UNACKD)
{
    /* The message should go to the transport layer */
    tsaSendParamPtr    = QueueTail(tsaOutQPtr);
    tsaSendParamPtr->altPathOverride = FALSE;
    tsaSendParamPtr->domainIndex = COMPUTE_DOMAIN_INDEX;
    *(AddrTableEntry *)(&tsaSendParamPtr->destAddr) = *ap;
    tsaSendParamPtr->service    = nvStrPtr->nvService;
    tsaSendParamPtr->auth       = nvStrPtr->nvAuth;
    /* See app.h for information on tag usage. */
    tsaSendParamPtr->tag        = GET_NV_UPDATE_TAG(primaryIndex);
    apduPtr                    = (APDU *) (tsaSendParamPtr + 1);
    apduPtr->code.nv.nvFlag     = 0x1;
    apduPtr->code.nv.nvDir      = NV_INPUT;
    apduPtr->code.nv.nvCode     = nvStrPtr->nvSelectorHi;
    apduPtr->data[0]           = nvStrPtr->nvSelectorLo;
    tsaSendParamPtr->apduSize   = 2 + nvLength;
    if (NV_SYNC(primaryIndex))
    {
        /* Send value given */
        memcpy(&apduPtr->data[1], valPtr, nvLength);
    }
    else
    {
        /* Send the most current value */

```

```

        memcpy(&apduPtr->data[1], nvPtr, nvLength);
    }

    EnQueue(tsaOutQPtr);
    return;
}

/* The message is for the network layer */
nwSendParamPtr = QueueTail(nwOutQPtr);
nwSendParamPtr->dropIfUnconfigured = TRUE;
nwSendParamPtr->tag = GET_NV_UPDATE_TAG(primaryIndex);

switch(ap->addrFormat)
{
    case SUBNET_NODE:
        nwSendParamPtr->destAddr.addressMode = SUBNET_NODE;
        nwSendParamPtr->destAddr.domainIndex =
            ap->snodeEntry.domainIndex;
        nwSendParamPtr->destAddr.addr.addr2a.subnet =
            ap->snodeEntry.subnetID;
        nwSendParamPtr->destAddr.addr.addr2a.node =
            ap->snodeEntry.node;

        break;

    case BROADCAST:
        nwSendParamPtr->destAddr.addressMode = BROADCAST;
        nwSendParamPtr->destAddr.domainIndex =
            ap->bcastEntry.domainIndex;
        nwSendParamPtr->destAddr.addr.addr0 =
            ap->bcastEntry.subnetID;

        break;

    default:
        /* Since the address table entry can't be unbound or turnaround,
           we must have group entry */
        nwSendParamPtr->destAddr.addressMode = MULTICAST;
        nwSendParamPtr->destAddr.domainIndex =
            ap->groupEntry.domainIndex;
        nwSendParamPtr->destAddr.addr.addr1 =
            ap->groupEntry.groupID;
} /* switch */

nwSendParamPtr->pduType = APDU_TYPE;
nwSendParamPtr->deltaBL = 0; /* No ack generated */
nwSendParamPtr->altPath = FALSE;
nwSendParamPtr->pduSize = 2 + nvLength;
apduPtr = (APDU *) (nwSendParamPtr + 1);
apduPtr->code.nv.nvFlag = 0x1;
apduPtr->code.nv.nvDir = NV_INPUT;
apduPtr->code.nv.nvCode = nvStrPtr->nvSelectorHi;
apduPtr->data[0] = nvStrPtr->nvSelectorLo;
if (NV_SYNC(primaryIndex))
{
    /* Send value given. */
    memcpy(&apduPtr->data[1], valPtr, nvLength);
}
else
{
    /* Send the most current value. */
    memcpy(&apduPtr->data[1], NV_ADDRESS(primaryIndex), nvLength);
}
EnQueue(nwOutQPtr);

return;
}

```

```

/*****
Function: PollThisIndex
Returns:  SUCCESS if the index is scheduled.
         FAILURE if the queue is full and hence not scheduled.
         INVALID if the index does not correspond to NV_INPUT.
Purpose:  To schedule a specific index of a network variable
         (primary or alias).
Comment:
         This function is local to this file and used by API functions
         Poll, PollNV, and PollArrayNV.
         nvIndexIn is always valid.
*****/
static Status PollThisIndex(int16 nvIndexIn)
{
    int16    *indexPtr;
    Queue    *indexQPtr;
    uint16   addrIndex;
    NVStruct *nvStructPtr;
    uint16   nvAliasTableSize;

    nvAliasTableSize = nmp->snvt.aliasPtr->hostAlias;
    nvStructPtr      = GetNVStructPtr(nvIndexIn);
    addrIndex       = nvStructPtr->nvAddrIndex;
    if (nvStructPtr->nvDirection != NV_INPUT)
    {
        return(INVALID);
    }

    indexQPtr = &gp->nvInIndexQ;

    if (QueueFull(indexQPtr))
    {
        return(FAILURE); /* Could not schedule all. */
    }
    indexPtr = QueueTail(indexQPtr);
    *indexPtr = nvIndexIn;
    EnQueue(indexQPtr);
    return(SUCCESS);
}

/*****
Function: PollThisPrimary
Returns:  None
Purpose:  To schedule a specific primary network variable.
         If the variable is bound
         then
         this schedules the primary and any alias entries for this
         primary using PollThisIndex.
         If nothing was scheduled
         then
         generate failure completion event.
         else
         generate success completion event.
Comment:  None.
*****/
void PollThisPrimary(int16 nvIndexIn)
{
    int16    *indexPtr;
    Queue    *indexQPtr;
    NVStruct *nvStructPtr;
    uint16   nvAliasTableSize;
    uint16   count, dim;
    int16    baseIndex;

```

```
int16    j;
uint16   queueSpace;

nvAliasTableSize = nmp->snvt.aliasPtr->hostAlias;
nvStructPtr     = GetNVStructPtr(nvIndexIn);

indexQPtr = &gp->nvInIndexQ;

queueSpace = QueueCnt(indexQPtr) - QueueSize(indexQPtr);

/* Schedule primary network input variables for poll */
if (IsNVBound(nvIndexIn))
{
    /* We need space for at least 2 entries to schedule.
    i.e we need to reserve one space for -1 at the end. */
    count = 0;
    if (queueSpace > 1 && PollThisIndex(nvIndexIn) == SUCCESS)
    {
        count++;
        queueSpace--;
    }
    /* Schedule all alias entries that map to this primary entry.
    If queue does not have much space, stop scheduling rest. */
    for (j = nmp->nvTableSize;
         j < nmp->nvTableSize + nvAliasTableSize && queueSpace > 1;
         j++)
    {
        if (GetPrimaryIndex(j) != nvIndexIn)
        {
            continue;
        }
        if (PollThisIndex(j) == SUCCESS)
        {
            count++;
            queueSpace--;
        }
    }
    if (count == 0)
    {
        IsArrayNV(nvIndexIn, &dim, &baseIndex);
        gp->nvArrayIndex = nvIndexIn - baseIndex;
        REF_IMP_TO_ALT(NV_ARRAY_INDEX, &nv_array_index);
        NVUpdateCompletes(FAILURE, baseIndex, gp->nvArrayIndex);
    }
    else
    {
        /* Schedule -1 to indicate end of indices for this primary. */
        /* There should be at least one space left in queue */
        indexPtr = QueueTail(indexQPtr);
        *indexPtr = -1;
        EnQueue(indexQPtr);
    }
}
else
{
    IsArrayNV(nvIndexIn, &dim, &baseIndex);
    gp->nvArrayIndex = nvIndexIn - baseIndex;
    REF_IMP_TO_ALT(NV_ARRAY_INDEX, &nv_array_index);
    NVUpdateCompletes(SUCCESS, baseIndex, gp->nvArrayIndex); /* Not bound. */
}
}

/*****
Function:  Poll
```

Returns: None
 Purpose: To poll all input network variables.
 Comment: This function is called by the application program to poll all network input variables.

Schedule all NV_INPUT indices with a valid address table entry regardless of whether it is primary or alias.

This function only schedules these variables by placing them in a queue for later processing by APPSend function. APPSend will call PollVar function to actually send out polling requests.

It is possible that not all variables can be scheduled due to space limitation in the queues. For guaranteed scheduling of all possible network input variables, the polling queue should be large enough.

NVUpdateCompletes for input variables means that they are completion indication of corresponding poll requests.

```
*****
void Poll(void)
{
    int16 i;

    /* Schedule primary network input variables for poll */
    for (i = 0; i < nmp->nvTableSize; i++)
    {
        PollThisPrimary(i);
    }
}

```

```
*****
Function: PollNV
Returns: None
Purpose: To poll a specific input network variable (simple or array)
Comment: This function is called by the application program to poll a specific network input variable.
          If the index corresponds to the first item of an array, then all items of the array are polled.
```

If the index does not correspond to first item of an array, only that index is polled.

The variable must be a primary variable. All alias entries for this primary are also scheduled.

This function only schedules these variables by placing them in a queue for later processing by APPSend function. APPSend will call PollVar function to actually send out polling requests.

There is no guarantee that all possible variables are scheduled due to space limitation in the schedule queue. To ensure that this does not happen, the queue size for the scheduling should be made larger.

The addressing information is implicit. If the network input variables does not correspond to an address table entry, then it can't be scheduled as we don't know how to generate the destination address.

NVUpdateCompletes for input variables means that they are completion indication of corresponding poll requests.

```
*****  
void PollNV(int16 nvIndexIn)  
{  
    uint16 dim;  
    int16 baseIndex;  
    int16 i;  
  
    if (nvIndexIn < 0 || nvIndexIn >= nmp->nvTableSize )  
    {  
        return; /* Must be a valid primary index. */  
    }  
  
    IsArrayNV(nvIndexIn, &dim, &baseIndex);  
    if (nvIndexIn != baseIndex)  
    {  
        dim = 1; /* nvIndexIn is not the first item of array */  
    }  
  
    /* Scheduled one or more (for array) primary indices. */  
    /* For array, nvIndexIn = baseIndex */  
    for (i = nvIndexIn; i < nvIndexIn + dim; i++)  
    {  
        PollThisPrimary(i);  
    }  
}
```

```
*****  
Function: PollArrayNV  
Returns: None  
Purpose: To poll a specific element of an array input network variable  
or any other network variable (i.e non-array).  
Comment: This function is called by the application program to poll  
a specific item of an array network input variable or any  
other network variable (non-array).
```

Once the primary is schedules, we also schedule alias entries that map to this primary to make sure that we reach all possible output connections.

This function only schedules these variables by placing them in a queue for later processing by APPSend function. APPSend will call PollVar function to actually send out polling requests.

The addressing information is implicit. If the network input variables does not correspond to an address table entry, then it can be scheduled as we don't know how to generate the destination address.

If arrayNVIndexIn corresponds to the base index of an array, the indexIn is used to get the specific item of the array to be polled. Otherwise, indexIn is set to 0 so that any other array item or any other network variable can be passed.

NVUpdateCompletes for input variables means that they are completion indication of corresponding poll requests.

```
*****  
void PollArrayNV(int16 arrayNVIndexIn, int16 indexIn)  
{  
    uint16 dim;  
    int16 baseIndex;  
    int16 nvIndex;
```

```

    if (arrayNVIndexIn < 0 || arrayNVIndexIn >= nmp->nvTableSize)
    {
        return; /* Invalid index. */
    }

    /* if arrayNVIndexIn is not an array variable, then dim is set to 1
       and baseIndex is set to arrayNVIndexIn by IsArrayNV function */
    if (!IsArrayNV(arrayNVIndexIn, &dim, &baseIndex))
    {
        indexIn = 0; /* Simple network variable */
    }
    else if (baseIndex != arrayNVIndexIn)
    {
        indexIn = 0; /* Any other array item. don't use indexIn passed. */
    }

    if (indexIn < 0 || indexIn >= dim)
    {
        return; /* Invalid index */
    }

    nvIndex = arrayNVIndexIn + indexIn;
    PollThisPrimary(nvIndex);
}

/*****
Function: PollVar
Returns: None
Purpose: Issues a poll message for a single network input variable.
         Sends NV Poll message for the connected output variables.

         If there exists a unique turnaround output, we update
         the network variable directly and send NVUpdateOccurs event
         to the application program. Thus, updates from externally
         connected output variables will arrive later.

Comments: Note that this return value does not mean that the
         poll transaction is complete. It only means that the
         polling request has been delivered to the session layer.

         nvIndexIn must be good as it was previously scheduled.
         nvIndexIn can be either primary or alias.

         Do not check turnaround entries unless the session layer
         has space in the request queue for scheduling the poll.
         Otherwise, we may do the turnaround but stuck with not
         being able send the poll request. If we keep the entry
         in the queue after turnaround entries are processed, we
         may end up with double processing of turnaround entries.

         The NV Variable Poll message must be Request. So, use
         session layer.
*****/
static void PollVar(void)
{
    Queue *indexQPtr;
    int16 nvIndex;
    int16 *indexPtr;
    int16 i; /* For loop. */
    int16 primaryIndex; /* For nvIndex. */
    uint16 nvLength; /* For nvIndex. */
    uint16 dim; /* For nvIndex, if it is array */
    int16 baseIndex; /* For nvIndex, if it is array */
}

```

```

uint16      selector;          /* For nvIndex. */
Byte        *nvPtr;           /* For nvIndex. Points to storage. */
int16       primaryIndexOut;  /* For output network variable */
uint16      nvLengthOut;     /* For output network variable */
Byte        *nvPtrOut;       /* For output network variable */
uint16      selectorOut;     /* For output network variable */
Queue       *tsaOutQPtr;
TSASendParam *tsaSendParamPtr;
APDU        *apduPtr;
uint16      nvAliasTableSize;
NVStruct    *nvStrPtr, *nvStrPtrOut;
uint16      addrIndex, addrIndexOut;
AddrTableEntry *ap;
Boolean     turnaroundOnly; /* does not mean turnaround for sure. Means
                             that the variable does not have addr table
                             entry or the address table entry is unbound
                             or it is turnaround entry. */
Boolean     foundMatchingOutputVar;
int16       matchingIndexOut;

```

```
indexQPtr = &gp->nvInIndexQ;
```

```

if (!gp->nvInCanSchedule || QueueEmpty(indexQPtr))
{
    return;
}
indexPtr = QueueHead(indexQPtr);
nvIndex = *indexPtr;

```

```

/* If the node enters unconfigured state before processing this nv poll
we do not want to schedule these indices. We simply do nothing and wait
for the node to go configured. */

```

```

if (eep->readOnlyData.nodeState == APPL_UNCNFG)
{
    return;
}

```

```
nvAliasTableSize = nmp->snvt.aliasPtr->hostAlias;
```

```

if (nvIndex >= 0)
{
    /* Make nvStrPtr point to the right NVStruct for nvIndex */
    nvStrPtr = GetNVStructPtr(nvIndex);
    /* START INFORMATIVE - Network Variable Alias Priority */
    /* The bracketed code in conjunction with other code in this implementation
    * is structured in a way that allows network variable aliases
    * to have a different priority attribute than the primary and for that
    * difference in priority to be honored. It is acceptable, however, to send
    * all aliases using the same priority attribute as that of the primary. */
    if (nvStrPtr->nvPriority)
    {
        tsaOutQPtr = &gp->tsaOutPriQ;
    }
    else
    {
        tsaOutQPtr = &gp->tsaOutQ;
    }
    /* END INFORMATIVE - Network Variable Alias Priority */
}

```

```

primaryIndex = GetPrimaryIndex(nvIndex);
nvPtr        = NV_ADDRESS(primaryIndex);
nvLength     = NV_LENGTH(primaryIndex);
selector     = (nvStrPtr->nvSelectorHi << 8) | nvStrPtr->nvSelectorLo;
addrIndex    = nvStrPtr->nvAddrIndex;

```

```

    /* The variable is turnaround only if addrIndex is 0xF or it is unbound
       (turnaround or not) */
    turnaroundOnly = (addrIndex == 0xF) ||
                     (eep->addrTable[addrIndex].addrFormat == UNBOUND);
}
else
{
    tsaOutQPtr = &gp->tsaOutQ;
}
/* If the address table entry is turnaround only, then we don't send out
   any nv poll messages and hence we don't need to check the queue
   for space availability */
if (nvIndex == -1 || !turnaroundOnly)
{
    if (QueueFull(tsaOutQPtr))
    {
        /* Can't send request yet - try later. Don't even try turnaround. */
        return;
    }
}

if (nvIndex == -1)
{
    /* Form a message with a special tag to transport layer. */
    tsaSendParamPtr = QueueTail(tsaOutQPtr);
    tsaSendParamPtr->altPathOverride = FALSE;
    tsaSendParamPtr->service = ACKD;
    tsaSendParamPtr->tag = NV_POLL_LAST_TAG_VALUE;
    tsaSendParamPtr->apduSize = 0;
    EnQueue(tsaOutQPtr);
    gp->nvInCanSchedule = FALSE; /* Only one at a time. */
    DeQueue(indexQPtr);
    return;
}

/* If nvIndex is part of an array, we need to get the dimension and
   the baseIndex so that we can report nvInAddr and nvArrayIndex
   properly, in case there is a turn around connected. Alias entries
   can't be used to determine whether it is array. Use primaryIndex.
   We will use baseIndex for NVUpdateOccurs event */
IsArrayNV(primaryIndex, &dim, &baseIndex);

/* If the variable is flagged as turnaround, then we look for first
   network output variables with matching selector number. Once found,
   we update this input variable, and then send NVUpdateOccurs event
   to the application program. */
if (nvStrPtr->nvTurnaround)
{
    foundMatchingOutputVar = FALSE;
    matchingIndexOut = -1;
    for (i = 0; i < nmp->nvTableSize+nvAliasTableSize; i++)
    {
        nvStrPtrOut = GetNVStructPtr(i);
        addrIndexOut = nvStrPtrOut->nvAddrIndex;
        /* Skip input network variables */
        if (nvStrPtrOut->nvDirection == NV_INPUT)
        {
            continue;
        }
        /* It is a network output variable. Match selector */
        selectorOut =
            (nvStrPtrOut->nvSelectorHi << 8) | nvStrPtrOut->nvSelectorLo;
        if (selector != selectorOut)
        {

```

```

        continue; /* Selector does not match */
    }
    /* Found a matching output variable for nvIndex */
    matchingIndexOut = i;
    break;
}

if (matchingIndexOut != -1)
{
    primaryIndexOut = GetPrimaryIndex(matchingIndexOut);
    nvPtrOut        = NV_ADDRESS(primaryIndexOut);
    nvLengthOut     = NV_LENGTH(primaryIndexOut);

    /* Update the input variable provided the length matches */
    if (nvLength == nvLengthOut)
    {
        /* We will skip authentication check as it is turnaround */
        memcpy(nvPtr, nvPtrOut, nvLength);
        foundMatchingOutputVar = TRUE;

        /* turnaround updates are ignored for valid data check for polls.
        The only time it is ignored is if the nv is turnaround only.
        So, do not update gp->nvInDataStatus flag here. */

        /* Notify application program if it is running. */
        if (AppPgmRuns())
        {
            gp->nvInAddr.format = 4; /* TURNAROUND */
            memset(&gp->nvInAddr.srcAddr, 0, sizeof(SubnetAddress));
            gp->nvInAddr.domain = 0; /* Not relevant */
            /* gp->nvArrayIndex is 0 for simple var */
            gp->nvArrayIndex    = primaryIndex - baseIndex;
            REF_IMP_TO_ALT(NV_IN_ADDR, &nv_in_addr);
            REF_IMP_TO_ALT(NV_ARRAY_INDEX, &nv_array_index);
            /* same as primaryIndex for simple var */
            NVUpdateOccurs(baseIndex, gp->nvArrayIndex);
        }
    }
}

if (turnAroundOnly)
{
    /* NV completion event is given in HandleMsgCompletion. */
    /* Don't clear the nvInCanSchedule flag as we can continue */
    /* Since this index does not go through HandleMsgCompletion, we need
    to set gp->nvInIndex here. This is to take care of the case when
    a variable is turnaround only with no alias. In this case, this index
    is followed by -1 in the queue. Hence, the gp->nvInIndex would never
    be initialized when HandleMsgCompletion gets NV_POLL_LAST_TAG_VALUE.
    Explicit initialization here will fix the problem. */
    gp->nvInIndex = GetPrimaryIndex(nvIndex);
    if (nvStrPtr->nvTurnaround && matchingIndexOut != -1)
    {
        /* We did find a matching output variable and updated the polled */
        /* variable */
        /* Note that even if one of the indices (primary or alias) is turnaround
        only, this flag is set to true. */
        gp->nvInDataStatus = SUCCESS; /* to enable poll to succeed */
    }
    DeQueue(indexQPtr);
    return;
}

```

```

gp->nvInCanSchedule = FALSE;
DeQueue(indexQPtr);

/* Build and send netvar poll message. It is a REQUEST message. */
ap = AccessAddress(addrIndex); /* ap can't be null */

tsaSendParamPtr = QueueTail(tsaOutQPtr);
tsaSendParamPtr->altPathOverride = FALSE;
tsaSendParamPtr->domainIndex = COMPUTE_DOMAIN_INDEX;
*(AddrTableEntry *)(&tsaSendParamPtr->destAddr) = *ap;
tsaSendParamPtr->service = REQUEST; /* Poll Message */
tsaSendParamPtr->auth = nvStrPtr->nvAuth;
/* See app.h for details on tag usage. */
tsaSendParamPtr->tag = GET_NV_POLL_TAG(primaryIndex);
apduPtr = (APDU *) (tsaSendParamPtr + 1);
apduPtr->code.nv.nvFlag = 0x1;
apduPtr->code.nv.nvDir = NV_OUTPUT;
apduPtr->code.nv.nvCode = nvStrPtr->nvSelectorHi;
apduPtr->data[0] = nvStrPtr->nvSelectorLo;
tsaSendParamPtr->apduSize = 2;

EnQueue(tsaOutQPtr);
return;
}

/*****
Function: NewMsgTag
Returns: A new message tag of the requested type (bindable or non-bindable).
Purpose: To allocate message tags for use by application program.
Comment: Reference implementation does not support rate information
         for tags.
*****/
MsgTag NewMsgTag(BindNoBind bindStatusIn)
{
    if (bindStatusIn == BIND)
    {
        if (gp->nextBindableMsgTag < NUM_ADDR_TBL_ENTRIES &&
            nmp->snvt.mtagCount < 0xFF)
        {
            nmp->snvt.mtagCount++;
            return(gp->nextBindableMsgTag++);
        }
        else
        {
            /* Ran out of addr table entries or no room in mtagCount. */
            return(-1);
        }
    }

    if (gp->nextNonbindableMsgTag < 0xFFFF)
    {
        return(gp->nextNonbindableMsgTag++); /* We have lots of this */
    }
    else
    {
        return(-1); /* Extremely unlikely to happen. */
    }
}

/*****
Function: IsArrayNV
Returns: Returns TRUE if a given primary index corresponds to a
         network array variable.
         The index can be any of the indices for the array
*****/

```

```
elements.
Reference: None
Purpose: To determine if an index corresponds to a network
array variable. This is needed as this info is not part
of the nv config or fixed tables.
For simple variables, dimOut is set to 1 and baseIndexOut
is set to the given index. (By default).
Comments: gp->nvArrayTbl is an array of structures with two
fields: nvIndex and dim. The table contains nvIndex
and dim only for array variables. The table is populated
during AddNV.
For array variables, dim (dimension of array) and array
base index passed back if provided with non-null addresses.
*****
static Boolean IsArrayNV(int16 nvIndexIn,
uint16 *dimOut, int16 *baseIndexOut)
{
    int16 i;

    if (dimOut)
    {
        *dimOut = 1; /* Default for simple variables */
    }
    if (baseIndexOut)
    {
        *baseIndexOut = nvIndexIn;
    }
    /* Sequential search. OK if there are not too many arrays. */
    if (nvIndexIn < 0 || nvIndexIn >= nmp->nvTableSize)
    {
        return(FALSE); /* Only primary variables can be arrays */
    }
    for (i = 0; i < gp->nvArrayTblSize; i++)
    {
        if (nvIndexIn >= gp->nvArrayTbl[i].nvIndex &&
            nvIndexIn < gp->nvArrayTbl[i].nvIndex + gp->nvArrayTbl[i].dim)
        {
            /* Lies in the range for this array variable */
            if (dimOut)
            {
                *dimOut = gp->nvArrayTbl[i].dim;
            }
            if (baseIndexOut)
            {
                *baseIndexOut = gp->nvArrayTbl[i].nvIndex;
            }
            return(TRUE);
        }
    }
    return(FALSE); /* Not found. Must be a simple variable */
}

/* Application can call this fn to put itself offline */
void GoOffline(void)
{
    OfflineEvent();
    gp->appPgmMode = OFF_LINE;
}

/* Appplication can call this fn to put itself unconfigured */
void GoUnconfigured(void)
{
    int i, numDomains;
```



```

eep->readOnlyData.nodeState = APPL_UNCFG;
/* Set appPgmMode to OFF_LINE so that when we configured again, the
   application program will be soft-off-line.
gp->appPgmMode = OFF_LINE;
if (eep->readOnlyData.twoDomains)
{
    numDomains = 2;
}
else
{
    numDomains = 1;
}

/* Overwrite all domain information. Destroys auth key */
for (i = 0; i < numDomains; i++)
{
    memcpy(eep->domainTable[i].domainId, "gmrdf", DOMAIN_ID_LEN);
    eep->domainTable[i].subnet = 0;
    eep->domainTable[i].cloneDomain = 0;
    eep->domainTable[i].node = 0;
    eep->domainTable[i].len = 0xFF;
    memcpy(eep->domainTable[i].key, "NO KEY", AUTH_KEY_LEN);
}
}

/*-----End of app.c-----*/

```

A.11 Network Management Commands

```

*****
Reference:      Section 13, Network management & diagnostics
File:          netmgmt.c
Version:       1.7
Reference:     13.7 of this International Standard.
Purpose:       App Layer/Network Management

The functions in this file handle the network
management messages (HandleNM()) and network
diagnostic messages (HandleND()).

Note:
          Discard if      Honor even if      Never
          Not Request     read/write prot  Authcated
          -----
Network Management Messages:
NM_QUERY_ID      0x61  YES      YES      YES
NM_RESPOND_TO_QUERY 0x62  no      YES      YES
NM_UPDATE_DOMAIN 0x63  no      YES      no
NM_LEAVE_DOMAIN  0x64  no      YES      no
NM_UPDATE_KEY    0x65  no      YES      no
NM_UPDATE_ADDR  0x66  no      YES      no
NM_QUERY_ADDR    0x67  YES     YES      no
NM_QUERY_NV_CNFG 0x68  YES     YES      no
NM_UPDATE_GROUP_ADDR 0x69  no      YES      no
NM_QUERY_DOMAIN  0x6A  YES     YES      no

```

| | | | | |
|--------------------|------|-----|---------|----|
| NM_UPDATE_NV_CNFG | 0x6B | no | YES | no |
| NM_SET_NODE_MODE | 0x6C | no | YES | no |
| NM_READ_MEMORY | 0x6D | YES | Limited | no |
| NM_WRITE_MEMORY | 0x6E | no | Limited | no |
| NM_CHECKSUM_RECALC | 0x6F | no | YES | no |
| NM_WINK | 0x70 | no | YES | no |
| NM_MEMORY_REFRESH | 0x71 | no | YES | no |
| NM_QUERY_SNV | 0x72 | YES | YES | no |
| NM_NV_FETCH | 0x73 | YES | YES | no |

Network Diagnostic Messages:

| | | | | |
|------------------|------|-----|-----|-----|
| ND_QUERY_STATUS | 0x51 | YES | YES | YES |
| ND_PROXY_COMMAND | 0x52 | YES | YES | YES |
| ND_CLEAR_STATUS | 0x53 | NO | YES | no |
| ND_QUERY_XCVR | 0x54 | YES | YES | no |

Manual Service Request Message:

| | | | | |
|---------------------------|------|------|------|------|
| NM_MANUAL_SERVICE_REQUEST | 0x1F | -na- | -na- | -na- |
|---------------------------|------|------|------|------|

The HandleNM() function is called for each network management message, and does the appropriate processing. Some messages are simple enough to be processed right in HandleNM(), others have their own function that is called by HandleNM().

The HandleND() function is called for each network diagnostic message. Like HandleNM(), the HandleND() function takes care of simple messages, and more complicated messages are handled by their own function.

```


*****
/*-----
Section: Includes
-----*/
#include <string.h>

#include <cnp_l.h>
#include <node.h>
#include <app.h>
#include <api.h>
#include <netmgmt.h>

/*-----
Section: Constant Definitions
-----*/
/* None */

/*-----
Section: Type Definitions
-----*/
#pragma maxalign(1)

typedef struct
{
    uint16  transmissionErrors;
    uint16  transmitTXFailures;
    uint16  receiveTXFull;
    uint16  lostMessages;
    uint16  missedMessages;
    uint8   resetCause;
    uint8   nodeState;
    uint8   versionNumber;
    uint8   errorLog;
    uint8   modelNumber;
}
    
```



```
} NDQueryStat;

#pragma maxalign()

/*-----
Section: Globals
-----*/
/* None */

/*-----
Section: Function Prototypes.
-----*/
/* Local Functions */
static void RecomputeChecksum(void);
static void NMNDRespond(NtwkMgmtMsgType msgType,
                       Status success,
                       APPReceiveParam *appReceiveParamPtr,
                       APDU *apduPtr);

/* Network management related functions */
void HandleNMQueryId(APPReceiveParam *appReceiveParamPtr,
                    APDU *apduPtr);

void HandleNMWink(APPReceiveParam *appReceiveParamPtr,
                 APDU *apduPtr);

void HandleNMLeaveDomain(APPReceiveParam *appReceiveParamPtr,
                       APDU *apduPtr);

void HandleNMQueryAddr(APPReceiveParam *appReceiveParamPtr,
                      APDU *apduPtr);

void HandleNMQueryNvCnfg(APPReceiveParam *appReceiveParamPtr,
                        APDU *apduPtr);

void HandleNMQuerySIData (APPReceiveParam *appReceiveParamPtr,
                          APDU *apduPtr);

void HandleNMNVFetch (APPReceiveParam *appReceiveParamPtr,
                     APDU *apduPtr);

void HandleNMReadMemory (APPReceiveParam *appReceiveParamPtr,
                        APDU *apduPtr);

void HandleNMWriteMemory (APPReceiveParam *appReceiveParamPtr,
                          APDU *apduPtr);

void HandleNMQueryDomain (APPReceiveParam *appReceiveParamPtr,
                          APDU *apduPtr);

/* Network diagnostics related functions */
void HandleNDQueryStatus (APPReceiveParam *appReceiveParamPtr,
                          APDU *apduPtr);

void HandleNDProxyCommand (APPReceiveParam *appReceiveParamPtr,
                           APDU *apduPtr);

void HandleNDTransceiverStatus (APPReceiveParam *appReceiveParamPtr,
                                APDU *apduPtr);

void HandleNDClearStatus (APPReceiveParam *appReceiveParamPtr,
                          APDU *apduPtr);

/* This function is for use by HandleNDProxyCommand */
```

```

void HandleNDQueryUnconfig(APPReceiveParam *appReceiveParamPtr,
                           APDU *apduPtr);

/* External function from physical layer to get the transceiver status. */
extern void GetTransceiverStatus(Byte transceiverStatusOut[]);

/*-----
Section: Function Definitions
-----*/
/*****
Function: RecomputeChecksum
Returns: None
Reference: None
Purpose: To compute the configuration checksum and store.
Comments: None.
*****/
static void RecomputeChecksum(void)
{
    eep->configCheckSum = ComputeConfigCheckSum();
}

/*****
Function: ManualServiceRequestMessage
Returns: TRUE if the message is sent, FALSE otherwise.
Reference: None
Purpose: Produces a manual service request message.
Comments: Prototype in api.h so that application program can use this
          function too. Returns TRUE or FALSE so that application
          program can determine whether the message was sent or not.
*****/
Boolean ManualServiceRequestMessage(void)
{
    NWSendParam *nwSendParamPtr;
    APDU *apduRespPtr;

    if (QueueFull(&gp->nwOutQ))
    {
        return(FALSE); /* Can't send it now. Try later. */
    }

    /* Send unack domain wide broadcast message. */
    nwSendParamPtr = QueueTail(&gp->nwOutQ);
    nwSendParamPtr->pduSize = 1 + UNIQUE_NODE_ID_LEN + ID_STR_LEN;
    if (nwSendParamPtr->pduSize > gp->nwOutBufSize)
    {
        return(FALSE); /* Do not have sufficient space to send the message. */
    }
    apduRespPtr = (APDU *) (nwSendParamPtr + 1);
    apduRespPtr->code.allBits = 0x7F; /* Manual Service Request. */
    nwSendParamPtr->destAddr.domainIndex = FLEX_DOMAIN;
    nwSendParamPtr->destAddr.flexDomainLen = 0;
    nwSendParamPtr->pduType = APDU_TYPE;
    nwSendParamPtr->destAddr.addressMode = BROADCAST;
    nwSendParamPtr->destAddr.addr.addr0 = 0; /* Domain wide broadcast. */
    nwSendParamPtr->deltaBL = 0;
    nwSendParamPtr->altPath = 0; /* don't use alternate path. */
    nwSendParamPtr->tag = MANUAL_SERVICE_REQ_TAG_VALUE;

    memcpy(apduRespPtr->data, eep->readOnlyData.uniqueNodeId,
           UNIQUE_NODE_ID_LEN);
    memcpy(&(apduRespPtr->data[UNIQUE_NODE_ID_LEN]),
           eep->readOnlyData.progId, ID_STR_LEN);
    EnQueue(&gp->nwOutQ);
}

```

```

gp->manualServiceRequest = FALSE;
return(TRUE);
}

/*****
Function:  NMNDRespond
Returns:   None
Reference: None
Purpose:   Respond with success or failure code to current message.
           Can be called either for ND or NM messages.
Comments:  None
*****/
static void NMNDRespond(NtwkMgmtMsgType msgType,
                       Status success,
                       APPReceiveParam *appReceiveParamPtr,
                       APDU *apduPtr)
{
    Queue *tsaOutQPtr;
    TSAParams *tsaSendParamPtr;
    APDU *apduRespPtr;

    /* If service type is not request, nothing to do. */
    if(appReceiveParamPtr->service != REQUEST)
    {
        /* Does not make sense to respond if the original is not a request. */
        return;
    }

    if (QueueFull(&gp->tsaRespQ))
    {
        return; /* Can't send the response. Do nothing. */
    }

    /* Send response. */
    tsaOutQPtr = &gp->tsaRespQ;
    tsaSendParamPtr = QueueTail(tsaOutQPtr);
    tsaSendParamPtr->altPathOverride = FALSE;
    tsaSendParamPtr->service = RESPONSE;
    tsaSendParamPtr->nullResponse = FALSE;
    tsaSendParamPtr->reqId = appReceiveParamPtr->reqId;
    tsaSendParamPtr->apduSize = 1;
    apduRespPtr = (APDU *) (tsaSendParamPtr + 1);
    if (msgType == NM_MESSAGE)
    {
        apduRespPtr->code.allBits =
            (success == SUCCESS?NM_resp_success:NM_resp_failure)
            | (apduPtr->code.allBits & 0x1F);
    }
    else
    {
        apduRespPtr->code.allBits =
            (success == SUCCESS?ND_resp_success:ND_resp_failure)
            | (apduPtr->code.allBits & 0x0F);
    }

    EnQueue(tsaOutQPtr);
}

/*****
Function:  HandleNMLeaveDomain
Returns:   None
Reference: None
Purpose:   Handle incoming NM LeaveDomain message.
*****/

```

```

- Delete the indicated domain table entry.
- Recompute the configuration checksum.
- If message was received on the indicated domain,
  do not respond
- If node no longer belongs to any Domain:
  + become unconfigured
  + reset
Comments: None.
*****/
void HandleNMLeaveDomain(APPReceiveParam *appReceiveParamPtr,
                        APDU *apduPtr)
{
  /* Fail if message is not 2 bytes long */
  /* *** START INFORMATIVE - Parameter Validation *** */
  /* It is not required that the processing of network management commands
   * include parameter validation. In general, it is the responsibility of the
   * configuration tool to ensure that requests are well formed. */
  if(appReceiveParamPtr->pduSize != 2)
  {
    NMNDRespond(NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
    DeQueue(&gp->appInQ);
    return;
  }
  /* If the domain index is bad, fail */
  if (apduPtr->data[0] != 0 && apduPtr->data[0] != 1)
  {
    nmp->errorLog = INVALID_DOMAIN;
    NMNDRespond(NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
    DeQueue(&gp->appInQ);
    return;
  }
  /* *** END INFORMATIVE - Parameter Validation *** */

  /* Leave the domain */
  memcpy(eep->domainTable[apduPtr->data[0]].domainId,
         "gmrdf",
         DOMAIN ID_LEN);
  eep->domainTable[apduPtr->data[0]].subnet = 0;
  eep->domainTable[apduPtr->data[0]].cloneDomain = 1;
  eep->domainTable[apduPtr->data[0]].node = 0;
  eep->domainTable[apduPtr->data[0]].len = 0xFF; /* not in use */
  memcpy(eep->domainTable[apduPtr->data[0]].key,
         "NO KEY",
         AUTH_KEY_LEN);

  /* Recompute the configuration checksum */
  RecomputeChecksum();

  /* If message not received on domain just left, then respond */
  if(apduPtr->data[0] != appReceiveParamPtr->srcAddr.domainIndex)
  {
    NMNDRespond(NM_MESSAGE, SUCCESS, appReceiveParamPtr, apduPtr);
  }

  /* If not a member of any domain, go unconfigured and reset. */
  if ((!eep->readOnlyData.twoDomains &&
       eep->domainTable[0].len == 0xFF) ||
      (eep->readOnlyData.twoDomains &&
       eep->domainTable[0].len == 0xFF &&
       eep->domainTable[1].len == 0xFF) )
  {
    eep->readOnlyData.nodeState = APPL_UNCNFG;
    nmp->resetCause = SOFTWARE_RESET;
    gp->resetNode = TRUE; /* Scheduler will reset the node */
  }
}

```

```

}

DeQueue (&gp->appInQ);
}

/*****
Function:  HandleNMQueryAddr
Returns:   None
Reference: None
Purpose:   Handle incoming NM Query Address message.
Comments:  None.
*****/
void HandleNMQueryAddr (APPReceiveParam *appReceiveParamPtr,
                        APDU *apduPtr)
{
    Queue *tsaOutQPtr;
    TSASendParam *tsaSendParamPtr;
    APDU *apduRespPtr;
    AddrTableEntry *ap;

    tsaOutQPtr = &gp->tsaRespQ;
    /* *** START INFORMATIVE - Parameter Validation *** */
    /* See "START INFORMATIVE - Parameter Validation" above. */
    /* Fail if message is not 2 bytes long. */
    if (appReceiveParamPtr->pduSize != 2)
    {
        NMNDRespond (NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
        DeQueue (&gp->appInQ);
        return;
    }
    /* *** END INFORMATIVE - Parameter Validation *** */
    /* Fail if the address table index is bad and set statistics. */
    if (apduPtr->data[0] >= NUM_ADDR_TBL_ENTRIES)
    {
        nmp->errorLog = INVALID_ADDR_TABLE_INDEX;
        NMNDRespond (NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
        DeQueue (&gp->appInQ);
        return;
    }
    /* Fail if the buffer is insufficient for the response. */
    if (1 + sizeof (AddrTableEntry) > gp->tsaRespBufSize )
    {
        NMNDRespond (NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
        DeQueue (&gp->appInQ);
        return;
    }

    ap = AccessAddress (apduPtr->data[0]); /* ap should not NULL. */

    /* Send response */
    tsaSendParamPtr = QueueTail (tsaOutQPtr);
    tsaSendParamPtr->altPathOverride = FALSE;
    tsaSendParamPtr->service = RESPONSE;
    tsaSendParamPtr->nullResponse = FALSE;
    tsaSendParamPtr->reqId = appReceiveParamPtr->reqId;
    apduRespPtr = (APDU *) (tsaSendParamPtr + 1);
    apduRespPtr->code.allBits = NM resp success | NM QUERY ADDR;
    tsaSendParamPtr->apduSize = 1 + sizeof (AddrTableEntry);
    memcpy (apduRespPtr->data, ap, sizeof (AddrTableEntry));
    EnQueue (tsaOutQPtr);
    DeQueue (&gp->appInQ);
}

/*****

```

```
Function: HandleNMQueryNvCnfg
Returns: None
Reference: None
Purpose: Handle incoming NM Query Netvar Config message.
Comments: None.
*****
void HandleNMQueryNvCnfg(APPReceiveParam *appReceiveParamPtr,
                        APDU *apduPtr)
{
    Queue *tsaOutQPtr;
    TSASendParam *tsaSendParamPtr;
    APDU *apduRespPtr;
    uint16 n;
    uint16 nvAliasTableSize;

    /* Fail if the request does not have correct size */
    /* *** START INFORMATIVE - Parameter Validation *** */
    /* See "START INFORMATIVE - Parameter Validation" above. */
    if (appReceiveParamPtr->pduSize != 2 && appReceiveParamPtr->pduSize != 4)
    {
        NMNDRespond(NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
        DeQueue(&gp->appInQ);
        return;
    }
    /* *** END INFORMATIVE - Parameter Validation *** */

    n = apduPtr->data[0];
    /* *** START INFORMATIVE - Parameter Validation *** */
    /* See "START INFORMATIVE - Parameter Validation" above. */
    if (n == 255 && appReceiveParamPtr->pduSize != 4)
    {
        NMNDRespond(NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
        DeQueue(&gp->appInQ);
        return;
    }
    /* *** END INFORMATIVE - Parameter Validation *** */

    /* Calculate current alias table size */
    nvAliasTableSize = nmp->snvt.aliasPtr->hostAlias;

    /* Decode index */

    /* *** START INFORMATIVE - Escaped NV Index *** */
    /* In implementations that handle a maximum number of network variables that is
    /* less than 255, it is not necessary to check for network variable escapes of
    /* 255.
    /*
    if(n == 255)
    {
        n = (uint16) apduPtr->data[1];
        n = (n << 8) | apduPtr->data[2];
    }
    /* *** END INFORMATIVE - Escaped NV Index *** */

    /* Fail if there is insufficient space to send the response */
    /* *** START INFORMATIVE - Parameter Validation *** */
    /* See "START INFORMATIVE - Parameter Validation" above. */
    if (
        (n < nmp->nvTableSize && (1 + sizeof(NVStruct)) > gp->tsaRespBufSize) ||
        (n >= nmp->nvTableSize && n < nmp->nvTableSize + nvAliasTableSize &&
         (1 + sizeof(AliasStruct)) > gp->tsaRespBufSize)
    )
    {
        NMNDRespond(NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
    }
}
```

```

        DeQueue (&gp->appInQ);
        return;
    }
    /* *** END INFORMATIVE - Parameter Validation *** */

    /* Send response */
    tsaOutQPtr          = &gp->tsaRespQ;
    tsaSendParamPtr    = QueueTail(tsaOutQPtr);
    tsaSendParamPtr->altPathOverride = FALSE;
    tsaSendParamPtr->service      = RESPONSE;
    tsaSendParamPtr->>nullResponse = FALSE;
    tsaSendParamPtr->reqId       = appReceiveParamPtr->reqId;
    apduRespPtr         = (APDU *) (tsaSendParamPtr + 1);
    apduRespPtr->code.allBits    = NM_resp_success | NM_QUERY_NV_CNFG;
    if (n < nmp->nvTableSize)
    {
        /* Copy the NVStruct entry */
        tsaSendParamPtr->apduSize = 1 + sizeof(NVStruct);
        memcpy(apduRespPtr->data, &(nmp->nvConfigTable[n]),
            sizeof(NVStruct));
    }
    else if (n < nmp->nvTableSize + nvAliasTableSize)
    {
        /* Copy the alias table entry. */
        tsaSendParamPtr->apduSize = 1 + sizeof(AliasStruct);
        n = n - nmp->nvTableSize;
        memcpy(apduRespPtr->data, &(nmp->nvAliasTable[n]),
            sizeof(AliasStruct));
    }
    else
    {
        nmp->errorLog          = INVALID_NV_INDEX;
        apduRespPtr->code.allBits = NM_resp_failure | NM_QUERY_NV_CNFG;
        tsaSendParamPtr->apduSize = 1;
    }
}

EnQueue(tsaOutQPtr);
DeQueue(&gp->appInQ);
}

/*****
Function:  HandleNMNVFetch
Returns:  None
Reference: None
Purpose:  Handle incoming NM NV Fetch message.
Comments: None
*****/
void HandleNMNVFetch (APPReceiveParam *appReceiveParamPtr,
                    APDU *apduPtr)
{
    Queue *tsaOutQPtr;
    TSASendParam *tsaSendParamPtr;
    APDU *apduRespPtr;
    uint16 n;
    uint8 i;

    /* Check if the message has correct size. If not, fail. */
    /* *** START INFORMATIVE - Parameter Validation *** */
    /* See "START INFORMATIVE - Parameter Validation" above. */
    if (appReceiveParamPtr->pduSize != 2 &&
        appReceiveParamPtr->pduSize != 4)
    {
        NMNDRespond (NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
        DeQueue (&gp->appInQ);
    }
}

```

```

    return;
}
/* *** END INFORMATIVE - Parameter Validation *** */
n = apduPtr->data[0];
/* *** START INFORMATIVE - Parameter Validation *** */
/* See "START INFORMATIVE - Parameter Validation" above. */
if (n == 255 && appReceiveParamPtr->pduSize != 4)
{
    NMNDRespond(NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
    DeQueue(&gp->appInQ);
    return;
}
/* *** END INFORMATIVE - Parameter Validation *** */
tsaOutQPtr = &gp->tsaRespQ;
/* Send response */
tsaSendParamPtr = QueueTail(tsaOutQPtr);
tsaSendParamPtr->altPathOverride = FALSE;
tsaSendParamPtr->service = RESPONSE;
tsaSendParamPtr->>nullResponse = FALSE;
tsaSendParamPtr->reqId = appReceiveParamPtr->reqId;
apduRespPtr = (APDU *) (tsaSendParamPtr + 1);

/* *** START INFORMATIVE - Escaped NV Index *** */
/* See "START INFORMATIVE - Escaped NV Index" above. */
if(n == 255)
{
    n = apduPtr->data[1];
    n = (n << 8) | apduPtr->data[2];
    memcpy(apduRespPtr->data, apduPtr->data, 3); /* copy the index */
    i = 3; /* index where value of nv is copied */
}
/* *** END INFORMATIVE - Escaped NV Index *** */
else
{
    apduRespPtr->data[0] = (char) n;
    i = 1;
}
if (n < nmp->nvTableSize)
{
    /* Make sure there is sufficient space for the response. Else, fail. */
    /* *** START INFORMATIVE - Parameter Validation *** */
    /* See "START INFORMATIVE - Parameter Validation" above. */
    if (nmp->nvFixedTable[n].nvLength + i + 1 > gp->tsaRespBufSize)
    {
        NMNDRespond(NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
        DeQueue(&gp->appInQ);
        return;
    }
    /* *** END INFORMATIVE - Parameter Validation *** */
    memcpy(&apduRespPtr->data[i],
           nmp->nvFixedTable[n].nvAddress,
           nmp->nvFixedTable[n].nvLength);
    tsaSendParamPtr->apduSize = nmp->nvFixedTable[n].nvLength + i + 1;
    apduRespPtr->code.allBits = NM_resp_success | NM_NV_FETCH;
    EnQueue(tsaOutQPtr);
}
else
{
    NMNDRespond(NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
}
DeQueue(&gp->appInQ);
}
}

```

```

/*****
Function:  HandleNMQuerySIData
Returns:  None
Reference: None
Purpose:  Handle incoming NM Query SI Data message.
Comments: None.
*****/
void HandleNMQuerySIData (APPReceiveParam *appReceiveParamPtr,
                          APDU          *apduPtr)
{
    Queue          *tsaOutQPtr;
    TSASendParam   *tsaSendParamPtr;
    APDU           *apduRespPtr;
    uint16         offset;
    uint8          count;

    tsaOutQPtr = &gp->tsaRespQ;

    /* *** START INFORMATIVE - Query SI Data *** */
    /* It is only necessary to respond to Query SI Data messages (AKA Query SNVT)
     * if the implementation does not support direct memory read/[write] of the
     * device self identification data. Only a device with a
     * "ReadOnlyDataStruct.snvtStruct" field with value 0xffff must implement this
     * function. */

    /* Fail if message is not 4 bytes long */
    if (appReceiveParamPtr->pduSize != 4)
    {
        NMNDRespond (NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
        DeQueue (&gp->appInQ);
        return;
    }

    /* Decode offset and count */
    offset = apduPtr->data[0];
    offset = (offset << 8) | apduPtr->data[1];
    count = apduPtr->data[2];
    /* Check if we have enough space to respond for this message */
    if (count + 1 > gp->tsaRespBufSize)
    {
        NMNDRespond (NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
        DeQueue (&gp->appInQ);
        return;
    }

    /* Send response */
    tsaSendParamPtr = QueueTail (tsaOutQPtr);
    tsaSendParamPtr->altPathOverride = FALSE;
    tsaSendParamPtr->service = RESPONSE;
    tsaSendParamPtr->nullResponse = FALSE;
    tsaSendParamPtr->reqId = appReceiveParamPtr->reqId;
    apduRespPtr = (APDU *) (tsaSendParamPtr + 1);
    apduRespPtr->code.allBits = NM_resp_success | NM_QUERY_SNVT;
    tsaSendParamPtr->apduSize = 1 + count;
    memcpy (apduRespPtr->data, offset + (char *) &(nmp->snvt), count);
    EnQueue (tsaOutQPtr);
    /* *** END INFORMATIVE - Query SI Data *** */
    DeQueue (&gp->appInQ);
}

/*****
Function:  HandleNMWink
Returns:  None
Reference: None
*****/

```

```

Purpose: Handle incoming NM Wink message.
Comments: None.
*****/
void HandleNMWink(APPReceiveParam *appReceiveParamPtr,
                  APDU *apduPtr)
{
    Queue *tsaQueuePtr;
    TSASendParam *tsaSendParamPtr;
    APDU *apduRespPtr;
    int8 subcmd;
    int8 niIndex;

    subcmd = 0;

    if (appReceiveParamPtr->pduSize > 1)
    {
        subcmd = apduPtr->data[0];
    }

    if (appReceiveParamPtr->pduSize > 2)
    {
        niIndex = apduPtr->data[1];
    }

    /* *** START INFORMATIVE - Parameter Validation *** */
    /* See "START INFORMATIVE - Parameter Validation" above. */
    if (appReceiveParamPtr->pduSize > 3)
    {
        /* Incorrect size */
        NMNDRespond(NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
        DeQueue(&gp->appInQ);
        return;
    }
    /* *** END INFORMATIVE - Parameter Validation *** */

    /* *** START INFORMATIVE - Wink Handling *** */
    /* Handling of wink subcommands is not required. That is, it is acceptable
     * to treat all requests with this code as if they were simple wink requests.
     * Wink subcommands are a set of backward compatible extensions to the wink
     * command code. */
    if (appReceiveParamPtr->pduSize <= 1 || subcmd == 0)
    {
        if (appReceiveParamPtr->service != REQUEST)
        {
            /* Any service except request/response */
            Wink(); /* Simple Wink */
        }
        else
        {
            NMNDRespond(NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
        }
        DeQueue(&gp->appInQ);
        return;
    }

    /* must be requesting SEND_ID_INFO. */
    if (appReceiveParamPtr->service != REQUEST)
    {
        DeQueue(&gp->appInQ); /* Discard */
        return; /* The message should be a request. */
    }

    tsaQueuePtr = &gp->tsaRespQ;
    if (QueueFull(tsaQueuePtr))

```

```

    return;
}
tsaSendParamPtr = QueueTail(tsaQueuePtr);
tsaSendParamPtr->altPathOverride = FALSE;
/* Note: This implementation only has one NI Interface. i.e 0 */
/* Send response. */
tsaSendParamPtr->service = RESPONSE;
tsaSendParamPtr->reqId = appReceiveParamPtr->reqId;
tsaSendParamPtr->nullResponse = FALSE;
apduRespPtr = (APDU *) (tsaSendParamPtr + 1);

if (niIndex == 0 &&
    UNIQUE_NODE_ID_LEN + ID_STR_LEN + 2 <= gp->tsaRespBufSize )
{
    tsaSendParamPtr->apduSize = ID_STR_LEN + UNIQUE_NODE_ID_LEN + 2;
    apduRespPtr->data[0] = 0; /* Interface not down. */
    apduRespPtr->code.allBits = NM_resp success | NM WINK;
    memcpy(&apduRespPtr->data[1], eep->readOnlyData.uniqueNodeId,
        UNIQUE_NODE_ID_LEN);
    memcpy(&(apduRespPtr->data[1+UNIQUE_NODE_ID_LEN]),
        eep->readOnlyData.progId, ID_STR_LEN);
}
else
{
    tsaSendParamPtr->apduSize = 1;
    apduRespPtr->code.allBits = NM_resp failure | NM WINK;
}
EnQueue(tsaQueuePtr);
/* *** END INFORMATIVE - Wink Handling *** */
DeQueue(&gp->appInQ);
}

/*****
Function: HandleNMQueryId
Returns: None
Reference: None
Purpose: Handle incoming NM Query ID message.
Comments: The message must be a request. There must be space in
response queue. See HandleNM (We do these checks first).
*****/
void HandleNMQueryId(APPReceiveParam *appReceiveParamPtr,
    APDU *apduPtr)
{
    NMQueryIdRequest *pid;
    char *memp;
    Queue *tsaOutQPtr;
    TSASendParam *tsaSendParamPtr;
    APDU *apduRespPtr;
    Boolean allowed;
    uint16 offset;

    /* Fail if message does not have the correct size. Should be 2 or 6+n */
    /* *** START INFORMATIVE - Parameter Validation *** */
    /* See "START INFORMATIVE - Parameter Validation" above. */
    if (appReceiveParamPtr->pduSize != 2 && appReceiveParamPtr->pduSize < 6)
    {
        NMNDRespond(NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
        DeQueue(&gp->appInQ);
        return;
    }
    /* *** END INFORMATIVE - Parameter Validation *** */

    tsaOutQPtr = &gp->tsaRespQ;

```

```
/* Init some fields here. Assume we may fail. */
tsaSendParamPtr = QueueTail(tsaOutQPtr);
tsaSendParamPtr->altPathOverride = FALSE;
apduRespPtr = (APDU *) (tsaSendParamPtr + 1);
tsaSendParamPtr->service = RESPONSE;
tsaSendParamPtr->nullResponse = FALSE;
tsaSendParamPtr->reqId = appReceiveParamPtr->reqId;
tsaSendParamPtr->apduSize = 1;
/* Since there are a lot of fail cases, init code to indicate failed
response. */
apduRespPtr->code.allBits = NM_resp_failure | NM_QUERY_ID;

pid = (NMQueryIdRequest *) &apduPtr->data;
offset = pid->offset;

/* if optional fields are present, check that the data field has
sufficient bytes. */
/* *** START INFORMATIVE - Parameter Validation *** */
/* See "START INFORMATIVE - Parameter Validation" above. */
if (appReceiveParamPtr->pduSize > 2 &&
    appReceiveParamPtr->pduSize != (6 + pid->count))
{
    /* The message does not have sufficient data or it has too much data. */
    NMNDRespond(NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
    DeQueue(&gp->appInQ);
    return;
}
/* *** END INFORMATIVE - Parameter Validation *** */

switch(pid->selector)
{
    case UNCONFIGURED:
        if(!NodeUnConfigured())
        {
            /* Not unconfigured - don't respond. */
            tsaSendParamPtr->nullResponse = TRUE;
            EnQueue(tsaOutQPtr);
            DeQueue(&gp->appInQ);
            return;
        }
        break;
    case SELECTED:
        if(!gp->selectQueryFlag)
        {
            /* Not selected - don't respond. */
            tsaSendParamPtr->nullResponse = TRUE;
            EnQueue(tsaOutQPtr);
            DeQueue(&gp->appInQ);
            return;
        }
        break;
    case SELECTED_UNCFG: /* must be selected and unconfigured */
        if(!gp->selectQueryFlag)
        {
            /* Not selected - don't respond. */
            tsaSendParamPtr->nullResponse = TRUE;
            EnQueue(tsaOutQPtr);
            DeQueue(&gp->appInQ);
            return;
        }
        if(!NodeUnConfigured())
        {
            /* Not unconfigured - don't respond */

```

```

        tsaSendParamPtr->nullResponse = TRUE;
        EnQueue(tsaOutQPtr);
        DeQueue(&gp->appInQ);
        return;
    }
    break;
default:
    EnQueue(tsaOutQPtr); /* Failed response. */
    DeQueue(&gp->appInQ);
    return;
}

/* If memory matching is present, check memory match */
if(appReceiveParamPtr->pduSize > 2)
{
    switch(pid->mode)
    {
        case ABSOLUTE_MEM_ADDR:
            memp = (char *)nmp;
            if(offset >= 0xF000)
            {
                memp = (char *)eep - 0xF000;
            }
            else if (offset >= 0xFC00)
            {
                memp = (char *)nmp->memMapSpace - 0xFC00;
            }
            break;
        case CONFIG_RELATIVE:
            memp = (char *)&(eep->configData);
            break;
        case READ_ONLY_RELATIVE:
            memp = (char *)&(eep->readOnlyData);
            break;
        default:
            EnQueue(tsaOutQPtr);
            DeQueue(&gp->appInQ);
            return; /* Failed response. */
    }

    memp += offset;

    /* Absolute addressing to read snvt is not possible */
    allowed = (memp >= (char *)&eep->readOnlyData &&
                memp + apduPtr->data[3] < (char *)&eep->domainTable[0]);
    if (!allowed)
    {
        EnQueue(tsaOutQPtr);
        DeQueue(&gp->appInQ);
        return; /* Failed response. */
    }

    if(memcmp(pid->data, memp, pid->count) != 0)
    {
        /* Compare failed - don't reply. */
        tsaSendParamPtr->nullResponse = TRUE;
        EnQueue(tsaOutQPtr);
        DeQueue(&gp->appInQ);
        return;
    }
}

/* Send response */
if (1 + UNIQUE_NODE_ID_LEN + ID_STR_LEN <= gp->tsaRespBufSize )

```

```

    tsaSendParamPtr->apduSize = 1 + UNIQUE_NODE_ID_LEN + ID_STR_LEN;
    apduRespPtr->code.allBits = NM_resp_success | NM_QUERY_ID;
    memcpy(apduRespPtr->data, eep->readOnlyData.uniqueNodeId,
           UNIQUE_NODE_ID_LEN);
    memcpy(&(apduRespPtr->data[UNIQUE_NODE_ID_LEN]),
           eep->readOnlyData.progId, ID_STR_LEN);
}

    EnQueue(tsaOutQPtr);
    DeQueue(&gp->appInQ);
}

/*****
Function:  HandleNMQueryDomain
Returns:  None
Reference: None
Purpose:  Handle incoming NM QueryDomain message.
Comments: Must be a Request.
*****/
void HandleNMQueryDomain(APPReceiveParam *appReceiveParamPtr,
                        APDU *apduPtr)
{
    Queue *tsaOutQPtr;
    TSASendParam *tsaSendParamPtr;
    APDU *apduRespPtr;
    int n; /* Domain Index */

    /* Fail if message does not have the correct size. */
    /* *** START INFORMATIVE - Parameter Validation *** */
    /* See "START INFORMATIVE - Parameter Validation" above. */
    if(appReceiveParamPtr->pduSize != 2)
    {
        NMNDRespond(NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
        DeQueue(&gp->appInQ);
        return;
    }
    /* *** END INFORMATIVE - Parameter Validation *** */

    tsaOutQPtr = &gp->tsaRespQ;
    n = apduPtr->data[0]; /* Domain Index */
    /* If domain index is other than 0 or 1 or if the node is in only one
       domain and the index is 1, then fail. */
    if ((n != 0 && n != 1) || (eep->readOnlyData.twoDomains == 0 && n == 1))
    {
        /* Domain index is bad. */
        nmp->errorLog = INVALID_DOMAIN;
        NMNDRespond(NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
        DeQueue(&gp->appInQ);
        return;
    }
    /* If there is not enough space, fail too. */
    if (1 + sizeof(DomainStruct) > gp->tsaRespBufSize)
    {
        NMNDRespond(NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
        DeQueue(&gp->appInQ);
        return;
    }

    /* Send response */
    tsaSendParamPtr = QueueTail(tsaOutQPtr);
    tsaSendParamPtr->altPathOverride = FALSE;
}

```

```

    tsaSendParamPtr->service      = RESPONSE;
    tsaSendParamPtr->nullResponse = FALSE;
    tsaSendParamPtr->reqId       = appReceiveParamPtr->reqId;
    tsaSendParamPtr->apduSize    = 1 + sizeof(DomainStruct);
    apduRespPtr                  = (APDU *) (tsaSendParamPtr + 1);
    apduRespPtr->code.allBits     = NM_resp_success | NM_QUERY_DOMAIN;
    memcpy(apduRespPtr->data, &eep->domainTable[n], sizeof(DomainStruct));

    EnQueue(tsaOutQPtr);
    DeQueue(&gp->appInQ);
}

/*****
Function:  HandleNMReadMemory
Returns:   None
Reference: None
Purpose:   Handle incoming NM ReadMemory message
Comments:  None
*****/
void HandleNMReadMemory(APPReceiveParam *appReceiveParamPtr,
                        APDU *apduPtr)
{
    Queue *tsaOutQPtr;
    TSASendParam *tsaSendParamPtr;
    APDU *apduRespPtr;
    char *memp;
    uint16 offset;
    Boolean allowed;

    tsaOutQPtr = &gp->tsaRespQ;

    /* Fail if message is not 5 bytes long. */
    /* *** START INFORMATIVE - Parameter Validation *** */
    /* See "START INFORMATIVE - Parameter Validation" above. */
    if (appReceiveParamPtr->pduSize != 5)
    {
        NMNDRespond(NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
        DeQueue(&gp->appInQ);
        return;
    }
    /* *** END INFORMATIVE - Parameter Validation *** */

    offset = (apduPtr->data[1] << 8) | apduPtr->data[2];

    /* Assemble response */
    tsaSendParamPtr = QueueTail(tsaOutQPtr);
    tsaSendParamPtr->altPathOverride = FALSE;
    tsaSendParamPtr->service = RESPONSE;
    tsaSendParamPtr->nullResponse = FALSE;
    tsaSendParamPtr->reqId = appReceiveParamPtr->reqId;
    tsaSendParamPtr->apduSize = 1 + apduPtr->data[3];

    apduRespPtr = (APDU *) (tsaSendParamPtr + 1);

    apduRespPtr->code.allBits = NM_resp_success | NM_READ_MEMORY;

    switch (apduPtr->data[0])
    {
        case ABSOLUTE_MEM_ADDR:
            memp = (char *) nmp;
            if (offset >= 0xF000)
            {
                memp = (char *) eep - 0xF000;
            }
    }
}

```

```

    }
    else if (offset >= 0xFC00)
    {
        memp = (char *)nmp->memMapSpace - 0xFC00;
    }
    break;
case READ_ONLY_RELATIVE:
default:
    memp = (char *)&(eep->readOnlyData);
    break;
case CONFIG_RELATIVE:
    memp = (char *)&(eep->configData);
    break;
case STAT_RELATIVE:
    memp = (char *)&(nmp->stats);
    break;
}

memp += offset;

/* If readWriteProtect flag is on, then only readonly data structure,
snvt structures, and configuration structure can be read.
The one byte read of location 0 (firmware number) is also allowed.
Reference implementation does not support snvt reading through
absolute addressing. readOnlyData.snvtStruct is 0xFFFF */

if(eep->readOnlyData.readWriteProtect == TRUE)
{
    allowed = (memp >= (char *)&eep->readOnlyData &&
                memp + apduPtr->data[3] < (char *)&eep->domainTable[0]) ||
                (memp == (char *)&nmp && apduPtr->data[3] == 1);

    if(!allowed)
    {
        tsaSendParamPtr->apduSize = 1;
        apduRespPtr->code.allBits = NM_resp_failure | NM_READ_MEMORY;
        EnQueue(tsaOutQPtr);
        DeQueue(&gp->appInQ);
        return;
    }
}

if (apduPtr->data[3] <= gp->tsaRespBufSize)
{
    memcpy(apduRespPtr->data, memp, apduPtr->data[3]);
}
else
{
    tsaSendParamPtr->apduSize = 1;
}

if (memp == (char *)nmp && apduPtr->data[3] == 1)
{
    /* trap for absolute read of location 0 and write
    version number (hard code it as 11) */
    apduRespPtr->data[0] = 11;
}
EnQueue(tsaOutQPtr);
DeQueue(&gp->appInQ);
}

/*****
Function: HandleNMWriteMemory

```

```

Returns: None
Reference: None
Purpose: Handle incoming NM WriteMemory message.
Comments: None.
*****
void HandleNMWriteMemory(APPReceiveParam *appReceiveParamPtr,
                        APDU *apduPtr)
{
    Queue *tsaOutQPtr;
    TSASendParam *tsaSendParamPtr;
    APDU *apduRespPtr;
    NMWriteMemoryRequest *pr;
    char *memp;
    uint16 offset;
    Boolean allowed;

    tsaOutQPtr = &gp->tsaRespQ;

    /* Fail if message is not at least 6 bytes long */
    /* *** START INFORMATIVE - Parameter Validation *** */
    /* See "START INFORMATIVE - Parameter Validation" above. */
    if(appReceiveParamPtr->pduSize < 6)
    {
        NMNDRespond(NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
        DeQueue(&gp->appInQ);
        return;
    }
    /* *** END INFORMATIVE - Parameter Validation *** */

    /* Pointer to struct describing memory request */
    pr = (NMWriteMemoryRequest *)&apduPtr->data[0];

    offset = pr->offset;

    /* Fail if message length doesn't match count. Poke can use 16 data bytes.
       Allow that. Note that the code takes one byte. */
    /* *** START INFORMATIVE - Parameter Validation *** */
    /* See "START INFORMATIVE - Parameter Validation" above. */
    if(appReceiveParamPtr->pduSize != 6 + pr->count &&
       appReceiveParamPtr->pduSize != 17)
    {
        NMNDRespond(NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
        DeQueue(&gp->appInQ);
        return;
    }
    /* *** END INFORMATIVE - Parameter Validation *** */

    if (appReceiveParamPtr->service == REQUEST)
    {
        /* Assemble response */
        tsaSendParamPtr = QueueTail(tsaOutQPtr);
        tsaSendParamPtr->altPathOverride = FALSE;
        tsaSendParamPtr->service = RESPONSE;
        tsaSendParamPtr->nullResponse = FALSE;
        tsaSendParamPtr->reqId = appReceiveParamPtr->reqId;
        tsaSendParamPtr->apduSize = 1;
        apduRespPtr = (APDU *) (tsaSendParamPtr + 1);
    }

    switch(pr->mode)
    {
        case ABSOLUTE_MEM_ADDR:
            memp = (char *)nmp;
            if(offset >= 0xF000)

```

```

    {
        memp = (char *)eep - 0xF000;
    }
    else if (offset >= 0xFC00)
    {
        memp = (char *)nmp->memMapSpace - 0xFC00;
    }
    break;
case CONFIG_RELATIVE:
    memp = (char *)&(eep->configData);
    break;
case STAT_RELATIVE:
    memp = (char *)&(nmp->stats);
    break;
case READ_ONLY_RELATIVE:
    memp = (char *)&(eep->readOnlyData);
    break;
default:
    /* Invalid Mode */
    NMNDRespond(NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
    DeQueue(&gp->appInQ);
    return;
}

memp += offset;

/* Check if the range of memory cells written is good. */
allowed = (memp >= (char *)nmp &&
           (memp + pr->count) <= ((char *)nmp + 64 * 1024)) ||
           (memp >= (char *)eep &&
           (memp + pr->count) <= ((char *)eep + sizeof(EEPROM)));
if (! allowed)
{
    /* Send failure response if the message was a request */
    NMNDRespond(NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
    DeQueue(&gp->appInQ);
    return;
}

/* If readwrite flag is on, then only config structure can be written. */
if(eep->readOnlyData.readWriteProtect == TRUE)
{
    allowed = (memp >= (char *)&eep->configData &&
              memp + pr->count < (char *)&eep->domainTable[0]);

    if(! allowed)
    {
        /* Send failure response if the message was a request */
        NMNDRespond(NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
        DeQueue(&gp->appInQ);
        return;
    }
}

/* Need to copy only the data array in NM_Req structure.
   The header is 5 bytes long */
/* We have to assume that pr->count is good. Max is 255 */
/* Reference implementation has no application check sum.
   Only config checksum */
memcpy(memp, apduPtr->data+5, pr->count);

if (pr->form & CNFG_CS_RECALC) {
    RecomputeChecksum();
}

```

```

}
if (pr->form & ACTION RESET) {
    gp->resetNode = TRUE;
    nmp->resetCause = SOFTWARE_RESET;
}

/* There is no harm in responding even when the node is reset. It will
be lost anyway */
if (appReceiveParamPtr->service == REQUEST)
{
    apduRespPtr->code.allBits = NM_resp_success | NM_WRITE_MEMORY;
    EnQueue (tsaOutQPtr);
}
DeQueue (&gp->appInQ);
}

/*****
Function: HandleProxyResponse
Returns: None
Reference: None
Purpose: Handle Proxy Response Message.
Comments: None.
*****/
void HandleProxyResponse (APPReceiveParam *appReceiveParamPtr,
                          APDU *apduPtr)
{
    Queue *tsaOutQPtr;
    TSASendParam *tsaSendParamPtr;
    APDU *apduRespPtr;

    /* Send response */
    tsaOutQPtr = &gp->tsaRespQ;

    if (QueueFull (tsaOutQPtr))
    {
        return; /* Return without processing message */
    }

    tsaSendParamPtr = QueueTail (tsaOutQPtr);
    tsaSendParamPtr->altPathOverride = FALSE;
    tsaSendParamPtr->service = RESPONSE;
    tsaSendParamPtr->nullResponse = FALSE;
    tsaSendParamPtr->reqId = nmp->pxyData.reqId;
    tsaSendParamPtr->apduSize = appReceiveParamPtr->pduSize;
    apduRespPtr = (APDU *) (tsaSendParamPtr + 1);
    if (appReceiveParamPtr->pduSize <= gp->tsaRespBufSize)
    {
        memcpy (apduRespPtr, apduPtr, appReceiveParamPtr->pduSize);
    }
    else
    {
        tsaSendParamPtr->apduSize = 1;
    }

    EnQueue (tsaOutQPtr);

    /* Done processing */
    DeQueue (&gp->appInQ);

    /* Reset the flag as we have now responded */
    nmp->pxyData.pxyType = -1;
}

```

```
Function: HandleNDQueryStatus
Returns: none
Reference: None
Purpose: Handle Network Diagnostics Query Status Message.
Comments: None.
*****
void HandleNDQueryStatus (APPReceiveParam *appReceiveParamPtr,
                          APDU *apduPtr)
{
    NDQueryStat    ndq;
    Queue          *tsaOutQPtr;
    TSASendParam  *tsaSendParamPtr;
    APDU          *apduRespPtr;

    tsaOutQPtr = &gp->tsaRespQ;
    if (((apduPtr->code.allBits & 0x0F) == ND_QUERY_STATUS) &&
        appReceiveParamPtr->pduSize != 1)
    {
        /* Incorrect size. Fail. */
        NMNDRespond(ND_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
        DeQueue (&gp->appInQ);
        return;
    }

    /* *** START INFORMATIVE - Parameter Validation *** */
    /* See "START INFORMATIVE - Parameter Validation" above. */
    if (((apduPtr->code.allBits & 0x0F) == ND_PROXY_COMMAND) &&
        appReceiveParamPtr->pduSize != 2)
    {
        /* Incorrect size. Fail. */
        NMNDRespond(ND_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
        DeQueue (&gp->appInQ);
        return;
    }
    /* *** END INFORMATIVE - Parameter Validation *** */

    ndq.transmissionErrors = nmp->stats.transmissionErrors;
    ndq.transmitTXFailures = nmp->stats.transmitTXFailures;
    ndq.receiveTXFull      = nmp->stats.receiveTXFull;
    ndq.lostMessages       = nmp->stats.lostMessages;
    ndq.missedMessages     = nmp->stats.missedMessages;
    ndq.resetCause         = nmp->resetCause;
    if (eep->readOnlyData.nodeState == CNFG_ONLINE &&
        gp->appPgmMode == OFF_LINE)
    {
        ndq.nodeState = SOFT_OFFLINE;
    }
    else
    {
        ndq.nodeState = eep->readOnlyData.nodeState;
    }
    ndq.versionNumber = 128;
    ndq.errorLog       = nmp->errorLog;
    ndq.modelNumber    = 128;
    /* Send response */
    tsaSendParamPtr    = QueueTail(tsaOutQPtr);
    tsaSendParamPtr->altPathOverride = FALSE;
    tsaSendParamPtr->service         = RESPONSE;
    tsaSendParamPtr->nullResponse   = FALSE;
    tsaSendParamPtr->reqId          = appReceiveParamPtr->reqId;
    tsaSendParamPtr->apduSize       = 1 + sizeof(NDQueryStat);
    apduRespPtr          = (APDU *) (tsaSendParamPtr + 1);
}
```

```

/* The response code is formed using apduPtr->code.allBits as the
actual could be a proxy command and the response code will be
different. Thus, using apduPtr->code.allBits works for both
native query status command as well as proxy based query status */
if (tsaSendParamPtr->apduSize <= gp->tsaRespBufSize)
{
    apduRespPtr->code.allBits =
        ND_resp_success | (apduPtr->code.allBits & 0x0F);
    memcpy(apduRespPtr->data, &ndq, sizeof(NDQueryStat));
}
else
{
    apduRespPtr->code.allBits =
        ND_resp_failure | (apduPtr->code.allBits & 0x0F);
    tsaSendParamPtr->apduSize = 1;
}
EnQueue(tsaOutQPtr);
DeQueue(&gp->appInQ);
}

/*****
Function: HandleNDProxyCommand
Returns: none
Reference: None
Purpose: Handle network diagnostics proxy request message.
Comments: None.
*****/
void HandleNDProxyCommand(APPREceiveParam *appReceiveParamPtr,
                          APDU *apduPtr)
{
    Queue *tsaOutQPtr;
    TSASendParam *tsaSendParamPtr;
    APDU *apduSendPtr;

    /* See if the proxy command is to be forwarded or it is for us
to process. If the address information in the packet is missing,
then there is no forwarding information and hence we respond directly */
if (appReceiveParamPtr->pduSize == 2)
{
    /* Address portion is missing. This node is the proxy target. */
    tsaOutQPtr = &gp->tsaRespQ;
    /* Send the response directly back to the sender */
    switch(apduPtr->data[0])
    {
        case 0:
            HandleNDQueryUnconfig(appReceiveParamPtr, apduPtr);
            break;
        case 1:
            HandleNDQueryStatus(appReceiveParamPtr, apduPtr);
            break;
        case 2:
            HandleNDTransceiverStatus(appReceiveParamPtr, apduPtr);
            break;
        default:
            /* Invalid sub command. Send failure response */
            NMNDRespond(ND_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
            DeQueue(&gp->appInQ);
    }
    return;
}

/* Send failure response if a proxy command is already in progress

```

```

    or we are proxy agent and the message received is on flex domain
    or it does not have correct size */
    if (
        nmp->pxyData.pxyType != -1 ||
        appReceiveParamPtr->srcAddr.domainIndex == FLEX_DOMAIN ||
        (apduPtr->data[1] == UNIQUE_NODE_ID &&
         appReceiveParamPtr->pduSize !=
         (2 + sizeof(AddrTableEntry) + UNIQUE_NODE_ID_LEN) ) ||
        (apduPtr->data[1] != UNIQUE_NODE_ID &&
         appReceiveParamPtr->pduSize != (2 + sizeof(AddrTableEntry)) )
    )
    {
        NMNDRespond(ND_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
        DeQueue(&gp->appInQ);
        return;
    }
}

```

```

/* We need to forward the proxy now. Set the target queue ptrs */
if(appReceiveParamPtr->priority)
{
    tsaOutQPtr = &gp->tsaOutPriQ;
}
else
{
    tsaOutQPtr = &gp->tsaOutQ;
}

```

```

/* Check if the target queue has space for forwarding this request. */
if(QueueFull(tsaOutQPtr))
{
    return; /* Return without processing message */
}

```

```

/* Save the proxy data for processing the response later.
Also, pxyType will no longer be equal to -1 that serves
as a kind of lock on this record. Future proxy commands
will be ignored until this proxy command is done. The proxy
command is done as soon as we get the response and we forward
it to the original sender or when the transaction forwarding
the proxy times out. Session layer will not give us duplicate
requests and hence we don't need to handle that here. Also,
session layer will take care of sending response again for
duplicate requests. */
nmp->pxyData.pxyType = apduPtr->data[0];
nmp->pxyData.reqId = appReceiveParamPtr->reqId;

```

```

/* Generate request message */
tsaSendParamPtr = QueueTail(tsaOutQPtr);
/* First copy the msg_out_addr info in the proxy command */
if (apduPtr->data[1] == UNIQUE_NODE_ID)
{
    memcpy(&tsaSendParamPtr->destAddr, &apduPtr->data[1],
           sizeof(MsgOutAddr) + UNIQUE_NODE_ID_LEN);
}
else
{
    memcpy(&tsaSendParamPtr->destAddr, &apduPtr->data[1],
           sizeof(MsgOutAddr));
}

```

```

/* Set the domain index to be the one in which it was received.
Note that this cannot be flex domain. Transport or session
will use this instead of the one in the destAddr (i.e msg_out_addr) */
tsaSendParamPtr->domainIndex = appReceiveParamPtr->srcAddr.domainIndex;

```

```

    tsaSendParamPtr->service = REQUEST;
    tsaSendParamPtr->auth = FALSE;
    tsaSendParamPtr->tag = (MsgTag) 0xFFFF;
    /* Proxy relays the message, the altpath bit should be same as the one
       used for the proxy message received */
    tsaSendParamPtr->altPathOverride = TRUE;
    tsaSendParamPtr->altPath = appReceiveParamPtr->altPath;
    tsaSendParamPtr->apduSize = 2; /* Always two bytes: code + sub_command */
    apduSendPtr = (APDU *) (tsaSendParamPtr + 1);
    /* Copy the code as it is */
    apduSendPtr->code.allBits = apduPtr->code.allBits;
    apduSendPtr->data[0] = apduPtr->data[0];
    EnQueue(tsaOutQPtr);
    DeQueue(&gp->appInQ);
}

/*****
Function: HandleNDTransceiverStatus
Returns: none
Reference: None
Purpose: Handle network diagnostics transceiver status message.
Comments: None.
*****/
void HandleNDTransceiverStatus (APPReceiveParam *appReceiveParamPtr,
                                APDU *apduPtr)
{
    Queue *tsaOutQPtr;
    TSASendParam *tsaSendParamPtr;
    APDU *apduRespPtr;
    Byte transceiverStatus[ NUM_COMM_PARAMS ];
    uint8 n;

    /* Check for proper size of the message. Regular pduSize is 1 byte.
       If this fn is called due to proxy request, then it is 2 bytes. */
    /* *** START INFORMATIVE - Parameter Validation *** */
    /* See "START INFORMATIVE - Parameter Validation" above. */
    if (appReceiveParamPtr->pduSize > 2)
    {
        NMNDRespond (ND_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
        DeQueue (&gp->appInQ);
        return;
    }
    /* *** END INFORMATIVE - Parameter Validation *** */
    else if (appReceiveParamPtr->pduSize == 2)
    {
        /* Make sure it is a proxy request. Or else, length is wrong. */
        if (apduPtr->code.nd.ndFlag == 0x5 &&
            apduPtr->code.nd.ndCode == ND_PROXY_COMMAND &&
            apduPtr->data[0] == 2)
        {
            /* It is indeed a proxy command. Length ok. Proceed. */
        }
        else
        {
            NMNDRespond (ND_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
            DeQueue (&gp->appInQ);
            return;
        }
    }
}

if (eep->configData.commType == SPECIAL_PURPOSE)
{
    GetTransceiverStatus (transceiverStatus);
    n = NUM_COMM_PARAMS;
}

```

```

    }
    else
    {
        n = 0;
    }

    /* Send response */
    tsaOutQPtr = &gp->tsaRespQ;
    tsaSendParamPtr = QueueTail(tsaOutQPtr);
    tsaSendParamPtr->altPathOverride = FALSE;
    tsaSendParamPtr->service = RESPONSE;
    tsaSendParamPtr->nullResponse = FALSE;
    tsaSendParamPtr->reqId = appReceiveParamPtr->reqId;
    tsaSendParamPtr->apduSize = 1 + n;
    apduRespPtr = (APDU *) (tsaSendParamPtr + 1);

    /* If a node does not have transceiver status registers, fail */
    if ( n > 0 && tsaSendParamPtr->apduSize <= gp->tsaRespBufSize)
    {
        /* No registers or not enough space */
        apduRespPtr->code.allBits = ND_resp_success |
            (apduPtr->code.allBits & 0x0F);

        memcpy(apduRespPtr->data, transceiverStatus, n);
    }
    else
    {
        apduRespPtr->code.allBits = ND_resp_failure |
            (apduPtr->code.allBits & 0x0F);

        tsaSendParamPtr->apduSize = 1;
    }
    EnQueue(tsaOutQPtr);
    DeQueue(&gp->appInQ);
}

/*****
Function: HandleNDClearStatus
Returns: none
Reference: None
Purpose: Handle network diagnostics clear status message.
Comments: None.
*****/
void HandleNDClearStatus(APPReceiveParam *appReceiveParamPtr,
                        APDU *apduPtr)
{
    /* Check for proper size of the message */
    /* *** START INFORMATIVE - Parameter Validation *** */
    /* See "START INFORMATIVE - Parameter Validation" above. */
    if (appReceiveParamPtr->pduSize != 1)
    {
        NMNDRespond(ND_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
        DeQueue(&gp->appInQ);
        return;
    }
    /* *** END INFORMATIVE - Parameter Validation *** */

    /* Clear Status */
    nmp->stats.transmissionErrors = 0;
    nmp->stats.transmitTXFailures = 0;
    nmp->stats.receiveTXFull = 0;
    nmp->stats.lostMessages = 0;
}

```

```

nmp->stats.missedMessages = 0;
nmp->stats.layer2Received = 0;
nmp->stats.layer3Received = 0;
nmp->stats.layer3Transmitted = 0;
nmp->stats.transmitTXRetries = 0;
nmp->stats.backlogOverflow = 0;
nmp->stats.lateAcknowledgements = 0;
nmp->stats.collisions = 0;
nmp->resetCause = CLEARED;
nmp->errorLog = NO_ERRORS; /* Cleared */

nmp->stats.layer6_7MsgsSent = 0;
nmp->stats.layer6_7RespSent = 0;
nmp->stats.layer6_7MsgsRcvd = 0;
nmp->stats.layer6_7RespRcvd = 0;
nmp->stats.lateResponses = 0;
nmp->stats.lateChallenges = 0;
nmp->stats.lateReplies = 0;

/* NMNDRespond will send response only if the msg is REQUEST */
NMNDRespond(ND_MESSAGE, SUCCESS, appReceiveParamPtr, apduPtr);
DeQueue (&gp->appInQ);
}

/*****
Function: HandleNDQueryUnconfig
Returns: None
Reference: None
Purpose: Handle Query Unconfig through Proxy message.
Comments: This is a simplified version of HandleNMQueryId.
          Only unconfig version of Query ID is supported.
*****/
void HandleNDQueryUnconfig (APPReceiveParam *appReceiveParamPtr,
                           APDU *apduPtr)
{
    Queue *tsaOutQPtr;
    TSASendParam *tsaSendParamPtr;
    APDU *apduRespPtr;

    /* Check for proper size of the message */
    /* *** START INFORMATIVE - Parameter Validation *** */
    /* See "START INFORMATIVE - Parameter Validation" above. */
    if (appReceiveParamPtr->pduSize != 2)
    {
        NMNDRespond(ND_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
        DeQueue (&gp->appInQ);
        return;
    }
    /* *** END INFORMATIVE - Parameter Validation *** */

    tsaOutQPtr = &gp->tsaRespQ;

    /* Init some fields here. */
    tsaSendParamPtr = QueueTail(tsaOutQPtr);
    tsaSendParamPtr->altPathOverride = FALSE;
    apduRespPtr = (APDU *) (tsaSendParamPtr + 1);
    tsaSendParamPtr->service = RESPONSE;
    tsaSendParamPtr->nullResponse = FALSE;
    tsaSendParamPtr->reqId = appReceiveParamPtr->reqId;
    tsaSendParamPtr->apduSize = 1;
    /* apduPtr->code.allBits should be proxy code */
    apduRespPtr->code.allBits = ND_resp_failure |
        (apduPtr->code.allBits & 0x0F);

```

```

if(!NodeUnConfigured())
{
    /* Not unconfigured - don't respond. */
    tsaSendParamPtr->nullResponse = TRUE;
    EnQueue(tsaOutQPtr);
    DeQueue(&gp->appInQ);
    return;
}

/* Send response */
if (1 + UNIQUE_NODE_ID_LEN + ID_STR_LEN <= gp->tsaRespBufSize )
{
    tsaSendParamPtr->apduSize = 1 + UNIQUE_NODE_ID_LEN + ID_STR_LEN;
    apduRespPtr->code.allBits = ND_resp_success |
        (apduPtr->code.allBits & 0x0F);
    memcpy(apduRespPtr->data, eep->readOnlyData.uniqueNodeId,
        UNIQUE_NODE_ID_LEN);
    memcpy(&(apduRespPtr->data[UNIQUE_NODE_ID_LEN]),
        eep->readOnlyData.progId, ID_STR_LEN);
}

EnQueue(tsaOutQPtr);
DeQueue(&gp->appInQ);
}

/*****
Function: HandleND
Returns: None
Reference: None
Purpose: Handle incoming network diagnostic message.
Comments: None.
*****/
void HandleND(APPReceiveParam *appReceiveParamPtr,
              APDU *apduPtr)
{
    if(appReceiveParamPtr->service == RESPONSE)
    {
        /* It is not legal for a response to be an ND command */
        DeQueue(&gp->appInQ);
        return;
    }

    /* If network diagnostics messages need authentication
    and the message did not pass authentication and
    the node is not unconfigured
    then discard those messages that should be discarded and return. */
    if(!NodeUnConfigured() && eep->configData.nmAuth &&
        !appReceiveParamPtr->auth)
    {
        /* Only two messages are allowed. Others should be discarded */
        if (apduPtr->code.nd.ndCode != ND_QUERY_STATUS &&
            apduPtr->code.nd.ndCode != ND_PROXY_COMMAND)
        {
            if(QueueFull(&gp->tsaRespQ))
            {
                return; /* Can't send response now. Try later. */
            }
            nmp->errorLog = AUTHENTICATION MISMATCH;
            NMNDRRespond(ND_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
            DeQueue(&gp->appInQ);
            return;
        }
    }
}

```

PDF-BOOKS.COM Click to view the full PDF of ISO/IEC 14908-1:2012

```

    }
}

/* Only clear status command need not be request message. Others
must be request/response */
if (apduPtr->code.nd.ndCode != ND_CLEAR_STATUS &&
    appReceiveParamPtr->service != REQUEST)
{
    /* Discard. We can't respond anyway as it is not a request */
    DeQueue(&gp->appInQ);
    return;
}

if (appReceiveParamPtr->service == REQUEST &&
    QueueFull(&gp->tsaRespQ))
{
    return; /* Can't send a response. Try later. */
}

/* Handle various network diagnostic message codes */
switch(apduPtr->code.nd.ndCode)
{
    case ND_QUERY_STATUS:
        HandleNDQueryStatus(appReceiveParamPtr, apduPtr);
        return;
    case ND_PROXY_COMMAND:
        HandleNDProxyCommand(appReceiveParamPtr, apduPtr);
        return;
    case ND_CLEAR_STATUS:
        HandleNDClearStatus(appReceiveParamPtr, apduPtr);
        return;
    case ND_QUERY_XCVR:
        HandleNDTransceiverStatus(appReceiveParamPtr, apduPtr);
        return;
    default:
        /* Discard unrecognized diagnostic command */
        NMNDRSpond(ND_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
        DeQueue(&gp->appInQ);
}
}

/*****
Function: HandleNM
Returns: None
Reference: None
Purpose: Handle incoming network management messages.
Comments: None.
*****/
void HandleNM(APPReceiveParam *appReceiveParamPtr,
              APDU *apduPtr)
{
    int16 i;
    uint16 n; /* for nv index */
    AddrTableEntry *ap;
    GroupAddrMode *groupStrPtr;
    uint16 addrIndex;
    NVStruct *np;
    uint16 nvAliasTableSize;
    uint8 pduSize;

    if(appReceiveParamPtr->service == RESPONSE)
    {
        /* It is not legal for a response to be an NM command. */
        DeQueue(&gp->appInQ);
    }
}

```

```

return;
}

/* If network management messages need authentication
and the message did not pass authentication and
the node is not unconfigured
then discard those messages that should be discarded and return. */
if(!NodeUnConfigured() && eep->configData.nmAuth && !appReceiveParamPtr->auth)
{
/* Only two messages are allowed. Others should be discarded */
if (apduPtr->code.nm.nmCode != NM_QUERY_ID &&
    apduPtr->code.nm.nmCode != NM_RESPOND_TO_QUERY)
{
if(QueueFull(&gp->tsaRespQ))
{
return; /* Can't send response now. Try later. */
}
nmp->errorLog = AUTHENTICATION_MISMATCH;
NMNDRespond(NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
DeQueue(&gp->appInQ);
return;
}
}

/* If the service type is not request, discard certain messages. */
if(appReceiveParamPtr->service != REQUEST)
{
switch(apduPtr->code.nm.nmCode)
{
/* messages that need request/resp. */
case NM_QUERY_ID:
case NM_QUERY_ADDR:
case NM_QUERY_NV_CNFG:
case NM_QUERY_DOMAIN:
case NM_READ_MEMORY:
case NM_QUERY_SNV:
case NM_NV_FETCH:
DeQueue(&gp->appInQ);
return;
default:
break;
}
}

/* If service type is request, and there is no room for response
return without processing - so message will be processed later. */
if(appReceiveParamPtr->service == REQUEST)
{
if(QueueFull(&gp->tsaRespQ))
{
return; /* Wait until there is room for response. */
}
}

/* Handle various network mgmt message codes */
switch(apduPtr->code.nm.nmCode)
{
case NM_QUERY_ID:
HandleNMQueryId(appReceiveParamPtr, apduPtr);
return;
case NM_RESPOND_TO_QUERY:
/* Fail if message is not 2 bytes long or the byte is bad. */
if(appReceiveParamPtr->pduSize != 2 ||
    (apduPtr->data[0] != 0 && apduPtr->data[0] != 1) )

```

```

{
    NMNDRespond(NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
    DeQueue(&gp->appInQ);
    return;
}
gp->selectQueryFlag = apduPtr->data[0];
NMNDRespond(NM_MESSAGE, SUCCESS, appReceiveParamPtr, apduPtr);
DeQueue(&gp->appInQ);
return;
case NM_UPDATE_DOMAIN:
    /* Fail if message is not the right size or the domain index is bad. */
    if (appReceiveParamPtr->pduSize != 2 + sizeof(DomainStruct))
    {
        NMNDRespond(NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
        DeQueue(&gp->appInQ);
        return;
    }
    if (apduPtr->data[0] != 0 && apduPtr->data[0] != 1)
    {
        nmp->errorLog = INVALID_DOMAIN;
        NMNDRespond(NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
        DeQueue(&gp->appInQ);
        return;
    }
    /* If the node is in only one domain and the request is to update
    domain index 1, then we send a failure response. */
    if (eep->readOnlyData.twoDomains == 0 &&
        apduPtr->data[0] == 1)
    {
        nmp->errorLog = INVALID_DOMAIN;
        NMNDRespond(NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
        DeQueue(&gp->appInQ);
        return;
    }
    /* Reference implementation allows even clone domain update. */
    if (((DomainStruct *) &apduPtr->data[1])->cloneDomain == 1)
    {
        UpdateDomain((DomainStruct *) &apduPtr->data[1], apduPtr->data[0]);
    }
    else
    {
        UpdateCloneDomain((DomainStruct *) &apduPtr->data[1],
            apduPtr->data[0]);
    }
    NMNDRespond(NM_MESSAGE, SUCCESS, appReceiveParamPtr, apduPtr);
    RecomputeChecksum();
    DeQueue(&gp->appInQ);
    return;
case NM_LEAVE_DOMAIN:
    HandleNMLeaveDomain(appReceiveParamPtr, apduPtr);
    return;
case NM_UPDATE_KEY:
    /* Fail if message is not of correct length or domain index is bad. */
    /* *** START INFORMATIVE - Parameter Validation *** */
    /* See "START INFORMATIVE - Parameter Validation" above. */
    if (appReceiveParamPtr->pduSize != 2 + AUTH_KEY_LEN)
    {
        NMNDRespond(NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
        DeQueue(&gp->appInQ);
        return;
    }
    if (apduPtr->data[0] != 0 && apduPtr->data[0] != 1)
    {
        nmp->errorLog = INVALID_DOMAIN;
    }

```

```

        NMNDRespond(NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
        DeQueue(&gp->appInQ);
        return;
    }
    /* *** END INFORMATIVE - Parameter Validation *** */

    for(i = 0; i < AUTH_KEY_LEN; i++)
    {
        eep->domainTable[apduPtr->data[0]].key[i] +=
            apduPtr->data[i+1];
    }
    RecomputeChecksum();
    NMNDRespond(NM_MESSAGE, SUCCESS, appReceiveParamPtr, apduPtr);
    DeQueue(&gp->appInQ);
    return;

case NM_UPDATE_ADDR:
    /* Check for incorrect size. Allow for padding. */
    /* *** START INFORMATIVE - Parameter Validation *** */
    /* See "START INFORMATIVE - Parameter Validation" above. */
    if ( appReceiveParamPtr->pduSize < 6 ||
        appReceiveParamPtr->pduSize > 7)
    {
        NMNDRespond(NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
        DeQueue(&gp->appInQ);
        return;
    }
    if (apduPtr->data[1] != UNBOUND)
    {
        /* Not turnaround. Must be 7 bytes. */
        if (appReceiveParamPtr->pduSize != 7)
        {
            NMNDRespond(NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
            DeQueue(&gp->appInQ);
            return;
        }
    }
    /* *** END INFORMATIVE - Parameter Validation *** */
    /* Fail if the address table index is bad. */
    if (apduPtr->data[0] >= NUM_ADDR_TBL_ENTRIES)
    {
        nmp->errorLog = INVALID_ADDR_TABLE_INDEX;
        NMNDRespond(NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
        DeQueue(&gp->appInQ);
        return;
    }

    UpdateAddress((AddrTableEntry *)&apduPtr->data[1], apduPtr->data[0]);
    RecomputeChecksum();
    NMNDRespond(NM_MESSAGE, SUCCESS, appReceiveParamPtr, apduPtr);
    DeQueue(&gp->appInQ);
    return;

case NM_QUERY_ADDR:
    HandleNMQueryAddr(appReceiveParamPtr, apduPtr);
    return;

case NM_QUERY_NV_CNFG:
    HandleNMQueryNvCnfg(appReceiveParamPtr, apduPtr);
    return;

case NM_UPDATE_GROUP_ADDR:
    /* This message must be delivered with group addressing and is
       updated based on the domain in which it was received. Hence,
       flex domain is not allowed. */
    if (appReceiveParamPtr->srcAddr.addressMode != MULTICAST ||
        appReceiveParamPtr->srcAddr.domainIndex == FLEX_DOMAIN)
    {

```

```

    /* This message should be sent in MULTICAST. Fail */
    NMNDRespond(NM MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
    DeQueue(&gp->appInQ);
    return;
}
/* *** START INFORMATIVE - Parameter Validation *** */
/* See "START INFORMATIVE - Parameter Validation" above. */
if (appReceiveParamPtr->pduSize != 1 + sizeof(AddrTableEntry))
{
    /* Incorrect size */
    NMNDRespond(NM MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
    DeQueue(&gp->appInQ);
    return;
}
/* *** END INFORMATIVE - Parameter Validation *** */
/* For accessing the corresponding address table entry,
   let us use the domainIndex in which it was received and
   the group in which it was received. It makes sense to use
   the domainIndex in which the message was received rather than
   the domain index in the packet(that will be same for all
   recipients) as it may be different for different nodes. */
groupStrPtr = (GroupAddrMode *)&apduPtr->data[0];
if (groupStrPtr->groupFlag == 1)
{
    addrIndex = AddrTableIndex(appReceiveParamPtr->srcAddr.domainIndex,
                              appReceiveParamPtr->srcAddr.group);
}

/* Make sure we got a good index. */
if (groupStrPtr->groupFlag != 1 || addrIndex == 0xFF)
{
    NMNDRespond(NM MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
    DeQueue(&gp->appInQ);
    return;
}
ap = AccessAddress(addrIndex); /* ap cannot be NULL */
/* Only group size and timer values should be changed */
ap->groupEntry.groupSize = groupStrPtr->groupSize;
ap->groupEntry.rptTimer = groupStrPtr->rptTimer;
ap->groupEntry.retryCount = groupStrPtr->retryCount;
ap->groupEntry.rcvTimer = groupStrPtr->rcvTimer;
ap->groupEntry.txTimer = groupStrPtr->txTimer;
RecomputeChecksum();
NMNDRespond(NM MESSAGE, SUCCESS, appReceiveParamPtr, apduPtr);
DeQueue(&gp->appInQ);
return;
case NM_QUERY_DOMAIN:
    HandleNMQueryDomain(appReceiveParamPtr, apduPtr);
    return;
case NM_UPDATE_NV_CNFG:
    /* Check for pdu size. Fail if the size is too small or too big */
    /* *** START INFORMATIVE - Parameter Validation *** */
    /* See "START INFORMATIVE - Parameter Validation" above. */
    if (appReceiveParamPtr->pduSize < 5 ||
        appReceiveParamPtr->pduSize > 10)
    {
        NMNDRespond(NM MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
        DeQueue(&gp->appInQ);
        return;
    }
    /* *** END INFORMATIVE - Parameter Validation *** */
    nvAliasTableSize = nmp->snvt.aliasPtr->hostAlias;
    /* Decode index */

```

```

n = apduPtr->data[0];
/* *** START INFORMATIVE - Escaped NV Index *** */
/* See "START INFORMATIVE - Escaped NV Index" above. */
if(n == 255)
{
    n = (uint16)apduPtr->data[1];
    n = (n << 8) | apduPtr->data[2];
    if (n < nmp->nvTableSize)
    {
        pduSize = sizeof(NVStruct) + 4; /* escaped regular update */
    }
    else
    {
        /* Escaped alias update. Assume that host_primary is
        absent for now. */
        pduSize = (sizeof(AliasStruct) - 2) + 4;
    }
    np = (NVStruct *)(&apduPtr->data[3]);
}
/* *** END INFORMATIVE - Escaped NV Index *** */
else
{
    if (n < nmp->nvTableSize)
    {
        pduSize = sizeof(NVStruct) + 2; /* regular update */
    }
    else
    {
        /* Alias update. Assume that host_primary is absent for now. */
        /* last 2 is for index + code */
        pduSize = (sizeof(AliasStruct) - 2) + 2;
    }
    np = (NVStruct *)(&apduPtr->data[1]);
}

/* Update nv config or alias table */
if(n < nmp->nvTableSize)
{
    if (appReceiveParamPtr->pduSize >= pduSize)
    {
        memcpy(&nmp->nvConfigTable[n], np, sizeof(NVStruct));
    }
    else
    {
        /* Incorrect size */
        NMNDRespond(NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
        DeQueue(&gp->appInQ);
        return;
    }
}
else if(n < nmp->nvTableSize + nvAliasTableSize)
{
    n = n - nmp->nvTableSize; /* Alias table index */
    /* Check for various forms of alias update */
    if (((AliasStruct *)np)->primary == 0xFF &&
        appReceiveParamPtr->pduSize == pduSize)
    {
        /* host_primary missing. default to 0xffff. Null alias update. */
        ((AliasStruct *)np)->hostPrimary = 0xffff;
    }
    else if (((AliasStruct *)np)->primary == 0xFF)
    {
        /* escaped alias. hostPrimary is present */
        pduSize += 2;
    }
}

```

```

}
/* Update the nv alias table */
if (appReceiveParamPtr->pduSize >= pduSize)
{
    memcpy(&nmp->nvAliasTable[n], np, sizeof(AliasStruct));
}
else
{
    /* Incorrect size */
    NMNDRespond(NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
    DeQueue(&gp->appInQ);
    return;
}
}
else
{
    /* Invalid nv table index */
    nmp->errorLog = INVALID_NV_INDEX;
    NMNDRespond(NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
    DeQueue(&gp->appInQ);
    return;
}
}

```

```

/* Recompute checksum and send response */
RecomputeChecksum();
NMNDRespond(NM_MESSAGE, SUCCESS, appReceiveParamPtr, apduPtr);
DeQueue(&gp->appInQ);
return;

```

```

/* NM_SET_NODE_MODE:

```

| * Description | * State | * Mode | * Service LED | * Possible in ref imp? |
|---------------------------------|---------|--------|---------------|------------------------|
| * Applicationless, unconfigured | 3 | - | On | NO |
| * Unconfigured (w/application) | 2 | - | Flashing | YES |
| * Configured, Hard Offline | 6 | - | Off | NO |
| * Configured | 4 | 1 | Off | YES |
| * Configured, Soft offline | 4 | 0 | Off | YES |

```

* The NM_SET_NODE_MODE message encompasses a lot of functionality,
* and impacts some other areas of the implementation.
* 1) Mode is not maintained in EEPROM
* 2) A node that is soft-offline will go on-line when it is reset
* 3) The hard-offline state is preserved across reset
* 4) For either hard or soft offline, the scheduler is disabled
* 5) When soft-offline:
*   A) Polling an NV will return NULL data
*   B) Incoming network variable updates are handled normally
*   C) But nv_update_occurs events will be lost
* 6) In all other states except configured:
*   A) No response is returned on NV polls
*   B) Incoming NV updates are discarded
* 7) If a node is in a non-configured state, is reset and then issued
* a command to go configured, it will come up soft offline
* 8) If a set node mode message changes the mode to offline or online
* the appropriate task (if any) is executed
* 9) Changing the node state recomputes the configuration checksum
*/

```

```

case NM_SET_NODE_MODE:
/* Fail if message is not 2 or 3 bytes long. */
/* *** START INFORMATIVE - Parameter Validation *** */
/* See "START INFORMATIVE - Parameter Validation" above. */
if (appReceiveParamPtr->pduSize < 2 || appReceiveParamPtr->pduSize > 3)
{

```

```

    NMNDRespond(NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
    DeQueue (&gp->appInQ);
    return;
}
if ( (apduPtr->data[0] != 3 && (appReceiveParamPtr->pduSize < 2 ||
    appReceiveParamPtr->pduSize > 3)) ||
    (apduPtr->data[0] == 3 && appReceiveParamPtr->pduSize != 3)
)
{
    /* Incorrect size */
    NMNDRespond(NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
    DeQueue (&gp->appInQ);
    return;
}
/* *** END INFORMATIVE - Parameter Validation *** */

/* Mode on-line and mode off-line messages must not be request
messages.
if (
    (apduPtr->data[0] == 0 || apduPtr->data[0] == 1)
    &&
    appReceiveParamPtr->service == REQUEST
)
{
    /* Fail. */
    NMNDRespond(NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
    DeQueue (&gp->appInQ);
    return;
}

switch(apduPtr->data[0])
{
case 0: /* Go to soft offline state */
    if (AppPgmRuns())
    {
        OfflineEvent(); /* Indicate to application program. */
    }
    eep->readOnlyData.nodeState = CNFG_ONLINE;
    gp->appPgmMode = OFF_LINE;
    gp->ioOutputPin1 = FALSE; /* LED off */
    /* No response given as the message is not a request. */
    break;
case 1: /* Go on-line */
    OnlineEvent(); /* Indicate to application program. */
    eep->readOnlyData.nodeState = CNFG_ONLINE;
    gp->appPgmMode = ON_LINE;
    gp->ioOutputPin1 = FALSE; /* LED off */
    /* No response given as the message is not a request. */
    break;
case 2: /* Application reset */
    gp->resetNode = TRUE;
    nmp->resetCause = SOFTWARE_RESET; /* Software reset. */
    /* No response since the node is being reset. */
    break;
case 3: /* Change State */
    /* Fail if message is not 3 bytes long. */
    if (appReceiveParamPtr->pduSize != 3)
    {
        NMNDRespond(NM_MESSAGE, FAILURE,
            appReceiveParamPtr, apduPtr);
        break;
    }
    eep->readOnlyData.nodeState = apduPtr->data[1];
    /* Preserve the state of appPgmMode except for

```

```

        NO APPL UNCNFG. */
        if (eep->readOnlyData.nodeState == NO APPL UNCNFG)
        {
            gp->appPgmMode = NOT_RUNNING;
        }
        RecomputeChecksum();
        /* Respond with success if the message was a request. */
        NMNDRespond(NM_MESSAGE, SUCCESS,
                    appReceiveParamPtr, apduPtr);
        break;
    default:
        /* Let us reset the node for this case */
        gp->resetNode = TRUE;
        nmp->resetCause = SOFTWARE_RESET;
        break;
    }
    DeQueue(&gp->appInQ);
    return;
case NM_READ_MEMORY:
    HandleNMReadMemory(appReceiveParamPtr, apduPtr);
    return;
case NM_WRITE_MEMORY:
    HandleNMWriteMemory(appReceiveParamPtr, apduPtr);
    return;
case NM_CHECKSUM_RECALC:
    /* Fail if the message does not have correct size or has bad value. */
    /* *** START INFORMATIVE - Parameter Validation *** */
    /* See "START INFORMATIVE - Parameter Validation" above. */
    if (appReceiveParamPtr->pduSize != 2 ||
        (apduPtr->data[0] != 1 && apduPtr->data[0] != 4))
    {
        NMNDRespond(NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
        DeQueue(&gp->appInQ);
        return;
    }
    /* *** END INFORMATIVE - Parameter Validation *** */
    /* We don't have checksum for application. Just config checksum */
    RecomputeChecksum();
    NMNDRespond(NM_MESSAGE, SUCCESS, appReceiveParamPtr, apduPtr);
    DeQueue(&gp->appInQ);
    return;
case NM_WINK: /* Same as NM_INSTALL */
    HandleNMWink(appReceiveParamPtr, apduPtr);
    return;
case NM_MEMORY_REFRESH:
    /* *** START INFORMATIVE - Memory Refresh *** */
    /* It is acceptable to also respond with a failure to the memory
     * refresh request if the implementation does not include memory
     * that requires refreshing. An example of responding to memory
     * refresh with non failure responses is not provided here. */
    NMNDRespond(NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
    DeQueue(&gp->appInQ);
    /* *** END INFORMATIVE - Memory Refresh *** */
    return;
case NM_QUERY_SNVT:
    HandleNMQuerySIData(appReceiveParamPtr, apduPtr);
    return;
case NM_NV_FETCH:
    HandleNMNVFetch(appReceiveParamPtr, apduPtr);
    return;
case NM_MANUAL_SERVICE_REQUEST:
    /* This is unsolicited message from a node. Reference
     * implementation ignores manual service request message from other nodes
     */

```

```

    DeQueue(&gp->appInQ);
    return;
default:
    /* This is where any message that is not taken care of should be
       handled. An example is product query command. For now, we treat
       everything else as unrecognized network management message. */
    NMNDRespond(NM_MESSAGE, FAILURE, appReceiveParamPtr, apduPtr);
    DeQueue(&gp->appInQ); /* Simply discard it */
}
}

```

```

/*****

```

A.12 Configuration data structures

```

/*****
Reference: Annex B, Additional data structures

```

```
File: node.c
```

```
Version: 1.7
```

```

Purpose: Configuration Data Structures that contain
information about this node.
Also, define all type definitions needed.

```

```

Note: RefImp supports any number of stacks.
A global structure called ProtocolStackData
is defined in node.h. An array of such
structures is used so that each stack has
its own data that it works on. A global
pointer gp points to the right structure
before the stack code is executed. This
is done by the scheduler.

```

```

The support for multiple-stacks does not include support
for mac layer to handle multiple stacks or multiple application
programs. A true multi-stack system needs some extra coding.

```

```
To Do: None
```

```

/*****

```

```

/*-----
Section: Includes
-----*/

```

```

#include <stdio.h>
#include <string.h>
#include <stdlib.h>

```

```

#include <cnp_1.h>
#include <custom.h>
#include <node.h>
#include <physical.h>

```

```

/*-----

```

```
Section: Constant Definitions
-----*/

```

```

/* None */

```

```

/*-----

```

```
Section: Type Definitions

```

```

-----*/
/* None */

/*-----
Section: Globals
-----*/
EEPROM          *eep; /* actual structure is in eeprom.c */
NmMap           *nmp;
NmMap           nm[NUM_STACKS] = {{0}};
ProtocolStackData *gp;
ProtocolStackData protocolStackDataGbl[NUM_STACKS];

#if defined(ALTERNATE_STRUCTURES_NEEDED)
msg_in_type      msg_in;
msg_out_type     msg_out;
resp_in_type     resp_in;
resp_out_type    resp_out;
nv_in_addr_type nv_in_addr;
int16           nv_array_index;
#endif

/*-----
Section: Local Globals
-----*/
static uint16 bufSizeCodeLgbl[16] =
{
    255,20,20,21,22,24,26,30,34,42,50,66,82,114,146,210
};
static uint16 bufCntCodeLgbl[16] =
{
    0,1,1,2,3,5,7,11,15,23,31,47,63,95,127,191
};
static uint16 rptTimerCodeLgbl[16] =
{
    16,24,32,48,64,96,128,192,256,384,512,768,1024,1536,2048,3072
};
static uint16 rcvTimerCodeLgbl[16] =
{
    128,192,256,384,512,768,1024,1536,2048,3072,4096,6144, 8192,
    12288,16384,24576
};
static uint16 txTimerCodeLgbl[16] =
{
    16,24,32,48,64,96,128,192,256,384,512,768,1024,1536,2048,3072
};
static uint16 nonGroupTimerCodeLgbl[16] =
{
    128,192,256,384,512,768,1024,1536,2048,3072,4096,6144,8192,
    12288,16384,24576
};

/*-----
Section: Local Function Prototypes
-----*/
/* None */

/*-----
Section: Function Definitions
-----*/
/*****
Function: AccessDomain
Returns:  Address of structure corresponding to given index
Purpose:  To return the address of the structure that has domain
information for this node

```

Comments: If an invalid index is given, log error message.

```
DomainStruct *AccessDomain(uint8 indexIn)
{
    if (indexIn < MAX_DOMAINS)
    {
        return(&eep->domainTable[indexIn]);
    }
    return(NULL);
}
```

Function: UpdateDomain
Returns: None
Purpose: To Change the domain table entry with given structure.
Comments: If an invalid index is given, log error message.

```
void UpdateDomain(DomainStruct *domainInp, uint8 indexIn)
{
    if (domainInp && (indexIn < MAX_DOMAINS))
    {
        eep->domainTable[indexIn] = *domainInp;
        eep->domainTable[indexIn].cloneDomain = 1;
        return;
    }
    if (domainInp)
    {
        ErrorMsg("UpdateDomain: Invalid index.\n");
    }
    else
    {
        ErrorMsg("UpdateDomain: NULL domainInp passed.\n");
    }
}
```

Function: UpdateCloneDomain
Returns: None
Purpose: To Change the domain table entry with given structure.
Comments: If an invalid index is given, log error message.
If this fn is called, then the node can only receive
messages addressed with Unique Node ID, group unack or
broadcast addressing mode. CloneDomain is set to 0.
Clone Domain allows a node to have same subnet and node ID
as another node and yet receive messages of above types.
All messages in network have this bit set to 1.

```
void UpdateCloneDomain(DomainStruct *domainInp, uint8 indexIn)
{
    if (domainInp && (indexIn < MAX_DOMAINS))
    {
        eep->domainTable[indexIn] = *domainInp;
        eep->domainTable[indexIn].cloneDomain = 0;
        return;
    }
    if (domainInp)
    {
        ErrorMsg("UpdateDomain: Invalid index.\n");
    }
}
```



```

    }
    else
    {
        ErrorMsg("UpdateDomain: NULL domainInp passed.\n");
    }
}

/*****
Function: AccessAddress
Returns: Address of structure at given index
Reference: None
Purpose: To access address table entry
Comments: None
*****/
AddrTableEntry *AccessAddress(uint16 indexIn)
{
    if (indexIn < NUM_ADDR_TBL_ENTRIES)
    {
        return(&eep->addrTable[indexIn]);
    }
    return(NULL);
}

/*****
Function: UpdateAddress
Returns: None
Reference: None
Purpose: To update an address table entry.
Comments: None
*****/
void UpdateAddress(AddrTableEntry *addrEntryInp, uint16 indexIn)
{
    if (addrEntryInp && indexIn < NUM_ADDR_TBL_ENTRIES)
    {
        eep->addrTable[indexIn] = *addrEntryInp;
        return;
    }
    if (addrEntryInp)
    {
        nmp->errorLog = INVALID_ADDR_TABLE_INDEX;
        ErrorMsg("UpdateAddress: Invalid index.\n");
    }
    else
    {
        ErrorMsg("UpdateAddress: NULL addrEntryInp passed.\n");
    }
}

/*****
Function: IsGroupMember
Returns: TRUE if this node belongs to given group. FALSE, else.
Reference: None
Purpose: To check if a node belongs to a given group in the
        given domain. If it does, also get the member number.
Comments: If groupMemberOut is NULL, then it is not used.
*****/
Boolean IsGroupMember(Byte domainIndexIn, uint8 groupIn,
                    uint8 *groupMemberOut)
{
    uint16 i;

    for (i = 0; i < NUM_ADDR_TBL_ENTRIES; i++)
    {
        if (eep->addrTable[i].addrFormat >= 128)

```

```
{
    /* Group Format */
    if (eep->addrTable[i].groupEntry.groupID == groupIn &&
        eep->addrTable[i].groupEntry.domainIndex == domainIndexIn)
    {
        break;
    }
}
if (i == NUM_ADDR_TBL_ENTRIES)
{
    return(FALSE); /* Not Found */
}
if (groupMemberOut)
{
    *groupMemberOut = eep->addrTable[i].groupEntry.member;
}
return(TRUE); /* Found */
}
```

Function: AddrTableIndex
Returns: The index of the address table for the given domain and group. 0xFF if not found.
Reference: None
Purpose: To get the addr table index for a given group and domain. If there is no such entry in the addr table, return 0xff.
Comments: None

```
uint16 AddrTableIndex(uint8 domainIndexIn, uint8 groupIn)
{
    uint16 i;

    for (i = 0; i < NUM_ADDR_TBL_ENTRIES; i++)
    {
        if (eep->addrTable[i].addrFormat >= 128)
        {
            /* Group Format */
            if (eep->addrTable[i].groupEntry.groupID == groupIn &&
                eep->addrTable[i].groupEntry.domainIndex == domainIndexIn)
            {
                return(i);
            }
        }
    }

    return(0xFF); /* Not Found */
}
```

Function: DecodeBufferSize
Returns: Actual Buffer Size
Reference: None
Purpose: To compute the actual buffer size from code
Comments: None

```
uint16 DecodeBufferSize(uint8 bufSizeIn)
{
    if (bufSizeIn <= 15)
    {
        return(bufSizeCodeLgbl[bufSizeIn]);
    }
    errorMsg("DecodeBufferSize: Invalid code.\n");
    return(0);
}
```

```
}

/*****
Function: DecodeBufferCnt
Returns: Actual Buffer Count
Reference: NonePurpose: To compute the actual buffer count from code
Comments: None
*****/
uint16 DecodeBufferCnt(uint8 bufCntIn)
{
    if (bufCntIn <= 15)
    {
        return(bufCntCodeLGl[bufCntIn]);
    }
    ErrorMessage("DecodeBufferCnt: Invalid code.\n");
    return(0);
}

/*****
Function: DecodeRptTimer
Returns: Actual timer value in ms
Reference: None
Purpose: To compute the actual rpt timer value from code
Comments: None
*****/
uint16 DecodeRptTimer(uint8 rptTimerIn)
{
    if (rptTimerIn <= 15)
    {
        return(rptTimerCodeLGl[rptTimerIn]);
    }
    ErrorMessage("DecodeRptTimer: Invalid code.\n");
    return(0);
}

/*****
Function: DecodeRcvTimer
Returns: Actual Receive Timer value in ms
Reference: NonePurpose: To compute the actual rcv timer value in ms from code
Comments: None
*****/
uint16 DecodeRcvTimer(uint8 rcvTimerIn)
{
    if (rcvTimerIn <= 15)
    {
        return(rcvTimerCodeLGl[rcvTimerIn]);
    }
    ErrorMessage("DecodeRcvTimer: Invalid code.\n");
    return(0);
}

/*****
Function: DecodeTxTimer
Returns: Actual Transmit Timer Value in ms
Reference: NonePurpose: To compute the actual transmit timer value from code
Comments: None
*****/
uint16 DecodeTxTimer(uint8 txTimerIn)
{
    if (txTimerIn <= 15)
    {
        return(txTimerCodeLGl[txTimerIn]);
    }
    ErrorMessage("DecodeTxTimer: Invalid code.\n");
}


```

```
return(0);
}

/*****
Function: DecodeNonGroupTimer
Returns: Actual non-group timer value in ms
Reference: None
Purpose: To Compute the actual non-group timer value from code
Comments: None
*****/
uint16 DecodeNonGroupTimer(uint8 nonGroupTimerIn)
{
    if (nonGroupTimerIn <= 15)
    {
        return(nonGroupTimerCodeLGbl[nonGroupTimerIn]);
    }
    ErrorMsg("DecodeNonGroupTimer: Invalid code.\n");
    return(0);
}

/*****
Function: AccessNV
Returns: Address of NV conf table entry
Reference: None
Purpose: To Access the NV Config Table Entry given the Index
Comments: None
*****/
NVStruct *AccessNV(uint16 indexIn)
{
    if (indexIn < nmp->nvTableSize)
    {
        return(&nmp->nvConfigTable[indexIn]);
    }
    ErrorMsg("AccessNV: Invalid index.\n");
    return(NULL);
}

/*****
Function: UpdateNV
Returns: None
Reference: None
Purpose: To update an entry in NV Config Table
Comments: None
*****/
void UpdateNV(NVStruct *nvStructInp, uint16 indexIn)
{
    if (nvStructInp && indexIn < nmp->nvTableSize)
    {
        nmp->nvConfigTable[indexIn] = *nvStructInp;
        return;
    }
    if (nvStructInp)
    {
        ErrorMsg("UpdateNV: Invalid index.\n");
    }
    else
    {
        ErrorMsg("UpdateNV: NULL nvStructInp.\n");
    }
}

/*****
Function: NVTableIndex
Returns: index of NV Config Table
*****/
```

Click to view the full PDF of ISO/IEC 14908-1:2012

```

Reference: None
Purpose: To retrieve the index corresponding to a network varname.
Comments: We don't need this fn for Ref Imp. as the app pgm already
         has the index for all variables.
*****
uint16 NVTableIndex(char varNameIn[])
{
    return(0);
}

/*****
Function:  ErrorMsg
Returns:   None
Reference: None
Purpose:  To store error msgs produced by these functions.
Comments: It is just a sequence of Bytes that is large.
         If there is no more space, it wraps around and
         logs. Thus, if there are too many error logs,
         we will only have the latest ones.
         Each Log is automatically given a number.
         The output has log number followed by message.
*****
void ErrorMsg(char errMessageIn[])
{
    uint16 j, msgNumber;
    uint16 spaceNeeded;

    /* Set the starting index for copy */
    /* If there is insufficient space, wrap around */
    /* spaceNeeded includes space for the null character */
    /* header(xxx. ) + msg + \0 */
    spaceNeeded = 5 + strlen(errMessageIn) + 1;
    if (gp->errorMsgIndex + spaceNeeded > ERROR_MSG_SIZE)
    {
        gp->errorMsgIndex = 0; /* Wrap around */
    }

    /* Compute the Log Number. Make sure it is no more
       than 3 digits */
    gp->errorMsgNumber++;
    if (gp->errorMsgNumber > 999)
    {
        gp->errorMsgNumber = 1;
    }
    msgNumber = gp->errorMsgNumber;

    j = gp->errorMsgIndex;
    sprintf(gp->errorMsg + j, "%3d. ", msgNumber);
    j = j + 5;

    /* Write the message */
    strcpy(gp->errorMsg + j, errMessageIn);

    /* Update errorMsgIndex. Don't count the space for null char */
    gp->errorMsgIndex = gp->errorMsgIndex + spaceNeeded - 1;
}

/*****
Function:  DebugMsg
Returns:   None
Reference: None
Purpose:  To Print Debugging Messages for stacks.
Comments: Actually not recorded anywhere. One needs to set
         breakpoint at the end of this fn and print temp

```

```
to see the msg.
*****
void DebugMsg(char debugMsgIn[])
{
    char temp[200];
    uint8 i;

    if (strlen(debugMsgIn) > 170)
    {
        return; /* Too large for temp. Ignore it. */
    }

    /* Find our Stack # */
    for (i = 0; i < NUM_STACKS; i++)
    {
        if (gp == &protocolStackDataGbl[i])
        {
            break;
        }
    }
    sprintf(temp, "Time:%5u: Stack %2d: ", GetCurrentMsTime(), i+1);
    strcpy(temp + strlen(temp), debugMsgIn);
}

*****
Function: AllocateStorage
Returns: Pointer to data storage allocated or NULL
Reference: None
Purpose: A Simple version of storage allocator similar to malloc.
         A Global array is used to allocate the storage.
         If no more space, NULL is returned.
Comments: There is no function similar to free. There is no need
         for such a function in the Reference Implementation.
*****
void *AllocateStorage(uint16 sizeIn)
{
    Byte *ptr;

    if (gp->mallocUsedSize + sizeIn > MALLOC_SIZE)
    {
        nmp->errorLog = MEMORY_ALLOC_FAILURE;
        return(NULL); /* No space for requested size */
    }

    ptr = gp->mallocStorage + gp->mallocUsedSize;
    gp->mallocUsedSize += sizeIn;

    return(ptr);
}

*****
Function: GetCurrentTime
Returns: Current Time (not necessarily real time)
Reference: None
Purpose: To get the current time.
Comments: None
*****
uint32 GetCurrentTime(void)
{
    return(*(gp->currentTime));
}

*****
Function: GetCurrentMsTime
```

ECNTRIP.COM Click to view the PDF of ISO/IEC 14908-1:2012

Returns: Current Time (not necessarily real time)

Reference: None

Purpose: To get the current time.

Comments: None

```

*****
uint32 GetCurrentMsTime(void)
{
    return(*(gp->currentTime)/CLOCK_TICKS_PER_MS);
}

```

Function: SetMsTimer

Returns: None

Reference: None

Purpose: To set a timer value to a given value in ms.

Comments: The timer is set to given value. The lastUpdateTime is set to current time. UpdateTimer is called later to update the timer value.

```

*****
void SetMsTimer(MsTimer *timerOut, uint16 initValueIn)
{
    timerOut->curTimerValue = initValueIn * CLOCK_TICKS_PER_MS;
    timerOut->lastUpdatedTime = GetCurrentTime();
    /* If the initial value is 0, then we assume that the timer is
       actually disabled. */
    if (initValueIn > 0)
    {
        timerOut->expired = FALSE;
    }
    else
    {
        timerOut->expired = TRUE;
    }
}

```

Function: UpdateMsTimer

Returns: None

Reference: None

Purpose: To Update a timer value.

Comments: Get CurrentTime. See the difference between cur time and last updated time. Subtract that qty from timer value. Make sure that the timer value is not reduced below 0 (that will make it a big positive).

```

*****
void UpdateMsTimer(MsTimer *timerInOut)
{
    uint32 curTime, elapsedTime;

    if (timerInOut->curTimerValue == 0)
    {
        return; /* Already expired. */
    }
}

```

/* Since the timer values are unsigned, C guarantees that simple subtraction will give the right value even if the timer has already wrapped. We just have to make sure that we update the timer within one cycle of the clock. For 32 bit clock, this is long enough and hence no problem. */

```

curTime = GetCurrentTime();
elapsedTime = curTime - timerInOut->lastUpdatedTime;
if (elapsedTime >= timerInOut->curTimerValue)
{
    timerInOut->curTimerValue = 0;
}

```

```

    }
    else
    {
        timerInOut->curTimerValue -= elapsedTime;
    }

    timerInOut->lastUpdatedTime = curTime;
}

/*****
Function: MsTimerExpired
Returns: TRUE if the timer has expired. FALSE if the timer has
        not expired or it has expired but has already been
        reported as expired.
Reference: None
Purpose: To update given timer and test if it expired.
Comments: None
*****/
Boolean MsTimerExpired(MsTimer *timerInOut)
{
    if (timerInOut->curTimerValue > 0)
    {
        UpdateMsTimer(timerInOut); /* Not expired. First update it. */
    }
    if (timerInOut->expired)
    {
        return(FALSE); /* Already expired. */
    }
    if (timerInOut->curTimerValue == 0)
    {
        /* First time expiry. */
        timerInOut->expired = TRUE; /* Remember this expiry */
        return(TRUE);
    }
    return(FALSE); /* Not expired yet */
}

/*****
Function: NodeReset
Returns: None
Reference: None
Purpose: Initialization of node data structures.
Comments:
*****/
void NodeReset(Boolean firstReset)
{
    void APPReset(void), TCSReset(void), TSAReset(void),
        NWRReset(void), LKReset(void), PHYReset(void);
    void AppReset(void);
    uint32 seed;
#ifdef SIMULATION
    uint32 *StackTimerInit(void);
#endif
    int i;

#ifdef SIMULATION
    if (!firstReset)
    {
        PHYDisableSPMIsr();
    }
#endif

    /* Init variables that are not in EEPROM */

```



```

memset(&nmp->stats, 0, sizeof(StatsStruct));
if (firstReset)
{
    nmp->errorLog      = NO_ERRORS;
}
nmp->pxyData.pxyType = -1;
gp->errorMsgIndex   = 0;
gp->errorMsgNumber   = 0;
gp->softwareTime     = 0;
gp->prevPinState[0] = 0;

#ifdef SIMULATION
    gp->currentTime   = &gp->softwareTime;
#else
    if (firstReset)
    {
        gp->currentTime = StackTimerInit();
    }
#endif
/* A node in soft off-line state should go on-line state */
if (eep->readOnlyData.nodeState == CNFG_ONLINE && gp->appPgmMode == OFF_LINE)
{
    gp->appPgmMode = ON_LINE; /* Normal state. on-line. */
}

/* If a node is reset while in unconfigured state, it will come back in
offline mode when asked to go configured later. */
if (NodeUnConfigured())
{
    gp->appPgmMode = OFF_LINE;
}

/* First, Let each layer determine the address of all its
data structures */
gp->mallocUsedSize = 0;

APPReset(); /* Application Layer */
if (!gp->resetOk)
{
    return;
}
TCSReset();
if (!gp->resetOk)
{
    return;
}
TSAReset();
if (!gp->resetOk)
{
    return;
}
NWRReset();
if (!gp->resetOk)
{
    return;
}
LKRReset();
if (!gp->resetOk)
{
    return;
}
PHYReset();

```

```
    if (!gp->resetOk)
    {
        return;
    }

    /* Call this function last as this function can call functions
       that will use data structures that should already exist. */
    AppReset(); /* Application Program Reset */
    if (!gp->resetOk)
    {
        return;
    }

#ifdef SIMULATION
    if (firstReset)
    {
        PHYInitSPM();
    }
    else
    {
        PHYEnableSPMIsr();
    }
#endif

    if (firstReset)
    {
        gp->prevChallenge[i] = 0; /* Init prevRand. Don't change during */
                                /* other reset. */
    }

    /* Init Seed to some unpredictable value at start */
    seed = 0;
#ifdef SIMULATION
    seed = GetCurrentTime(); /* Current Value of Timer */
#endif
    srand((unsigned int) seed);

    if (nmp->resetCause == EXTERNAL RESET || nmp->resetCause == POWER UP RESET)
    {
        SetMsTimer(&gp->tsDelayTimer, TS_RESET_DELAY_TIME);
    }
    else
    {
        SetMsTimer(&gp->tsDelayTimer, 0); /* Disable */
    }
    gp->resetNode = FALSE;
}

/*****
Function: InitEEPROM
Returns: None
Reference: None
Purpose: To initialize the EEPROM data items based on constants
         in custom.h and values set in custom.c
Comments: Incomplete Initialization. Make sure it has the var you
         want or else add it here or in custom.h or custom.c
         depending on where it fits.
*****/
void InitEEPROM(void)
{
    int i;
    char *p;

    /* Init the entire readOnlyData to 0 first. */

```



```
memset(&eep->readOnlyData, 0, sizeof(eep->readOnlyData));
/* Init the entire configData to 0 first. */
memset(&eep->configData, 0, sizeof(eep->configData));
```

```
/* Init Based on custom.h and default values */
eep->readOnlyData.modelNum = MODEL_NUM;
eep->readOnlyData.minorModelNum = MINOR_MODEL_NUM;
eep->readOnlyData.checkSum = 0;
```

```
eep->readOnlyData.nvFixed[0] = 0xFF; /* not useful */
eep->readOnlyData.nvFixed[1] = 0xFF;
```

```
eep->readOnlyData.runWhenUnconf = RUN_WHEN_UNCONF;
eep->readOnlyData.nvCount = 0;
/* MIP uses 0xFFFF for snvtStruct field. p 9-8 */
eep->readOnlyData.snvtStruct[0] = 0xFF;
eep->readOnlyData.snvtStruct[1] = 0xFF;
eep->readOnlyData.nodeState = CNFG_ONLINE;
/* NUM_ADDR_TBL_ENTRIES can be larger than 15, but
addressCnt is set to min(15, NUM_ADDR_TBL_ENTRIES).
The remaining entries are not seen by the lonbuilder tool */
eep->readOnlyData.addressCnt =
(NUM_ADDR_TBL_ENTRIES <= 15)?NUM_ADDR_TBL_ENTRIES:15;
eep->readOnlyData.receiveTransCnt =
(RECEIVE_TRANS_COUNT < 16)?RECEIVE_TRANS_COUNT-1:15;
eep->readOnlyData.appOutBufSize = APP_OUT_BUF_SIZE;
eep->readOnlyData.appInBufSize = APP_IN_BUF_SIZE;
eep->readOnlyData.nwOutBufSize = NW_OUT_BUF_SIZE;
eep->readOnlyData.nwInBufSize = NW_IN_BUF_SIZE;
eep->readOnlyData.nwOutBufPriCnt = NW_OUT_PRI_Q_CNT;
eep->readOnlyData.appOutBufPriCnt = APP_OUT_PRI_Q_CNT;
eep->readOnlyData.appOutBufCnt = APP_OUT_Q_CNT;
eep->readOnlyData.appInBufCnt = APP_IN_Q_CNT;
eep->readOnlyData.nwOutBufCnt = NW_OUT_Q_CNT;
eep->readOnlyData.nwInBufCnt = NW_IN_Q_CNT;
eep->readOnlyData.msgTagCnt = 0;
```

```
eep->readOnlyData.readWriteProtect = READ_WRITE_PROTECT;
eep->readOnlyData.txByAddress = 0;
eep->readOnlyData.aliasCnt = 0; /* Host based node */
```

```
/* Initialize configData */
eep->configData.channelId = 0;
eep->configData.commClock = 3;
eep->configData.inputClock = 5;
eep->configData.commType = SPECIAL_PURPOSE;
eep->configData.commPinDir = 0x1E; /* 0x17 if wake-up pin is input */
eep->configData.reserved[0] = 0x00; /* for special purpose mode. */
eep->configData.reserved[1] = 0x3F; /* packet_cycle */
eep->configData.reserved[2] = 0xA6; /* beta2 control */
eep->configData.reserved[3] = 0x77; /* xmit_interpacket */
eep->configData.reserved[4] = 0x67; /* recv_interpacket */
eep->configData.nodePriority = 1; /* 0-255. 0 => no priority slot. */
eep->configData.channelPriorities = 8; /* 0-255 */
eep->configData.param.xcvrParams[0] = 0x0e;
eep->configData.param.xcvrParams[1] = 0x01;
eep->configData.param.xcvrParams[2] = 0;
eep->configData.param.xcvrParams[3] = 0;
eep->configData.param.xcvrParams[4] = 0;
eep->configData.param.xcvrParams[5] = 0;
eep->configData.param.xcvrParams[6] = 0;
/* dirParams only used for direct mode not special purpose mode */
/* eep->configData.param.dirParams.bitSyncThreshHold = 1; */
```

```

eep->configData.nonGroupTimer      = NON_GROUP_TIMER;
eep->configData.nmAuth              = NM_AUTH;
eep->configData.preemptionTimeout   = 0;

/* Initializaiton based on custom.c */
memcpy(eep->readOnlyData.uniqueNodeId, cp->uniqueNodeId, UNIQUE_NODE_ID_LEN);
eep->readOnlyData.twoDomains = cp->twoDomains;
memcpy(eep->readOnlyData.progId, cp->progId, ID_STR_LEN);
memcpy(eep->configData.location, cp->location, LOCATION_LEN);
for (i = 0; i <= cp->twoDomains; i++)
{
    eep->domainTable[i].len = cp->len[i];
    memcpy(eep->domainTable[i].domainId, cp->domainId[i],
           cp->len[i]);
    eep->domainTable[i].subnet = cp->subnet[i];
    eep->domainTable[i].node   = cp->node[i];
    eep->domainTable[i].cloneDomain = 1;
    memcpy(eep->domainTable[i].key, cp->key[i], AUTH_KEY_LEN);
}
/* Init Address Table based on custom.c */
for (i = 0; i < NUM_ADDR_TBL_ENTRIES; i++)
{
    memcpy(&eep->addrTable[i], &cp->addrTbl[i], 5);
}

/* Init Alias Table based in custom.c */
/* Since C initializes missing elements with 0 we use
any non-zero value for hostPrimary field to indicate that
we did initialize an entry. We don't need 0 anyway for
hostPrimary as we can use primary for such entries. */

for (i = 0; i < NV_ALIAS_TABLE_SIZE; i++)
{
    memcpy(&nmp->nvAliasTable[i], &cp->aliasTbl[i], 6);
}

nmp->nvTableSize = 0;

/* Initialize Alias Tables that are not initialized in custom.h */
for (i = 0; i < NV_ALIAS_TABLE_SIZE; i++)
{
    /* Init only those that are not given meaningful values
in custom.h */
    if (nmp->nvAliasTable[i].hostPrimary != 0)
    {
        continue; /* Skip this as it was initialized in custom.c */
    }

    p = (char *) &nmp->nvAliasTable[i];
    *p      = (char) 0x70;
    *(p + 1) = (char) 0x00;
    *(p + 2) = (char) 0x0F;
    *(p + 3) = (char) 0xFF;
    *(p + 4) = (char) 0xFF;
    *(p + 5) = (char) 0xFF;
}

/*****
Function:  GetPrimaryIndex
Returns:  The primary index of the given variable.
Reference: None
Purpose:  To compute the primary index
Comments: Given index can be either primary or alias.
*****/

```

```

*****/
int16 GetPrimaryIndex(int16 nvIndex)
{
    int16 primaryIndex;
    uint16 nvAliasTableSize;

    /* Fetch the alias table size */
    nvAliasTableSize = nmp->snvt.aliasPtr->hostAlias;

    if (nvIndex < 0 || nvIndex >= nmp->nvTableSize + nvAliasTableSize)
    {
        return(-1); /* Bad index value. */
    }

    if (nvIndex < nmp->nvTableSize)
    {
        primaryIndex = nvIndex; /* Primary index itself. */
    }
    else
    {
        nvIndex = nvIndex - nmp->nvTableSize; /* Get alias table index. */
        /* Compute the primary index. */
        primaryIndex = nmp->nvAliasTable[nvIndex].primary;
        if (primaryIndex == 0xFF)
        {
            primaryIndex = nmp->nvAliasTable[nvIndex].hostPrimary;
        }
        if (primaryIndex >= nmp->nvTableSize)
        {
            return(-1); /* Bad index in alias structure. */
        }
    }
    return(primaryIndex);
}

/*****
Function: GetNVStructPtr
Returns: Pointer to the network variable structure.
Reference: None
Purpose: To compute the pointer to the network variable structure.
Comments: The given index can be either primary or alias.
*****/
NVStruct *GetNVStructPtr(int16 nvIndexIn)
{
    uint16 nvAliasTableSize;

    /* Fetch the alias table size */
    nvAliasTableSize = nmp->snvt.aliasPtr->hostAlias;

    if (nvIndexIn < 0 || nvIndexIn >= nmp->nvTableSize + nvAliasTableSize)
    {
        return(NULL); /* Bad index value. */
    }

    if (nvIndexIn < nmp->nvTableSize)
    {
        return(&nmp->nvConfigTable[nvIndexIn]);
    }

    return(&nmp->nvAliasTable[nvIndexIn - nmp->nvTableSize].nvConfig);
}

/*****
Function: CheckSum4

```

Returns: 4 bit checksum of a given data.

Reference: None

Purpose: To Compute the checksum of an array of bytes of a given length. The check sum is the successive application of exclusive or of successive 4 bits.

Comments: None

```

*****
uint8 CheckSum4(void *dataIn, uint16 lengthIn)
{
    unsigned char *p;
    uint16 i;
    uint8 result = 0; /* Final checksum in low order 4 bits. */

    p = dataIn;
    for (i = 0; i < lengthIn; i++)
    {
        result = result ^ (*p >> 4); /* exclusive or with high order
                                        4 bits */
        result = result ^ (*p & 0x0F); /* With low order 4 bits */
        p++;
    }
    return(result);
}

```

Function: CheckSum8

Returns: 8 bit checksum of a given data

Reference: None

Purpose: To compute the checksum of an array of bytes of a given length. The check sum is the successive application of exclusive or of successive 4 bits.

Comments: None

```

*****
uint8 CheckSum8(void *dataIn, uint16 lengthIn)
{
    unsigned char *p;
    uint16 i;
    uint8 result = 0; /* Final checksum */

    p = dataIn;
    for (i = 0; i < lengthIn; i++)
    {
        result = result ^ *p;
        p++;
    }
    return(result);
}

```

Function: ComputeConfigChecksum

Returns: The configuration checksum.

Reference: None

Purpose: To compute the configuration checksum.

Comments: Do not include reserved portion as it does not have any configuration data. Since, reference implementation has nv tables in nmp structure rather than EEPROM, we should include them in the computation.

```

*****
uint8 ComputeConfigChecksum(void)
{
    uint8 checkSum;
    uint16 size;

    size = (char *)&eep->addrTable[NUM_ADDR_TBL_ENTRIES] - (char *)eep;

```



```

    checksum = CheckSum8(eep, size);
    size = (char *)&nmp->nvFixedTable[NV_TABLE_SIZE] -
           (char *)&nmp->nvConfigTable[0] + 2;
    checksum = checksum ^ CheckSum8(&nmp->nvConfigTable, size);
    return(checksum);
}

/*****
Function: IOChanges
Returns:  TRUE if the state of input pin changed.
Reference: None
Purpose:  To determine whether there is a state change in input
          Pin 0.
Comments: None
*****/
Boolean IOChanges(uint8 pinNumberIn)
{
    if (pinNumberIn != 0)
    {
        return(FALSE); /* Only Input Pin 0 is supported for now */
    }

    if (gp->prevPinState[0] == 0 && gp->ioInputPin0)
    {
        /* Prev state = released curstate = pressed */
        gp->prevPinState[0] = 1;
        return(TRUE);
    }
    if (gp->prevPinState[0] == 1 && !gp->ioInputPin0)
    {
        /* prevstate = pressed and curstate = released */
        gp->prevPinState[0] = 0;
        return(TRUE);
    }
    return(FALSE);
}

Boolean IsTagBound(uint8 tagIn)
{
    return(tagIn < nmp->snvt_mtagCount &&
           tagIn < NUM_ADDR_TBL_ENTRIES &&
           eep->addrTable[tagIn].addrFormat != UNBOUND);
}

/*****
Function: IsNvBound
Returns:  TRUE if the variable is bound. FALSE otherwise.
Purpose:  To determine if a primary variable is bound or not.
Comment:  A variable is bound if its address index is not 0xF
          or there is an alias attached to it whose address
          index is not 0xF.
*****/
Boolean IsNVBound(int16 nvIndexIn)
{
    uint16 i;
    int16 primaryIndex;
    uint16 addrIndex;
    uint16 nvAliasTableSize;

    if (nvIndexIn < 0 || nvIndexIn >= nmp->nvTableSize)
    {
        return(FALSE); /* not an index of a primary network variable */
    }
}

```

```

/* If the primary has a valid address table index and the address
   table entry is not unbound, then the variable is bound */
addrIndex = nmp->nvConfigTable[nvIndexIn].nvAddrIndex;
if ( addrIndex != 0x0F &&
     (eep->addrTable[addrIndex].addrFormat != UNBOUND ||
      eep->addrTable[addrIndex].turnaEntry.turnaround == 1) )
{
    return(TRUE);
}

nvAliasTableSize = nmp->snvt.aliasPtr->hostAlias;

/* Primary is not bound. See if there is an alias for this variable
   that is bound. */
for (i = 0; i < nvAliasTableSize; i++)
{
    primaryIndex = GetPrimaryIndex(i + nmp->nvTableSize);
    addrIndex = nmp->nvAliasTable[i].nvConfig.nvAddrIndex;
    /* If the alias matches the primary, has a valid address table
       index and the address table entry is not UNBOUND, then
       the primary variable is bound */
    if (primaryIndex == nvIndexIn &&
        addrIndex != 0x0F &&
        (eep->addrTable[addrIndex].addrFormat != UNBOUND )
        eep->addrTable[addrIndex].turnaEntry.turnaround == 1) )
    {
        return(TRUE);
    }
}
return(FALSE); /* No alias entry for this primary that is bound. */
}

/*****
Function: AppPgmRuns
Returns: TRUE if the application program is running on the node.
        FALSE otherwise.
Purpose: To determine whether the application program is running or not.
        This is used to determine whether to deliver messages, responses,
        and events to the application. Also used to determine whether
        to call DoApp or not.
*****/
Boolean AppPgmRuns(void)
{
    /* Normal Mode. Configured and running. */
    if (eep->readOnlyData.nodeState == CNFG_ONLINE &&
        gp->appPgmMode == ON_LINE)
    {
        return(TRUE);
    }

    /* Unconfigured and running. */
    if (eep->readOnlyData.nodeState == APPL_UNCNFG &&
        eep->readOnlyData.runWhenUnconf &&
        gp->appPgmMode == ON_LINE)
    {
        return(TRUE);
    }

    return(FALSE);
}

/*****
Function: NodeConfigured
Returns: TRUE if the node configured is valid.
*****/

```

```

Purpose: To determine whether currently the node is configured.
*****/
Boolean NodeConfigured(void)
{
    return(eep->readOnlyData.nodeState == CNFG_ONLINE ||
           eep->readOnlyData.nodeState == CNFG_OFFLINE);
}

/*****
Function: NodeUnConfigured
Returns: TRUE if the node is configured.
Purpose: To determine whether currently node is unconfigured.
*****/
Boolean NodeUnConfigured(void)
{
    return(eep->readOnlyData.nodeState == APPL_UNCNFG ||
           eep->readOnlyData.nodeState == NO_APPL_UNCNFG);
}

/*****End of node.c*****/

```

A.13 Include files for the reference implementation

```

/*****
File:      cnp_1.h
Version:   1.7
Purpose:   To define constants and types that are needed
           by all files. Most .c files will include
           cnp_1.h either directly or indirectly.
Note:     Reference implementation does not support
           special purpose nodes such as routers, repeaters
           etc. Additional code is required to implement
           these nodes.
To Do:    None.
*****/
#ifndef _CNP_1_H
#define _CNP_1_H

/-----
Section: Includes
-----*/
/* None */

/-----
Section: Macro Definitions
-----*/
#define MIN(x,y) (((x)<(y))?(x):(y))
#define MAX(x,y) (((x)>(y))?(x):(y))
#define INCR_STATS(x) ((x < (uint16)0xFFFF)?x++:x)

/-----
Section: Constant Definitions
-----*/
/* Reference implementation supports the use of alternate structures such
   as msg_in, msg_out etc for ease of porting application
   programs. However, the disadvantage is the extra copy needed to
   use these structures. Uncomment this constant if you do not want
   to use the alternate structures (i.e you prefer to use reference implementation
   structures that use a different naming convention.) */

```

```

#define ALTERNATE_STRUCTURES_NEEDED

#define UNIQUE_NODE_ID_LEN 6 /* Length of the Unique Node Id. */
#define ID_STR_LEN 8 /* Length of the program id string. */
#define AUTH_KEY_LEN 6 /* Length of the authentication key. */
#define DOMAIN_ID_LEN 6 /* Maximum length for a domain id. */
#define LOCATION_LEN 6 /* Maximum length for location string. */
#define NUM_COMM_PARAMS 7 /* Max # of parameters for a tranceiver. */
#define PROTOCOL_VERSION 0 /* 0 for reference implementaion. */
#define MAX_DOMAINS 2 /* Maximum # of domains allowed. */

/* Set the size of the array to log error messages from the protocol stack.
   The error messages wrap around, if there are too many errors.
   Errors seldom happen. So, there is no need for this to be too large. */
#define ERROR_MSG_SIZE 1 000 /* 20 messages each with 50 chars */

#define FLEX_DOMAIN 2 /* Indicates that the message was received
   in flex domain when domain index is 2 */
#define COMPUTE_DOMAIN_INDEX 3 /* When application layer communicates
   with transport or session layer,
   the domainIndex for the outgoing message
   can be either set by the application layer
   or computed by transport or session layer
   based on the destination address.
   This value is used only in TSASenParam
   structure. */
#define MAX_GROUP_NUMBER 63 /* Maximum number of a node in a group */

/*-----
Section: Type Definitions
-----*/

/* The following type definitions need to be changed based on the
   compiler used. The rest of the files should use only int8,
   int16, uint8 etc. Application programs should use
   nint (8-bit int), nlong etc as much as possible. */
typedef char int8;
typedef short int int16;
typedef long int int32;
typedef unsigned char uint8;
typedef unsigned short int uint16;
typedef unsigned long int uint32;

/* Typical definitions for int long etc. */
typedef int8 nshort;
typedef int8 nint;
typedef uint8 nuint;
typedef uint8 nushort;
typedef int16 nlong;
typedef uint16 nulong;

typedef unsigned char Byte;
typedef unsigned char Bits;
typedef int16 MsgTag; /* Lots of Tags!!! */

/* This type definition may need #ifndef macro wrapped
   around when porting to other platforms. */
typedef enum
{
    FALSE = 0,
    TRUE = 1
} Boolean;

typedef Boolean boolean; /* For nc compatibility. */

```

```

typedef enum
{
    NOBIND = 0,
    NON_BINDABLE = 0, /* Same as NOBIND. */
    BIND = 1,
    BINDABLE = 1 /* Same as BIND. */
} BindNoBind;

typedef enum
{
    NV_INPUT = 0,
    NV_OUTPUT = 1
} NVDirection;

/* Address Types. */
typedef enum
{
    UNBOUND = 0,
    SUBNET_NODE = 1,
    UNIQUE_NODE_ID = 2,
    BROADCAST = 3,
    MULTICAST = 4,
    MULTICAST_ACK = 5,
    BROADCAST_GROUP = 0x23 /* Used for broadcast req/resp requiring
                             up to N responses to be delivered. */
} AddrMode;

/* In the reference implementation, the application is always loaded
when downloading the code into the system. There is no provision
to download application program from management tools. However,
application can be placed in offline by calling GoOffline fn.
Thus the node state NO APPL UNCNFG is not possible.
gp->appPgmMode indicates the state of the application program. */
typedef enum
{
    /* For nodeState */
    APPL_UNCNFG = 2, /* Application is loaded but conf is not */
    NO_APPL_UNCNFG = 3, /* Application is not loaded yet or bad */
    CNFG_ONLINE = 4, /* Normal operation mode */
    CNFG_OFFLINE = 6, /* same as hard offline state */
    HARD_OFFLINE = 6,
    SOFT_OFFLINE = 0xC, /* For reporting purpose */
    CNFG_BYPASS = 0x8C /* Not supported in reference imp. */
} NodeState;

/* These constants are used to represent the mode when the node is
configured. */
typedef enum
{
    OFF_LINE = 0, /* For soft off-line */
    ON_LINE = 1, /* For normal mode */
    NOT_RUNNING = 2 /* For hard-offline. Not used in reference impl.
                    unless commanded to enter this state. */
} ConfigMode;

/* The order of the first 4 items is important as it is used by
network layer to determine the type of PDU. */

```

```

typedef enum
{
    /* Do not change the order. The values are sent across the network */
    TPDU_TYPE,
    SPDU_TYPE,
    AUTHPDU_TYPE,
    APDU_TYPE,

    /* Something extra for internal use of the protocol stack */
    NPDU_TYPE,
    LPDU_TYPE,
} PDUType;

/* Services offered to application program. These are not sent over
the network */
typedef enum
{
    ACKD, /* Transport Layer */
    UNACK_RPT, /* Transport Layer */
    UNACKD, /* Network Layer */
    REQUEST, /* Session Layer */

    RESPONSE /* Session Layer. Used by resp_send function */
} ServiceType;

/* Tranceiver types. Only the constants are used */
typedef enum
{
    BLANK = 0,
    SINGLE_ENDED = 1,
    SPECIAL_PURPOSE = 2,
    DIFFERENTIAL = 5
} TranceiverType;

/* Return status for all functions. */
typedef enum
{
    SUCCESS = 0,
    FAILURE = 1,
    INVALID = 2
} Status;

/* Reset cause */
typedef enum
{
    POWER_UP_RESET = 0x01,
    EXTERNAL_RESET = 0x02,
    WATCHDOG_RESET = 0x0C,
    SOFTWARE_RESET = 0x14,
    CLEARED = 0x00
} ResetCause;

/* Turn alignment on so that structures packed tightly */
#pragma maxalign(1)

/* Software Timer definition. */
typedef struct
{
    uint32 curTimerValue; /* Number of clock ticks left in timer. */
    uint32 lastUpdatedTime; /* The time when the timer was last updated. */
    Boolean expired; /* TRUE => it has already expired. */
} MsTimer;

```