![ISO logo]

International Standard

ISO 15360-3

Recycled pulps — Estimation of stickies and plastics —

Part 3:
Determination and identification by applying near-infrared measurement

First edition
2024-05

Contents

Page

Foreword

ISO (the International Organization for Standardization) is a worldwide federation of national standards bodies (ISO member bodies). The work of preparing International Standards is normally carried out through ISO technical committees. Each member body interested in a subject for which a technical committee has been established has the right to be represented on that committee. International organizations, governmental and non-governmental, in liaison with ISO, also take part in the work. ISO collaborates closely with the International Electrotechnical Commission (IEC) on all matters of electrotechnical standardization.

The procedures used to develop this document and those intended for its further maintenance are described in the ISO/IEC Directives, Part 1. In particular, the different approval criteria needed for the different types of ISO document should be noted. This document was drafted in accordance with the editorial rules of the ISO/IEC Directives, Part 2 (see www.iso.org/directives).

ISO draws attention to the possibility that the implementation of this document may involve the use of (a) patent(s). ISO takes no position concerning the evidence, validity or applicability of any claimed patent rights in respect thereof. As of the date of publication of this document, ISO had not received notice of (a) patent(s) which may be required to implement this document. However, implementers are cautioned that this may not represent the latest information, which may be obtained from the patent database available at www.iso.org/patents. ISO shall not be held responsible for identifying any or all such patent rights.

Any trade name used in this document is information given for the convenience of users and does not constitute an endorsement.

For an explanation of the voluntary nature of standards, the meaning of ISO specific terms and expressions related to conformity assessment, as well as information about ISO's adherence to the World Trade Organization (WTO) principles in the Technical Barriers to Trade (TBT), see www.iso.org/iso/foreword.html.

This document was prepared by Technical Committee ISO/TC 6, *Paper, board and pulps*.

A list of all parts in the ISO 15360 series can be found on the ISO website.

Any feedback or questions on this document should be directed to the user's national standards body. A complete listing of these bodies can be found at www.iso.org/members.html.

Introduction

Tacky particles, commonly named stickies, are a major issue in paper recycling since they can affect the processes as well as the quality of the recycled products. Therefore, a variety of test methods have been developed over decades. Existing laboratory test procedures for sticky contaminants in pulps made from paper for recycling or in recycled papers require an elaborate sample preparation to increase the concentration of these sticky contaminants by screening the pulp through a slotted plate and analysing the rejects. With the test procedure and equipment based on this document, the content of sticky contaminants can be determined at a laboratory handsheet or at the paper by means of near-infrared (NIR) measurement but also on filter paper where stickies have been concentrated and deposited with existing test procedures.

The approach to the measurements specified in this document is different from established test methods because the amount and chemical composition of polymeric substances are determined by applying NIR measurements. The content of these substances, which are typical constituents of adhesives are assigned as stickies. This is a further major difference from existing methods, which typically analyse the sticky behaviour, but not the chemical composition. The results determined by applying the method specified in this document correlate very well with established sticky measurement techniques, e.g. ISO 15360-2 or INGEDE Method 4.[1] The measurement procedure in this document also enables to simultaneously analyse polymeric substances without tacky behaviour, typically called "plastics" in other methods.

The method described here can be implemented by any system that combines particle size measurement and NIR analysis. For example, "3DStick"[2,3] involves laser triangulation to determine size and location of particles and subsequent NIR to determine chemical composition. Alternatively, direct camera imaging in the NIR spectrum has been used to both locate and identify the chemical composition of particles.[4] This method can prove valuable for online measurement in systems that generate dry sheet samples[5].

Recycled pulps — Estimation of stickies and plastics —

Part 3:
Determination and identification by applying near-infrared measurement

1 Scope

This document specifies a method for the determination of stickies and non-tacky polymeric contaminants present in pulp or paper sheets near-infrared measurement. This document is applicable to recycled pulps and papers.

Sampling of pulp and paper as well as the preparation of handsheets are outside the scope of this document.

2 Normative references

The following documents are referred to in the text in such a way that some or all of their content constitutes requirements of this document. For dated references, only the edition cited applies. For undated references, the latest edition of the referenced document (including any amendments) applies.

ISO 216, *Writing paper and certain classes of printed matter — Trimmed sizes — A and B series, and indication of machine direction*

ISO 534, *Paper and board — Determination of thickness, density and specific volume*

ISO 536, *Paper and board — Determination of grammage*

ISO 4119, *Pulps — Determination of stock concentration*

ISO 5263-2, *Pulps — Laboratory wet disintegration — Part 2: Disintegration of mechanical pulps at 20 degrees C*

ISO 5269-1, *Pulps — Preparation of laboratory sheets for physical testing — Part 1: Conventional sheet-former method*

ISO 5269-2, *Pulps — Preparation of laboratory sheets for physical testing — Part 2: Rapid-Köthen method*

ISO 5270, *Pulps — Laboratory sheets — Determination of physical properties*

ISO 15360-1, *Recycled pulps — Estimation of Stickies and Plastics — Part 1: Visual method*

ISO 15360-2, *Recycled pulps — Estimation of Stickies and Plastics — Part 2: Image analysis method*

3 Terms and definitions

For the purposes of this document, the following terms and definitions apply.

ISO and IEC maintain terminology databases for use in standardization at the following addresses:

— ISO Online browsing platform: available at https://www.iso.org/obp

— IEC Electropedia: available at https://www.electropedia.org/

3.1
stickies
diverse group of materials in disintegrated pulp that can adhere to objects at ambient temperature or can adopt adhesive characteristics when subjected to elevated temperature, elevated pressure or change of pH

[SOURCE: ISO 4046-2:2016, 2.61, modified — two instances of the word "may" replaced with "can".]

3.2
non-tacky polymeric contaminant
polymeric substance that is usually not found in adhesives, excluding cellulosic materials and inorganic substances

Note 1 to entry: ISO 15360-2 defines these substances as "plastics".

4   Principle

This document specifies the determination of the chemical composition of an air dry paper sample applying a near-infrared (NIR) analysis system. The sample to be analysed can have various origins – pulp, paper machine, pilot plant, laboratory etc. – but shall be made using recycled fibres. The surface areas of particles, which are neither natural fibres nor inorganic substances are determined. The measurement differentiates between stickies or non-tacky polymeric contaminants according to their chemical nature.

5   Apparatus (near-infrared analysis system)

5.1   Hardware (measuring device)

The measuring device is a hyperspectral NIR imaging system. The illumination device, optics and sensor shall cover at least the spectral range from 1 400 nm to 1 800 nm. The optical system has a lateral resolution of at least 127 DPI (i. e. object pixel size ≤200 μm). The optical system may be of the wide-field type, or of the point-, line- or wavelength-scanning type.

Annex A details the characteristics of such compatible hyperspectral NIR systems.

It is recommended that the system allows analysing paper sheets of ISO A4 according to ISO 216 format or larger.

5.2   Software

The required software is a NIR-evaluation system for qualitative and quantitative assessment of polymeric substances by size and number. The software shall consist of an NIR imaging algorithm, including chemometrics and classification.

For examples, see Annex B.

5.3   Penetration test reference piece

A film or plate with an approximate size of ISO A4 in accordance with ISO 216 and a maximum thickness of 300 μm consisting of at least one polymeric substance, which is assigned to the sticky or non-tacky polymeric contaminants group (see 8.1).

5.4   Calibration of the NIR sensor

Calibration shall be done according to the manual of the respective device. The calibration shall be checked in accordance with Annex A.

6 Preparation of specimen

6.1 General

In the case of determination of plastics and stickies deposited on filter paper, the measurement can be performed directly, without the need of the penetration test defined in 7.4.

In the case of determination on paper sample, the NIR signal can be submitted through a limited specimen thickness only. For pulp or paper sheets, this specimen thickness is depending on the fibre type, the degree of densification, the filler content and the like. Therefore, a penetration test shall be performed to determine whether the thickness of the specimen is below the maximum allowable specimen thickness δ_{max} (see 7.4).

6.2 Pulp samples

6.2.1 Measurement of stickies and non-tacky contaminants deposited on filter

The contaminants shall be isolated in accordance to ISO 15360-1 or ISO 15360-2 and deposited on filter paper before air drying. The oven dry mass of pulp used to concentrate the contaminants shall be determined.

6.2.2 Measurement of stickies and non-tacky contaminants directly on paper or handsheets

Determine the oven-dry mass of the stock used for preparing the handsheets in accordance with ISO 4119.

Prepare handsheets having a thickness of maximum δ_{max} in accordance with ISO 534 by using a sheet former in accordance with ISO 5269-1 or ISO 5269-2. The cumulative area of multiple handsheets shall be a minimum of 0,1 m^2 and a maximum of 0,5 m^2. When statistical results are reported, they should be based on measurements of at least 50 particles, which can require scanning multiple handsheets or paper samples.

EXAMPLE   If using a Rapid-Köthen sheet former according to ISO 5269-2, usually four handsheets are prepared.

The polymeric substances, which have a detectable size for the measurement, but are not retained in the handsheet are negligible.

If the penetration test cannot be performed in advance (see 7.4), and therefore δ_{max} is unknown, it is recommended to prepare handsheet samples having a thickness of max. 100 μm for recycled pulps.

When preparing several handsheets from the same pulp sample, the weight of the suspension used for the handsheet forming should be the same for each handsheet.

Determine the oven-dry grammage of the handsheets in accordance with ISO 5270.

When statistical results are reported, they should be based on measurements of at least 50 particles, which can require scanning multiple handsheets or paper samples, the grammage of individual handsheets made from stock samples taken at different positions within the process should not vary more than ±10 % from their average grammage.

6.3 Paper samples

Determine the oven-dry grammage of the paper samples in accordance with ISO 536. The cumulative area of multiple paper samples shall be a minimum of 0,1 m^2 and a maximum of 0,5 m^2. When statistical results are reported, they should be based on measurements of at least 50 particles, which can require scanning multiple handsheets or paper samples. The paper samples can be cut to paper sheets, suitable for the measurements.

To determine the stickie area in mm^2/kg when analyzing paper samples, the following cases shall be distinguished:

— If the paper sheet thickness is $\leq \delta_{max}$, place the paper sheets under the NIR sensor and perform the NIR analysis;

— If the paper sheet thickness is $> \delta_{max}$, pulp the paper samples on laboratory scale in accordance with ISO 5263-2, and prepare handsheets as specified in 6.2. The procedure that shall be followed is the same as specified for pulp samples.

NOTE   The pulping can cause size reduction of the particles (stickies non-tacky polymeric contaminants) thus effecting the detectable amount and the size distribution.

7   Procedure

7.1   Parameters for the analysis

Define the size classes for the particles and select the available substances.

Size classes in circle equivalent diameter in accordance with INGEDE Method 4[1] see Table 1.

Table 1 — Size classes in circle equivalent diameter

Dimensions in µm

Size classes	Lower limit	Upper limit
K1	100	200
K2	201	300
K3	301	400
K4	401	500
K5	501	600
K6	601	1 000
K7	1 001	1 500
K8	1 501	2 000
K9	2 001	3 000
K10	3 001	5 000
K11	5 001	10 000
K12	10 001	20 000
K13	20 001	50 000
K14	50 001	200 000

7.2   Placement of specimen

Place the specimen under the NIR sensor and fix it. When analysing laboratory handsheets, place them with the wire side facing up.

If analysing paper sheets $\leq \delta_{max}$, the side of the paper sample having the first contact with a heated drying cylinder should be facing up. Use the same side facing up for all paper sheets of one paper sample. When several paper samples from the same paper machine are measured, ensure that always the same side of the paper samples are measured by applying the NIR analysis.

If the paper sheet thickness is $> \delta_{max}$ the NIR measurements can be performed for only one side facing up, preferably the paper side having the first contact with a heated drying cylinder. The specific stickie area can be determined in relation to the total surface area of the sample.

7.3   Measurement

After placing the specimen under the NIR sensor, start the measurement. The specimen shall be scanned in individual stripes and the individual scans are assembled if using a line scan sensor. If using a matrix sensor, the entire sheet may either be analysed by one shot or by individual rectangular scans that are assembled. If using a single spot sensor, the entire sheet is analysed by 2D point scanning.

7.4 Penetration test

If necessary (in accordance with [6.1]), perform a penetration test by placing the penetration test reference piece under a specimen and carry out the NIR measurement. If the polymeric substances covered by the specimen can be detected by the NIR measurement, the specimen's thickness is $\leq \delta_{max}$. This is fulfilled if the covered area of polymeric substances detected is 90 % or more of the specimen's area. If the polymeric substances covered by the specimen cannot be detected by the NIR measurement, the specimen's thickness is $> \delta_{max}$. In that case, prepare samples with lower thickness and repeat the penetration test.

8 Analysis

8.1 Determination of stickies and non-tacky polymeric contaminants

The planar geometrical properties of particles, which are neither natural fibres nor inorganic substances are determined by measuring their NIR spectral response and by comparing these responses with those of known chemical substances, which are summarized in a data base.

The assignment to the stickies and non-tacky contaminant groups can be done as follows (non-exhaustive):

a) stickies can be classified based on their chemical origin:

— Polyvinyl Acetates (PVAc);

— Ethylene-vinyl Acetates (EVA);

— Acrylates;

— Others, including Pressure Sensitive Adhesives (PSA) and Pressure Sensitive Hot melt Adhesives (PSA-Hotmelt).

b) non-tacky polymeric contaminants:

— Polyethylene (PE);

— Polystyrene (PS);

— Polyvinyl chloride (PVC);

— Polypropylene (PP);

— Polyethylene terephthalate (PET).

c) unknown and other polymeric contaminants.

The geometrical properties feature the following information:

— surface area of the sticky and non-tacky contaminant particles;

— size of particles as circle equivalent diameter;

— length and width for particles having a circle equivalent diameter >1 000 μm.

For every polymeric particle that is detected the information summarized above is stored individually, allowing comprehensive evaluation and clustering of results including the introduction of size classes.

NOTE 1   A polymeric substance, which does not give any reflection in the NIR wavelength range, cannot be detected. For example, if a non-tacky particle is deeply dyed in black.

The software classifies the measured stickies and non-tacky polymeric contaminants as absolute areas according to the following parameters:

— number of stickies and non-tacky polymeric contaminants per size class and/or clustered for the chemical properties;

— total stickie area and non-tacky polymeric contaminants per size class and/or clustered for the chemical properties;

— logarithmic area density per size class and/or clustered for the chemical properties.

The software classifies the measured stickies and non-tacky polymeric contaminants as specific areas. For this purpose, the following steps shall be performed:

— The total surface area of all specimens analysed by the NIR for one sample shall be determined.

NOTE 2   For Rapid-Köthen handsheets according to ISO 5269-2, the surface area of one individual handsheet is 314 cm^2 ± 2 cm^2.

— Determining specific areas for pulp samples, the absolute area of stickies and non-tacky polymeric contaminants are divided by the total oven-dry mass of the stock used for preparing the handsheets.

— Determining specific areas for paper samples, the absolute area of stickies and non-tacky polymeric contaminants are divided by the product of the surface area analysed by the NIR measurements and the bone-dry grammage of the paper samples.

8.2   Calculation

8.2.1   Pulp samples

After applying the procedure according Clause 7, the following specific areas [see Formulae (1) to (4)] for stickies and non-tacky polymeric contaminants are determined:

a)   specific number of stickies and non-tacky polymeric contaminants per kg of pulp per size class:

$$Y_{i,\text{pulp}} = \frac{a_i}{m_{\text{pulp}}}$$

(1)

where

i is an indicator for the size classes K1 to K14;

$Y_{i,\text{pulp}}$ is the number of stickies or non-tacky polymeric contaminants, as relevant, per kg of oven-dry pulp of each size class;

a_i is the observed number of stickies or non-tacky polymeric contaminants, as relevant, of each size class;

m_{pulp} is the oven-dry mass of the pulp, used for handsheet preparation, in kg.

b)   total specific number of stickies and non-tacky polymeric contaminants per kg of pulp:

$$Y_{\text{total,pulp}} = \sum_{i=\text{K1}}^{\text{K14}} Y_{i,\text{pulp}}$$

(2)

where

i is an indicator for the size classes K1 to K14;

$Y_{i,\text{pulp}}$ is the number of stickies or non-tacky polymeric contaminants, as relevant, per kg of oven-dry pulp of each size class;

$Y_{\text{total,pulp}}$ is the total number of stickies or non-tacky polymeric contaminants, as relevant, per kg of oven-dry pulp.

c) specific stickie area and non-tacky polymeric contaminants per kg of pulp per size class:

$$X_{i,\text{pulp}} = \frac{A_i}{m_{\text{pulp}}}$$

(3)

where

i is an indicator for the size classes K1 to K14;

$X_{i,\text{pulp}}$ is the stickie area or non-tacky polymeric contaminants, as relevant, per kg of oven-dry pulp of each size class;

A_i is the stickie area or non-tacky polymeric contaminants, as relevant, of each size class;

m_{pulp} is the oven-dry mass of the pulp, used for handsheet preparation, in kg.

d) total specific stickie area and non-tacky polymeric contaminants, per kg of pulp:

$$X_{\text{total,pulp}} = \sum_{i=\text{K1}}^{\text{K14}} X_{i,\text{pulp}}$$

(4)

where

i is an indicator for the size classes K1 to K14;

$X_{i,\text{pulp}}$ is the stickie area or non-tacky polymeric contaminants, as relevant, per kg of oven-dry pulp of each size class;

$X_{\text{total,pulp}}$ is the total stickie area or non-tacky polymeric contaminants, as relevant, per kg of oven-dry pulp.

8.2.2 Paper samples

After applying the procedure according to Clause 7, the following specific areas [see Formulae(5) to (9)] for stickies and non-tacky polymeric contaminants are determined:

a) specific number of stickies and non-tacky polymeric contaminants per kg of paper per size class:

$$m_{\text{paper}} = \frac{M \times g_{\text{paper}}}{1\,000}$$

(5)

where

m_{paper} is the oven-dry mass of the paper samples, in kg;

M is total measured surface area of the paper samples, in m^2;

g_{paper} is the oven-dry grammage of the paper samples, in g per m^2.

$$Y_{i,\text{paper}} = \frac{a_i}{m_{\text{paper}}}$$

(6)

where

i is an indicator for the size classes K1 to K14;

$Y_{i,\,\text{paper}}$ is the number of stickies or non-tacky polymeric contaminants, as relevant, per kg of the paper samples of each size class;

a_i is the observed number of stickies or non-tacky polymeric contaminants, as relevant, of each size class.

b) total specific number of stickies and non-tacky polymeric contaminants per kg of paper:

$$Y_{\text{total},\,\text{paper}} = \sum_{i=\text{K1}}^{\text{K14}} Y_{i,\,\text{paper}} \qquad (7)$$

where

i is an indicator for the size classes K1 to K14;

$Y_{i,\,\text{paper}}$ is the number of stickies or non-tacky polymeric contaminants, as relevant, per kg of the paper samples of each size class;

$Y_{\text{total},\,\text{paper}}$ is the total number of stickies or non-tacky polymeric contaminants, as relevant, per kg of oven-dry paper.

c) specific area of stickies and non-tacky polymeric contaminants per kg of paper per size class:

$$X_{i,\,\text{paper}} = \frac{A_i}{m_{\text{paper}}} \qquad (8)$$

where

i is an indicator for the size classes K1 to K14;

$X_{i,\,\text{paper}}$ is the stickie area or non-tacky polymeric contaminants, as relevant, per kg of paper of each size class;

A_i is the stickie area or non-tacky polymeric contaminants, as relevant, of each size class;

m_{paper} is the oven-dry mass of the paper samples, in kg [see Formula (5)].

d) total specific stickie area and non-tacky polymeric contaminants, per kg of paper:

$$X_{\text{total},\,\text{paper}} = \sum_{i=\text{K1}}^{\text{K14}} X_{i,\,\text{paper}} \qquad (9)$$

where

i is an indicator for the size classes K1 to K14;

$X_{i,\,\text{paper}}$ is the stickie area or non-tacky polymeric contaminants, as relevant, per kg of paper of each size class;

$X_{\text{total},\,\text{paper}}$ is the total stickie area or non-tacky polymeric contaminants, as relevant, per kg of paper.

9 Precision

While it is desirable to have a full precision statement, at this time there are only a limited number of devices available, and thus, only an estimate of repeatability has been provided. As more devices become available, a full interlaboratory study can be used to provide data for a future revision of this standard.

Standard deviation on repeatability has been calculated with maximum 3 % regarding the total area of detected objects. Those number is based on artificial as well as real samples, making at least 8 measurements of a sample under the following conditions:

a) measurements without touching the sample;

b) measurements after newly putting the sample in;

c) measurements after rotating the sample.

10 Test report

The test report shall include at least the following information:

a) reference to this document, i.e. ISO 15360-3:2024;

b) identification of the sample;

c) oven-dry mass of stock used for preparing the handsheets, see 6.2.2 (for pulp samples);

d) oven-dry mass of stock used for screening, see 6.2.1 (for contaminants deposited on filter);

e) oven-dry mass of paper which is measured, see 6.3 (for paper samples);

f) grammage of the test specimen, see 6.3 (for paper samples);

g) result of the penetration test, see 7.4 (for paper samples);

h) thickness of the test specimen, see 6.3 (for paper samples);

i) specific number of stickies and non-tacky polymeric contaminants per kg of pulp respective paper (per size class and as total), see 8.2.1, Formula (1), Formula (2) and see 8.2.2, Formula (6), Formula (7);

j) specific stickie area and non-tacky polymeric contaminants per kg of pulp respective paper (per size class and as total), see 8.2.1, Formula (3), Formula (4) and see 8.2.2, Formula (8), Formula (9);

k) any deviations from the procedure;

l) any unusual observations that can have affected the test results;

m) the date of the test.

Annex A
(normative)

Calibration check

A.1 General

The calibration shall be checked using reference sheets in A.2. They contain pieces of materials with which the identification of polymers and the accuracy of the measured areas can be checked.

A.2 Reference sheets

A.2.1 General

The sheets consist of uncoated, wood free paper of 160 g/m^2 to 250 g/m^2. Two sheets are necessary:

— reference material of plastics and stickies: qualitative assessment, see A.2.2; and

— reference material in different sizes and shapes: quantitative assessment, see A.2.3.

A.2.2 Qualitative assessment

Macroscopic pieces of the stickies and non-tacky polymeric contaminants (see 8.1) are attached to the paper sheet. The size shall be of 0,5 cm to 1 cm in diameter. The pieces shall be non-transparent and of flat surface. Reference method shall be IR spectroscopy.

A.2.3 Quantitative assessment

Polymeric objects of different sizes and shapes are printed on the paper sheet. The printer shall use wax colours. The objects are at least: quadratic, rectangular, round and elliptic with a ratio of longer to shorter width of 1:1, 2:1 and 3:1. All objects shall have a representative in the middle of each size class (see 7.1). Reference method shall be visual assessment with a resolution of at least 1 200 dpi.