

**SAE** The Engineering Society  
For Advancing Mobility  
Land Sea Air and Space

400 COMMONWEALTH DRIVE, WARRENDALE, PA 15096

**AEROSPACE  
RECOMMENDED  
PRACTICE**

Submitted for recognition as an American National Standard

ARP823C

Issued 1-31-64  
Revised 10-1-88

Superseding ARP823B

**MINIMIZING STRESS-CORROSION CRACKING IN WROUGHT  
HEAT-TREATABLE ALUMINUM ALLOY PRODUCTS**

1. PURPOSE:

- 1.1 The purpose of this recommended practice is to provide the aerospace industry with recommendations concerning minimizing stress-corrosion cracking (SCC) in wrought high-strength aluminum alloy products.
- 1.2 The detailed recommendations are based on practical engineering experience and reflect those design practices and fabricating procedures which have been found to be most effective in minimizing stress-corrosion cracking in wrought high-strength aluminum alloy products.
- 1.3 This ARP provides general guidelines. For further information see  
Ø references in 3.3.

2. GENERAL: Stress-corrosion cracking failures of wrought, high-strength aluminum alloy parts have been attributed to the following combination of factors:

- a) presence of a sustained surface tensile stress developed as a result of assembly stresses and/or residual stresses due to heat treatment, forming, or service stresses acting in a direction perpendicular to the plane of predominant grain flow.
- b) presence of a corrosive environment, which need not be severe (atmospheric water vapor may be sufficient), and
- c) existence, in the product, of a metallurgical condition which makes the product susceptible to stress-corrosion cracking.

SAE Technical Board Rules provide that: "This report is published by SAE to advance the state of technical and engineering sciences. The use of this report is entirely voluntary, and its applicability and suitability for any particular use, including any patent infringement arising therefrom, is the sole responsibility of the user."

SAE reviews each technical report at least every five years at which time it may be reaffirmed, revised, or cancelled. SAE invites your written comments and suggestions.

2.1 Al-Cu-Mg alloys of the 2xxx series, 5xxx alloys with magnesium greater than 3%, Al-Zn-Mg and Al-Zn-Mg-Cu alloys of the 7xxx series are most susceptible to stress-corrosion cracking especially in the short-transverse direction. The alloy-temper combinations of particular concern are:

2011-T3x	2024-T3x	7001-T6x
2011-T4x	2024-T36x	7075-T6x
2014-T3x	2024-T4x	7079-T6x
2014-T4x	2024-T6x	7079-T611x
2014-T6x	2219-T31x	7175-T66
2017-T4x	2219-T37x	7178-T66
2018-T6x	2618-T61	

2.1.1 In addition, control of the fabrication process is important for the avoidance of stress-corrosion cracking susceptibility in some 2xxx alloys in the T8x tempers.

### 3. RECOMMENDATIONS:

#### 3.1 General:

Applied stresses in the short-transverse direction should be minimized. Besides material susceptibility, residual forming stresses, stresses from machining, and stresses from assembly or misfit of parts can contribute to stress-corrosion cracking. Such stresses should not be overlooked in the design phase.

- Use alloys and tempers resistant to SCC.
- Use stress-relieved parts.
- Perform severe forming on product in the annealed condition, followed by heat treatment, if required.
- Perform forming and straightening on newly quenched product to lessen forming stresses.
- Avoid fitup stresses by careful attention to tolerances. Misaligned parts should not be forced into place.
- Where surface tensile stresses cannot be avoided, consider techniques like shot peening, surface rolling, or thermal stress relief to reduce undesirable stresses. When using thermal treatments for stress relief, consideration also needs to be given to the effect of time at elevated temperature on the properties of the product.
- Heat treat weldments after welding. To avoid stress-corrosion cracking while the product is in the W temper, parts should be stored in a dry environment for as short a time as possible before artificial aging.
- Quenching causes desirable surface compressive stresses and undesirable internal tensile stresses. This should be considered when machining the parts.